

Note X: Covered *: New update

Opel V10.0									
Model Information					Diagnostic Function				
Market	Year	Model	Class	System	ECU Info.	DTC	Data List	Active Test	Special Func.
EUROPE	2011	Astra-J	A20DTH	Engine Control Module	X	X	X	X	APP Learn Clutch Pedal Position Learn DPF Pressure Sensor Learn Exhaust Gas Temperature Sensor Learn H02S Learn MAF Sensor Learn EGR Valve Learn Fuel Rail Pressure Sensor or Fuel Rail Learn Crankshaft Position Reluctor Wheel Learn Turbocharger Learn Flywheel Learn DPF Reset Catalyst Reset Engine Oil Life Reset Glow Plug Control Module Reset Regeneration Diesel Particulate Filter
EUROPE	2011	Astra-J	A16XER	Engine Control Module	X	X	X	X	Engine Oil Life Reset DPF Reset Catalyst Reset Glow Plug Control Module Reset H02S Learn MAF Sensor Learn APP Learn Clutch Pedal Position Learn Crankshaft Position Reluctor Wheel Learn DPF Pressure Sensor Learn EGR Valve Learn Exhaust Gas Temperature Sensor Learn Flywheel Learn Fuel Rail Pressure Sensor or Fuel Rail Learn Regeneration Diesel Particulate Filter

EUROPE	2011	Astra-J	A18XER	Engine Control Module	*	*	*	*	Clutch Pedal Position Learn Crankshaft Position Variation Learn HO2S Heater Learn Idle Learn Engine Oil Life Reset Fuel Trim Reset
EUROPE	2011	Astra-J	TCM	Engine Control Module	X	X	X	X	Clutch Pedal Position Learn Crankshaft Position Variation Learn HO2S Heater Learn Idle Learn Engine Oil Life Reset Fuel Trim Reset
EUROPE	2011	Astra-J	FPCM	Transmission Control Module	*	*	*	*	Gear Selector N Position Learn Learned Values Reset
EUROPE	2011	Astra-J	EPSCM	Fuel Pump Control Module	*	*	*	*	Fuel Trim Reset
EUROPE	2011	Astra-J	EBCM	Electric Power Steering Control Module	*	*			Power Steering Softstops Reset Power Steering Softstops Learn
EUROPE	2011	Astra-J	PBCM	Electronic Brake Control Module	X	X	X	X	Brake Pressure Sensor Calibration Yaw Rate Sensor Learn Steering Wheel Angle Sensor Learns
EUROPE	2011	Astra-J	BCM	Parking Brake Control Module	X	X	X	X	Park Brake Calibration
EUROPE	2011	Astra-J	IC	Body Control Module	X	X	X	X	Brake Pedal Position Sensor Learn Clear Driver Window Learn Values Clear Left Rear Window Learn Values Clear Passenger Window Learn Values Clear Right Rear Window Learn Values
EUROPE	2011	Astra-J		Instrument Cluster	X	X	X	X	CAN Bus Configuration Learn
EUROPE	2011	Astra-J		Inflatable Restraint Sensing and Diagnostic Module	X	X	X	X	
EUROPE	2011	Astra-J	RHACCM	Radio	X	X	X	X	
EUROPE	2011	Astra-J	Vehicle DTC Information	Remote Heater and Air Conditioning Control Module	X	X	X	X	HVAC Actuators Learn CAN Bus Configuration Learn
EUROPE	2010	Astra-J	A13DTE	Vehicle		X			

EUROPE	2010	Astra-J	A20DTH	Engine Control Module	X	X	X	X	APP Learn Clutch Pedal Position Learn DPF Pressure Sensor Learn Exhaust Gas Temperature Sensor Learn H02S Learn MAF Sensor Learn EGR Valve Learn Fuel Rail Pressure Sensor or Fuel Rail Learn Crankshaft Position Reluctor Wheel Learn Turbocharger Learn Flywheel Learn DPF Reset Catalyst Reset Engine Oil Life Reset Glow Plug Control Module Reset Regeneration Diesel Particulate Filter
EUROPE	2010	Astra-J	A16XER	Engine Control Module	X	X	X	X	Engine Oil Life Reset DPF Reset Catalyst Reset Glow Plug Control Module Reset H02S Learn MAF Sensor Learn APP Learn Clutch Pedal Position Learn Crankshaft Position Reluctor Wheel Learn DPF Pressure Sensor Learn EGR Valve Learn Exhaust Gas Temperature Sensor Learn Flywheel Learn Fuel Rail Pressure Sensor or Fuel Rail Learn Regeneration Diesel Particulate Filter
EUROPE	2010	Astra-J	A18XER	Engine Control Module	*	*	*	*	Clutch Pedal Position Learn Crankshaft Position Variation Learn H02S Heater Learn Idle Learn Engine Oil Life Reset Fuel Trim Reset

EUROPE	2010	Astra-J	TCM	Engine Control Module	X	X	X	X	Clutch Pedal Position Learn Crankshaft Position Variation Learn HO2S Heater Learn Idle Learn Engine Oil Life Reset Fuel Trim Reset
EUROPE	2010	Astra-J	FPCM	Transmission Control Module	*	*	*	*	Gear Selector N Position Learn Learned Values Reset
EUROPE	2010	Astra-J	EPSCM	Fuel Pump Control Module	*	*	*	*	Fuel Trim Reset
EUROPE	2010	Astra-J	EBCM	Electric Power Steering Control Module	*	*			Power Steering Softstops Reset Power Steering Softstops Learn
EUROPE	2010	Astra-J	PBCM	Electronic Brake Control Module	X	X	X	X	Brake Pressure Sensor Calibration Yaw Rate Sensor Learn Steering Wheel Angle Sensor Learns
EUROPE	2010	Astra-J	BCM	Parking Brake Control Module	X	X	X	X	Park Brake Calibration
EUROPE	2010	Astra-J	IC	Body Control Module	X	X	X	X	Brake Pedal Position Sensor Learn Clear Driver Window Learn Values Clear Left Rear Window Learn Values Clear Passenger Window Learn Values Clear Right Rear Window Learn Values
EUROPE	2010	Astra-J		Instrument Cluster	X	X	X	X	CAN Bus Configuration Learn
EUROPE	2010	Astra-J		Inflatable Restraint Sensing and Diagnostic Module	X	X	X	X	
EUROPE	2010	Astra-J	RHACCM	Radio	X	X	X	X	
EUROPE	2010	Astra-J	Vehicle DTC Information	Remote Heater and Air Conditioning Control Module	X	X	X	X	HVAC Actuators Learn CAN Bus Configuration Learn
EUROPE	2011	Insignia	A20DTH	Vehicle		X			

EUROPE	2011	Insignia	A20DTJ	Engine Control Module	X	X	X	X	1.Engine Oil Life Reset 2.DPF Reset 3.Catalyst Reset 4.Glow Plug Control Module Reset 5.H02S Learn 6.MAF Sensor Learn 7.APP Learn 8.Clutch Pedal Position Learn 9.Crankshaft Position Reluctor Wheel Learn 10.DPF Pressure Sensor Learn 11.EGR Valve Learn 12.Exhaust Gas Temperature Sensor Learn 13.Flywheel Learn 14.Fuel Rail Pressure Sensor or Fuel Rail Learn 15.Regeneration DPF
EUROPE	2011	Insignia	A18XER	Engine Control Module	X	X	X	X	1.Engine Oil Life Reset 2.DPF Reset 3.Catalyst Reset 4.Glow Plug Control Module Reset 5.H02S Learn 6.MAF Sensor Learn 7.APP Learn 8.Clutch Pedal Position Learn 9.Crankshaft Position Reluctor Wheel Learn 10.DPF Pressure Sensor Learn 11.EGR Valve Learn 12.Exhaust Gas Temperature Sensor Learn 13.Flywheel Learn 14.Fuel Rail Pressure Sensor or Fuel Rail Learn 15.Regeneration DPF
EUROPE	2011	Insignia	TCM	Engine Control Module	X	X	X	X	Clutch Pedal Position Learn Crankshaft Position Variation Learn HO2S Heater Learn Idle Learn Engine Oil Life Reset Fuel Trim Reset
EUROPE	2011	Insignia	FPCM	Transmission Control Module	X	X	X	X	Gear Selector N Position Learn Learned Values Reset
EUROPE	2011	Insignia	EPSCM	Fuel Pump Control Module	*	*	*	*	Fuel Trim Reset
EUROPE	2011	Insignia	EBCM	Electric Power Steering Control Module	*	*			Power Steering Softstops Reset Power Steering Softstops Learn

EUROPE	2011	Insignia	PBCM	Electronic Brake Control Module	X	X	X	X	Brake Pedal Position Sensor Calibration Yaw Rate Sensor Learn Steering Wheel Angle Sensor Learn
EUROPE	2011	Insignia	BCM	Parking Brake Control Module	X	X	X	X	Park Brake Calibration
EUROPE	2011	Insignia	IC	Body Control Module	X	X	X	X	Brake Pedal Position Sensor Learn Clear Driver Window Learn Values Clear Left Rear Window Learn Values Clear Passenger Window Learn Values Clear Right Rear Window Learn Values
EUROPE	2011	Insignia		Instrument Cluster	X	X	X	X	CAN Bus Configuration Learn
EUROPE	2011	Insignia		Inflatable Restraint Sensing and Diagnostic Module	X	X	X	X	
EUROPE	2011	Insignia	RHACCM	Radio	X	X	X	X	
EUROPE	2011	Insignia	Vehicle DTC Information	Remote Heater and Air Conditioning Control Module	X	X	X	X	HVAC Actuators Learn CAN Bus Configuration Learn
EUROPE	2010	Insignia	A20DTH	Vehicle		X			
EUROPE	2010	Insignia	A20DTJ	Engine Control Module	X	X	X	X	1.Engine Oil Life Reset 2.DPF Reset 3.Catalyst Reset 4.Glow Plug Control Module Reset 5.H02S Learn 6.MAF Sensor Learn 7.APP Learn 8.Clutch Pedal Position Learn 9.Crankshaft Position Reluctor Wheel Learn 10.DPF Pressure Sensor Learn 11.EGR Valve Learn 12.Exhaust Gas Temperature Sensor Learn 13.Flywheel Learn 14.Fuel Rail Pressure Sensor or Fuel Rail Learn 15.Regeneration DPF

EUROPE	2010	Insignia	A18XER	Engine Control Module	X	X	X	X	1.Engine Oil Life Reset 2.DPF Reset 3.Catalyst Reset 4.Glow Plug Control Module Reset 5.H02S Learn 6.MAF Sensor Learn 7.APP Learn 8.Clutch Pedal Position Learn 9.Crankshaft Position Reluctor Wheel Learn 10.DPF Pressure Sensor Learn 11.EGR Valve Learn 12.Exhaust Gas Temperature Sensor Learn 13.Flywheel Learn 14.Fuel Rail Pressure Sensor or Fuel Rail Learn 15.Regeneration DPF
EUROPE	2010	Insignia	TCM	Engine Control Module	X	X	X	X	Clutch Pedal Position Learn Crankshaft Position Variation Learn HO2S Heater Learn Idle Learn Engine Oil Life Reset Fuel Trim Reset
EUROPE	2010	Insignia	FPCM	Transmission Control Module	X	X	X	X	Gear Selector N Position Learn Learned Values Reset
EUROPE	2010	Insignia	EPSCM	Fuel Pump Control Module	*	*	*	*	Fuel Trim Reset
EUROPE	2010	Insignia	EBCM	Electric Power Steering Control Module	*	*			Power Steering Softstops Reset Power Steering Softstops Learn
EUROPE	2010	Insignia	PBCM	Electronic Brake Control Module	X	X	X	X	Brake Pedal Position Sensor Calibration Yaw Rate Sensor Learn Steering Wheel Angle Sensor Learn
EUROPE	2010	Insignia	BCM	Parking Brake Control Module	X	X	X	X	Park Brake Calibration
EUROPE	2010	Insignia	IC	Body Control Module	X	X	X	X	Brake Pedal Position Sensor Learn Clear Driver Window Learn Values Clear Left Rear Window Learn Values Clear Passenger Window Learn Values Clear Right Rear Window Learn Values
EUROPE	2010	Insignia		Instrument Cluster	X	X	X	X	CAN Bus Configuration Learn
EUROPE	2010	Insignia		Inflatable Restraint Sensing and Diagnostic Module	X	X	X	X	
EUROPE	2010	Insignia	RHACCM	Radio	X	X	X	X	

EUROPE	2010	Insignia		Remote Heater and Air Conditioning Control Module	X	X	X	X	HVAC Actuators Learn CAN Bus Configuration Learn
EUROPE	2009	Insignia	RHACCM	Radio	X	X	X	X	
EUROPE	2009	Insignia	Z 10 XEP	Remote Heater and Air Conditioning Control Module	X	X	X	X	HVAC Actuators Learn CAN Bus Configuration Learn
EUROPE	2007	Agila	Z 12 XE	Engine	X	X	X		
EUROPE	2007	Agila	Z 12 XEP	Engine	X	X	X	X	
EUROPE	2007	Agila	Z 13 DT	Engine	X	X	X		
EUROPE	2007	Agila	ABS	Engine	X	X	X	X	1.Inject Cutoff Test; 2.RPM Control; 3.Program Idle Speed.
EUROPE	2007	Agila	Electronic Power Steering	Chassis	X	X	X		
EUROPE	2007	Agila	Immobiliser	Chassis	X	X	X		
EUROPE	2007	Agila	Airbag	Body	X	X	X		1.Erase Key Set; 2.Program Transponder-Keys
EUROPE	2007	Agila	Instrument	Body	X	X	X		
EUROPE	2007	Agila	Z 10 XEP	Body	X	X	X		
EUROPE	2006	Agila	Z 12 XE	Engine	X	X	X		
EUROPE	2006	Agila	Z 12 XEP	Engine	X	X	X	X	
EUROPE	2006	Agila	Z 13 DT	Engine	X	X	X		
EUROPE	2006	Agila	ABS	Engine	X	X	X	X	1.Inject Cutoff Test; 2.RPM Control; 3.Program Idle Speed.
EUROPE	2006	Agila	Electronic Power Steering	Chassis	X	X	X		
EUROPE	2006	Agila	Immobiliser	Chassis	X	X	X		
EUROPE	2006	Agila	Airbag	Body	X	X	X		1.Erase Key Set; 2.Program Transponder-Keys
EUROPE	2006	Agila	Instrument	Body	X	X	X		
EUROPE	2006	Agila	Z 10 XEP	Body	X	X	X		
EUROPE	2005	Agila	Z 12 XE	Engine	X	X	X		
EUROPE	2005	Agila	Z 12 XEP	Engine	X	X	X	X	
EUROPE	2005	Agila	Z 13 DT	Engine	X	X	X		
EUROPE	2005	Agila	ABS	Engine	X	X	X	X	1.Inject Cutoff Test; 2.RPM Control; 3.Program Idle Speed.
EUROPE	2005	Agila	Electronic Power Steering	Chassis	X	X	X		
EUROPE	2005	Agila	Immobiliser	Chassis	X	X	X		
EUROPE	2005	Agila	Airbag	Body	X	X	X		1.Erase Key Set; 2.Program Transponder-Keys

EUROPE	2005	Agila	Instrument	Body	X	X	X		
EUROPE	2005	Agila	Z 10 XEP	Body	X	X	X		
EUROPE	2004	Agila	Z 12 XE	Engine	X	X	X		
EUROPE	2004	Agila	Z 13 DT	Engine	X	X	X	X	
EUROPE	2004	Agila	ABS	Engine	X	X	X	X	1.Inject Cutoff Test; 2.RPM Control; 3.Program Idle Speed.
EUROPE	2004	Agila	Electronic Power Steering	Chassis	X	X	X		
EUROPE	2004	Agila	Immobiliser	Chassis	X	X	X		
EUROPE	2004	Agila	Airbag	Body	X	X	X		
EUROPE	2004	Agila	Instrument	Body	X	X	X		
EUROPE	2004	Agila	Z 10 XE	Body	X	X	X		
EUROPE	2003	Agila	Z 12 XE	Engine	X	X	X		
EUROPE	2003	Agila	ABS	Engine	X	X	X	X	
EUROPE	2003	Agila	Electronic Power Steering	Chassis	X	X	X		
EUROPE	2003	Agila	Immobiliser	Chassis	X	X	X		
EUROPE	2003	Agila	Airbag	Body	X	X	X		
EUROPE	2003	Agila	Instrument	Body	X	X	X		
EUROPE	2003	Agila	Z 10 XE	Body	X	X	X		
EUROPE	2002	Agila	Z 12 XE	Engine	X	X	X		
EUROPE	2002	Agila	ABS	Engine	X	X	X	X	
EUROPE	2002	Agila	Electronic Power Steering	Chassis	X	X	X		
EUROPE	2002	Agila	Immobiliser	Chassis	X	X	X		
EUROPE	2002	Agila	Airbag	Body	X	X	X		
EUROPE	2002	Agila	Instrument	Body	X	X	X		
EUROPE	2002	Agila	Z 10 XE	Body	X	X	X		
EUROPE	2001	Agila	Z 12 XE	Engine	X	X	X		
EUROPE	2001	Agila	ABS	Engine	X	X	X	X	
EUROPE	2001	Agila	Electronic Power Steering	Chassis	X	X	X		
EUROPE	2001	Agila	Immobiliser	Chassis	X	X	X		
EUROPE	2001	Agila	Airbag	Body	X	X	X		
EUROPE	2001	Agila	Instrument	Body	X	X	X		
EUROPE	2001	Agila	Z 10 XE	Body	X	X	X		
EUROPE	2000	Agila	Z 12 XE	Engine	X	X	X		
EUROPE	2000	Agila	ABS	Engine	X	X	X	X	
EUROPE	2000	Agila	Electronic Power Steering	Chassis	X	X	X		
EUROPE	2000	Agila	Immobiliser	Chassis	X	X	X		
EUROPE	2000	Agila	Airbag	Body	X	X	X		
EUROPE	2000	Agila	Instrument	Body	X	X	X		

EUROPE	2000	Agila	X 16 SZR	Body	X	X	X		
EUROPE	2002	Astra-F	X 16 XEL	Engine	X	X	X	X	
EUROPE	2002	Astra-F	Immobiliser	Engine	X	X	X	X	Adjust Idle Speed
EUROPE	2002	Astra-F	Airbag-S	Body	X	X	X		
EUROPE	2002	Astra-F	Anti Theft Warning	Body	X	X	X		
EUROPE	2002	Astra-F	X 16 SZR	Body	X	X	X		
EUROPE	2001	Astra-F	X 16 XEL	Engine	X	X	X	X	
EUROPE	2001	Astra-F	Immobiliser	Engine	X	X	X	X	Adjust Idle Speed
EUROPE	2001	Astra-F	Airbag-S	Body	X	X	X		
EUROPE	2001	Astra-F	16 NZR	Body	X	X	X		
EUROPE	2000	Astra-F	X 16 SZR	Engine	X	X	X		
EUROPE	2000	Astra-F	X 16 XEL	Engine	X	X	X	X	
EUROPE	2000	Astra-F	AF 13II/20/22/30	Engine	X	X	X	X	Adjust Idle Speed
EUROPE	2000	Astra-F	Immobiliser	Transmission	X	X	X		
EUROPE	2000	Astra-F	Airbag-S	Body	X	X	X		
EUROPE	2000	Astra-F	16 NZR	Body	X	X	X		
EUROPE	1999	Astra-F	X 16 SZR	Engine	X	X	X		
EUROPE	1999	Astra-F	X 16 XEL	Engine	X	X	X	X	
EUROPE	1999	Astra-F	18 SE	Engine	X	X	X	X	Adjust Idle Speed
EUROPE	1999	Astra-F	C 18 SEL	Engine	X	X	X		
EUROPE	1999	Astra-F	AF 13II/20/22/30	Engine	X	X	X		
EUROPE	1999	Astra-F	Immobiliser	Transmission	X	X	X		
EUROPE	1999	Astra-F	Airbag-S	Body	X	X	X		
EUROPE	1999	Astra-F	X 14 XE	Body	X	X	X		
EUROPE	1998	Astra-F	16 NZR	Engine	X	X	X		
EUROPE	1998	Astra-F	X 16 SZR	Engine	X	X	X		
EUROPE	1998	Astra-F	X 16 XEL	Engine	X	X	X	X	
EUROPE	1998	Astra-F	18 SE	Engine	X	X	X	X	Adjust Idle Speed
EUROPE	1998	Astra-F	C 18 SEL	Engine	X	X	X		
EUROPE	1998	Astra-F	X 18 XE	Engine	X	X	X		
EUROPE	1998	Astra-F	X 20 XEV	Engine	X	X	X		Adjust Idle Speed
EUROPE	1998	Astra-F	AF 13II/20/22/30	Engine	X	X	X		Adjust Idle Speed
EUROPE	1998	Astra-F	Immobiliser	Transmission	X	X	X		
EUROPE	1998	Astra-F	Airbag-S	Body	X	X	X		
EUROPE	1998	Astra-F	C 14 NZ	Body	X	X	X		
EUROPE	1997	Astra-F	X 14 XE	Engine	X	X	X		
EUROPE	1997	Astra-F	16 NZR	Engine	X	X	X		
EUROPE	1997	Astra-F	X 16 SZR	Engine	X	X	X		
EUROPE	1997	Astra-F	X 16 XEL	Engine	X	X	X	X	
EUROPE	1997	Astra-F	18 SE	Engine	X	X	X	X	Adjust Idle Speed
EUROPE	1997	Astra-F	C 18 SEL	Engine	X	X	X		
EUROPE	1997	Astra-F	X 18 XE	Engine	X	X	X		
EUROPE	1997	Astra-F	X 20 XEV	Engine	X	X	X		Adjust Idle Speed

EUROPE	1997	Astra-F	AF 13II/20/22/30	Engine	X	X	X		Adjust Idle Speed
EUROPE	1997	Astra-F	Traction Control (TC)	Transmission	X	X	X		
EUROPE	1997	Astra-F	Immobiliser	Chassis	X	X	X		
EUROPE	1997	Astra-F	Airbag-S	Body	X	X	X		
EUROPE	1997	Astra-F	Z 12 XE	Body	X	X	X		
EUROPE	2011	Astra-G	Z 14 XE	Engine	X	X	X	X	
EUROPE	2011	Astra-G	Z 14 XEP	Engine	X	X	X		
EUROPE	2011	Astra-G	C 16 SEL	Engine	X	X	X	X	1.Reset Learn Values 2.Reset O2-Loop Block Lean Map 3. ECU Control-Electronic throttle control 4.Idle speed program. 5.ECU Reset
EUROPE	2011	Astra-G	Z 16 SE	Engine	X	X	X	X	
EUROPE	2011	Astra-G	Z 16 XE	Engine	X	X	X		
EUROPE	2011	Astra-G	Z 16 XEP	Engine	X	X	X	X	
EUROPE	2011	Astra-G	Z 16 YNG	Engine	X	X	X		
EUROPE	2011	Astra-G	Y 17 DT	Engine	X	X	X		
EUROPE	2011	Astra-G	Z 17 DTL	Engine	X	X	X	X	
EUROPE	2011	Astra-G	Z 18 XE	Engine	X	X	X		
EUROPE	2011	Astra-G	Z 18 XEL	Engine	X	X	X	X	
EUROPE	2011	Astra-G	Y 20 DTH	Engine	X	X	X		
EUROPE	2011	Astra-G	Z 20 LET	Engine	X	X	X	X	Adjust Idle Speed
EUROPE	2011	Astra-G	Y 22 DTR	Engine	X	X	X		
EUROPE	2011	Astra-G	Z 22 SE	Engine	X	X	X		Adjust Idle Speed
EUROPE	2011	Astra-G	AF 13-II/17/20/22	Engine	X	X	X	X	Programming ECU Control
EUROPE	2011	Astra-G	AF 13-II/17/20/22 CAN	Transmission	X	X	X	X	
EUROPE	2011	Astra-G	ABS-5.3/5.4 (+TC)	Transmission	X	X	X	X	
EUROPE	2011	Astra-G	ESP	Chassis	X	X	X	X	
EUROPE	2011	Astra-G	Cruise Control	Chassis	X	X	X		
EUROPE	2011	Astra-G	Electronic Power Steering	Chassis	X	X	X		
EUROPE	2011	Astra-G	Immobiliser	Chassis	X	X	X	X	
EUROPE	2011	Astra-G	Instrument	Body	X	X	X		Erase Key Set Program Transponder-Keys
EUROPE	2011	Astra-G	Airbag	Body	X	X	X	X	
EUROPE	2011	Astra-G	Anti Theft Warning	Body	X	X	X		
EUROPE	2011	Astra-G	Central Door Lock	Body	X	X	X		Erase Key Set Program Transponder-Keys

EUROPE	2011	Astra-G	Engine Cooling Module	Body	X	X	X		
EUROPE	2011	Astra-G	Electronic Climate Control	Body	X	X	X		
EUROPE	2011	Astra-G	HeadLamp Levelling Device	Body	X	X	X		
EUROPE	2011	Astra-G	Z 12 XE	Body	X	X	X	X	Calibration
EUROPE	2010	Astra-G	Z 14 XE	Engine	X	X	X	X	
EUROPE	2010	Astra-G	Z 14 XEP	Engine	X	X	X		
EUROPE	2010	Astra-G	C 16 SEL	Engine	X	X	X	X	1.Reset Learn Values 2.Reset O2-Loop Block Lean Map 3. ECU Control-Electronic throttle control 4.Idle speed program. 5.ECU Reset
EUROPE	2010	Astra-G	Z 16 SE	Engine	X	X	X	X	
EUROPE	2010	Astra-G	Z 16 YNG	Engine	X	X	X		
EUROPE	2010	Astra-G	Z 16 XE	Engine	X	X	X		
EUROPE	2010	Astra-G	Z 16 XEP	Engine	X	X	X	X	
EUROPE	2010	Astra-G	Y 17 DT	Engine	X	X	X		
EUROPE	2010	Astra-G	Z 17 DTL	Engine	X	X	X	X	
EUROPE	2010	Astra-G	Z 18 XE	Engine	X	X	X		
EUROPE	2010	Astra-G	Z 18 XEL	Engine	X	X	X	X	
EUROPE	2010	Astra-G	Y 20 DTH	Engine	X	X	X		
EUROPE	2010	Astra-G	Z 20 LET	Engine	X	X	X	X	Adjust Idle Speed
EUROPE	2010	Astra-G	Y 22 DTR	Engine	X	X	X		
EUROPE	2010	Astra-G	Z 22 SE	Engine	X	X	X		Adjust Idle Speed
EUROPE	2010	Astra-G	AF 13-II/17/20/22	Engine	X	X	X	X	Programming ECU Control
EUROPE	2010	Astra-G	AF 13-II/17/20/22 CAN	Transmission	X	X	X	X	
EUROPE	2010	Astra-G	ABS-5.3/5.4 (+TC)	Transmission	X	X	X	X	
EUROPE	2010	Astra-G	ESP	Chassis	X	X	X	X	
EUROPE	2010	Astra-G	Cruise Control	Chassis	X	X	X		
EUROPE	2010	Astra-G	Electronic Power Steering	Chassis	X	X	X		
EUROPE	2010	Astra-G	Immobiliser	Chassis	X	X	X	X	
EUROPE	2010	Astra-G	Instrument	Body	X	X	X		Erase Key Set Program Transponder-Keys
EUROPE	2010	Astra-G	Airbag	Body	X	X	X	X	
EUROPE	2010	Astra-G	Anti Theft Warning	Body	X	X	X		
EUROPE	2010	Astra-G	Central Door Lock	Body	X	X	X		Erase Key Set Program Transponder-Keys

EUROPE	2010	Astra-G	Engine Cooling Module	Body	X	X	X		
EUROPE	2010	Astra-G	Electronic Climate Control	Body	X	X	X		
EUROPE	2010	Astra-G	HeadLamp Levelling Device	Body	X	X	X		
EUROPE	2010	Astra-G	Z 12 XE	Body	X	X	X	X	Calibration
EUROPE	2009	Astra-G	Z 14 XE	Engine	X	X	X	X	
EUROPE	2009	Astra-G	Z 14 XEP	Engine	X	X	X		
EUROPE	2009	Astra-G	C 16 SEL	Engine	X	X	X	X	1.Reset Learn Values 2.Reset O2-Loop Block Lean Map 3. ECU Control-Electronic throttle control 4.Idle speed program. 5.ECU Reset
EUROPE	2009	Astra-G	Z 16 SE	Engine	X	X	X	X	
EUROPE	2009	Astra-G	Z 16 XE	Engine	X	X	X		
EUROPE	2009	Astra-G	Z 16 XEP	Engine	X	X	X	X	
EUROPE	2009	Astra-G	Z 16 YNG	Engine	X	X	X		
EUROPE	2009	Astra-G	Y 17 DT	Engine	X	X	X		
EUROPE	2009	Astra-G	Z 17 DTL	Engine	X	X	X	X	
EUROPE	2009	Astra-G	Z 18 XE	Engine	X	X	X		
EUROPE	2009	Astra-G	Z 18 XEL	Engine	X	X	X	X	
EUROPE	2009	Astra-G	Y 20 DTH	Engine	X	X	X		
EUROPE	2009	Astra-G	Z 20 LET	Engine	X	X	X	X	Adjust Idle Speed
EUROPE	2009	Astra-G	Y 22 DTR	Engine	X	X	X		
EUROPE	2009	Astra-G	Z 22 SE	Engine	X	X	X		
EUROPE	2009	Astra-G	AF 13-II/17/20/22	Engine	X	X	X		
EUROPE	2009	Astra-G	AF 13-II/17/20/22 CAN	Transmission	X	X	X	X	
EUROPE	2009	Astra-G	ABS-5.3/5.4 (+TC)	Transmission	X	X	X	X	
EUROPE	2009	Astra-G	ESP	Chassis	X	X	X	X	
EUROPE	2009	Astra-G	Cruise Control	Chassis	X	X	X		
EUROPE	2009	Astra-G	Electronic Power Steering	Chassis	X	X	X		
EUROPE	2009	Astra-G	Immobiliser	Chassis	X	X	X		
EUROPE	2009	Astra-G	Instrument	Body	X	X	X		1.Erase Key Set; 2.Program Transponder-Keys
EUROPE	2009	Astra-G	Airbag	Body	X	X	X		
EUROPE	2009	Astra-G	Anti Theft Warning	Body	X	X	X		
EUROPE	2009	Astra-G	Central Door Lock	Body	X	X	X		

EUROPE	2009	Astra-G	Engine Cooling Module	Body	X	X	X		
EUROPE	2009	Astra-G	Electronic Climate Control	Body	X	X	X		
EUROPE	2009	Astra-G	HeadLamp Levelling Device	Body	X	X	X		
EUROPE	2009	Astra-G	Z 24XE	Body	X	X	X	X	Calibration
EUROPE	2010	Antara(short body)	2.0L	Engine	*	*	*		
EUROPE	2010	Antara(short body)	TCCM(Transfer Case Control Module)	Engine	*	*	*	*	1.Program High CanBus Configration 2.Replace Rail Pressure Sensor 3.Replace Diff.-Press. Sensor 4.Regeneration DPF
EUROPE	2010	Antara(short body)	SDM(Airbag)	Transmission	*	*	*		
EUROPE	2010	Antara(short body)	IPC(Instrument)	Body	*	*	*		
EUROPE	2010	Antara(short body)	AT	Body	*	*	*		
EUROPE	2010	Antara(short body)	Immobiliser	Body	*	*	*	*	
EUROPE	2010	Antara(short body)	Body Control Module	Body	*	*			
EUROPE	2010	Antara(short body)	Electronic Climate Control	Body	*	*	*		
EUROPE	2010	Antara(short body)	RFA(Multipurpose Receiver Module)	Body	*	*	*		
EUROPE	2010	Antara(short body)	ABS	Body	*	*			
EUROPE	2010	Antara(short body)	Z 24XE	Chassis	*	*	*	*	
EUROPE	2009	Antara(short body)	2.0L	Engine	*	*	*		
EUROPE	2009	Antara(short body)	TCCM(Transfer Case Control Module)	Engine	*	*	*	*	1.Program High CanBus Configration 2.Replace Rail Pressure Sensor 3.Replace Diff.-Press. Sensor 4.Regeneration DPF
EUROPE	2009	Antara(short body)	SDM(Airbag)	Transmission	*	*	*		
EUROPE	2009	Antara(short body)	IPC(Instrument)	Body	*	*	*		
EUROPE	2009	Antara(short body)	AT	Body	*	*	*		

EUROPE	2009	Antara(short body)	Immobiliser	Body	*	*	*	*	
EUROPE	2009	Antara(short body)	Body Control Module	Body	*	*			
EUROPE	2009	Antara(short body)	Electronic Climate Control	Body	*	*	*		
EUROPE	2009	Antara(short body)	RFA(Multipurpose Receiver Module)	Body	*	*	*		
EUROPE	2009	Antara(short body)	ABS	Body	*	*			
EUROPE	2009	Antara(short body)	Z 24XE	Chassis	*	*	*	*	
EUROPE	2008	Antara(short body)	2.0L	Engine	*	*	*		
EUROPE	2008	Antara(short body)	TCCM(Transfer Case Control Module)	Engine	*	*	*	*	1.Program High CanBus Configuration 2.Replace Rail Pressure Sensor 3.Replace Diff.-Press. Sensor 4.Regeneration DPF
EUROPE	2008	Antara(short body)	SDM(Airbag)	Transmission	*	*	*		
EUROPE	2008	Antara(short body)	IPC(Instrument)	Body	*	*	*		
EUROPE	2008	Antara(short body)	AT	Body	*	*	*		
EUROPE	2008	Antara(short body)	Immobiliser	Body	*	*	*	*	
EUROPE	2008	Antara(short body)	Body Control Module	Body	*	*			
EUROPE	2008	Antara(short body)	Electronic Climate Control	Body	*	*	*		
EUROPE	2008	Antara(short body)	RFA(Multipurpose Receiver Module)	Body	*	*	*		
EUROPE	2008	Antara(short body)	ABS	Body	*	*			
EUROPE	2008	Antara(short body)	Z 12 XE	Chassis	*	*	*	*	
EUROPE	2008	Astra-G	Z 14 XE	Engine	X	X	X	X	
EUROPE	2008	Astra-G	Z 14 XEP	Engine	X	X	X		

EUROPE	2008	Astra-G	C 16 SEL	Engine	X	X	X	X	1.Reset Learn Values 2.Reset O2-Loop Block Lean Map 3. ECU Control-Electronic throttle control 4.Idle speed program. 5.ECU Reset
EUROPE	2008	Astra-G	Z 16 SE	Engine	X	X	X	X	
EUROPE	2008	Astra-G	Z 16 XE	Engine	X	X	X		
EUROPE	2008	Astra-G	Z 16 XEP	Engine	X	X	X	X	
EUROPE	2008	Astra-G	Z 16 YNG	Engine	X	X	X		
EUROPE	2008	Astra-G	Y 17 DT	Engine	X	X	X		
EUROPE	2008	Astra-G	Z 17 DTL	Engine	X	X	X	X	
EUROPE	2008	Astra-G	Z 18 XE	Engine	X	X	X		
EUROPE	2008	Astra-G	Z 18 XEL	Engine	X	X	X	X	
EUROPE	2008	Astra-G	Y 20 DTH	Engine	X	X	X		
EUROPE	2008	Astra-G	Z 20 LET	Engine	X	X	X	X	Adjust Idle Speed
EUROPE	2008	Astra-G	Y 22 DTR	Engine	X	X	X		
EUROPE	2008	Astra-G	Z 22 SE	Engine	X	X	X		
EUROPE	2008	Astra-G	AF 13-II/17/20/22	Engine	X	X	X		
EUROPE	2008	Astra-G	AF 13-II/17/20/22 CAN	Transmission	X	X	X	X	
EUROPE	2008	Astra-G	ABS-5.3/5.4 (+TC)	Transmission	X	X	X	X	
EUROPE	2008	Astra-G	ESP	Chassis	X	X	X	X	
EUROPE	2008	Astra-G	Cruise Control	Chassis	X	X	X		
EUROPE	2008	Astra-G	Electronic Power Steering	Chassis	X	X	X		
EUROPE	2008	Astra-G	Immobiliser	Chassis	X	X	X		
EUROPE	2008	Astra-G	Instrument	Body	X	X	X		1.Erase Key Set; 2.Program Transponder-Keys
EUROPE	2008	Astra-G	Airbag	Body	X	X	X		
EUROPE	2008	Astra-G	Anti Theft Warning	Body	X	X	X		
EUROPE	2008	Astra-G	Central Door Lock	Body	X	X	X		
EUROPE	2008	Astra-G	Engine Cooling Module	Body	X	X	X		
EUROPE	2008	Astra-G	Electronic Climate Control	Body	X	X	X		
EUROPE	2008	Astra-G	HeadLamp Levelling Device	Body	X	X	X		
EUROPE	2008	Astra-G	Z 12 XE	Body	X	X	X	X	Calibration
EUROPE	2007	Astra-G	Z 14 XE	Engine	X	X	X	X	
EUROPE	2007	Astra-G	Z 14 XEP	Engine	X	X	X		

EUROPE	2007	Astra-G	C 16 SEL	Engine	X	X	X	X	1.Reset Learn Values 2.Reset O2-Loop Block Lean Map 3. ECU Control-Electronic throttle control 4.Idle speed program. 5.ECU Reset
EUROPE	2007	Astra-G	Z 16 SE	Engine	X	X	X	X	
EUROPE	2007	Astra-G	Z 16 XE	Engine	X	X	X		
EUROPE	2007	Astra-G	Z 16 XEP	Engine	X	X	X	X	
EUROPE	2007	Astra-G	Z 16 YNG	Engine	X	X	X		
EUROPE	2007	Astra-G	Y 17 DT	Engine	X	X	X		
EUROPE	2007	Astra-G	Z 17 DTL	Engine	X	X	X	X	
EUROPE	2007	Astra-G	Z 18 XE	Engine	X	X	X		
EUROPE	2007	Astra-G	Z 18 XEL	Engine	X	X	X	X	
EUROPE	2007	Astra-G	Y 20 DTH	Engine	X	X	X		
EUROPE	2007	Astra-G	Z 20 LET	Engine	X	X	X	X	Adjust Idle Speed
EUROPE	2007	Astra-G	Y 22 DTR	Engine	X	X	X		
EUROPE	2007	Astra-G	Z 22 SE	Engine	X	X	X		
EUROPE	2007	Astra-G	AF 13-II/17/20/22	Engine	X	X	X		
EUROPE	2007	Astra-G	AF 13-II/17/20/22 CAN	Transmission	X	X	X	X	
EUROPE	2007	Astra-G	ABS-5.3/5.4 (+TC)	Transmission	X	X	X	X	
EUROPE	2007	Astra-G	ESP	Chassis	X	X	X	X	
EUROPE	2007	Astra-G	Cruise Control	Chassis	X	X	X		
EUROPE	2007	Astra-G	Electronic Power Steering	Chassis	X	X	X		
EUROPE	2007	Astra-G	Immobiliser	Chassis	X	X	X		
EUROPE	2007	Astra-G	Instrument	Body	X	X	X		1.Erase Key Set; 2.Program Transponder-Keys
EUROPE	2007	Astra-G	Airbag	Body	X	X	X		
EUROPE	2007	Astra-G	Anti Theft Warning	Body	X	X	X		
EUROPE	2007	Astra-G	Central Door Lock	Body	X	X	X		
EUROPE	2007	Astra-G	Engine Cooling Module	Body	X	X	X		
EUROPE	2007	Astra-G	Electronic Climate Control	Body	X	X	X		
EUROPE	2007	Astra-G	HeadLamp Levelling Device	Body	X	X	X		
EUROPE	2007	Astra-G	Z 12 XE	Body	X	X	X	X	Calibration
EUROPE	2006	Astra-G	Z 14 XE	Engine	X	X	X	X	
EUROPE	2006	Astra-G	Z 14 XEP	Engine	X	X	X		

EUROPE	2006	Astra-G	C 16 SEL	Engine	X	X	X	X	1.Reset Learn Values 2.Reset O2-Loop Block Lean Map 3. ECU Control-Electronic throttle control 4.Idle speed program. 5.ECU Reset
EUROPE	2006	Astra-G	Z 16 SE	Engine	X	X	X	X	
EUROPE	2006	Astra-G	Z 16 XE	Engine	X	X	X		
EUROPE	2006	Astra-G	Z 16 XEP	Engine	X	X	X	X	
EUROPE	2006	Astra-G	Z 16 YNG	Engine	X	X	X		
EUROPE	2006	Astra-G	Y 17 DT	Engine	X	X	X		
EUROPE	2006	Astra-G	Z 17 DTL	Engine	X	X	X	X	
EUROPE	2006	Astra-G	Z 18 XE	Engine	X	X	X		
EUROPE	2006	Astra-G	Z 18 XEL	Engine	X	X	X	X	
EUROPE	2006	Astra-G	Y 20 DTH	Engine	X	X	X		
EUROPE	2006	Astra-G	Z 20 LET	Engine	X	X	X	X	Adjust Idle Speed
EUROPE	2006	Astra-G	Y 22 DTR	Engine	X	X	X		
EUROPE	2006	Astra-G	Z 22 SE	Engine	X	X	X		
EUROPE	2006	Astra-G	AF 13-II/17/20/22	Engine	X	X	X		
EUROPE	2006	Astra-G	AF 13-II/17/20/22 CAN	Transmission	X	X	X	X	
EUROPE	2006	Astra-G	ABS-5.3/5.4 (+TC)	Transmission	X	X	X	X	
EUROPE	2006	Astra-G	ESP	Chassis	X	X	X	X	
EUROPE	2006	Astra-G	Cruise Control	Chassis	X	X	X		
EUROPE	2006	Astra-G	Electronic Power Steering	Chassis	X	X	X		
EUROPE	2006	Astra-G	Immobiliser	Chassis	X	X	X		
EUROPE	2006	Astra-G	Instrument	Body	X	X	X		1.Erase Key Set; 2.Program Transponder-Keys
EUROPE	2006	Astra-G	Airbag	Body	X	X	X		
EUROPE	2006	Astra-G	Anti Theft Warning	Body	X	X	X		
EUROPE	2006	Astra-G	Central Door Lock	Body	X	X	X		
EUROPE	2006	Astra-G	Engine Cooling Module	Body	X	X	X		
EUROPE	2006	Astra-G	Electronic Climate Control	Body	X	X	X		
EUROPE	2006	Astra-G	HeadLamp Levelling Device	Body	X	X	X		
EUROPE	2006	Astra-G	Z 12 XE	Body	X	X	X	X	Calibration
EUROPE	2005	Astra-G	Z 14 XE	Engine	X	X	X	X	
EUROPE	2005	Astra-G	Z 14 XEP	Engine	X	X	X		

EUROPE	2005	Astra-G	C 16 SEL	Engine	X	X	X	X	1.Reset Learn Values 2.Reset O2-Loop Block Lean Map 3. ECU Control-Electronic throttle control 4.Idle speed program. 5.ECU Reset
EUROPE	2005	Astra-G	Z 16 SE	Engine	X	X	X	X	
EUROPE	2005	Astra-G	Z 16 XE	Engine	X	X	X		
EUROPE	2005	Astra-G	Z 16 XEP	Engine	X	X	X	X	
EUROPE	2005	Astra-G	Z 16 YNG	Engine	X	X	X		
EUROPE	2005	Astra-G	Y 17 DT	Engine	X	X	X		
EUROPE	2005	Astra-G	Z 17 DTL	Engine	X	X	X	X	
EUROPE	2005	Astra-G	Z 18 XE	Engine	X	X	X		
EUROPE	2005	Astra-G	Z 18 XEL	Engine	X	X	X	X	
EUROPE	2005	Astra-G	Y 20 DTH	Engine	X	X	X		
EUROPE	2005	Astra-G	Z 20 LET	Engine	X	X	X	X	Adjust Idle Speed
EUROPE	2005	Astra-G	Y 22 DTR	Engine	X	X	X		
EUROPE	2005	Astra-G	Z 22 SE	Engine	X	X	X		
EUROPE	2005	Astra-G	AF 13-II/17/20/22	Engine	X	X	X		
EUROPE	2005	Astra-G	AF 13-II/17/20/22 CAN	Transmission	X	X	X	X	
EUROPE	2005	Astra-G	ABS-5.3/5.4 (+TC)	Transmission	X	X	X	X	
EUROPE	2005	Astra-G	ESP	Chassis	X	X	X	X	
EUROPE	2005	Astra-G	Cruise Control	Chassis	X	X	X		
EUROPE	2005	Astra-G	Electronic Power Steering	Chassis	X	X	X		
EUROPE	2005	Astra-G	Immobiliser	Chassis	X	X	X		
EUROPE	2005	Astra-G	Instrument	Body	X	X	X		1.Erase Key Set; 2.Program Transponder-Keys
EUROPE	2005	Astra-G	Airbag	Body	X	X	X		
EUROPE	2005	Astra-G	Anti Theft Warning	Body	X	X	X		
EUROPE	2005	Astra-G	Central Door Lock	Body	X	X	X		
EUROPE	2005	Astra-G	Engine Cooling Module	Body	X	X	X		
EUROPE	2005	Astra-G	Electronic Climate Control	Body	X	X	X		
EUROPE	2005	Astra-G	HeadLamp Levelling Device	Body	X	X	X		
EUROPE	2005	Astra-G	Z 12 XE	Body	X	X	X	X	Calibration
EUROPE	2004	Astra-G	Z 14 XE	Engine	X	X	X	X	
EUROPE	2004	Astra-G	C 16 SEL	Engine	X	X	X		
EUROPE	2004	Astra-G	Z 16 SE	Engine	X	X	X	X	

EUROPE	2004	Astra-G	Z 16 XE	Engine	X	X	X		
EUROPE	2004	Astra-G	Z 16 XEP	Engine	X	X	X	X	
EUROPE	2004	Astra-G	Z 16 YNG	Engine	X	X	X		
EUROPE	2004	Astra-G	Y 17 DT	Engine	X	X	X		
EUROPE	2004	Astra-G	Z 17 DTL	Engine	X	X	X	X	
EUROPE	2004	Astra-G	Z 18 XE	Engine	X	X	X		
EUROPE	2004	Astra-G	Z 18 XEL	Engine	X	X	X	X	
EUROPE	2004	Astra-G	Y 20 DTH	Engine	X	X	X		
EUROPE	2004	Astra-G	Z 20 LET	Engine	X	X	X	X	Adjust Idle Speed
EUROPE	2004	Astra-G	Y 22 DTR	Engine	X	X	X		
EUROPE	2004	Astra-G	Z 22 SE	Engine	X	X	X		
EUROPE	2004	Astra-G	AF 13-II/17/20/22	Engine	X	X	X		
EUROPE	2004	Astra-G	AF 13-II/17/20/22 CAN	Transmission	X	X	X	X	
EUROPE	2004	Astra-G	ABS-5.3/5.4 (+TC)	Transmission	X	X	X	X	
EUROPE	2004	Astra-G	ESP	Chassis	X	X	X	X	
EUROPE	2004	Astra-G	Cruise Control	Chassis	X	X	X		
EUROPE	2004	Astra-G	Electronic Power Steering	Chassis	X	X	X		
EUROPE	2004	Astra-G	Immobiliser	Chassis	X	X	X		
EUROPE	2004	Astra-G	Instrument	Body	X	X	X		1.Erase Key Set; 2.Program Transponder-Keys
EUROPE	2004	Astra-G	Airbag	Body	X	X	X		
EUROPE	2004	Astra-G	Anti Theft Warning	Body	X	X	X		
EUROPE	2004	Astra-G	Central Door Lock	Body	X	X	X		
EUROPE	2004	Astra-G	Engine Cooling Module	Body	X	X	X		
EUROPE	2004	Astra-G	Electronic Climate Control	Body	X	X	X		
EUROPE	2004	Astra-G	HeadLamp Levelling Device	Body	X	X	X		
EUROPE	2004	Astra-G	Z 12 XE	Body	X	X	X	X	Calibration
EUROPE	2003	Astra-G	Z 14 XE	Engine	X	X	X	X	
EUROPE	2003	Astra-G	C 16 SEL	Engine	X	X	X		
EUROPE	2003	Astra-G	Z 16 SE	Engine	X	X	X	X	
EUROPE	2003	Astra-G	Z 16 XE	Engine	X	X	X		
EUROPE	2003	Astra-G	Z 16 XEP	Engine	X	X	X	X	
EUROPE	2003	Astra-G	Z 16 YNG	Engine	X	X	X		
EUROPE	2003	Astra-G	Y 17 DT	Engine	X	X	X		
EUROPE	2003	Astra-G	Z 17 DTL	Engine	X	X	X	X	
EUROPE	2003	Astra-G	Z 18 XE	Engine	X	X	X		

EUROPE	2003	Astra-G	Z 18 XEL	Engine	X	X	X	X	
EUROPE	2003	Astra-G	Y 20 DTH	Engine	X	X	X		
EUROPE	2003	Astra-G	Z 20 LET	Engine	X	X	X	X	Adjust Idle Speed
EUROPE	2003	Astra-G	Y 22 DTR	Engine	X	X	X		
EUROPE	2003	Astra-G	Z 22 SE	Engine	X	X	X		
EUROPE	2003	Astra-G	AF 13-II/17/20/22	Engine	X	X	X		
EUROPE	2003	Astra-G	AF 13-II/17/20/22 CAN	Transmission	X	X	X	X	
EUROPE	2003	Astra-G	ABS-5.3/5.4 (+TC)	Transmission	X	X	X	X	
EUROPE	2003	Astra-G	ESP	Chassis	X	X	X	X	
EUROPE	2003	Astra-G	Cruise Control	Chassis	X	X	X		
EUROPE	2003	Astra-G	Electronic Power Steering	Chassis	X	X	X		
EUROPE	2003	Astra-G	Immobiliser	Chassis	X	X	X		
EUROPE	2003	Astra-G	Instrument	Body	X	X	X		1.Erase Key Set; 2.Program Transponder-Keys
EUROPE	2003	Astra-G	Airbag	Body	X	X	X		
EUROPE	2003	Astra-G	Anti Theft Warning	Body	X	X	X		
EUROPE	2003	Astra-G	Central Door Lock	Body	X	X	X		
EUROPE	2003	Astra-G	Engine Cooling Module	Body	X	X	X		
EUROPE	2003	Astra-G	Electronic Climate Control	Body	X	X	X		
EUROPE	2003	Astra-G	HeadLamp Levelling Device	Body	X	X	X		
EUROPE	2003	Astra-G	Z 12 XE	Body	X	X	X	X	Calibration
EUROPE	2002	Astra-G	Z 14 XE	Engine	X	X	X	X	
EUROPE	2002	Astra-G	C 16 SEL	Engine	X	X	X		
EUROPE	2002	Astra-G	Z 16 SE	Engine	X	X	X	X	
EUROPE	2002	Astra-G	Z 16 XE	Engine	X	X	X		
EUROPE	2002	Astra-G	Y 17 DT	Engine	X	X	X	X	
EUROPE	2002	Astra-G	Z 18 XE	Engine	X	X	X	X	
EUROPE	2002	Astra-G	Z 18 XEL	Engine	X	X	X	X	
EUROPE	2002	Astra-G	Y 20 DTL	Engine	X	X	X		
EUROPE	2002	Astra-G	Y 20 DTH	Engine	X	X	X		
EUROPE	2002	Astra-G	Z 20 LET	Engine	X	X	X	X	Adjust Idle Speed
EUROPE	2002	Astra-G	Z 22 SE	Engine	X	X	X		
EUROPE	2002	Astra-G	AF 13-II/17/20/22	Engine	X	X	X		
EUROPE	2002	Astra-G	AF 13-II/17/20/22 CAN	Transmission	X	X	X	X	

EUROPE	2002	Astra-G	ABS-5.3/5.4 (+TC)	Transmission	X	X	X	X	
EUROPE	2002	Astra-G	ESP	Chassis	X	X	X	X	
EUROPE	2002	Astra-G	Cruise Control	Chassis	X	X	X		
EUROPE	2002	Astra-G	Electronic Power Steering	Chassis	X	X	X		
EUROPE	2002	Astra-G	Immobiliser	Chassis	X	X	X		
EUROPE	2002	Astra-G	Instrument	Body	X	X	X		1.Erase Key Set; 2.Program Transponder-Keys
EUROPE	2002	Astra-G	Airbag	Body	X	X	X		
EUROPE	2002	Astra-G	Anti Theft Warning	Body	X	X	X		
EUROPE	2002	Astra-G	Central Door Lock	Body	X	X	X		
EUROPE	2002	Astra-G	Engine Cooling Module	Body	X	X	X		
EUROPE	2002	Astra-G	HeadLamp Levelling Device	Body	X	X	X		
EUROPE	2002	Astra-G	Z 12 XE	Body	X	X	X	X	Calibration
EUROPE	2001	Astra-G	Z 14 XE	Engine	X	X	X	X	
EUROPE	2001	Astra-G	C 16 SEL	Engine	X	X	X		
EUROPE	2001	Astra-G	X 16 SZR	Engine	X	X	X	X	
EUROPE	2001	Astra-G	Z 16 SE	Engine	X	X	X		
EUROPE	2001	Astra-G	Z 16 XE	Engine	X	X	X		
EUROPE	2001	Astra-G	Y 17 DT	Engine	X	X	X	X	
EUROPE	2001	Astra-G	X 18 XE1	Engine	X	X	X	X	
EUROPE	2001	Astra-G	Z 18 XE	Engine	X	X	X	X	Adjust Idle Speed
EUROPE	2001	Astra-G	Z 18 XEL	Engine	X	X	X	X	
EUROPE	2001	Astra-G	Y 20 DTL	Engine	X	X	X		
EUROPE	2001	Astra-G	Y 20 DTH	Engine	X	X	X		
EUROPE	2001	Astra-G	Z 20 LET	Engine	X	X	X	X	Adjust Idle Speed
EUROPE	2001	Astra-G	Z 22 SE	Engine	X	X	X		
EUROPE	2001	Astra-G	AF 13-II/17/20/22	Engine	X	X	X		
EUROPE	2001	Astra-G	AF 13-II/17/20/22 CAN	Transmission	X	X	X	X	
EUROPE	2001	Astra-G	ABS-5.3/5.4 (+TC)	Transmission	X	X	X	X	
EUROPE	2001	Astra-G	ESP	Chassis	X	X	X	X	
EUROPE	2001	Astra-G	Cruise Control	Chassis	X	X	X		
EUROPE	2001	Astra-G	Electronic Power Steering	Chassis	X	X	X		
EUROPE	2001	Astra-G	Immobiliser	Chassis	X	X	X		
EUROPE	2001	Astra-G	Instrument	Body	X	X	X		1.Erase Key Set; 2.Program Transponder-Keys

EUROPE	2001	Astra-G	Airbag	Body	X	X	X		
EUROPE	2001	Astra-G	Anti Theft Warning	Body	X	X	X		
EUROPE	2001	Astra-G	Central Door Lock	Body	X	X	X		
EUROPE	2001	Astra-G	Engine Cooling Module	Body	X	X	X		
EUROPE	2001	Astra-G	X 12 XE	Body	X	X	X		
EUROPE	2000	Astra-G	X 14 XE	Engine	X	X	X		
EUROPE	2000	Astra-G	C 16 SEL	Engine	X	X	X		
EUROPE	2000	Astra-G	X 16 SZR	Engine	X	X	X	X	
EUROPE	2000	Astra-G	X 16 XEL	Engine	X	X	X		
EUROPE	2000	Astra-G	X 17 DTL	Engine	X	X	X		Adjust Idle Speed
EUROPE	2000	Astra-G	Y 17 DT	Engine	X	X	X		
EUROPE	2000	Astra-G	X 18 XE1	Engine	X	X	X	X	
EUROPE	2000	Astra-G	X 20 DTL	Engine	X	X	X	X	Adjust Idle Speed
EUROPE	2000	Astra-G	X 20 XEV	Engine	X	X	X		
EUROPE	2000	Astra-G	X 20 XER	Engine	X	X	X		Adjust Idle Speed
EUROPE	2000	Astra-G	Y 20 DTH	Engine	X	X	X		
EUROPE	2000	Astra-G	Z 22 SE	Engine	X	X	X	X	Adjust Idle Speed
EUROPE	2000	Astra-G	AF 13-II/17/20/22	Engine	X	X	X		
EUROPE	2000	Astra-G	ABS-5.3/5.4 (+TC)	Transmission	X	X	X	X	
EUROPE	2000	Astra-G	ESP	Chassis	X	X	X	X	
EUROPE	2000	Astra-G	Cruise Control	Chassis	X	X	X		
EUROPE	2000	Astra-G	Electronic Power Steering	Chassis	X	X	X		
EUROPE	2000	Astra-G	Immobiliser	Chassis	X	X	X		
EUROPE	2000	Astra-G	Instrument	Body	X	X	X		1.Erase Key Set; 2.Program Transponder-Keys
EUROPE	2000	Astra-G	Airbag	Body	X	X	X		
EUROPE	2000	Astra-G	Airbag SAB6	Body	X	X	X		
EUROPE	2000	Astra-G	Anti Theft Warning	Body	X	X	X		
EUROPE	2000	Astra-G	Central Door Lock	Body	X	X	X		
EUROPE	2000	Astra-G	Engine Cooling Module	Body	X	X	X		
EUROPE	2000	Astra-G	X 12 XE	Body	X	X	X		
EUROPE	1999	Astra-G	X 14 XE	Engine	X	X	X		
EUROPE	1999	Astra-G	C 16 SEL	Engine	X	X	X		
EUROPE	1999	Astra-G	X 16 SZR	Engine	X	X	X	X	
EUROPE	1999	Astra-G	X 16 XEL	Engine	X	X	X		
EUROPE	1999	Astra-G	X 17 DTL	Engine	X	X	X		Adjust Idle Speed

EUROPE	1999	Astra-G	X 18 XE1	Engine	X	X	X		
EUROPE	1999	Astra-G	X 20 DTL	Engine	X	X	X	X	Adjust Idle Speed
EUROPE	1999	Astra-G	X 20 XEV	Engine	X	X	X		
EUROPE	1999	Astra-G	AF 13-II/17/20/22	Engine	X	X	X		Adjust Idle Speed
EUROPE	1999	Astra-G	ABS-5.3/5.4 (+TC)	Transmission	X	X	X	X	
EUROPE	1999	Astra-G	Cruise Control	Chassis	X	X	X	X	
EUROPE	1999	Astra-G	Immobiliser	Chassis	X	X	X		
EUROPE	1999	Astra-G	Instrument	Body	X	X	X		1.Erase Key Set; 2.Program Transponder-Keys
EUROPE	1999	Astra-G	Airbag SAB6	Body	X	X	X		
EUROPE	1999	Astra-G	Anti Theft Warning	Body	X	X	X		
EUROPE	1999	Astra-G	Central Door Lock	Body	X	X	X		
EUROPE	1999	Astra-G	Engine Cooling Module	Body	X	X	X		
EUROPE	1999	Astra-G	X 12 XE	Body	X	X	X		
EUROPE	1998	Astra-G	X 14 XE	Engine	X	X	X		
EUROPE	1998	Astra-G	X 16 SZR	Engine	X	X	X		
EUROPE	1998	Astra-G	X 16 XEL	Engine	X	X	X		
EUROPE	1998	Astra-G	X 17 DTL	Engine	X	X	X		Adjust Idle Speed
EUROPE	1998	Astra-G	X 18 XE1	Engine	X	X	X		
EUROPE	1998	Astra-G	X 20 DTL	Engine	X	X	X	X	Adjust Idle Speed
EUROPE	1998	Astra-G	X 20 XEV	Engine	X	X	X		
EUROPE	1998	Astra-G	AF 13-II/17/20/22	Engine	X	X	X		Adjust Idle Speed
EUROPE	1998	Astra-G	ABS-5.3/5.4 (+TC)	Transmission	X	X	X	X	
EUROPE	1998	Astra-G	Cruise Control	Chassis	X	X	X	X	
EUROPE	1998	Astra-G	Immobiliser	Chassis	X	X	X		
EUROPE	1998	Astra-G	Instrument	Body	X	X	X		1.Erase Key Set; 2.Program Transponder-Keys
EUROPE	1998	Astra-G	Airbag SAB6	Body	X	X	X		
EUROPE	1998	Astra-G	Anti Theft Warning	Body	X	X	X		
EUROPE	1998	Astra-G	Central Door Lock	Body	X	X	X		
EUROPE	1998	Astra-G	Engine Cooling Module	Body	X	X	X		
EUROPE	1998	Astra-G	Vehicle DTC Information	Body	X	X	X		
EUROPE	2011	Astra-H	Z 12 XEP	Vehicle		X			
EUROPE	2011	Astra-H	Z13DTH	Engine	X	X	X	X	

EUROPE	2011	Astra-H	Y 13 DTH	Engine	X	X	X	X	ECU Control Program High Speed CAN-Bus Configuration Reset ECU Program Injector
EUROPE	2011	Astra-H	Z14XEL	Engine	X	X	X	X	
EUROPE	2011	Astra-H	Z14XEP	Engine	X	X	X	X	ECU Control Program Idle Speed Reset O2-Loop Block Learn Map Program High Speed CAN-Bus Configuration Reset ECU
EUROPE	2011	Astra-H	Z16XEP	Engine	X	X	X	X	ECU Control Program Idle Speed Reset O2-Loop Block Learn Map Program High Speed CAN-Bus Configuration Reset ECU
EUROPE	2011	Astra-H	Z16XER	Engine	X	X	X	X	ECU Control Program Idle Speed Reset O2-Loop Block Learn Map Program High Speed CAN-Bus Configuration Reset ECU
EUROPE	2011	Astra-H	Z 16 LET	Engine	X	X	X	X	ECU Control Program Idle Speed Reset Learned Values Program High Speed CAN-Bus Configuration Reset ECU
EUROPE	2011	Astra-H	Z 16 XE1	Engine	X	X	X	X	
EUROPE	2011	Astra-H	Z 17DTH	Engine	X	X	X	X	
EUROPE	2011	Astra-H	Z 17 DTR	Engine	X	X	X	X	Program High Speed CAN-Bus Configuration Reset ECU Replace Injector Replace Rail Pressure Sensor
EUROPE	2011	Astra-H	Z 17 DTJ	Engine	X	X	X	X	Program High CanBus Configuration Replace DPF Replace Rail Pressure Sensor Replace Diff.-Press. Sensor Replace Precatalyst Replace MAF Sensor Regeneration DPF
EUROPE	2011	Astra-H	Z 17 DTL	Engine	X	X	X	X	
EUROPE	2011	Astra-H	Z18XE	Engine	X	X	X	X	
EUROPE	2011	Astra-H	Z18XER	Engine	X	X	X	X	ECU Control Program High Speed CAN-Bus Configuration Reset ECU

EUROPE	2011	Astra-H	Z19DT	Engine	X	X	X	X	Program Idle Speed Reset Learned Values Program High Speed CAN-Bus Configuration Reset ECU
EUROPE	2011	Astra-H	Z19DTH	Engine	X	X	X	X	1.Replace Diesel Particulate Filter 2.Replace Mass air flow sensor 3.Replace Precatalyst 4.Replace Rail Progressure sensor 5.Reset Engine Oil Life 6.Regeneration Diesel Particulate Filter *7.Replace Injector *8.Program Injector *9.Program High Speed CAN-Bus Configuration *10.Reset ECU *11.Replace 02 Sensor *12.Program Idle Speed
EUROPE	2011	Astra-H	Z 20 LEH	Engine	X	X	X	X	1.Replace Mass air flow sensor 2.Replace Precatalyst 3.Replace Rail Progressure sensor 4.Regeneration Diesel Particulate Filter 5.Replace Disel Particulate Filter 6.Replace Injector 7.Program Injector 8.Program High Speed CAN-Bus Configuration 9.Reset ECU 10.Replace 02 Sensor 11.Program Idle Speed
EUROPE	2011	Astra-H	Z 20 LEL	Engine	X	X	X	X	
EUROPE	2011	Astra-H	Z 20 LER	Engine	X	X	X	X	
EUROPE	2011	Astra-H	Z 22 YH	Engine	X	X	X	X	
EUROPE	2011	Astra-H	AF 17-4	Engine	X	X	X	X	
EUROPE	2011	Astra-H	AF 22-4	Transmission	X	X	X		
EUROPE	2011	Astra-H	MTA(Easytronic)	Transmission	X	X	X	X	
EUROPE	2011	Astra-H	MTA(Easytronic Magneti Marelli)	Transmission	X	X	X	X	
EUROPE	2011	Astra-H	ABS/TC/ESP ECU (Electronic Control Unit)	Transmission	X	X	X	X	
EUROPE	2011	Astra-H	EHPS (Electro Hydraulic Power Steering)	Chassis	X	X	X	X	
EUROPE	2011	Astra-H	CDC(Continuous Damping Control)	Chassis	X	X	X		
EUROPE	2011	Astra-H	SDM (Airbag)	Chassis	X	X	X	X	

EUROPE	2011	Astra-H	CIM(Steering Column Module)	Body	X	X	X		
EUROPE	2011	Astra-H	IPC ECU (Instrument Control unit)	Body	X	X	X	X	Erase Transponder-Keys And Remote Program Transponder-Keys And Remote
EUROPE	2011	Astra-H	REC (Rear Electrical Centre)	Body	X	X	*		
EUROPE	2011	Astra-H	UEC (Underhood Electrical Centre)	Body	X	X	X		
EUROPE	2011	Astra-H	PAS(Park Pilot)	Body	X	X	*		
EUROPE	2011	Astra-H	PEPS(Open and Start)	Body	X	X	X	X	
EUROPE	2011	Astra-H	SLM(Shift Lever Module)	Body	X	X	X		
EUROPE	2011	Astra-H	Vehicle DTC Information	Body	X	X	X	X	
EUROPE	2010	Astra-H	Z 12 XEP	Vehicle		X			
EUROPE	2010	Astra-H	Z13DTH	Engine	X	X	X	X	
EUROPE	2010	Astra-H	Y 13 DTH	Engine	X	X	X	X	ECU Control Program High Speed CAN-Bus Configuration Reset ECU Program Injector
EUROPE	2010	Astra-H	Z14XEL	Engine	X	X	X	X	
EUROPE	2010	Astra-H	Z14XEP	Engine	X	X	X	X	ECU Control Program Idle Speed Reset O2-Loop Block Learn Map Program High Speed CAN-Bus Configuration Reset ECU
EUROPE	2010	Astra-H	Z16XEP	Engine	X	X	X	X	ECU Control Program Idle Speed Reset O2-Loop Block Learn Map Program High Speed CAN-Bus Configuration Reset ECU
EUROPE	2010	Astra-H	Z16XER	Engine	X	X	X	X	ECU Control Program Idle Speed Reset O2-Loop Block Learn Map Program High Speed CAN-Bus Configuration Reset ECU
EUROPE	2010	Astra-H	Z 16 LET	Engine	X	X	X	X	ECU Control Program Idle Speed Reset Learned Values Program High Speed CAN-Bus Configuration Reset ECU
EUROPE	2010	Astra-H	Z 16 XE1	Engine	X	X	X	X	

EUROPE	2010	Astra-H	Z17DTH	Engine	X	X	X	X	
EUROPE	2010	Astra-H	Z 17 DTR	Engine	X	X	X	X	Program High Speed CAN-Bus Configuration Reset ECU Replace Injector Replace Rail Pressure Sensor
EUROPE	2010	Astra-H	Z 17 DTJ	Engine	X	X	X	X	Program High CanBus Configuration Replace DPF Replace Rail Pressure Sensor Replace Diff.-Press. Sensor Replace Precatalyst Replace MAF Sensor Regeneration DPF
EUROPE	2010	Astra-H	Z 17 DTL	Engine	X	X	X	X	
EUROPE	2010	Astra-H	Z18XE	Engine	X	X	X	X	
EUROPE	2010	Astra-H	Z18XER	Engine	X	X	X	X	ECU Control Program High Speed CAN-Bus Configuration Reset ECU
EUROPE	2010	Astra-H	Z19DT	Engine	X	X	X	X	Program Idle Speed Reset Learned Values Program High Speed CAN-Bus Configuration Reset ECU
EUROPE	2010	Astra-H	Z19DTH	Engine	X	X	X	X	1.Replace Diesel Particulate Filter 2.Replace Mass air flow sensor 3.Replace Precatalyst 4.Replace Rail Progressure sensor 5.Reset Engine Oil Life 6.Regeneration Diesel Particulate Filter *7.Replace Injector *8.Program Injector *9.Program High Speed CAN-Bus Configuration *10.Reset ECU *11.Replace O2 Sensor
EUROPE	2010	Astra-H	Z 20 LEH	Engine	X	X	X	X	1.Replace Mass air flow sensor 2.Replace Precatalyst 3.Replace Rail Progressure sensor 4.Regeneration Diesel Particulate Filter 5.Replace Diesel Particulate Filter 6.Replace Injector 7.Program Injector 8.Program High Speed CAN-Bus Configuration 9.Reset ECU 10.Replace O2 Sensor 11.Program Idle Speed
EUROPE	2010	Astra-H	Z 20 LEL	Engine	X	X	X	X	

EUROPE	2010	Astra-H	Z 20 LER	Engine	X	X	X	X	
EUROPE	2010	Astra-H	Z 22 YH	Engine	X	X	X	X	
EUROPE	2010	Astra-H	AF 17-4	Engine	X	X	X	X	
EUROPE	2010	Astra-H	AF 22-4	Transmission	X	X	X		
EUROPE	2010	Astra-H	MTA(Easytronic)	Transmission	X	X	X	X	
EUROPE	2010	Astra-H	MTA(Easytronic Magneti Marelli)	Transmission	X	X	X	X	
EUROPE	2010	Astra-H	ABS/TC/ESP ECU (Electronic Control Unit)	Transmission	X	X	X	X	
EUROPE	2010	Astra-H	EHPS (Electro Hydraulic Power Steering)	Chassis	X	X	X	X	
EUROPE	2010	Astra-H	CDC(Continuous Damping Control)	Chassis	X	X	X		
EUROPE	2010	Astra-H	SDM (Airbag)	Chassis	X	X	X	X	
EUROPE	2010	Astra-H	CIM(Steering Column Module)	Body	X	X	X		
EUROPE	2010	Astra-H	IPC ECU (Instrument Control unit)	Body	X	X	X	X	Erase Transponder-Keys And Remote Program Transponder-Keys And Remote
EUROPE	2010	Astra-H	REC (Rear Electrical Centre)	Body	X	X	*		
EUROPE	2010	Astra-H	UEC (Underhood Electrical Centre)	Body	X	X	X		
EUROPE	2010	Astra-H	PAS(Park Pilot)	Body	X	X	*		
EUROPE	2010	Astra-H	PEPS(Open and Start)	Body	X	X	X	X	
EUROPE	2010	Astra-H	SLM(Shift Lever Module)	Body	X	X	X		
EUROPE	2010	Astra-H	Vehicle DTC Information	Body	X	X	X	X	
EUROPE	2009	Astra-H	Z 12 XEP	Vehicle		X			
EUROPE	2009	Astra-H	Y 13 DTH	Engine	X	X	X	X	
EUROPE	2009	Astra-H	Z 13 DTH	Engine	X	X	X	X	
EUROPE	2009	Astra-H	Z 14 XEL	Engine	X	X	X	X	ECU Control(Injector cutoff test) Program High CanBus Configuration ECU Reset Program Injector
EUROPE	2009	Astra-H	Z 14 XEP	Engine	X	X	X		
EUROPE	2009	Astra-H	Z 16 XEP	Engine	X	X	X		
EUROPE	2009	Astra-H	Z 16 XER	Engine	X	X	X		
EUROPE	2009	Astra-H	Z 16 LET	Engine	X	X	X		Injector Cutoff Test
EUROPE	2009	Astra-H	Z 16 XE1	Engine	X	X	X	X	

EUROPE	2009	Astra-H	Z 17 DTH	Engine	X	X	X	X	
EUROPE	2009	Astra-H	Z 17 DTR	Engine	X	X	X	X	
EUROPE	2009	Astra-H	Z 17 DTJ	Engine	X	X	X	X	Program High CanBus Configuration Replace DPF Replace Rail Pressure Sensor Replace Diff.-Press. Sensor Replace Precatalyst Replace MAF Sensor Regeneration DPF
EUROPE	2009	Astra-H	Z 18 XE	Engine	X	X	X	X	
EUROPE	2009	Astra-H	Z 18 XER	Engine	X	X	X		Injector Cutoff Test
EUROPE	2009	Astra-H	Z 19 DT	Engine	X	X	X	X	Injector Cutoff Test
EUROPE	2009	Astra-H	Z 19 DTH	Engine	X	X	X	X	1.Replace Mass air flow sensor 2.Replace Precatalyst 3.Replace Rail Progressure sensor 4.Regeneration Diesel Particulate Filter 5.Replace Diesel Particulate Filter 6.Replace Injector 7.Program Injector 8.Program High Speed CAN-Bus Configuration 9.Reset ECU 10.Replace O2 Sensor 11.Program Idle Speed
EUROPE	2009	Astra-H	Z 20 LEH	Engine	X	X	X	X	1.Replace Mass air flow sensor 2.Replace Precatalyst 3.Replace Rail Progressure sensor 4.Regeneration D. Particulate Filter *5.Replace DPF *6.Replace Injector *7.Program Injector *8.Program High Speed CAN-Bus Configuration *9.Reset ECU *10.Replace O3 Sensor
EUROPE	2009	Astra-H	Z 17 DTL	Engine	X	X	X	X	
EUROPE	2009	Astra-H	Z 20 LEL	Engine	X	X	X	X	
EUROPE	2009	Astra-H	Z 20 LER	Engine	X	X	X	X	
EUROPE	2009	Astra-H	Z 22 YH	Engine	X	X	X	X	
EUROPE	2009	Astra-H	MTA(Easytronic)	Engine	X	X	X	X	
EUROPE	2009	Astra-H	MTA(Easytronic Magneti Marelli)	Transmission	X	X	X	X	
EUROPE	2009	Astra-H	AF 22-4	Transmission	X	X	X	X	
EUROPE	2009	Astra-H	AF 17-4	Transmission	X	X	X	X	

EUROPE	2009	Astra-H	ABS/TC/ESP ECU (Electronic Control unit)	Transmission	X	X	X		
EUROPE	2009	Astra-H	EHPS (Electrohydraulic Power Steering)	Chassis	X	X	X	X	
EUROPE	2009	Astra-H	CDC(Continuous Damping Control)	Chassis	X	X	X		
EUROPE	2009	Astra-H	PEPS(Open&Start)	Chassis	X	X	X	X	
EUROPE	2009	Astra-H	PAS(Park Pilot)	Body	X	X	X		
EUROPE	2009	Astra-H	SLM(Shift Lever Module)	Body	X	X	X	X	
EUROPE	2009	Astra-H	SDM (Airbag)	Body	X	X	X	X	
EUROPE	2009	Astra-H	CIM (Steering Column Module)	Body	X	X	X		
EUROPE	2009	Astra-H	IPC ECU (Instrument Control unit)	Body	X	X	X		
EUROPE	2009	Astra-H	REC (Rear Electrical Centre)	Body	X	X	*		
EUROPE	2009	Astra-H	UEC (Underhood Electrical Centre)	Body	X	X	X		
EUROPE	2009	Astra-H	Vehicle DTC Information	Body	X	X	*		
EUROPE	2008	Astra-H	Z 12 XEP	Vehicle		X			
EUROPE	2008	Astra-H	Y 13 DTH	Engine	X	X	X	X	
EUROPE	2008	Astra-H	Z 13 DTH	Engine	X	X	X	X	
EUROPE	2008	Astra-H	Z 14 XEL	Engine	X	X	X	X	ECU Control(Injector cutoff test) Program High CanBus Configuration ECU Reset Program Injector
EUROPE	2008	Astra-H	Z 14 XEP	Engine	X	X	X		
EUROPE	2008	Astra-H	Z 16 XEP	Engine	X	X	X		
EUROPE	2008	Astra-H	Z 16 LET	Engine	X	X	X		
EUROPE	2008	Astra-H	Z 16 XE1	Engine	X	X	X	X	
EUROPE	2008	Astra-H	Z 16 XER	Engine	X	X	X	X	
EUROPE	2008	Astra-H	Z 17 DTH	Engine	X	X	X		Injector Cutoff Test
EUROPE	2008	Astra-H	Z 17 DTR	Engine	X	X	X	X	

EUROPE	2008	Astra-H	Z 17 DTJ	Engine	X	X	X	X	Program High CanBus Configuration Replace DPF Replace Rail Pressure Sensor Replace Diff.-Press. Sensor Replace Precatalyst Replace MAF Sensor Regeneration DPF
EUROPE	2008	Astra-H	Z 18 XE	Engine	X	X	X	X	
EUROPE	2008	Astra-H	Z 18 XER	Engine	X	X	X		Injector Cutoff Test
EUROPE	2008	Astra-H	Z 19 DT	Engine	X	X	X	X	Injector Cutoff Test
EUROPE	2008	Astra-H	Z 19 DTH	Engine	X	X	X	X	1.Replace Diesel Particulate Filter 2.Replace Mass air flow sensor 3.Replace Precatalyst 4.Replace Rail Progressure sensor 5.Reset Engine Oil Life 6.Regeneration D. Particulate Filter *7.Replace Injector *8.Program Injector *9.Program High Speed CAN-Bus Configuration *10.Reset ECU *11.Replace O2 Sensor
EUROPE	2008	Astra-H	Z 20 LEH	Engine	X	X	X	X	1.Replace Mass air flow sensor 2.Replace Precatalyst 3.Replace Rail Progressure sensor 4.Regeneration Diesel Particulate Filter 5.Replace Diesel Particulate Filter 6.Replace Injector 7.Program Injector 8.Program High Speed CAN-Bus Configuration 9.Reset ECU 10.Replace O2 Sensor 11.Program Idle Speed
EUROPE	2008	Astra-H	Z 17 DTL	Engine	X	X	X	X	
EUROPE	2008	Astra-H	Z 20 LEL	Engine	X	X	X	X	
EUROPE	2008	Astra-H	Z 20 LER	Engine	X	X	X	X	
EUROPE	2008	Astra-H	Z 22 YH	Engine	X	X	X	X	
EUROPE	2008	Astra-H	MTA(Easytronic)	Engine	X	X	X	X	
EUROPE	2008	Astra-H	MTA(Easytronic Magneti Marelli)	Transmission	X	X	X	X	
EUROPE	2008	Astra-H	AF 22-4	Transmission	X	X	X	X	
EUROPE	2008	Astra-H	AF 17-4	Transmission	X	X	X	X	
EUROPE	2008	Astra-H	ABS/TC/ESP ECU (Electronic Control unit)	Transmission	X	X	X		

EUROPE	2008	Astra-H	EHPS (Electrohydraulic Power Steering)	Chassis	X	X	X	X	
EUROPE	2008	Astra-H	CDC(Continuous Damping Control)	Chassis	X	X	X		
EUROPE	2008	Astra-H	PEPS(Open&Start)	Chassis	X	X	X	X	
EUROPE	2008	Astra-H	PAS(Park Pilot)	Body	X	X	X		
EUROPE	2008	Astra-H	SLM(Shift Lever Module)	Body	X	X	X	X	
EUROPE	2008	Astra-H	SDM (Airbag)	Body	X	X	X	X	
EUROPE	2008	Astra-H	CIM (Steering Column Module)	Body	X	X	X		
EUROPE	2008	Astra-H	IPC ECU (Instrument Control unit)	Body	X	X	X		
EUROPE	2008	Astra-H	REC (Rear Electrical Centre)	Body	X	X	*		
EUROPE	2008	Astra-H	UEC (Underhood Electrical Centre)	Body	X	X	X		
EUROPE	2008	Astra-H	Vehicle DTC Information	Body	X	X	*		
EUROPE	2007	Astra-H	Z 12 XEP	Vehicle		X			
EUROPE	2007	Astra-H	Y 13 DTH	Engine	X	X	X	X	
EUROPE	2007	Astra-H	Z 13 DTH	Engine	X	X	X	X	
EUROPE	2007	Astra-H	Z 14 XEL	Engine	X	X	X	X	ECU Control(Injector cutoff test) Program High CanBus Configuration ECU Reset Program Injector
EUROPE	2007	Astra-H	Z 14 XEP	Engine	X	X	X		
EUROPE	2007	Astra-H	Z 16 XEP	Engine	X	X	X		
EUROPE	2007	Astra-H	Z 16 XER	Engine	X	X	X		
EUROPE	2007	Astra-H	Z 16 LET	Engine	X	X	X		Injector Cutoff Test
EUROPE	2007	Astra-H	Z 16 XE1	Engine	X	X	X	X	
EUROPE	2007	Astra-H	Z 17 DTH	Engine	X	X	X	X	
EUROPE	2007	Astra-H	Z 17 DTR	Engine	X	X	X	X	
EUROPE	2007	Astra-H	Z 17 DTJ	Engine	X	X	X	X	Program High CanBus Configuration Replace DPF Replace Rail Pressure Sensor Replace Diff.-Press. Sensor Replace Precatalyst Replace MAF Sensor Regeneration DPF
EUROPE	2007	Astra-H	Z 18 XE	Engine	X	X	X	X	

EUROPE	2007	Astra-H	Z 18 XER	Engine	X	X	X		Injector Cutoff Test
EUROPE	2007	Astra-H	Z 19 DT	Engine	X	X	X	X	Injector Cutoff Test
EUROPE	2007	Astra-H	Z 19 DTH	Engine	X	X	X	X	1.Replace Diesel Particulate Filter 2.Replace Mass air flow sensor 3.Replace Precatalyst 4.Replace Rail Progressure sensor 5.Reset Engine Oil Life 6.Regeneration D. Particulate Filter *7.Replace Injector *8.Program Injector *9.Program High Speed CAN-Bus Configuration *10.Reset ECU *11.Replace O2 Sensor
EUROPE	2007	Astra-H	Z 20 LEH	Engine	X	X	X	X	1.Replace Mass air flow sensor 2.Replace Precatalyst 3.Replace Rail Progressure sensor 4.Regeneration Diesel Particulate Filter 5.Replace Diesel Particulate Filter 6.Replace Injector 7.Program Injector 8.Program High Speed CAN-Bus Configuration 9.Reset ECU 10.Replace O2 Sensor 11.Program Idle Speed
EUROPE	2007	Astra-H	Z 17 DTL	Engine	X	X	X	X	
EUROPE	2007	Astra-H	Z 20 LEL	Engine	X	X	X	X	
EUROPE	2007	Astra-H	Z 20 LER	Engine	X	X	X	X	
EUROPE	2007	Astra-H	Z 22 YH	Engine	X	X	X	X	
EUROPE	2007	Astra-H	MTA(Easytronic)	Engine	X	X	X	X	
EUROPE	2007	Astra-H	MTA(Easytronic Magneti Marelli)	Transmission	X	X	X	X	
EUROPE	2007	Astra-H	AF 22-4	Transmission	X	X	X	X	
EUROPE	2007	Astra-H	AF 17-4	Transmission	X	X	X	X	
EUROPE	2007	Astra-H	ABS/TC/ESP ECU (Electronic Control unit)	Transmission	X	X	X		
EUROPE	2007	Astra-H	EHPS (Electrohydraulic Power Steering)	Chassis	X	X	X	X	
EUROPE	2007	Astra-H	CDC(Continuous Damping Control)	Chassis	X	X	X		
EUROPE	2007	Astra-H	PEPS(Open&Start)	Chassis	X	X	X	X	
EUROPE	2007	Astra-H	PAS(Park Pilot)	Body	X	X	X		

EUROPE	2007	Astra-H	SLM(Shift Lever Module)	Body	X	X	X	X	
EUROPE	2007	Astra-H	SDM (Airbag)	Body	X	X	X	X	
EUROPE	2007	Astra-H	CIM (Steering Column Module)	Body	X	X	X		
EUROPE	2007	Astra-H	IPC ECU (Instrument Control unit)	Body	X	X	X		
EUROPE	2007	Astra-H	REC (Rear Electrical Centre)	Body	X	X	*		
EUROPE	2007	Astra-H	UEC (Underhood Electrical Centre)	Body	X	X	X		
EUROPE	2007	Astra-H	Vehicle DTC Information	Body	X	X	*		
EUROPE	2006	Astra-H	Z 12 XEP	Vehicle		X			
EUROPE	2006	Astra-H	Y 13 DTH	Engine	X	X	X	X	
EUROPE	2006	Astra-H	Z 13 DTH	Engine	X	X	X	X	
EUROPE	2006	Astra-H	Z 14 XEL	Engine	X	X	X	X	ECU Control(Injector cutoff test) Program High CanBus Configuration ECU Reset Program Injector
EUROPE	2006	Astra-H	Z 14 XEP	Engine	X	X	X		
EUROPE	2006	Astra-H	Z 16 XEP	Engine	X	X	X		
EUROPE	2006	Astra-H	Z 17 DTH	Engine	X	X	X		
EUROPE	2006	Astra-H	Z 18 XE	Engine	X	X	X	X	
EUROPE	2006	Astra-H	Z 18 XER	Engine	X	X	X		Injector Cutoff Test
EUROPE	2006	Astra-H	Z 19 DT	Engine	X	X	X	X	Injector Cutoff Test
EUROPE	2006	Astra-H	Z 19 DTH	Engine	X	X	X	X	1.Replace Diesel Particulate Filter 2.Replace Mass air flow sensor 3.Replace Precatalyst 4.Replace Rail Progressure sensor 5.Reset Engine Oil Life 6.Regeneration D. Particulate Filter *7.Replace Injector *8.Program Injector *9.Program High Speed CAN-Bus Configuration *10.Reset ECU *11.Replace 02 Sensor

EUROPE	2006	Astra-H	Z 20 LEH	Engine	X	X	X	X	1.Replace Mass air flow sensor 2.Replace Precatalyst 3.Replace Rail Progressure sensor 4.Regeneration Diesel Particulate Filter 5.Replace Diesel Particulate Filter 6.Replace Injector 7.Program Injector 8.Program High Speed CAN-Bus Configuration 9.Reset ECU 10.Replace O2 Sensor 11.Program Idle Speed
EUROPE	2006	Astra-H	Z 17 DTL	Engine	X	X	X	X	
EUROPE	2006	Astra-H	Z 20 LEL	Engine	X	X	X	X	
EUROPE	2006	Astra-H	Z 20 LER	Engine	X	X	X	X	
EUROPE	2006	Astra-H	Z 22 YH	Engine	X	X	X	X	
EUROPE	2006	Astra-H	MTA(Easytronic)	Engine	X	X	X	X	
EUROPE	2006	Astra-H	MTA(Easytronic Magneti Marelli)	Transmission	X	X	X	X	
EUROPE	2006	Astra-H	AF 22-4	Transmission	X	X	X	X	
EUROPE	2006	Astra-H	AF 17-4	Transmission	X	X	X	X	
EUROPE	2006	Astra-H	ABS/TC/ESP ECU (Electronic Control unit)	Transmission	X	X	X		
EUROPE	2006	Astra-H	EHPS (Electrohydraulic Power Steering)	Chassis	X	X	X	X	
EUROPE	2006	Astra-H	CDC(Continuous Damping Control)	Chassis	X	X	X		
EUROPE	2006	Astra-H	PEPS(Open&Start)	Chassis	X	X	X	X	
EUROPE	2006	Astra-H	PAS(Park Pilot)	Body	X	X	X		
EUROPE	2006	Astra-H	SLM(Shift Lever Module)	Body	X	X	X	X	
EUROPE	2006	Astra-H	SDM (Airbag)	Body	X	X	X	X	
EUROPE	2006	Astra-H	CIM (Steering Column Module)	Body	X	X	X		
EUROPE	2006	Astra-H	IPC ECU (Instrument Control unit)	Body	X	X	X		
EUROPE	2006	Astra-H	REC (Rear Electrical Centre)	Body	X	X	*		
EUROPE	2006	Astra-H	UEC (Underhood Electrical Centre)	Body	X	X	X		

EUROPE	2006	Astra-H	Vehicle DTC Information	Body	X	X	*		
EUROPE	2005	Astra-H	Z 13 DTH	Vehicle		X			
EUROPE	2005	Astra-H	Z 14 XEP	Engine	X	X	X	X	ECU Control(Injector cutoff test) Program High CanBus Configuration ECU Reset Program Injector
EUROPE	2005	Astra-H	Z 16 XEP	Engine	X	X	X		
EUROPE	2005	Astra-H	Z 17 DTH	Engine	X	X	X		
EUROPE	2005	Astra-H	Z 18 XE	Engine	X	X	X	X	
EUROPE	2005	Astra-H	Z 19 DTH	Engine	X	X	X		Injector Cutoff Test
EUROPE	2005	Astra-H	Z 20 LEH	Engine	X	X	X	X	1.Replace Mass air flow sensor 2.Replace Precatalyst 3.Replace Rail Progressure sensor 4.Regeneration Diesel Particulate Filter 5.Replace Diesel Particulate Filter 6.Replace Injector 7.Program Injector 8.Program High Speed CAN-Bus Configuration 9.Reset ECU 10.Replace O2 Sensor 11.Program Idle Speed
EUROPE	2005	Astra-H	AF 17-4	Engine	X	X	X	X	
EUROPE	2005	Astra-H	ABS/TC/ESP ECU (Electronic Control unit)	Transmission	X	X	X		
EUROPE	2005	Astra-H	EHPS (Electrohydraulic Power Steering)	Chassis	X	X	X	X	
EUROPE	2005	Astra-H	SDM (Airbag)	Chassis	X	X	X		
EUROPE	2005	Astra-H	CIM (Steering Column Module)	Body	X	X	X		
EUROPE	2005	Astra-H	IPC ECU (Instrument Control unit)	Body	X	X	X		
EUROPE	2005	Astra-H	REC (Rear Electrical Centre)	Body	X	X	*		
EUROPE	2005	Astra-H	UEC (Underhood Electrical Centre)	Body	X	X	X		
EUROPE	2005	Astra-H	Vehicle DTC Information	Body	X	X	*		
EUROPE	2004	Astra-H	Z 14 XEP	Vehicle		X			
EUROPE	2004	Astra-H	Z 16 XEP	Engine	X	X	X		
EUROPE	2004	Astra-H	Z 17 DTH	Engine	X	X	X		

EUROPE	2004	Astra-H	Z 18 XE	Engine	X	X	X	X	
EUROPE	2004	Astra-H	AF 17-4	Engine	X	X	X		Injector Cutoff Test
EUROPE	2004	Astra-H	ABS/TC/ESP ECU (Electronic Control unit)	Transmission	X	X	X		
EUROPE	2004	Astra-H	EHPS (Electrohydraulic Power Steering)	Chassis	X	X	X	X	
EUROPE	2004	Astra-H	SDM (Airbag)	Chassis	X	X	X		
EUROPE	2004	Astra-H	CIM (Steering Column Module)	Body	X	X	X		
EUROPE	2004	Astra-H	IPC ECU (Instrument Control unit)	Body	X	X	X		
EUROPE	2004	Astra-H	REC (Rear Electrical Centre)	Body	X	X	*		
EUROPE	2004	Astra-H	UEC (Underhood Electrical Centre)	Body	X	X	X		
EUROPE	2004	Astra-H	X 20 XEV	Body	X	X	*		
EUROPE	1997	Calibra	X 25 XE	Engine	X	X	X		Adjust Idle Speed
EUROPE	1997	Calibra	AF 13II/20/22/30	Engine	X	X	X		
EUROPE	1997	Calibra	Traction Control (TC)	Transmission	X	X	X		
EUROPE	1997	Calibra	Immobiliser	Chassis	X	X	X		
EUROPE	1997	Calibra	Airbag-S	Body	X	X	X		
EUROPE	1997	Calibra	X 14 SZ	Body	X	X	X		
EUROPE	2003	Corsa-B	ABS-5.3	Engine	X	X	X		
EUROPE	2003	Corsa-B	Electronic Power Steering	Chassis	X	X	X	X	
EUROPE	2003	Corsa-B	Immobiliser	Chassis	X	X	X		
EUROPE	2003	Corsa-B	Instrument	Body	X	X	X		
EUROPE	2003	Corsa-B	Airbag-S	Body	X	X	X	X	1.Service Light Reset 2.Service Due In
EUROPE	2003	Corsa-B	Airbag SAB6	Body	X	X	X		
EUROPE	2003	Corsa-B	X 14 SZ	Body	X	X	X		
EUROPE	2002	Corsa-B	ABS-5.3	Engine	X	X	X		
EUROPE	2002	Corsa-B	Electronic Power Steering	Chassis	X	X	X	X	
EUROPE	2002	Corsa-B	Immobiliser	Chassis	X	X	X		
EUROPE	2002	Corsa-B	Airbag-S	Body	X	X	X		
EUROPE	2002	Corsa-B	Airbag SAB6	Body	X	X	X		
EUROPE	2002	Corsa-B	X 14 SZ	Body	X	X	X		
EUROPE	2001	Corsa-B	ABS-5.3	Engine	X	X	X		

EUROPE	2001	Corsa-B	Electronic Power Steering	Chassis	X	X	X	X	
EUROPE	2001	Corsa-B	Immobiliser	Chassis	X	X	X		
EUROPE	2001	Corsa-B	Airbag-S	Body	X	X	X		
EUROPE	2001	Corsa-B	Airbag SAB6	Body	X	X	X		
EUROPE	2001	Corsa-B	X 10 XE	Body	X	X	X		
EUROPE	2000	Corsa-B	X 12 XE	Engine	X	X	X		
EUROPE	2000	Corsa-B	C 14 SEL	Engine	X	X	X		
EUROPE	2000	Corsa-B	X 14 SZ	Engine	X	X	X		
EUROPE	2000	Corsa-B	X 14 XE	Engine	X	X	X		
EUROPE	2000	Corsa-B	C 16 SEL	Engine	X	X	X		
EUROPE	2000	Corsa-B	X 16 XE	Engine	X	X	X		
EUROPE	2000	Corsa-B	AF 13II/20/22/30	Engine	X	X	X		
EUROPE	2000	Corsa-B	ABS-5.3	Transmission	X	X	X		
EUROPE	2000	Corsa-B	Electronic Power Steering	Chassis	X	X	X	X	
EUROPE	2000	Corsa-B	Immobiliser	Chassis	X	X	X		
EUROPE	2000	Corsa-B	Airbag-S	Body	X	X	X		
EUROPE	2000	Corsa-B	Airbag-SAB6	Body	X	X	X		
EUROPE	2000	Corsa-B	X 10 XE	Body	X	X	X		
EUROPE	1999	Corsa-B	X 12 XE	Engine	X	X	X		
EUROPE	1999	Corsa-B	C 14 SEL	Engine	X	X	X		
EUROPE	1999	Corsa-B	X 14 SZ	Engine	X	X	X		
EUROPE	1999	Corsa-B	X 14 XE	Engine	X	X	X		
EUROPE	1999	Corsa-B	C 16 SEL	Engine	X	X	X		
EUROPE	1999	Corsa-B	X 16 XE	Engine	X	X	X		
EUROPE	1999	Corsa-B	AF 13II/20/22/30	Engine	X	X	X		
EUROPE	1999	Corsa-B	ABS-5.3	Transmission	X	X	X		
EUROPE	1999	Corsa-B	Electronic Power Steering	Chassis	X	X	X	X	
EUROPE	1999	Corsa-B	Immobiliser	Chassis	X	X	X		
EUROPE	1999	Corsa-B	Airbag-S	Body	X	X	X		
EUROPE	1999	Corsa-B	Airbag-SAB6	Body	X	X	X		
EUROPE	1999	Corsa-B	X 10 XE	Body	X	X	X		
EUROPE	1998	Corsa-B	X 12 XE	Engine	X	X	X		
EUROPE	1998	Corsa-B	C 14 NZ	Engine	X	X	X		
EUROPE	1998	Corsa-B	C 14 SEL	Engine	X	X	X		
EUROPE	1998	Corsa-B	X 14 SZ	Engine	X	X	X		
EUROPE	1998	Corsa-B	X 14 XE	Engine	X	X	X		
EUROPE	1998	Corsa-B	C 16 SEL	Engine	X	X	X		
EUROPE	1998	Corsa-B	X 16 XE	Engine	X	X	X		
EUROPE	1998	Corsa-B	AF 13II/20/22/30	Engine	X	X	X		
EUROPE	1998	Corsa-B	ABS-5.3	Transmission	X	X	X		

EUROPE	1998	Corsa-B	Electronic Power Steering	Chassis	X	X	X	X	
EUROPE	1998	Corsa-B	Immobiliser	Chassis	X	X	X		
EUROPE	1998	Corsa-B	Airbag-S	Body	X	X	X		
EUROPE	1998	Corsa-B	X 10 XE	Body	X	X	X		
EUROPE	1997	Corsa-B	C 14 NZ	Engine	X	X	X		
EUROPE	1997	Corsa-B	X 14 SZ	Engine	X	X	X		
EUROPE	1997	Corsa-B	X 14 XE	Engine	X	X	X		
EUROPE	1997	Corsa-B	X 16 XE	Engine	X	X	X		
EUROPE	1997	Corsa-B	ABS-5.3	Engine	X	X	X		
EUROPE	1997	Corsa-B	Electronic Power Steering	Chassis	X	X	X	X	
EUROPE	1997	Corsa-B	Immobiliser	Chassis	X	X	X		
EUROPE	1997	Corsa-B	Airbag-S	Body	X	X	X		
EUROPE	1997	Corsa-B	Z 10 XEP	Body	X	X	X		
EUROPE	2011	Corsa-C	Z 12 XE	Engine	X	X	X		
EUROPE	2011	Corsa-C	Z 12 XEP	Engine	X	X	X	X	
EUROPE	2011	Corsa-C	Y 13 DT	Engine	X	X	X		
EUROPE	2011	Corsa-C	Z 13 DT	Engine	X	X	X		
EUROPE	2011	Corsa-C	Z 14 XE	Engine	X	X	X	X	1.Injector Cutoff Test; 2.RPM Control; 3.Program Idle Speed.
EUROPE	2011	Corsa-C	Z 14 XEP	Engine	X	X	X		
EUROPE	2011	Corsa-C	Z 16 SE	Engine	X	X	X	X	1.Reset Learn Values 2.Reset O2-Loop Block Lean Map 3. ECU Control-Electronic throttle control 4.Idle speed program. 5.ECU Reset
EUROPE	2011	Corsa-C	Z 16 YNG	Engine	X	X	X		
EUROPE	2011	Corsa-C	Y 17 DT	Engine	X	X	X		
EUROPE	2011	Corsa-C	Y 17 DTL	Engine	X	X	X	X	
EUROPE	2011	Corsa-C	Z 17 DTH	Engine	X	X	X		
EUROPE	2011	Corsa-C	Z 18 XE	Engine	X	X	X	X	1.Injector Cutoff Test; 2.EGR Control; 3.Replace Fuel Pump.
EUROPE	2011	Corsa-C	AF 13-II/17/20/22 CAN	Engine	X	X	X		
EUROPE	2011	Corsa-C	MTA (Easytronic)	Transmission	X	X	X	X	
EUROPE	2011	Corsa-C	ABS-5.3/5.4 (+TC)	Transmission	X	X	X	X	
EUROPE	2011	Corsa-C	ABS8/ESP8	Chassis	X	X	X	X	
EUROPE	2011	Corsa-C	Electronic Power Steering	Chassis	X	X	X	X	Steering Angle Sensor Calibration

EUROPE	2011	Corsa-C	Body Control Module	Chassis	X	X	X		
EUROPE	2011	Corsa-C	Immobiliser	Body	X	X	X	X	ECU Control Erase Remote Keys Program Remote Key
EUROPE	2011	Corsa-C	Airbag	Body	X	X	X		1.Erase Key Set; 2.Program Transponder-Keys
EUROPE	2011	Corsa-C	Instrument	Body	X	X	X		Clear Deployment Record
EUROPE	2011	Corsa-C	Z 10 XEP	Body	X	X	X	X	
EUROPE	2010	Corsa-C	Z 12 XE	Engine	X	X	X		
EUROPE	2010	Corsa-C	Z 12 XEP	Engine	X	X	X	X	
EUROPE	2010	Corsa-C	Y 13 DT	Engine	X	X	X		
EUROPE	2010	Corsa-C	Z 13 DT	Engine	X	X	X		
EUROPE	2010	Corsa-C	Z 14 XE	Engine	X	X	X	X	1.Injector Cutoff Test; 2.RPM Control; 3.Program Idle Speed.
EUROPE	2010	Corsa-C	Z 14 XEP	Engine	X	X	X		
EUROPE	2010	Corsa-C	Z 16 SE	Engine	X	X	X	X	1.Reset Learn Values 2.Reset O2-Loop Block Lean Map 3. ECU Control-Electronic throttle control 4.Idle speed program. 5.ECU Reset
EUROPE	2010	Corsa-C	Z 16 YNG	Engine	X	X	X		
EUROPE	2010	Corsa-C	Y 17 DT	Engine	X	X	X		
EUROPE	2010	Corsa-C	Y 17 DTL	Engine	X	X	X	X	
EUROPE	2010	Corsa-C	Z 17 DTH	Engine	X	X	X		
EUROPE	2010	Corsa-C	Z 18 XE	Engine	X	X	X	X	1.Injector Cutoff Test; 2.EGR Control; 3.Replace Fuel Pump.
EUROPE	2010	Corsa-C	AF 13-II/17/20/22 CAN	Engine	X	X	X		
EUROPE	2010	Corsa-C	MTA (Easytronic)	Transmission	X	X	X	X	
EUROPE	2010	Corsa-C	ABS-5.3/5.4 (+TC)	Transmission	X	X	X	X	
EUROPE	2010	Corsa-C	ABS8/ESP8	Chassis	X	X	X	X	
EUROPE	2010	Corsa-C	Electronic Power Steering	Chassis	X	X	X	X	Steering Angle Sensor Calibration
EUROPE	2010	Corsa-C	Body Control Module	Chassis	X	X	X		
EUROPE	2010	Corsa-C	Immobiliser	Body	X	X	X	X	ECU Control Erase Remote Keys Program Remote Key

EUROPE	2010	Corsa-C	Airbag	Body	X	X	X		1.Erase Key Set; 2.Program Transponder-Keys
EUROPE	2010	Corsa-C	Instrument	Body	X	X	X		Clear Deployment Record
EUROPE	2010	Corsa-C	Z 10 XEP	Body	X	X	X	X	
EUROPE	2009	Corsa-C	Z 12 XE	Engine	X	X	X		
EUROPE	2009	Corsa-C	Z 12 XEP	Engine	X	X	X	X	
EUROPE	2009	Corsa-C	Y 13 DT	Engine	X	X	X		
EUROPE	2009	Corsa-C	Z 13 DT	Engine	X	X	X		
EUROPE	2009	Corsa-C	Z 14 XE	Engine	X	X	X	X	1.Inject Cutoff Test; 2.RPM Control; 3.Program Idle Speed.
EUROPE	2009	Corsa-C	Z 14 XEP	Engine	X	X	X		
EUROPE	2009	Corsa-C	Z 16 SE	Engine	X	X	X	X	1.Reset Learn Values 2.Reset O2-Loop Block Lean Map 3. ECU Control-Electronic throttle control 4.Idle speed program. 5.ECU Reset
EUROPE	2009	Corsa-C	Z 16 YNG	Engine	X	X	X		
EUROPE	2009	Corsa-C	Y 17 DTL	Engine	X	X	X		
EUROPE	2009	Corsa-C	Y 17 DT	Engine	X	X	X		
EUROPE	2009	Corsa-C	Z 17 DTH	Engine	X	X	X	X	
EUROPE	2009	Corsa-C	Z 18 XE	Engine	X	X	X	X	1.Inject Cutoff Test; 2.RPM Control; 3.Replace Fuel Pump.
EUROPE	2009	Corsa-C	AF 13-II/17/20/22 CAN	Engine	X	X	X		
EUROPE	2009	Corsa-C	MTA (Easytronic)	Transmission	X	X	X	X	
EUROPE	2009	Corsa-C	ABS8/ESP8	Transmission	X	X	X	X	
EUROPE	2009	Corsa-C	ABS-5.3/5.4 (+TC)	Chassis	X	X	X	X	
EUROPE	2009	Corsa-C	Electronic Power Steering	Chassis	X	X	X	X	
EUROPE	2009	Corsa-C	Body Control Module	Chassis	X	X	X	X	
EUROPE	2009	Corsa-C	Immobiliser	Body	X	X	X	X	
EUROPE	2009	Corsa-C	Instrument	Body	X	X	X		1.Erase Key Set; 2.Program Transponder-Keys
EUROPE	2009	Corsa-C	Airbag	Body	X	X	X	X	1.Service Light Reset 2.Service Due In
EUROPE	2009	Corsa-C	Z 10 XEP	Body	X	X	X	X	
EUROPE	2008	Corsa-C	Z 12 XE	Engine	X	X	X		
EUROPE	2008	Corsa-C	Z 12 XEP	Engine	X	X	X	X	
EUROPE	2008	Corsa-C	Y 13 DT	Engine	X	X	X		

EUROPE	2008	Corsa-C	Z 13 DT	Engine	X	X	X		
EUROPE	2008	Corsa-C	Z 14 XE	Engine	X	X	X	X	1.Inject Cutoff Test; 2.RPM Control; 3.Program Idle Speed.
EUROPE	2008	Corsa-C	Z 14 XEP	Engine	X	X	X		
EUROPE	2008	Corsa-C	Z 16 SE	Engine	X	X	X	X	1.Reset Learn Values 2.Reset O2-Loop Block Lean Map 3. ECU Control-Electronic throttle control 4.Idle speed program. 5.ECU Reset
EUROPE	2008	Corsa-C	Z 16 YNG	Engine	X	X	X		
EUROPE	2008	Corsa-C	Y 17 DTL	Engine	X	X	X		
EUROPE	2008	Corsa-C	Y 17 DT	Engine	X	X	X		
EUROPE	2008	Corsa-C	Z 17 DTH	Engine	X	X	X	X	
EUROPE	2008	Corsa-C	Z 18 XE	Engine	X	X	X	X	1.Inject Cutoff Test; 2.RPM Control; 3.Replace Fuel Pump.
EUROPE	2008	Corsa-C	AF 13-II/17/20/22 CAN	Engine	X	X	X		
EUROPE	2008	Corsa-C	MTA (Easytronic)	Transmission	X	X	X	X	
EUROPE	2008	Corsa-C	ABS8/ESP8	Transmission	X	X	X	X	
EUROPE	2008	Corsa-C	ABS-5.3/5.4 (+TC)	Chassis	X	X	X	X	
EUROPE	2008	Corsa-C	Electronic Power Steering	Chassis	X	X	X	X	
EUROPE	2008	Corsa-C	Body Control Module	Chassis	X	X	X		
EUROPE	2008	Corsa-C	Immobiliser	Body	X	X	X	X	
EUROPE	2008	Corsa-C	Instrument	Body	X	X	X		1.Erase Key Set; 2.Program Transponder-Keys
EUROPE	2008	Corsa-C	Airbag	Body	X	X	X	X	1.Service Light Reset 2.Service Due In
EUROPE	2008	Corsa-C	Z 10 XEP	Body	X	X	X	X	
EUROPE	2007	Corsa-C	Z 12 XE	Engine	X	X	X		
EUROPE	2007	Corsa-C	Z 12 XEP	Engine	X	X	X	X	
EUROPE	2007	Corsa-C	Y 13 DT	Engine	X	X	X		
EUROPE	2007	Corsa-C	Z 13 DT	Engine	X	X	X		
EUROPE	2007	Corsa-C	Z 14 XE	Engine	X	X	X	X	1.Inject Cutoff Test; 2.RPM Control; 3.Program Idle Speed.
EUROPE	2007	Corsa-C	Z 14 XEP	Engine	X	X	X		

EUROPE	2007	Corsa-C	Z 16 SE	Engine	X	X	X	X	1.Reset Learn Values 2.Reset O2-Loop Block Lean Map 3. ECU Control-Electronic throttle control 4.Idle speed program. 5.ECU Reset
EUROPE	2007	Corsa-C	Z 16 YNG	Engine	X	X	X		
EUROPE	2007	Corsa-C	Y 17 DTL	Engine	X	X	X		
EUROPE	2007	Corsa-C	Y 17 DT	Engine	X	X	X		
EUROPE	2007	Corsa-C	Z 17 DTH	Engine	X	X	X	X	
EUROPE	2007	Corsa-C	Z 18 XE	Engine	X	X	X	X	1.Inject Cutoff Test; 2.RPM Control; 3.Replace Fuel Pump.
EUROPE	2007	Corsa-C	AF 13-II/17/20/22 CAN	Engine	X	X	X		
EUROPE	2007	Corsa-C	MTA (Easytronic)	Transmission	X	X	X	X	
EUROPE	2007	Corsa-C	ABS8/ESP8	Transmission	X	X	X	X	
EUROPE	2007	Corsa-C	ABS-5.3/5.4 (+TC)	Chassis	X	X	X	X	
EUROPE	2007	Corsa-C	Electronic Power Steering	Chassis	X	X	X	X	
EUROPE	2007	Corsa-C	Body Control Module	Chassis	X	X	X		
EUROPE	2007	Corsa-C	Immobiliser	Body	X	X	X	X	
EUROPE	2007	Corsa-C	Instrument	Body	X	X	X		1.Erase Key Set; 2.Program Transponder-Keys
EUROPE	2007	Corsa-C	Airbag	Body	X	X	X	X	1.Service Light Reset 2.Service Due In
EUROPE	2007	Corsa-C	Z 10 XEP	Body	X	X	X	X	
EUROPE	2006	Corsa-C	Z 12 XE	Engine	X	X	X		
EUROPE	2006	Corsa-C	Z 12 XEP	Engine	X	X	X	X	
EUROPE	2006	Corsa-C	Y 13 DT	Engine	X	X	X		
EUROPE	2006	Corsa-C	Z 13 DT	Engine	X	X	X		
EUROPE	2006	Corsa-C	Z 14 XE	Engine	X	X	X	X	1.Inject Cutoff Test; 2.RPM Control; 3.Program Idle Speed.
EUROPE	2006	Corsa-C	Z 14 XEP	Engine	X	X	X		
EUROPE	2006	Corsa-C	Z 16 SE	Engine	X	X	X	X	1.Reset Learn Values 2.Reset O2-Loop Block Lean Map 3. ECU Control-Electronic throttle control 4.Idle speed program. 5.ECU Reset
EUROPE	2006	Corsa-C	Z 16 YNG	Engine	X	X	X		
EUROPE	2006	Corsa-C	Y 17 DTL	Engine	X	X	X		

EUROPE	2006	Corsa-C	Y 17 DT	Engine	X	X	X		
EUROPE	2006	Corsa-C	Z 17 DTH	Engine	X	X	X	X	
EUROPE	2006	Corsa-C	Z 18 XE	Engine	X	X	X	X	1.Inject Cutoff Test; 2.RPM Control; 3.Replace Fuel Pump.
EUROPE	2006	Corsa-C	AF 13-II/17/20/22 CAN	Engine	X	X	X		
EUROPE	2006	Corsa-C	MTA (Easytronic)	Transmission	X	X	X	X	
EUROPE	2006	Corsa-C	ABS8/ESP8	Transmission	X	X	X	X	
EUROPE	2006	Corsa-C	ABS-5.3/5.4 (+TC)	Chassis	X	X	X	X	
EUROPE	2006	Corsa-C	Electronic Power Steering	Chassis	X	X	X	X	
EUROPE	2006	Corsa-C	Body Control Module	Chassis	X	X	X		
EUROPE	2006	Corsa-C	Immobiliser	Body	X	X	X	X	
EUROPE	2006	Corsa-C	Instrument	Body	X	X	X		1.Erase Key Set; 2.Program Transponder-Keys
EUROPE	2006	Corsa-C	Airbag	Body	X	X	X	X	1.Service Light Reset 2.Service Due In
EUROPE	2006	Corsa-C	Z 10 XEP	Body	X	X	X	X	
EUROPE	2005	Corsa-C	Z 12 XE	Engine	X	X	X		
EUROPE	2005	Corsa-C	Z 12 XEP	Engine	X	X	X	X	
EUROPE	2005	Corsa-C	Y 13 DT	Engine	X	X	X		
EUROPE	2005	Corsa-C	Z 13 DT	Engine	X	X	X		
EUROPE	2005	Corsa-C	Z 14 XE	Engine	X	X	X	X	1.Inject Cutoff Test; 2.RPM Control; 3.Program Idle Speed.
EUROPE	2005	Corsa-C	Z 14 XEP	Engine	X	X	X		
EUROPE	2005	Corsa-C	Z 16 SE	Engine	X	X	X	X	1.Reset Learn Values 2.Reset O2-Loop Block Lean Map 3. ECU Control-Electronic throttle control 4.Idle speed program. 5.ECU Reset
EUROPE	2005	Corsa-C	Z 16 YNG	Engine	X	X	X		
EUROPE	2005	Corsa-C	Y 17 DTL	Engine	X	X	X		
EUROPE	2005	Corsa-C	Y 17 DT	Engine	X	X	X		
EUROPE	2005	Corsa-C	Z 17 DTH	Engine	X	X	X	X	
EUROPE	2005	Corsa-C	Z 18 XE	Engine	X	X	X	X	1.Inject Cutoff Test; 2.RPM Control; 3.Replace Fuel Pump.
EUROPE	2005	Corsa-C	AF 13-II/17/20/22 CAN	Engine	X	X	X		

EUROPE	2005	Corsa-C	MTA (Easytronic)	Transmission	X	X	X	X	
EUROPE	2005	Corsa-C	ABS8/ESP8	Transmission	X	X	X	X	
EUROPE	2005	Corsa-C	ABS-5.3/5.4 (+TC)	Chassis	X	X	X	X	
EUROPE	2005	Corsa-C	Electronic Power Steering	Chassis	X	X	X	X	
EUROPE	2005	Corsa-C	Body Control Module	Chassis	X	X	X		
EUROPE	2005	Corsa-C	Immobiliser	Body	X	X	X	X	
EUROPE	2005	Corsa-C	Instrument	Body	X	X	X		1.Erase Key Set; 2.Program Transponder-Keys
EUROPE	2005	Corsa-C	Airbag	Body	X	X	X	X	1.Service Light Reset 2.Service Due In
EUROPE	2005	Corsa-C	Z 10 XEP	Body	X	X	X	X	
EUROPE	2004	Corsa-C	Z 12 XE	Engine	X	X	X		
EUROPE	2004	Corsa-C	Z 13 DT	Engine	X	X	X	X	
EUROPE	2004	Corsa-C	Z 14 XE	Engine	X	X	X	X	1.Inject Cutoff Test; 2.RPM Control; 3.Program Idle Speed.
EUROPE	2004	Corsa-C	Z 14 XEP	Engine	X	X	X		
EUROPE	2004	Corsa-C	Z 16 SE	Engine	X	X	X	X	1.Reset Learn Values 2.Reset O2-Loop Block Lean Map 3. ECU Control-Electronic throttle control 4.Idle speed program. 5.ECU Reset
EUROPE	2004	Corsa-C	Y 17 DTL	Engine	X	X	X		
EUROPE	2004	Corsa-C	Y 17 DT	Engine	X	X	X		
EUROPE	2004	Corsa-C	Z 17 DTH	Engine	X	X	X	X	
EUROPE	2004	Corsa-C	Z 18 XE	Engine	X	X	X	X	1.Inject Cutoff Test; 2.RPM Control; 3.Replace Fuel Pump.
EUROPE	2004	Corsa-C	AF 13-II/17/20/22 CAN	Engine	X	X	X		
EUROPE	2004	Corsa-C	MTA (Easytronic)	Transmission	X	X	X		
EUROPE	2004	Corsa-C	ABS8/ESP8	Transmission	X	X	X	X	
EUROPE	2004	Corsa-C	ABS-5.3/5.4 (+TC)	Chassis	X	X	X	X	
EUROPE	2004	Corsa-C	Electronic Power Steering	Chassis	X	X	X	X	
EUROPE	2004	Corsa-C	Body Control Module	Chassis	X	X	X		
EUROPE	2004	Corsa-C	Immobiliser	Body	X	X	X	X	

EUROPE	2004	Corsa-C	Instrument	Body	X	X	X		1.Erase Key Set; 2.Program Transponder-Keys
EUROPE	2004	Corsa-C	Airbag	Body	X	X	X	X	1.Service Light Reset 2.Service Due In
EUROPE	2004	Corsa-C	Z 10 XE	Body	X	X	X	X	
EUROPE	2003	Corsa-C	Z 12 XE	Engine	X	X	X		
EUROPE	2003	Corsa-C	Z 14 XE	Engine	X	X	X	X	
EUROPE	2003	Corsa-C	Z 16 SE	Engine	X	X	X		
EUROPE	2003	Corsa-C	Y 17 DTL	Engine	X	X	X		
EUROPE	2003	Corsa-C	Y 17 DT	Engine	X	X	X		
EUROPE	2003	Corsa-C	Z 18 XE	Engine	X	X	X	X	
EUROPE	2003	Corsa-C	AF 13-II/17/20/22 CAN	Engine	X	X	X		
EUROPE	2003	Corsa-C	MTA (Easytronic)	Transmission	X	X	X	X	
EUROPE	2003	Corsa-C	ABS-5.3/5.4 (+TC)	Transmission	X	X	X	X	
EUROPE	2003	Corsa-C	Electronic Power Steering	Chassis	X	X	X	X	
EUROPE	2003	Corsa-C	Body Control Module	Chassis	X	X	X		
EUROPE	2003	Corsa-C	Immobiliser	Body	X	X	X	X	
EUROPE	2003	Corsa-C	Instrument	Body	X	X	X		
EUROPE	2003	Corsa-C	Airbag	Body	X	X	X	X	1.Service Light Reset 2.Service Due In
EUROPE	2003	Corsa-C	Z 10 XE	Body	X	X	X	X	
EUROPE	2002	Corsa-C	Z 12 XE	Engine	X	X	X		
EUROPE	2002	Corsa-C	Z 14 XE	Engine	X	X	X	X	
EUROPE	2002	Corsa-C	Z 16 SE	Engine	X	X	X		
EUROPE	2002	Corsa-C	Y 17 DTL	Engine	X	X	X		
EUROPE	2002	Corsa-C	Y 17 DT	Engine	X	X	X		
EUROPE	2002	Corsa-C	Z 18 XE	Engine	X	X	X	X	
EUROPE	2002	Corsa-C	AF 13-II/17/20/22 CAN	Engine	X	X	X		
EUROPE	2002	Corsa-C	MTA (Easytronic)	Transmission	X	X	X	X	
EUROPE	2002	Corsa-C	ABS-5.3/5.4 (+TC)	Transmission	X	X	X	X	
EUROPE	2002	Corsa-C	Electronic Power Steering	Chassis	X	X	X	X	
EUROPE	2002	Corsa-C	Body Control Module	Chassis	X	X	X		
EUROPE	2002	Corsa-C	Immobiliser	Body	X	X	X	X	
EUROPE	2002	Corsa-C	Instrument	Body	X	X	X		

EUROPE	2002	Corsa-C	Airbag	Body	X	X	X	X	1.Service Light Reset 2.Service Due In
EUROPE	2002	Corsa-C	Z 10 XE	Body	X	X	X	X	
EUROPE	2001	Corsa-C	Z 12 XE	Engine	X	X	X		
EUROPE	2001	Corsa-C	Z 14 XE	Engine	X	X	X	X	
EUROPE	2001	Corsa-C	Y 17 DTL	Engine	X	X	X		
EUROPE	2001	Corsa-C	Y 17 DT	Engine	X	X	X		
EUROPE	2001	Corsa-C	Z 18 XE	Engine	X	X	X	X	
EUROPE	2001	Corsa-C	AF 13-II/17/20/22 CAN	Engine	X	X	X		
EUROPE	2001	Corsa-C	MTA (Easytronic)	Transmission	X	X	X	X	
EUROPE	2001	Corsa-C	ABS-5.3/5.4 (+TC)	Transmission	X	X	X	X	
EUROPE	2001	Corsa-C	Electronic Power Steering	Chassis	X	X	X	X	
EUROPE	2001	Corsa-C	Body Control Module	Chassis	X	X	X		
EUROPE	2001	Corsa-C	Immobiliser	Body	X	X	X	X	
EUROPE	2001	Corsa-C	Instrument	Body	X	X	X		
EUROPE	2001	Corsa-C	Airbag	Body	X	X	X	X	1.Service Light Reset 2.Service Due In
EUROPE	2001	Corsa-C	A 10 XEP	Body	X	X	X	X	
EUROPE	2011	Corsa-D	Z 10 XEP	Engine	*	*	*	*	
EUROPE	2011	Corsa-D	Z 12 XEP	Engine	X	X	X	X	
EUROPE	2011	Corsa-D	Z 13 DTJ	Engine	X	X	X	X	
EUROPE	2011	Corsa-D	Z 13 DTH	Engine	X	X	X	X	ECU Control(Injector cutoff test) Program High CanBus Configuration ECU Reset Program Injector
EUROPE	2011	Corsa-D	Z 14 XEP	Engine	X	X	X	X	ECU Control(Injector cutoff test) Program High CanBus Configuration ECU Reset Program Injector
EUROPE	2011	Corsa-D	Z 17 DTR	Engine	X	X	X	X	
EUROPE	2011	Corsa-D	MTA	Engine	X	X	X	X	Program High CanBus Configuration Replace DPF Replace Rail Pressure Sensor Replace Diff.-Press. Sensor Replace Precatalyst Replace MAF Sensor Regeneration DPF
EUROPE	2011	Corsa-D	ABS/ESP	Transmission	X	X	X	X	

EUROPE	2011	Corsa-D	Electronic Power Steering	Chassis	X	X	X	X	
EUROPE	2011	Corsa-D	SDM (Airbag)	Chassis	X	X	X		Steering angle calibration
EUROPE	2011	Corsa-D	IPC (Instrument)	Body	X	X	X		
EUROPE	2011	Corsa-D	Central Door Lock	Body	X	X	X	X	
EUROPE	2011	Corsa-D	TIM(Trailer Interface Module)	Body	X	X	X	X	
EUROPE	2011	Corsa-D	BCM(Body Control Module)	Body	X	X	X	X	
EUROPE	2011	Corsa-D	EHS(Electrical Heater System)	Body	X	X	X	X	Erase Key And Remote Program Key And Remote
EUROPE	2011	Corsa-D	Z 10 XEP	Body	X	X	X	X	Reset ECU
EUROPE	2010	Corsa-D	Z 12 XEP	Engine	X	X	X	X	
EUROPE	2010	Corsa-D	Z 13 DTJ	Engine	X	X	X	X	
EUROPE	2010	Corsa-D	Z 13 DTH	Engine	X	X	X	X	ECU Control(Injector cutoff test) Program High CanBus Configuration ECU Reset Program Injector
EUROPE	2010	Corsa-D	Z 14 XEP	Engine	X	X	X	x	ECU Control(Injector cutoff test) Program High CanBus Configuration ECU Reset Program Injector
EUROPE	2010	Corsa-D	Z 17 DTR	Engine	X	X	X	X	
EUROPE	2010	Corsa-D	MTA	Engine	X	X	X	X	Program High CanBus Configuration Replace DPF Replace Rail Pressure Sensor Replace Diff.-Press. Sensor Replace Precatalyst Replace MAF Sensor Regeneration DPF
EUROPE	2010	Corsa-D	ABS/ESP	Transmission	X	X	X	X	
EUROPE	2010	Corsa-D	Electronic Power Steering	Chassis	X	X	X	X	
EUROPE	2010	Corsa-D	SDM (Airbag)	Chassis	X	X	X		Steering angle calibration
EUROPE	2010	Corsa-D	IPC (Instrument)	Body	X	X	X		
EUROPE	2010	Corsa-D	Central Door Lock	Body	X	X	X	X	
EUROPE	2010	Corsa-D	TIM(Trailer Interface Module)	Body	X	X	X	X	
EUROPE	2010	Corsa-D	EHS(Electrical Heater System)	Body	X	X	X	X	

EUROPE	2010	Corsa-D	BCM(Body Control Module)	Body	X	X	X	X	Reset ECU
EUROPE	2010	Corsa-D	Z 12 XEP	Body	X	X	X	X	Erase Key And Remote Program Key And Remote
EUROPE	2009	Corsa-D	Z 13 DTJ	Engine	X	X	X	X	
EUROPE	2009	Corsa-D	Z 13 DTH	Engine	X	X	X	X	ECU Control(Injector cutoff test) Program High CanBus Configuration ECU Reset Program Injector
EUROPE	2009	Corsa-D	Z 14 XEP	Engine	X	X	X	x	ECU Control(Injector cutoff test) Program High CanBus Configuration ECU Reset Program Injector
EUROPE	2009	Corsa-D	Z 17 DTR	Engine	X	X	X	X	
EUROPE	2009	Corsa-D	MTA	Engine	X	X	X	X	Program High CanBus Configuration Replace DPF Replace Rail Pressure Sensor Replace Diff.-Press. Sensor Replace Precatalyst Replace MAF Sensor Regeneration DPF
EUROPE	2009	Corsa-D	ABS/ESP	Transmission	X	X	X	X	
EUROPE	2009	Corsa-D	Electronic Power Steering	Chassis	X	X	X	X	
EUROPE	2009	Corsa-D	TIM	Chassis	X	X	X		
EUROPE	2009	Corsa-D	EHS	Body	X	X	X	X	
EUROPE	2009	Corsa-D	SDM (Airbag)	Body	X	X	X	X	Reset ECU
EUROPE	2009	Corsa-D	IPC (Instrument)	Body	X	X	X		
EUROPE	2009	Corsa-D	Central Door Lock	Body	X	X			
EUROPE	2009	Corsa-D	BCM(Body Control Module)	Body	X	X	X	X	
EUROPE	2009	Corsa-D	Z 10 XEP	Body	X	X	X	X	Erase Key And Remote Program Key And Remote
EUROPE	2008	Corsa-D	Z 12 XEP	Engine	X	X	X	X	
EUROPE	2008	Corsa-D	Z 13 DTJ	Engine	X	X	X	X	
EUROPE	2008	Corsa-D	Z 13 DTH	Engine	X	X	X	X	ECU Control(Injector cutoff test) Program High CanBus Configuration ECU Reset Program Injector
EUROPE	2008	Corsa-D	Z 14 XEP	Engine	X	X	X	X	ECU Control(Injector cutoff test) Program High CanBus Configuration ECU Reset Program Injector

EUROPE	2008	Corsa-D	Z 17 DTR	Engine	X	X	X	X	
EUROPE	2008	Corsa-D	MTA	Engine	X	X	X	X	1.Program High CanBus Configuration 2.Replace DPF 3.Replace Rail Pressure Sensor 4.Replace Diff.-Press. Sensor 5.Replace Precatalyst 6.Replace MAF Sensor 7.Regeneration DPF
EUROPE	2008	Corsa-D	ABS/ESP	Transmission	X	X	X	X	
EUROPE	2008	Corsa-D	Electronic Power Steering	Chassis	X	X	X	X	
EUROPE	2008	Corsa-D	BCM	Chassis	X	X	X		Steering angle calibration
EUROPE	2008	Corsa-D	TIM	Body	X	X	X	X	1.Erase Key And Remote 2.Program Key And Remote
EUROPE	2008	Corsa-D	EHS	Body	X	X	X	X	
EUROPE	2008	Corsa-D	SDM (Airbag)	Body	X	X	X	X	Reset ECU
EUROPE	2008	Corsa-D	IPC (Instrument)	Body	X	X	X		
EUROPE	2008	Corsa-D	Central Door Lock	Body	X	X	X	X	
EUROPE	2008	Corsa-D	BCM(Body Control Module)	Body	X	X	X	X	
EUROPE	2008	Corsa-D	Z 12 XEP	Body	X	X	X	X	Erase Key And Remote Program Key And Remote
EUROPE	2007	Corsa-D	Z 13 DTJ	Engine	X	X	X	X	
EUROPE	2007	Corsa-D	Z 13 DTH	Engine	X	X	X	X	
EUROPE	2007	Corsa-D	Z 14 XEP	Engine	X	X	X	X	ECU Control(Injector cutoff test) Program High CanBus Configuration ECU Reset
EUROPE	2007	Corsa-D	Z 17 DTR	Engine	X	X	X	X	
EUROPE	2007	Corsa-D	MTA	Engine	X	X	X	X	Program High CanBus Configuration Replace DPF Replace Rail Pressure Sensor Replace Diff.-Press. Sensor Replace Precatalyst Replace MAF Sensor Regeneration DPF
EUROPE	2007	Corsa-D	ABS/ESP	Transmission	X	X	X	X	
EUROPE	2007	Corsa-D	Electronic Power Steering	Chassis	X	X	X	X	
EUROPE	2007	Corsa-D	TIM	Chassis	X	X	X		Steering angle calibration
EUROPE	2007	Corsa-D	EHS	Body	X	X	X	X	
EUROPE	2007	Corsa-D	SDM (Airbag)	Body	X	X	X	X	Reset ECU
EUROPE	2007	Corsa-D	IPC (Instrument)	Body	X	X	X		

EUROPE	2007	Corsa-D	Central Door Lock	Body	X	X	X	X	
EUROPE	2007	Corsa-D	BCM(Body Control Module)	Body	X	X	X	X	
EUROPE	2007	Corsa-D	25 TDS	Body	X	X	X	X	Erase Key And Remote Program Key And Remote
EUROPE	1998	Frontera	ABS 415	Engine	X	X	X		
EUROPE	1998	Frontera	Immobiliser	Chassis	X	X	X		
EUROPE	1998	Frontera	25 TDS	Body	X	X	X		
EUROPE	1997	Frontera	ABS 415	Engine	X	X	X		
EUROPE	1997	Frontera	Immobiliser	Chassis	X	X	X		
EUROPE	1997	Frontera	Y 22 DTH	Body	X	X	X		
EUROPE	2003	Frontera-B	AR 25/35	Engine	X	X	X		
EUROPE	2003	Frontera-B	Y 22 DTH	Transmission	X	X	X		
EUROPE	2002	Frontera-B	AR 25/35	Engine	X	X	X		
EUROPE	2002	Frontera-B	Y 22 DTH	Transmission	X	X	X		
EUROPE	2001	Frontera-B	AR 25/35	Engine	X	X	X		
EUROPE	2001	Frontera-B	X 22 DTH	Transmission	X	X	X		
EUROPE	2000	Frontera-B	AR 25/35	Engine	X	X	X		
EUROPE	2000	Frontera-B	X 22 DTH	Transmission	X	X	X		
EUROPE	1999	Frontera-B	AR 25/35	Engine	X	X	X		
EUROPE	1999	Frontera-B	Y 13 DT	Transmission	X	X	X		
EUROPE	2010	Meriva	Z13DTJ	Engine	X	X	X		
EUROPE	2010	Meriva	Z 14 XEP	Engine	X	X	X	X	Injector CutOff Test RPM Control Program Idle Speed
EUROPE	2010	Meriva	Z 16 SE	Engine	X	X	X	X	1.Reset Learn Values 2.Reset O2-Loop Block Lean Map 3. ECU Control-Electronic throttle control 4.Idle speed program. 5.ECU Reset
EUROPE	2010	Meriva	Z 16 XE	Engine	X	X	X		
EUROPE	2010	Meriva	Z 16 XEP	Engine	X	X	X	X	
EUROPE	2010	Meriva	Y 17 DT	Engine	X	X	X		
EUROPE	2010	Meriva	Z 17 DTH	Engine	X	X	X	X	
EUROPE	2010	Meriva	Z 18 XE	Engine	X	X	X	X	1.Injector Cutoff Test; 2.EGR Control; 3.Replace Fuel Pump.
EUROPE	2010	Meriva	MTA (Easytronic)	Engine	X	X	X		
EUROPE	2010	Meriva	ABS8/ESP8	Transmission	X	X	X	X	
EUROPE	2010	Meriva	Electronic Power Steering	Chassis	X	X	X	X	Steering Angle Sensor Calibration

EUROPE	2010	Meriva	Body Control Module	Chassis	X	X	X		
EUROPE	2010	Meriva	Immobiliser	Body	X	X	X	X	ECU Control Erase Remote Keys Program Remote Key
EUROPE	2010	Meriva	Airbag	Body	X	X	X		1.Erase Key Set; 2.Program Transponder-Keys
EUROPE	2010	Meriva	Instrument	Body	X	X	X		Clear Deployment Record
EUROPE	2010	Meriva	HeadLamp Levelling Device	Body	X	X	X	X	
EUROPE	2010	Meriva	Electronic Climate Control	Body	X	X	X	X	Calibration
EUROPE	2010	Meriva	Z13DTJ	Body	X	X	X	X	
EUROPE	2009	Meriva	Y 13 DT	Engine	X	X	X	X	Injector Cut Off Test RPM Control Program Idle Speed
EUROPE	2009	Meriva	Z 14 XEP	Engine	X	X	X		
EUROPE	2009	Meriva	Z 16 SE	Engine	X	X	X	X	1.Reset Learned Values; 2.Reset O2-Loop Block Learn Map. 3.ECU Control-Electronic throttle control 4.Idle speed program
EUROPE	2009	Meriva	Z 16 XE	Engine	X	X	X		
EUROPE	2009	Meriva	Z 16 XEP	Engine	X	X	X	X	
EUROPE	2009	Meriva	Y 17 DT	Engine	X	X	X		
EUROPE	2009	Meriva	Z 17 DTH	Engine	X	X	X	X	
EUROPE	2009	Meriva	Z 18 XE	Engine	X	X	X	X	1.Inject Cutoff Test; 2.RPM Control; 3.Replace Fuel Pump.
EUROPE	2009	Meriva	MTA (Easytronic)	Engine	X	X	X		
EUROPE	2009	Meriva	ABS8/ESP8	Transmission	X	X	X	X	
EUROPE	2009	Meriva	Electronic Power Steering	Chassis	X	X	X	X	
EUROPE	2009	Meriva	Body Control Module	Chassis	X	X	X		
EUROPE	2009	Meriva	Immobiliser	Body	X	X	X	X	
EUROPE	2009	Meriva	Instrument	Body	X	X	X		1.Erase Key Set; 2.Program Transponder-Keys
EUROPE	2009	Meriva	Airbag	Body	X	X	X	X	1.Service Light Reset 2.Service Due In
EUROPE	2009	Meriva	HeadLamp Levelling Device	Body	X	X	X	X	
EUROPE	2009	Meriva	Electronic Climate Control	Body	X	X	X	X	Calibration

EUROPE	2009	Meriva	Z13DTJ	Body	X	X	X	X	
EUROPE	2008	Meriva	Y 13 DT	Engine	X	X	X	X	Injector Cut Off Test RPM Control Program Idle Speed
EUROPE	2008	Meriva	Z 14 XEP	Engine	X	X	X		
EUROPE	2008	Meriva	Z 16 SE	Engine	X	X	X	X	1.Reset Learn Values 2.Reset O2-Loop Block Lean Map 3. ECU Control-Electronic throttle control 4.Idle speed program. 5.ECU Reset
EUROPE	2008	Meriva	Z 16 XE	Engine	X	X	X		
EUROPE	2008	Meriva	Z 16 XEP	Engine	X	X	X	X	
EUROPE	2008	Meriva	Y 17 DT	Engine	X	X	X		
EUROPE	2008	Meriva	Z 17 DTH	Engine	X	X	X	X	
EUROPE	2008	Meriva	Z 18 XE	Engine	X	X	X	X	1.Inject Cutoff Test; 2.RPM Control; 3.Replace Fuel Pump.
EUROPE	2008	Meriva	MTA (Easytronic)	Engine	X	X	X		
EUROPE	2008	Meriva	ABS&ESP8	Transmission	X	X	X	X	
EUROPE	2008	Meriva	Electronic Power Steering	Chassis	X	X	X	X	
EUROPE	2008	Meriva	Body Control Module	Chassis	X	X	X		
EUROPE	2008	Meriva	Immobiliser	Body	X	X	X	X	
EUROPE	2008	Meriva	Instrument	Body	X	X	X		1.Erase Key Set; 2.Program Transponder-Keys
EUROPE	2008	Meriva	Airbag	Body	X	X	X	X	1.Service Light Reset 2.Service Due In
EUROPE	2008	Meriva	HeadLamp Levelling Device	Body	X	X	X	X	
EUROPE	2008	Meriva	Electronic Climate Control	Body	X	X	X	X	Calibration
EUROPE	2008	Meriva	Y 13 DT	Body	X	X	X	X	
EUROPE	2007	Meriva	Z13DTJ	Engine	X	X	X		
EUROPE	2007	Meriva	Z 14 XEP	Engine	X	X	X	X	Injector Cut Off Test RPM Control Program Idle Speed
EUROPE	2007	Meriva	Z 16 SE	Engine	X	X	X	X	1.Reset Learn Values 2.Reset O2-Loop Block Lean Map 3. ECU Control-Electronic throttle control 4.Idle speed program. 5.ECU Reset
EUROPE	2007	Meriva	Z 16 XE	Engine	X	X	X		

EUROPE	2007	Meriva	Z 16 XEP	Engine	X	X	X	X	
EUROPE	2007	Meriva	Y 17 DT	Engine	X	X	X		
EUROPE	2007	Meriva	Z 17 DTH	Engine	X	X	X	X	
EUROPE	2007	Meriva	Z 18 XE	Engine	X	X	X	X	1.Inject Cutoff Test; 2.RPM Control; 3.Replace Fuel Pump.
EUROPE	2007	Meriva	MTA (Easytronic)	Engine	X	X	X		
EUROPE	2007	Meriva	ABS8/ESP8	Transmission	X	X	X	X	
EUROPE	2007	Meriva	Electronic Power Steering	Chassis	X	X	X	X	
EUROPE	2007	Meriva	AFL (Adaptive Forward Lighting)	Chassis	X	X	X		
EUROPE	2007	Meriva	Body Control Module	Body	X	X	X		
EUROPE	2007	Meriva	Immobiliser	Body	X	X	X	X	
EUROPE	2007	Meriva	Instrument	Body	X	X	X		1.Erase Key Set; 2.Program Transponder-Keys
EUROPE	2007	Meriva	Airbag	Body	X	X	X	X	1.Service Light Reset 2.Service Due In
EUROPE	2007	Meriva	HeadLamp Levelling Device	Body	X	X	X	X	
EUROPE	2007	Meriva	Electronic Climate Control	Body	X	X	X	X	Calibration
EUROPE	2007	Meriva	Y 13 DT	Body	X	X	X	X	
EUROPE	2006	Meriva	Z13DTJ	Engine	X	X	X		
EUROPE	2006	Meriva	Z 14 XEP	Engine	X	X	X	X	Injector Cut Off Test RPM Control Program Idle Speed
EUROPE	2006	Meriva	Z 16 SE	Engine	X	X	X	X	1.Reset Learn Values 2.Reset O2-Loop Block Lean Map 3. ECU Control-Electronic throttle control 4.Idle speed program. 5.ECU Reset
EUROPE	2006	Meriva	Z 16 XE	Engine	X	X	X		
EUROPE	2006	Meriva	Z 16 XEP	Engine	X	X	X	X	
EUROPE	2006	Meriva	Y 17 DT	Engine	X	X	X		
EUROPE	2006	Meriva	Z 17 DTH	Engine	X	X	X	X	
EUROPE	2006	Meriva	Z 18 XE	Engine	X	X	X	X	1.Inject Cutoff Test; 2.RPM Control; 3.Replace Fuel Pump.
EUROPE	2006	Meriva	MTA (Easytronic)	Engine	X	X	X		

EUROPE	2006	Meriva	ABS8/ESP8	Transmission	X	X	X	X	
EUROPE	2006	Meriva	Electronic Power Steering	Chassis	X	X	X	X	
EUROPE	2006	Meriva	Body Control Module	Chassis	X	X	X		
EUROPE	2006	Meriva	Immobiliser	Body	X	X	X	X	
EUROPE	2006	Meriva	Instrument	Body	X	X	X		1.Erase Key Set; 2.Program Transponder-Keys
EUROPE	2006	Meriva	Airbag	Body	X	X	X	X	1.Service Light Reset 2.Service Due In
EUROPE	2006	Meriva	HeadLamp Levelling Device	Body	X	X	X	X	
EUROPE	2006	Meriva	Electronic Climate Control	Body	X	X	X	X	Calibration
EUROPE	2006	Meriva	Y 13 DT	Body	X	X	X	X	
EUROPE	2005	Meriva	Z 14 XEP	Engine	X	X	X		
EUROPE	2005	Meriva	Z 16 SE	Engine	X	X	X	X	1.Reset Learn Values 2.Reset O2-Loop Block Lean Map 3. ECU Control-Electronic throttle control 4.Idle speed program. 5.ECU Reset
EUROPE	2005	Meriva	Z 16 XE	Engine	X	X	X		
EUROPE	2005	Meriva	Y 17 DT	Engine	X	X	X	X	
EUROPE	2005	Meriva	Z 17 DTH	Engine	X	X	X	X	
EUROPE	2005	Meriva	Z 18 XE	Engine	X	X	X	X	1.Inject Cutoff Test; 2.RPM Control; 3.Replace Fuel Pump.
EUROPE	2005	Meriva	MTA (Easytronic)	Engine	X	X	X		
EUROPE	2005	Meriva	ABS8/ESP8	Transmission	X	X	X	X	
EUROPE	2005	Meriva	Electronic Power Steering	Chassis	X	X	X	X	
EUROPE	2005	Meriva	Body Control Module	Chassis	X	X	X		
EUROPE	2005	Meriva	Immobiliser	Body	X	X	X	X	
EUROPE	2005	Meriva	Instrument	Body	X	X	X		1.Erase Key Set; 2.Program Transponder-Keys
EUROPE	2005	Meriva	Airbag	Body	X	X	X	X	1.Service Light Reset 2.Service Due In
EUROPE	2005	Meriva	HeadLamp Levelling Device	Body	X	X	X	X	
EUROPE	2005	Meriva	Electronic Climate Control	Body	X	X	X	X	Calibration
EUROPE	2005	Meriva	Z 16 SE	Body	X	X	X	X	

EUROPE	2004	Meriva	Z 16 XE	Engine	X	X	X		
EUROPE	2004	Meriva	Y 17 DT	Engine	X	X	X	X	
EUROPE	2004	Meriva	Z 17 DTH	Engine	X	X	X	X	
EUROPE	2004	Meriva	Z 18 XE	Engine	X	X	X	X	1.Inject Cutoff Test; 2.RPM Control; 3.Replace Fuel Pump.
EUROPE	2004	Meriva	MTA (Easytronic)	Engine	X	X	X		
EUROPE	2004	Meriva	ABS-5.3/5.4 (+TC)	Transmission	X	X	X	X	
EUROPE	2004	Meriva	ESP	Chassis	X	X	X	X	
EUROPE	2004	Meriva	Electronic Power Steering	Chassis	X	X	X		
EUROPE	2004	Meriva	Body Control Module	Chassis	X	X	X		
EUROPE	2004	Meriva	Immobiliser	Body	X	X	X	X	
EUROPE	2004	Meriva	Instrument	Body	X	X	X		
EUROPE	2004	Meriva	Airbag	Body	X	X	X	X	1.Service Light Reset 2.Service Due In
EUROPE	2004	Meriva	HeadLamp Levelling Device	Body	X	X	X	X	
EUROPE	2004	Meriva	Electronic Climate Control	Body	X	X	X	X	Calibration
EUROPE	2004	Meriva	Z 16 SE	Body	X	X	X	X	
EUROPE	2003	Meriva	Z 16 XE	Engine	X	X	X		
EUROPE	2003	Meriva	Z 18 XE	Engine	X	X	X	X	
EUROPE	2003	Meriva	MTA (Easytronic)	Engine	X	X	X		
EUROPE	2003	Meriva	ABS-5.3/5.4 (+TC)	Transmission	X	X	X	X	
EUROPE	2003	Meriva	ESP	Chassis	X	X	X	X	
EUROPE	2003	Meriva	Electronic Power Steering	Chassis	X	X	X		
EUROPE	2003	Meriva	Body Control Module	Chassis	X	X	X		
EUROPE	2003	Meriva	Immobiliser	Body	X	X	X	X	
EUROPE	2003	Meriva	Instrument	Body	X	X	X		1.Erase Key Set; 2.Program Transponder-Keys
EUROPE	2003	Meriva	Airbag	Body	X	X	X	X	1.Service Light Reset 2.Service Due In
EUROPE	2003	Meriva	HeadLamp Levelling Device	Body	X	X	X	X	
EUROPE	2003	Meriva	Electronic Climate Control	Body	X	X	X	X	Calibration

EUROPE	2003	Meriva	ABS 5	Body	X	X	X	X	
EUROPE	1999	Monterey	ABS 5	Chassis	X	X	X		
EUROPE	1998	Monterey	ABS 5	Chassis	X	X	X		
EUROPE	1997	Monterey	Y 22 DTH	Chassis	X	X	X		
EUROPE	2003	Omega-B	Z 22 XE	Engine	X	X	X		
EUROPE	2003	Omega-B	Y 25 DT	Engine	X	X	X	X	1.EGR Control 2.Fuel Tank Ventilation Control 3.Electronic Throttle Control 4.RPM Control 5.Injector Cutoff Test
EUROPE	2003	Omega-B	Y 26 SE	Engine	X	X	X		
EUROPE	2003	Omega-B	X 30 XE	Engine	X	X	X		
EUROPE	2003	Omega-B	Y 32 SE	Engine	X	X	X		
EUROPE	2003	Omega-B	AR 25/35	Engine	X	X	X		
EUROPE	2003	Omega-B	ABS-5.3/5.4 (+TC)	Transmission	X	X	X		
EUROPE	2003	Omega-B	ESP	Chassis	X	X	X	X	
EUROPE	2003	Omega-B	Cruise Control	Chassis	X	X	X		
EUROPE	2003	Omega-B	Immobiliser	Chassis	X	X	X		
EUROPE	2003	Omega-B	Airbag	Body	X	X	X		
EUROPE	2003	Omega-B	HeadLamp Levelling Device	Body	X	X	X		
EUROPE	2003	Omega-B	Y 22 DTH	Body	X	X	X	X	Calibration
EUROPE	2002	Omega-B	Z 22 XE	Engine	X	X	X		
EUROPE	2002	Omega-B	Y 25 DT	Engine	X	X	X	X	1.EGR Control 2.Fuel Tank Ventilation Control 3.Electronic Throttle Control 4.RPM Control 5.Injector Cutoff Test
EUROPE	2002	Omega-B	Y 26 SE	Engine	X	X	X		
EUROPE	2002	Omega-B	X 30 XE	Engine	X	X	X		
EUROPE	2002	Omega-B	Y 32 SE	Engine	X	X	X		
EUROPE	2002	Omega-B	AR 25/35	Engine	X	X	X		
EUROPE	2002	Omega-B	ABS-5.3/5.4 (+TC)	Transmission	X	X	X		
EUROPE	2002	Omega-B	ESP	Chassis	X	X	X	X	
EUROPE	2002	Omega-B	Cruise Control	Chassis	X	X	X		
EUROPE	2002	Omega-B	Immobiliser	Chassis	X	X	X		
EUROPE	2002	Omega-B	Airbag	Body	X	X	X		
EUROPE	2002	Omega-B	HeadLamp Levelling Device	Body	X	X	X		
EUROPE	2002	Omega-B	X 20 XEV	Body	X	X	X	X	Calibration
EUROPE	2001	Omega-B	Y 22 DTH	Engine	X	X	X		Adjust Idle Speed
EUROPE	2001	Omega-B	Z 22 XE	Engine	X	X	X		

EUROPE	2001	Omega-B	Y 26 SE	Engine	X	X	X	X	1.EGR Control 2.Fuel Tank Ventilation Control 3.Electronic Throttle Control 4.RPM Control 5.Injector Cutoff Test
EUROPE	2001	Omega-B	X 30 XE	Engine	X	X	X		
EUROPE	2001	Omega-B	Y 32 SE	Engine	X	X	X		
EUROPE	2001	Omega-B	AR 25/35	Engine	X	X	X		
EUROPE	2001	Omega-B	ABS-5.3/5.4 (+TC)	Transmission	X	X	X		
EUROPE	2001	Omega-B	Cruise Control	Chassis	X	X	X	X	
EUROPE	2001	Omega-B	Airbag	Chassis	X	X	X		
EUROPE	2001	Omega-B	HeadLamp Levelling Device	Body	X	X	X		
EUROPE	2001	Omega-B	X 20 DTH	Body	X	X	X	X	Calibration
EUROPE	2000	Omega-B	X 20 XEV	Engine	X	X	X		
EUROPE	2000	Omega-B	Y 22 XE	Engine	X	X	X		Adjust Idle Speed
EUROPE	2000	Omega-B	X 25 XE	Engine	X	X	X		
EUROPE	2000	Omega-B	X 30 XE	Engine	X	X	X		
EUROPE	2000	Omega-B	AR 25/35	Engine	X	X	X		
EUROPE	2000	Omega-B	ABS-5.3/5.4 (+TC)	Transmission	X	X	X		
EUROPE	2000	Omega-B	Cruise Control	Chassis	X	X	X	X	
EUROPE	2000	Omega-B	Airbag	Chassis	X	X	X		
EUROPE	2000	Omega-B	HeadLamp Levelling Device	Body	X	X	X		
EUROPE	2000	Omega-B	X 20 DTH	Body	X	X	X	X	Calibration
EUROPE	1999	Omega-B	X 20 XEV	Engine	X	X	X		
EUROPE	1999	Omega-B	X 25 XE	Engine	X	X	X		Adjust Idle Speed
EUROPE	1999	Omega-B	X 30 XE	Engine	X	X	X		
EUROPE	1999	Omega-B	AR 25/35	Engine	X	X	X		
EUROPE	1999	Omega-B	ABS-5.3/5.4 (+TC)	Transmission	X	X	X		
EUROPE	1999	Omega-B	Cruise Control	Chassis	X	X	X	X	
EUROPE	1999	Omega-B	Airbag SAB6	Chassis	X	X	X		
EUROPE	1999	Omega-B	HeadLamp Levelling Device	Body	X	X	X		
EUROPE	1999	Omega-B	X 20 DTH	Body	X	X	X	X	Calibration
EUROPE	1998	Omega-B	X 20 XEV	Engine	X	X	X		
EUROPE	1998	Omega-B	X 25 XE	Engine	X	X	X		Adjust Idle Speed
EUROPE	1998	Omega-B	X 30 XE	Engine	X	X	X		
EUROPE	1998	Omega-B	AR 25/35	Engine	X	X	X		
EUROPE	1998	Omega-B	ABS-5.3/5.4 (+TC)	Transmission	X	X	X		

EUROPE	1998	Omega-B	Cruise Control	Chassis	X	X	X	X	
EUROPE	1998	Omega-B	Immobiliser	Chassis	X	X	X		
EUROPE	1998	Omega-B	Airbag SAB6	Body	X	X	X		
EUROPE	1998	Omega-B	HeadLamp Levelling Device	Body	X	X	X		
EUROPE	1998	Omega-B	X 20 XEV	Body	X	X	X	X	Calibration
EUROPE	1997	Omega-B	X 25 XE	Engine	X	X	X		Adjust Idle Speed
EUROPE	1997	Omega-B	X 30 XE	Engine	X	X	X		
EUROPE	1997	Omega-B	ABS-2SE (+TC)	Engine	X	X	X		
EUROPE	1997	Omega-B	Cruise Control	Chassis	X	X	X		
EUROPE	1997	Omega-B	Immobiliser	Chassis	X	X	X		
EUROPE	1997	Omega-B	Airbag-S	Body	X	X	X		
EUROPE	1997	Omega-B	Airbag SAB6	Body	X	X	X		
EUROPE	1997	Omega-B	X 22 DTH	Body	X	X	X		
EUROPE	1999	Sintra	AF 13II/20/22/30	Engine	X	X	X		
EUROPE	1999	Sintra	Cruise Control	Transmission	X	X	X		
EUROPE	1999	Sintra	X 22 DTH	Chassis	X	X	X		
EUROPE	1998	Sintra	AF 13II/20/22/30	Engine	X	X	X		
EUROPE	1998	Sintra	Cruise Control	Transmission	X	X	X		
EUROPE	1998	Sintra	AF 13II/20/22/30	Chassis	X	X	X		
EUROPE	1997	Sintra	Cruise Control	Transmission	X	X	X		
EUROPE	1997	Sintra	Z 20 LET	Chassis	X	X	X		
EUROPE	2007	Speedster/V X220	Z 22 SE	Engine	X	X	X		
EUROPE	2007	Speedster/V X220	ABS 430	Engine	X	X	X		
EUROPE	2007	Speedster/V X220	Immobiliser	Chassis	X	X	X	X	
EUROPE	2007	Speedster/V X220	Airbag	Body	X	X	X		1.Erase Key Set; 2.Program Transponder-Keys
EUROPE	2007	Speedster/V X220	Z 20 LET	Body	X	X	X		
EUROPE	2006	Speedster/V X220	Z 22 SE	Engine	X	X	X		
EUROPE	2006	Speedster/V X220	ABS 430	Engine	X	X	X		
EUROPE	2006	Speedster/V X220	Immobiliser	Chassis	X	X	X	X	
EUROPE	2006	Speedster/V X220	Airbag	Body	X	X	X		1.Erase Key Set; 2.Program Transponder-Keys
EUROPE	2006	Speedster/V X220	Z 20 LET	Body	X	X	X		
EUROPE	2005	Speedster/V X220	Z 22 SE	Engine	X	X	X		

EUROPE	2005	Speedster/V X220	ABS 430	Engine	X	X	X		
EUROPE	2005	Speedster/V X220	Immobiliser	Chassis	X	X	X	X	
EUROPE	2005	Speedster/V X220	Airbag	Body	X	X	X		1.Erase Key Set; 2.Program Transponder-Keys
EUROPE	2005	Speedster/V X220	Z 20 LET	Body	X	X	X		
EUROPE	2004	Speedster/V X220	Z 22 SE	Engine	X	X	X		
EUROPE	2004	Speedster/V X220	ABS 430	Engine	X	X	X		
EUROPE	2004	Speedster/V X220	Immobiliser	Chassis	X	X	X	X	
EUROPE	2004	Speedster/V X220	Airbag	Body	X	X	X		
EUROPE	2004	Speedster/V X220	Z 20 LET	Body	X	X	X		
EUROPE	2003	Speedster/V X220	Z 22 SE	Engine	X	X	X		
EUROPE	2003	Speedster/V X220	ABS 430	Engine	X	X	X		
EUROPE	2003	Speedster/V X220	Immobiliser	Chassis	X	X	X	X	
EUROPE	2003	Speedster/V X220	Airbag	Body	X	X	X		
EUROPE	2003	Speedster/V X220	Z 20 LET	Body	X	X	X		
EUROPE	2002	Speedster/V X220	Z 22 SE	Engine	X	X	X		
EUROPE	2002	Speedster/V X220	ABS 430	Engine	X	X	X		
EUROPE	2002	Speedster/V X220	Immobiliser	Chassis	X	X	X	X	
EUROPE	2002	Speedster/V X220	Airbag	Body	X	X	X		
EUROPE	2002	Speedster/V X220	Z 22 SE	Body	X	X	X		
EUROPE	2001	Speedster/V X220	ABS 430	Engine	X	X	X		
EUROPE	2001	Speedster/V X220	Immobiliser	Chassis	X	X	X	X	
EUROPE	2001	Speedster/V X220	Airbag	Body	X	X	X		

EUROPE	2001	Speedster/V X220	C 14 SEL	Body	X	X	X		
EUROPE	2000	Tigra	X 14 XE	Engine	X	X	X		
EUROPE	2000	Tigra	C 16 SEL	Engine	X	X	X		
EUROPE	2000	Tigra	X 16 XE	Engine	X	X	X		
EUROPE	2000	Tigra	ABS-5.3	Engine	X	X	X		
EUROPE	2000	Tigra	Immobiliser	Chassis	X	X	X	X	
EUROPE	2000	Tigra	Airbag-S	Body	X	X	X		
EUROPE	2000	Tigra	Airbag-SAB6	Body	X	X	X		
EUROPE	2000	Tigra	C 14 SEL	Body	X	X	X		
EUROPE	1999	Tigra	X 14 XE	Engine	X	X	X		
EUROPE	1999	Tigra	C 16 SEL	Engine	X	X	X		
EUROPE	1999	Tigra	X 16 XE	Engine	X	X	X		
EUROPE	1999	Tigra	ABS-5.3	Engine	X	X	X		
EUROPE	1999	Tigra	Immobiliser	Chassis	X	X	X	X	
EUROPE	1999	Tigra	Airbag-S	Body	X	X	X		
EUROPE	1999	Tigra	Airbag-SAB6	Body	X	X	X		
EUROPE	1999	Tigra	C 14 SEL	Body	X	X	X		
EUROPE	1998	Tigra	X 14 XE	Engine	X	X	X		
EUROPE	1998	Tigra	C 16 SEL	Engine	X	X	X		
EUROPE	1998	Tigra	X 16 XE	Engine	X	X	X		
EUROPE	1998	Tigra	ABS-5.3	Engine	X	X	X		
EUROPE	1998	Tigra	Immobiliser	Chassis	X	X	X	X	
EUROPE	1998	Tigra	Airbag-S	Body	X	X	X		
EUROPE	1998	Tigra	X 14 XE	Body	X	X	X		
EUROPE	1997	Tigra	X 16 XE	Engine	X	X	X		
EUROPE	1997	Tigra	ABS-5.3	Engine	X	X	X		
EUROPE	1997	Tigra	Immobiliser	Chassis	X	X	X	X	
EUROPE	1997	Tigra	Airbag-S	Body	X	X	X		
EUROPE	1997	Tigra	Z 13 DT	Body	X	X	X		
EUROPE	2009	Tigra-B	Z 14 XEP	Engine	X	X	X	X	1.Inject Cutoff Test; 2.RPM Control; 3.Program Idle Speed.
EUROPE	2009	Tigra-B	Z 18 XE	Engine	X	X	X	X	1.Reset Learn Values 2.Reset O2-Loop Block Lean Map 3. ECU Control-Electronic throttle control 4.Idle speed program. 5.ECU Reset
EUROPE	2009	Tigra-B	MTA (Easytronic)	Engine	X	X	X		
EUROPE	2009	Tigra-B	ABS8/ESP8	Transmission	X	X	X	X	
EUROPE	2009	Tigra-B	Electronic Power Steering	Chassis	X	X	X	X	

EUROPE	2009	Tigra-B	Body Control Module	Chassis	X	X	X		
EUROPE	2009	Tigra-B	Immobiliser	Body	X	X	X	X	
EUROPE	2009	Tigra-B	Instrument	Body	X	X	X		1.Erase Key Set; 2.Program Transponder-Keys
EUROPE	2009	Tigra-B	Airbag	Body	X	X	X	X	1.Service Light Reset 2.Service Due In
EUROPE	2009	Tigra-B	Z 13 DT	Body	X	X	X	X	
EUROPE	2008	Tigra-B	Z 14 XEP	Engine	X	X	X	X	1.Inject Cutoff Test; 2.RPM Control; 3.Program Idle Speed.
EUROPE	2008	Tigra-B	Z 18 XE	Engine	X	X	X	X	1.Reset Learn Values 2.Reset O2-Loop Block Lean Map 3. ECU Control-Electronic throttle control 4.Idle speed program. 5.ECU Reset
EUROPE	2008	Tigra-B	MTA (Easytronic)	Engine	X	X	X		
EUROPE	2008	Tigra-B	ABS8/ESP8	Transmission	X	X	X	X	
EUROPE	2008	Tigra-B	Electronic Power Steering	Chassis	X	X	X	X	
EUROPE	2008	Tigra-B	Body Control Module	Chassis	X	X	X		
EUROPE	2008	Tigra-B	Immobiliser	Body	X	X	X	X	
EUROPE	2008	Tigra-B	Instrument	Body	X	X	X		1.Erase Key Set; 2.Program Transponder-Keys
EUROPE	2008	Tigra-B	Airbag	Body	X	X	X	X	1.Service Light Reset 2.Service Due In
EUROPE	2008	Tigra-B	Z 13 DT	Body	X	X	X	X	
EUROPE	2007	Tigra-B	Z 14 XEP	Engine	X	X	X	X	1.Inject Cutoff Test; 2.RPM Control; 3.Program Idle Speed.
EUROPE	2007	Tigra-B	Z 18 XE	Engine	X	X	X	X	1.Reset Learn Values 2.Reset O2-Loop Block Lean Map 3. ECU Control-Electronic throttle control 4.Idle speed program. 5.ECU Reset
EUROPE	2007	Tigra-B	MTA (Easytronic)	Engine	X	X	X	X	
EUROPE	2007	Tigra-B	ABS8/ESP8	Transmission	X	X	X	X	
EUROPE	2007	Tigra-B	Electronic Power Steering	Chassis	X	X	X	X	
EUROPE	2007	Tigra-B	Body Control Module	Chassis	X	X	X		

EUROPE	2007	Tigra-B	Immobiliser	Body	X	X	X	X	
EUROPE	2007	Tigra-B	Instrument	Body	X	X	X		1.Erase Key Set; 2.Program Transponder-Keys
EUROPE	2007	Tigra-B	Airbag	Body	X	X	X	X	1.Service Light Reset 2.Service Due In
EUROPE	2007	Tigra-B	Z 13 DT	Body	X	X	X	X	
EUROPE	2006	Tigra-B	Z 14 XEP	Engine	X	X	X	X	1.Inject Cutoff Test; 2.RPM Control; 3.Program Idle Speed.
EUROPE	2006	Tigra-B	Z 18 XE	Engine	X	X	X	X	1.Reset Learn Values 2.Reset O2-Loop Block Lean Map 3. ECU Control-Electronic throttle control 4.Idle speed program. 5.ECU Reset
EUROPE	2006	Tigra-B	MTA (Easytronic)	Engine	X	X	X	X	
EUROPE	2006	Tigra-B	ABS8/ESP8	Transmission	X	X	X	X	
EUROPE	2006	Tigra-B	Electronic Power Steering	Chassis	X	X	X	X	
EUROPE	2006	Tigra-B	Body Control Module	Chassis	X	X	X		
EUROPE	2006	Tigra-B	Immobiliser	Body	X	X	X	X	
EUROPE	2006	Tigra-B	Instrument	Body	X	X	X		1.Erase Key Set; 2.Program Transponder-Keys
EUROPE	2006	Tigra-B	Airbag	Body	X	X	X	X	1.Service Light Reset 2.Service Due In
EUROPE	2006	Tigra-B	Z 13 DT	Body	X	X	X	X	
EUROPE	2005	Tigra-B	Z 14 XEP	Engine	X	X	X	X	1.Inject Cutoff Test; 2.RPM Control; 3.Program Idle Speed.
EUROPE	2005	Tigra-B	Z 18 XE	Engine	X	X	X	X	1.Reset Learn Values 2.Reset O2-Loop Block Lean Map 3. ECU Control-Electronic throttle control 4.Idle speed program. 5.ECU Reset
EUROPE	2005	Tigra-B	MTA (Easytronic)	Engine	X	X	X		
EUROPE	2005	Tigra-B	ABS8/ESP8	Transmission	X	X	X	X	
EUROPE	2005	Tigra-B	Electronic Power Steering	Chassis	X	X	X	X	
EUROPE	2005	Tigra-B	Body Control Module	Chassis	X	X	X		
EUROPE	2005	Tigra-B	Immobiliser	Body	X	X	X	X	

EUROPE	2005	Tigra-B	Instrument	Body	X	X	X		1.Erase Key Set; 2.Program Transponder-Keys
EUROPE	2005	Tigra-B	Airbag	Body	X	X	X	X	1.Service Light Reset 2.Service Due In
EUROPE	2005	Tigra-B	X 16 XEL	Body	X	X	X	X	
EUROPE	2001	Vectra-B	Y 16 XE	Engine	X	X	X	X	
EUROPE	2001	Vectra-B	Z 16 XE	Engine	X	X	X		
EUROPE	2001	Vectra-B	X 18 XE	Engine	X	X	X	X	
EUROPE	2001	Vectra-B	Z 18 XE	Engine	X	X	X		Adjust Idle Speed
EUROPE	2001	Vectra-B	Z 18 XEL	Engine	X	X	X	X	
EUROPE	2001	Vectra-B	C 20 SEL	Engine	X	X	X		
EUROPE	2001	Vectra-B	X 20 XEV	Engine	X	X	X	X	Adjust Idle Speed
EUROPE	2001	Vectra-B	Y 20 DTH	Engine	X	X	X		Adjust Idle Speed
EUROPE	2001	Vectra-B	C 22 SEL	Engine	X	X	X	X	Adjust Idle Speed
EUROPE	2001	Vectra-B	Y 22 DTR	Engine	X	X	X		Adjust Idle Speed
EUROPE	2001	Vectra-B	Z 22 SE	Engine	X	X	X		
EUROPE	2001	Vectra-B	Y 26 SE	Engine	X	X	X		
EUROPE	2001	Vectra-B	AF 13-II/17/20/22	Engine	X	X	X		
EUROPE	2001	Vectra-B	AF 13-II/17/20/22 CAN	Transmission	X	X	X	X	
EUROPE	2001	Vectra-B	ABS 430	Transmission	X	X	X	X	
EUROPE	2001	Vectra-B	ABS-5.3/5.4 (+TC)	Chassis	X	X	X	X	
EUROPE	2001	Vectra-B	Cruise Control	Chassis	X	X	X	X	
EUROPE	2001	Vectra-B	Airbag	Chassis	X	X	X		
EUROPE	2001	Vectra-B	Airbag SAB6	Body	X	X	X		
EUROPE	2001	Vectra-B	Immobiliser	Body	X	X	X		
EUROPE	2001	Vectra-B	Instrument	Body	X	X	X		
EUROPE	2001	Vectra-B	X 16 SZR	Body	X	X	X		
EUROPE	2000	Vectra-B	X 16 XEL	Engine	X	X	X		
EUROPE	2000	Vectra-B	Y 16 XE	Engine	X	X	X	X	Adjust Idle Speed
EUROPE	2000	Vectra-B	X 18 XE1	Engine	X	X	X		
EUROPE	2000	Vectra-B	20 NEJ	Engine	X	X	X	X	Adjust Idle Speed
EUROPE	2000	Vectra-B	C 20 SEL	Engine	X	X	X		
EUROPE	2000	Vectra-B	X 20 DTL	Engine	X	X	X	X	Adjust Idle Speed
EUROPE	2000	Vectra-B	X 20 DTH	Engine	X	X	X		
EUROPE	2000	Vectra-B	X 20 XEV	Engine	X	X	X		
EUROPE	2000	Vectra-B	C 22 SEL	Engine	X	X	X		Adjust Idle Speed
EUROPE	2000	Vectra-B	AF 13-II/17/20/22	Engine	X	X	X		Adjust Idle Speed
EUROPE	2000	Vectra-B	AF 13-II/17/20/22 CAN	Transmission	X	X	X	X	
EUROPE	2000	Vectra-B	ABS 430	Transmission	X	X	X	X	
EUROPE	2000	Vectra-B	ABS-5.3/5.4 (+TC)	Chassis	X	X	X	X	

EUROPE	2000	Vectra-B	Cruise Control	Chassis	X	X	X	X	
EUROPE	2000	Vectra-B	Airbag SAB6	Chassis	X	X	X		
EUROPE	2000	Vectra-B	Immobiliser	Body	X	X	X		
EUROPE	2000	Vectra-B	Instrument	Body	X	X	X		
EUROPE	2000	Vectra-B	X 16 SZR	Body	X	X	X		
EUROPE	1999	Vectra-B	X 16 XEL	Engine	X	X	X		
EUROPE	1999	Vectra-B	X 18 XE	Engine	X	X	X	X	Adjust Idle Speed
EUROPE	1999	Vectra-B	X 18 XE1	Engine	X	X	X		Adjust Idle Speed
EUROPE	1999	Vectra-B	20 NEJ	Engine	X	X	X	X	Adjust Idle Speed
EUROPE	1999	Vectra-B	C 20 SEL	Engine	X	X	X		
EUROPE	1999	Vectra-B	X 20 DTL	Engine	X	X	X	X	Adjust Idle Speed
EUROPE	1999	Vectra-B	X 20 DTH	Engine	X	X	X		
EUROPE	1999	Vectra-B	X 20 XEV	Engine	X	X	X		
EUROPE	1999	Vectra-B	C 22 SEL	Engine	X	X	X		Adjust Idle Speed
EUROPE	1999	Vectra-B	AF 13-II/17/20/22	Engine	X	X	X		Adjust Idle Speed
EUROPE	1999	Vectra-B	AF 13II/20/22/30	Transmission	X	X	X	X	
EUROPE	1999	Vectra-B	ABS 415	Transmission	X	X	X		
EUROPE	1999	Vectra-B	ABS 430	Chassis	X	X	X		
EUROPE	1999	Vectra-B	ABS-5-TC	Chassis	X	X	X	X	
EUROPE	1999	Vectra-B	ABS-5.3/5.4 (+TC)	Chassis	X	X	X		
EUROPE	1999	Vectra-B	Cruise Control	Chassis	X	X	X	X	
EUROPE	1999	Vectra-B	Immobiliser	Chassis	X	X	X		
EUROPE	1999	Vectra-B	Instrument	Body	X	X	X		
EUROPE	1999	Vectra-B	Airbag SAB6	Body	X	X	X		
EUROPE	1999	Vectra-B	X 16 SZR	Body	X	X	X		
EUROPE	1998	Vectra-B	X 16 XEL	Engine	X	X	X		
EUROPE	1998	Vectra-B	X 18 XE	Engine	X	X	X	X	Adjust Idle Speed
EUROPE	1998	Vectra-B	X 18 XE1	Engine	X	X	X		Adjust Idle Speed
EUROPE	1998	Vectra-B	20 NEJ	Engine	X	X	X	X	Adjust Idle Speed
EUROPE	1998	Vectra-B	C 20 SEL	Engine	X	X	X		
EUROPE	1998	Vectra-B	X 20 DTL	Engine	X	X	X	X	Adjust Idle Speed
EUROPE	1998	Vectra-B	X 20 DTH	Engine	X	X	X		
EUROPE	1998	Vectra-B	X 20 XEV	Engine	X	X	X		
EUROPE	1998	Vectra-B	C 22 SEL	Engine	X	X	X		Adjust Idle Speed
EUROPE	1998	Vectra-B	AF 13-II/17/20/22	Engine	X	X	X		Adjust Idle Speed
EUROPE	1998	Vectra-B	AF 13II/20/22/30	Transmission	X	X	X	X	
EUROPE	1998	Vectra-B	ABS 415	Transmission	X	X	X		
EUROPE	1998	Vectra-B	ABS 430	Chassis	X	X	X		
EUROPE	1998	Vectra-B	ABS-5-TC	Chassis	X	X	X	X	
EUROPE	1998	Vectra-B	ABS-5.3/5.4 (+TC)	Chassis	X	X	X		
EUROPE	1998	Vectra-B	Cruise Control	Chassis	X	X	X	X	
EUROPE	1998	Vectra-B	Immobiliser	Chassis	X	X	X		

EUROPE	1998	Vectra-B	Instrument	Body	X	X	X		
EUROPE	1998	Vectra-B	Airbag SAB6	Body	X	X	X		
EUROPE	1998	Vectra-B	X 16 SZR	Body	X	X	X		
EUROPE	1997	Vectra-B	X 16 XEL	Engine	X	X	X		
EUROPE	1997	Vectra-B	X 18 XE	Engine	X	X	X	X	Adjust Idle Speed
EUROPE	1997	Vectra-B	20 NEJ	Engine	X	X	X		Adjust Idle Speed
EUROPE	1997	Vectra-B	C 20 SEL	Engine	X	X	X		
EUROPE	1997	Vectra-B	X 20 DTL	Engine	X	X	X	X	Adjust Idle Speed
EUROPE	1997	Vectra-B	X 20 XEV	Engine	X	X	X		
EUROPE	1997	Vectra-B	AF 13II/20/22/30	Engine	X	X	X		Adjust Idle Speed
EUROPE	1997	Vectra-B	ABS 415	Transmission	X	X	X		
EUROPE	1997	Vectra-B	ABS-5-TC	Chassis	X	X	X		
EUROPE	1997	Vectra-B	Cruise Control	Chassis	X	X	X		
EUROPE	1997	Vectra-B	Immobiliser	Chassis	X	X	X		
EUROPE	1997	Vectra-B	Instrument	Body	X	X	X		
EUROPE	1997	Vectra-B	Airbag	Body	X	X	X		
EUROPE	1997	Vectra-B	Airbag SAB6	Body	X	X	X		
EUROPE	1997	Vectra-B	Vehicle DTC Information	Body	X	X	X		
EUROPE	2008	Vectra-C/Signum	Engine Cooling	Vehicle		X			
EUROPE	2008	Vectra-C/Signum	Z 20 NET	Engine	X	X	X		
EUROPE	2008	Vectra-C/Signum	Z 16 XEP	Engine	X	X	X	X	Reset Oil Life
EUROPE	2008	Vectra-C/Signum	Z 18 XE	Engine	X	X	X		
EUROPE	2008	Vectra-C/Signum	Z 18 XER	Engine	X	*	X		Injector Cutoff Test
EUROPE	2008	Vectra-C/Signum	Z 19 DT	Engine	X	X	X	X	Injector Cutoff Test
EUROPE	2008	Vectra-C/Signum	Z 19 DTH	Engine	X	X	X	X	1.Replace Diesel Particulate Filter 2.Replace Mass air flow sensor 3.Replace Precatalyst 4.Replace Rail Progressure sensor 5.Reset Engine Oil Life 6.Regeneration D. Particulate Filter

EUROPE	2008	Vectra-C/Signum	Y 20 DTH	Engine	X	X	X	X	1.Replace Diesel Particulate Filter 2.Replace Mass air flow sensor 3.Replace Precatalyst 4.Replace Rail Progressure sensor 5.Reset Engine Oil Life 6.Regeneration D. Particulate Filter 7.Reset engine oil sensor 8.Program High Speed Can Bus Config. 9.Reset O2 sensor 10.Idle Speed 11.DPF Regeneration
EUROPE	2008	Vectra-C/Signum	Y 22 DTR	Engine	X	X	X		Adjust Idle Speed
EUROPE	2008	Vectra-C/Signum	Z 22 SE	Engine	X	X	X		
EUROPE	2008	Vectra-C/Signum	Z 22 YH	Engine	X	X	X		
EUROPE	2008	Vectra-C/Signum	Z 32 SE	Engine	X	X	X		Injector Cutoff Test
EUROPE	2008	Vectra-C/Signum	AF 23-5/33-5/40-6	Engine	X	X	X		
EUROPE	2008	Vectra-C/Signum	ABS/TC/ESP	Transmission	X	X	X		
EUROPE	2008	Vectra-C/Signum	EHPS (Electrohydraulic Power Steering)	Chassis	X	X	X	X	
EUROPE	2008	Vectra-C/Signum	CDC (Continuous Damping Control)	Chassis	X	X	X		
EUROPE	2008	Vectra-C/Signum	SDM (Airbag Sensing & Diagnostic Module)	Chassis	X	X			
EUROPE	2008	Vectra-C/Signum	Instrument	Body	*	X	X		
EUROPE	2008	Vectra-C/Signum	CIM (Steering Column Module)	Body	X	X	X		
EUROPE	2008	Vectra-C/Signum	BCM (Body Control Module)	Body	X	X			1.Erase Transponder-Keys And Remote 2.Program Transponder-Keys And Remote
EUROPE	2008	Vectra-C/Signum	DDM (Driver Door Module)	Body	X	X	X		
EUROPE	2008	Vectra-C/Signum	PDM (Passenger Door Module)	Body	X	X			
EUROPE	2008	Vectra-C/Signum	REC (Rear Electrical Centre)	Body	X	X			

EUROPE	2008	Vectra-C/Signum	UEC (Underhood Electrical Centre)	Body	X	X	X		
EUROPE	2008	Vectra-C/Signum	SLM (Shift Lever Module)	Body	X	X	X		
EUROPE	2008	Vectra-C/Signum	SRM (Sun Roof Module)	Body	X	X			
EUROPE	2008	Vectra-C/Signum	AHL/AFL (Headlamp Levelling)	Body	X	X			
EUROPE	2008	Vectra-C/Signum	Vehicle DTC Information	Body	X	X			
EUROPE	2007	Vectra-C/Signum	Engine Cooling	Vehicle		X			
EUROPE	2007	Vectra-C/Signum	Z 20 NET	Engine	X	X	X		
EUROPE	2007	Vectra-C/Signum	Z 16 XEP	Engine	X	X	X	X	Reset Oil Life
EUROPE	2007	Vectra-C/Signum	Z 18 XE	Engine	X	X	X		
EUROPE	2007	Vectra-C/Signum	Z 18 XER	Engine	X	*	X		Injector Cutoff Test
EUROPE	2007	Vectra-C/Signum	Z 19 DT	Engine	X	X	X	X	Injector Cutoff Test
EUROPE	2007	Vectra-C/Signum	Z 19 DTH	Engine	X	X	X	X	1.Replace Diesel Particulate Filter 2.Replace Mass air flow sensor 3.Replace Precatalyst 4.Replace Rail Progressure sensor 5.Reset Engine Oil Life 6.Regeneration D. Particulate Filter
EUROPE	2007	Vectra-C/Signum	Y 20 DTH	Engine	X	X	X	X	1.Replace Diesel Particulate Filter 2.Replace Mass air flow sensor 3.Replace Precatalyst 4.Replace Rail Progressure sensor 5.Reset Engine Oil Life 6.Regeneration D. Particulate Filter
EUROPE	2007	Vectra-C/Signum	Y 22 DTR	Engine	X	X	X		Adjust Idle Speed
EUROPE	2007	Vectra-C/Signum	Z 22 SE	Engine	X	X	X		
EUROPE	2007	Vectra-C/Signum	Z 22 YH	Engine	X	X	X		
EUROPE	2007	Vectra-C/Signum	Z 32 SE	Engine	X	X	X		Injector Cutoff Test

EUROPE	2007	Vectra-C/Signum	AF 23-5/33-5/40-6	Engine	X	X	X		
EUROPE	2007	Vectra-C/Signum	ABS/TC/ESP	Transmission	X	X	X		
EUROPE	2007	Vectra-C/Signum	EHPS (Electrohydraulic Power Steering)	Chassis	X	X	X	X	
EUROPE	2007	Vectra-C/Signum	CDC (Continuous Damping Control)	Chassis	X	X	X		
EUROPE	2007	Vectra-C/Signum	SDM (Airbag Sensing & Diagnostic Module)	Chassis	X	X			
EUROPE	2007	Vectra-C/Signum	Instrument	Body	*	X	X		
EUROPE	2007	Vectra-C/Signum	CIM (Steering Column Module)	Body	X	X	X		
EUROPE	2007	Vectra-C/Signum	BCM (Body Control Module)	Body	X	X			1.Erase Transponder-Keys And Remote 2.Program Transponder-Keys And Remote
EUROPE	2007	Vectra-C/Signum	DDM (Driver Door Module)	Body	X	X	X		
EUROPE	2007	Vectra-C/Signum	PDM (Passenger Door Module)	Body	X	X			
EUROPE	2007	Vectra-C/Signum	REC (Rear Electrical Centre)	Body	X	X			
EUROPE	2007	Vectra-C/Signum	UEC (Underhood Electrical Centre)	Body	X	X	X		
EUROPE	2007	Vectra-C/Signum	SLM (Shift Lever Module)	Body	X	X	X		
EUROPE	2007	Vectra-C/Signum	SRM (Sun Roof Module)	Body	X	X			
EUROPE	2007	Vectra-C/Signum	AHL/AFL (Headlamp Levelling)	Body	X	X			
EUROPE	2007	Vectra-C/Signum	Vehicle DTC Information	Body	X	X			
EUROPE	2006	Vectra-C/Signum	Engine Cooling	Vehicle		X			
EUROPE	2006	Vectra-C/Signum	Z 20 NET	Engine	X	X	X		
EUROPE	2006	Vectra-C/Signum	Z 16 XEP	Engine	X	X	X	X	Reset Oil Life
EUROPE	2006	Vectra-C/Signum	Z 18 XE	Engine	X	X	X		

EUROPE	2006	Vectra-C/Signum	Z 18 XER	Engine	X	*	X		Injector Cutoff Test
EUROPE	2006	Vectra-C/Signum	Z 19 DT	Engine	X	X	X	X	Injector Cutoff Test
EUROPE	2006	Vectra-C/Signum	Z 19 DTH	Engine	X	X	X	X	1.Replace Diesel Particulate Filter 2.Replace Mass air flow sensor 3.Replace Precatalyst 4.Replace Rail Progressure sensor 5.Reset Engine Oil Life 6.Regeneration D. Particulate Filter
EUROPE	2006	Vectra-C/Signum	Y 20 DTH	Engine	X	X	X	X	1.Replace Diesel Particulate Filter 2.Replace Mass air flow sensor 3.Replace Precatalyst 4.Replace Rail Progressure sensor 5.Reset Engine Oil Life 6.Regeneration D. Particulate Filter
EUROPE	2006	Vectra-C/Signum	Y 22 DTR	Engine	X	X	X		Adjust Idle Speed
EUROPE	2006	Vectra-C/Signum	Z 22 SE	Engine	X	X	X		
EUROPE	2006	Vectra-C/Signum	Z 22 YH	Engine	X	X	X		
EUROPE	2006	Vectra-C/Signum	Z 32 SE	Engine	X	X	X		Injector Cutoff Test
EUROPE	2006	Vectra-C/Signum	AF 23-5/33-5/40-6	Engine	X	X	X		
EUROPE	2006	Vectra-C/Signum	ABS/TC/ESP	Transmission	X	X	X		
EUROPE	2006	Vectra-C/Signum	EHPS (Electrohydraulic Power Steering)	Chassis	X	X	X	X	
EUROPE	2006	Vectra-C/Signum	CDC (Continuous Damping Control)	Chassis	X	X	X		
EUROPE	2006	Vectra-C/Signum	SDM (Airbag Sensing & Diagnostic Module)	Chassis	X	X			
EUROPE	2006	Vectra-C/Signum	Instrument	Body	*	X	X		
EUROPE	2006	Vectra-C/Signum	CIM (Steering Column Module)	Body	X	X	X		
EUROPE	2006	Vectra-C/Signum	BCM (Body Control Module)	Body	X	X			1.Erase Transponder-Keys And Remote 2.Program Transponder-Keys And Remote

EUROPE	2006	Vectra-C/Signum	DDM (Driver Door Module)	Body	X	X	X		
EUROPE	2006	Vectra-C/Signum	PDM (Passenger Door Module)	Body	X	X			
EUROPE	2006	Vectra-C/Signum	REC (Rear Electrical Centre)	Body	X	X			
EUROPE	2006	Vectra-C/Signum	UEC (Underhood Electrical Centre)	Body	X	X	X		
EUROPE	2006	Vectra-C/Signum	SLM (Shift Lever Module)	Body	X	X	X		
EUROPE	2006	Vectra-C/Signum	SRM (Sun Roof Module)	Body	X	X			
EUROPE	2006	Vectra-C/Signum	AHL/AFL (Headlamp Levelling)	Body	X	X			
EUROPE	2006	Vectra-C/Signum	Vehicle DTC Information	Body	X	X			
EUROPE	2005	Vectra-C/Signum	Engine Cooling	Vehicle		X			
EUROPE	2005	Vectra-C/Signum	Z 20 NET	Engine	X	X	X		
EUROPE	2005	Vectra-C/Signum	Z 18 XE	Engine	X	X	X	X	Reset Oil Life
EUROPE	2005	Vectra-C/Signum	Z 19 DT	Engine	X	*	X		Injector Cutoff Test
EUROPE	2005	Vectra-C/Signum	Z 19 DTH	Engine	X	X	X	X	1.Replace Diesel Particulate Filter 2.Replace Mass air flow sensor 3.Replace Precatalyst 4.Replace Rail Progressure sensor 5.Reset Engine Oil Life 6.Regeneration D. Particulate Filter
EUROPE	2005	Vectra-C/Signum	Y 20 DTH	Engine	X	X	X	X	1.Replace Diesel Particulate Filter 2.Replace Mass air flow sensor 3.Replace Precatalyst 4.Replace Rail Progressure sensor 5.Reset Engine Oil Life 6.Regeneration D. Particulate Filter
EUROPE	2005	Vectra-C/Signum	Y 22 DTR	Engine	X	X	X		Adjust Idle Speed
EUROPE	2005	Vectra-C/Signum	Z 22 SE	Engine	X	X	X		
EUROPE	2005	Vectra-C/Signum	Z 22 YH	Engine	X	X	X		

EUROPE	2005	Vectra-C/Signum	Y 30 DT	Engine	X	X	X		Injector Cutoff Test
EUROPE	2005	Vectra-C/Signum	Z 32 SE	Engine	X	X	X	X	
EUROPE	2005	Vectra-C/Signum	AF 23-5/33-5/40-6	Engine	X	X	X		
EUROPE	2005	Vectra-C/Signum	ABS/TC/ESP	Transmission	X	X	X		
EUROPE	2005	Vectra-C/Signum	EHPS (Electrohydraulic Power Steering)	Chassis	X	X	X		
EUROPE	2005	Vectra-C/Signum	CDC (Continuous Damping Control)	Chassis	X	X	X		
EUROPE	2005	Vectra-C/Signum	SDM (Airbag Sensing & Diagnostic Module)	Chassis	X	X			
EUROPE	2005	Vectra-C/Signum	Instrument	Body	*	X	X		
EUROPE	2005	Vectra-C/Signum	CIM (Steering Column Module)	Body	X	X	X		
EUROPE	2005	Vectra-C/Signum	BCM (Body Control Module)	Body	X	X			1.Erase Transponder-Keys And Remote 2.Program Transponder-Keys And Remote
EUROPE	2005	Vectra-C/Signum	DDM (Driver Door Module)	Body	X	X	X		
EUROPE	2005	Vectra-C/Signum	PDM (Passenger Door Module)	Body	X	X			
EUROPE	2005	Vectra-C/Signum	REC (Rear Electrical Centre)	Body	X	X			
EUROPE	2005	Vectra-C/Signum	UEC (Underhood Electrical Centre)	Body	X	X	X		
EUROPE	2005	Vectra-C/Signum	SLM (Shift Lever Module)	Body	X	X	X		
EUROPE	2005	Vectra-C/Signum	SRM (Sun Roof Module)	Body	X	X			
EUROPE	2005	Vectra-C/Signum	AHL/AFL (Headlamp Levelling)	Body	X	X			
EUROPE	2005	Vectra-C/Signum	Vehicle DTC Information	Body	X	X			
EUROPE	2004	Vectra-C/Signum	Engine Cooling	Vehicle		X			
EUROPE	2004	Vectra-C/Signum	Z 20 NET	Engine	X	X	X		

EUROPE	2004	Vectra-C/Signum	Z 18 XE	Engine	X	X	X	X	Reset Oil Life
EUROPE	2004	Vectra-C/Signum	Z 19 DT	Engine	X	*	X		Injector Cutoff Test
EUROPE	2004	Vectra-C/Signum	Z 19 DTH	Engine	X	X	X	X	1.Replace Diesel Particulate Filter 2.Replace Mass air flow sensor 3.Replace Precatalyst 4.Replace Rail Progressure sensor 5.Reset Engine Oil Life 6.Regeneration D. Particulate Filter
EUROPE	2004	Vectra-C/Signum	Y 20 DTH	Engine	X	X	X	X	1.Replace Diesel Particulate Filter 2.Replace Mass air flow sensor 3.Replace Precatalyst 4.Replace Rail Progressure sensor 5.Reset Engine Oil Life 6.Regeneration D. Particulate Filter
EUROPE	2004	Vectra-C/Signum	Y 22 DTR	Engine	X	X	X		Adjust Idle Speed
EUROPE	2004	Vectra-C/Signum	Z 22 SE	Engine	X	X	X		
EUROPE	2004	Vectra-C/Signum	Z 22 YH	Engine	X	X	X		
EUROPE	2004	Vectra-C/Signum	Y 30 DT	Engine	X	X	X		Injector Cutoff Test
EUROPE	2004	Vectra-C/Signum	Z 32 SE	Engine	X	X	X	X	
EUROPE	2004	Vectra-C/Signum	AF 23-5/33-5	Engine	X	X	X		
EUROPE	2004	Vectra-C/Signum	ABS/TC/ESP	Transmission	X	X	X		
EUROPE	2004	Vectra-C/Signum	EHPS (Electrohydraulic Power Steering)	Chassis	X	X	X		
EUROPE	2004	Vectra-C/Signum	SDM (Airbag Sensing & Diagnostic Module)	Chassis	X	X	X		
EUROPE	2004	Vectra-C/Signum	Instrument	Body	*	X	X		
EUROPE	2004	Vectra-C/Signum	CIM (Steering Column Module)	Body	X	X	X		
EUROPE	2004	Vectra-C/Signum	BCM (Body Control Module)	Body	X	X			1.Erase Transponder-Keys And Remote 2.Program Transponder-Keys And Remote

EUROPE	2004	Vectra-C/Signum	DDM (Driver Door Module)	Body	X	X	X		
EUROPE	2004	Vectra-C/Signum	PDM (Passenger Door Module)	Body	X	X			
EUROPE	2004	Vectra-C/Signum	REC (Rear Electrical Centre)	Body	X	X			
EUROPE	2004	Vectra-C/Signum	UEC (Underhood Electrical Centre)	Body	X	X	X		
EUROPE	2004	Vectra-C/Signum	SLM (Shift Lever Module)	Body	X	X	X		
EUROPE	2004	Vectra-C/Signum	SRM (Sun Roof Module)	Body	X	X			
EUROPE	2004	Vectra-C/Signum	AHL/AFL (Headlamp Levelling)	Body	X	X			
EUROPE	2004	Vectra-C/Signum	Vehicle DTC Information	Body	X	X			
EUROPE	2003	Vectra-C/Signum	Engine Cooling	Vehicle		X			
EUROPE	2003	Vectra-C/Signum	Z 18 XE	Engine	X	X	X		
EUROPE	2003	Vectra-C/Signum	Y 20 DTH	Engine	X	*	X		Injector Cutoff Test
EUROPE	2003	Vectra-C/Signum	Y 22 DTR	Engine	X	X	X		Adjust Idle Speed
EUROPE	2003	Vectra-C/Signum	Z 22 SE	Engine	X	X	X		
EUROPE	2003	Vectra-C/Signum	Z 22 YH	Engine	X	X	X		
EUROPE	2003	Vectra-C/Signum	Y 30 DT	Engine	X	X	X		Injector Cutoff Test
EUROPE	2003	Vectra-C/Signum	Z 32 SE	Engine	X	X	X	X	
EUROPE	2003	Vectra-C/Signum	AF 23-5/33-5	Engine	X	X	X		
EUROPE	2003	Vectra-C/Signum	ABS/TC/ESP	Transmission	X	X	X		
EUROPE	2003	Vectra-C/Signum	SDM (Airbag Sensing&Diagnostic Module)	Chassis	X	X	X	X	
EUROPE	2003	Vectra-C/Signum	Instrument	Body	*	X	X		
EUROPE	2003	Vectra-C/Signum	CIM (Steering Column Module)	Body	X	X	X		

EUROPE	2003	Vectra-C/Signum	BCM (Body Control Module)	Body	X	X			1.Erase Transponder-Keys And Remote 2.Program Transponder-Keys And Remote
EUROPE	2003	Vectra-C/Signum	DDM (Driver Door Module)	Body	X	X	X		
EUROPE	2003	Vectra-C/Signum	PDM (Passenger Door Module)	Body	X	X			
EUROPE	2003	Vectra-C/Signum	REC (Rear Electrical Centre)	Body	X	X			
EUROPE	2003	Vectra-C/Signum	UEC (Underhood Electrical Centre)	Body	X	X	X		
EUROPE	2003	Vectra-C/Signum	SLM (Shift Lever Module)	Body	X	X	X		
EUROPE	2003	Vectra-C/Signum	SRM (Sun Roof Module)	Body	X	X			
EUROPE	2003	Vectra-C/Signum	AHL/AFL (Headlamp Levelling)	Body	X	X			
EUROPE	2003	Vectra-C/Signum	Vehicle DTC Information	Body	X	X			
EUROPE	2002	Vectra-C/Signum	Engine Cooling	Vehicle		X			
EUROPE	2002	Vectra-C/Signum	Z 18 XE	Engine	X	X	X		
EUROPE	2002	Vectra-C/Signum	Y 20 DTH	Engine	X	*	X		Injector Cutoff Test
EUROPE	2002	Vectra-C/Signum	Y 22 DTR	Engine	X	X	X		
EUROPE	2002	Vectra-C/Signum	Z 22 SE	Engine	X	X	X		Adjust Idle Speed
EUROPE	2002	Vectra-C/Signum	Z 32 SE	Engine	X	X	X		
EUROPE	2002	Vectra-C/Signum	AF 23-5/33-5	Engine	X	X	X		
EUROPE	2002	Vectra-C/Signum	ABS/TC/ESP	Transmission	X	X	X		
EUROPE	2002	Vectra-C/Signum	SDM (Airbag Sensing&Diagnostic Module)	Chassis	X	X	X	X	
EUROPE	2002	Vectra-C/Signum	Instrument	Body	*	X	X		
EUROPE	2002	Vectra-C/Signum	CIM (Steering Column Module)	Body	X	X	X		
EUROPE	2002	Vectra-C/Signum	BCM (Body Control Module)	Body	X	X			1.Erase Transponder-Keys And Remote 2.Program Transponder-Keys And Remote

EUROPE	2002	Vectra-C/Signum	DDM (Driver Door Module)	Body	X	X	X		
EUROPE	2002	Vectra-C/Signum	PDM (Passenger Door Module)	Body	X	X			
EUROPE	2002	Vectra-C/Signum	REC (Rear Electrical Centre)	Body	X	X			
EUROPE	2002	Vectra-C/Signum	UEC (Underhood Electrical Centre)	Body	X	X	X		
EUROPE	2002	Vectra-C/Signum	SLM (Shift Lever Module)	Body	X	X	X		
EUROPE	2002	Vectra-C/Signum	SRM (Sun Roof Module)	Body	X	X			
EUROPE	2002	Vectra-C/Signum	AHL/AFL (Headlamp Levelling)	Body	X	X			
EUROPE	2002	Vectra-C/Signum	F9Q_760/762(1.9L)	Body	X	X			
EUROPE	2010	Vivaro	M9R_780(2.0L)	Engine	X	*	X	X	
EUROPE	2010	Vivaro	ABS/ESP	Engine	X	X	X	X	
EUROPE	2010	Vivaro	Airbag	Chassis	X	*	X	X	
EUROPE	2010	Vivaro	Body Control Module	Body	X	X	X		
EUROPE	2010	Vivaro	M9R_780	Body	X	X	X	X	
EUROPE	2009	Vivaro	F9Q_1.9L	Engine	X	X	X	X	
EUROPE	2009	Vivaro	ABS	Engine	X	*	X	X	
EUROPE	2009	Vivaro	BCM	Chassis	X	*	X	X	
EUROPE	2009	Vivaro	Airbag	Body	X	X	X	X	
EUROPE	2009	Vivaro	M9R_780	Body	X	X	X		
EUROPE	2008	Vivaro	F9Q_1.9L	Engine	X	X	X	X	
EUROPE	2008	Vivaro	ABS	Engine	X	*	X	X	
EUROPE	2008	Vivaro	BCM	Chassis	X	*	X	X	
EUROPE	2008	Vivaro	Airbag	Body	X	X	X	X	
EUROPE	2008	Vivaro	M9R_780	Body	X	X	X		
EUROPE	2007	Vivaro	F9Q_1.9L	Engine	X	X	X	X	
EUROPE	2007	Vivaro	ABS	Engine	X	*	X	X	
EUROPE	2007	Vivaro	BCM	Chassis	X	*	X	X	
EUROPE	2007	Vivaro	Airbag	Body	X	X	X	X	
EUROPE	2007	Vivaro	M9R_780	Body	X	X	X		
EUROPE	2006	Vivaro	F9Q_1.9L	Engine	X	X	X	X	
EUROPE	2006	Vivaro	ABS	Engine	X	*	X	X	
EUROPE	2006	Vivaro	BCM	Chassis	X	*	X	X	
EUROPE	2006	Vivaro	Airbag	Body	X	X	X	X	
EUROPE	2006	Vivaro	M9R_780	Body	X	X	X		
EUROPE	2005	Vivaro	F9Q_1.9L	Engine	X	X	X	X	

EUROPE	2005	Vivaro	ABS	Engine	X	*	X	X	
EUROPE	2005	Vivaro	BCM	Chassis	X	*	X	X	
EUROPE	2005	Vivaro	Airbag	Body	X	X	X	X	
EUROPE	2005	Vivaro	M9R_780	Body	X	X	X		
EUROPE	2004	Vivaro	F9Q_1.9L	Engine	X	X	X	X	
EUROPE	2004	Vivaro	ABS	Engine	X	*	X	X	
EUROPE	2004	Vivaro	BCM	Chassis	X	*	X	X	
EUROPE	2004	Vivaro	Airbag	Body	X	X	X	X	
EUROPE	2004	Vivaro	M9R_780	Body	X	X	X		
EUROPE	2003	Vivaro	F9Q_1.9L	Engine	X	X	X	X	
EUROPE	2003	Vivaro	ABS	Engine	X	*	X	X	
EUROPE	2003	Vivaro	BCM	Chassis	X	*	X	X	
EUROPE	2003	Vivaro	Airbag	Body	X	X	X	X	
EUROPE	2003	Vivaro	M9R_780	Body	X	X	X		
EUROPE	2009	Vivaro	F9Q_1.9L	Engine	X	X	X	X	
EUROPE	2002	Vivaro	ABS	Engine	X	*	X	X	
EUROPE	2002	Vivaro	BCM	Chassis	X	*	X	X	
EUROPE	2002	Vivaro	Airbag	Body	X	X	X	X	
EUROPE	2002	Vivaro	F9Q_1.9L	Body	X	X	X		
EUROPE	2001	Vivaro	ABS	Engine	X	*	X	X	
EUROPE	2001	Vivaro	BCM	Chassis	X	*	X	X	
EUROPE	2001	Vivaro	Z 16 XE	Body	X	X	X	X	
EUROPE	2005	Zafira	Z 16 YNG	Engine	X	X	X	X	
EUROPE	2005	Zafira	Z 18 XE	Engine	X	X	X		
EUROPE	2005	Zafira	Y 20 DTH	Engine	X	X	X	X	
EUROPE	2005	Zafira	Z 20 LET	Engine	X	X	X	X	Adjust Idle Speed
EUROPE	2005	Zafira	Y 22 DTR	Engine	X	X	X		
EUROPE	2005	Zafira	Z 22 SE	Engine	X	X	X		
EUROPE	2005	Zafira	AF 13-II/17/20/22 CAN	Engine	X	X	X		
EUROPE	2005	Zafira	ABS-5.3/5.4 (+TC)	Transmission	X	X	X	X	
EUROPE	2005	Zafira	ESP	Chassis	X	X	X	X	
EUROPE	2005	Zafira	Electronic Power Steering	Chassis	X	X	X		
EUROPE	2005	Zafira	Immobiliser	Chassis	X	X	X		
EUROPE	2005	Zafira	Instrument	Body	X	X	X		1.Erase Key Set; 2.Program Transponder-Keys
EUROPE	2005	Zafira	Airbag	Body	X	X	X		
EUROPE	2005	Zafira	Anti Theft Warning	Body	X	X	X		
EUROPE	2005	Zafira	Central Door Lock	Body	X	X	X		

EUROPE	2005	Zafira	Engine Cooling Module	Body	X	X	X		
EUROPE	2005	Zafira	Electronic Climate Control	Body	X	X	X		
EUROPE	2005	Zafira	Radio Car 300	Body	X	X	X		
EUROPE	2005	Zafira	Z 16 XE	Infotainment	X	X	X		
EUROPE	2004	Zafira	Z 16 YNG	Engine	X	X	X	X	
EUROPE	2004	Zafira	Z 18 XE	Engine	X	X	X		
EUROPE	2004	Zafira	Y 20 DTH	Engine	X	X	X	X	
EUROPE	2004	Zafira	Z 20 LET	Engine	X	X	X	X	Adjust Idle Speed
EUROPE	2004	Zafira	Y 22 DTR	Engine	X	X	X		
EUROPE	2004	Zafira	Z 22 SE	Engine	X	X	X		
EUROPE	2004	Zafira	AF 13-II/17/20/22 CAN	Engine	X	X	X		
EUROPE	2004	Zafira	ABS-5.3/5.4 (+TC)	Transmission	X	X	X	X	
EUROPE	2004	Zafira	ESP	Chassis	X	X	X	X	
EUROPE	2004	Zafira	Electronic Power Steering	Chassis	X	X	X		
EUROPE	2004	Zafira	Immobiliser	Chassis	X	X	X		
EUROPE	2004	Zafira	Instrument	Body	X	X	X		1.Erase Key Set; 2.Program Transponder-Keys
EUROPE	2004	Zafira	Airbag	Body	X	X	X		
EUROPE	2004	Zafira	Anti Theft Warning	Body	X	X	X		
EUROPE	2004	Zafira	Central Door Lock	Body	X	X	X		
EUROPE	2004	Zafira	Engine Cooling Module	Body	X	X	X		
EUROPE	2004	Zafira	Electronic Climate Control	Body	X	X	X		
EUROPE	2004	Zafira	Radio Car 300	Body	X	X	X		
EUROPE	2004	Zafira	Z 16 XE	Infotainment	X	X	X		
EUROPE	2003	Zafira	Z 16 YNG	Engine	X	X	X	X	
EUROPE	2003	Zafira	Z 18 XE	Engine	X	X	X		
EUROPE	2003	Zafira	Y 20 DTH	Engine	X	X	X	X	
EUROPE	2003	Zafira	Z 20 LET	Engine	X	X	X	X	Adjust Idle Speed
EUROPE	2003	Zafira	Y 22 DTR	Engine	X	X	X		
EUROPE	2003	Zafira	Z 22 SE	Engine	X	X	X		
EUROPE	2003	Zafira	AF 13-II/17/20/22 CAN	Engine	X	X	X		
EUROPE	2003	Zafira	ABS-5.3/5.4 (+TC)	Transmission	X	X	X	X	
EUROPE	2003	Zafira	ESP	Chassis	X	X	X	X	

EUROPE	2003	Zafira	Electronic Power Steering	Chassis	X	X	X		
EUROPE	2003	Zafira	Immobiliser	Chassis	X	X	X		
EUROPE	2003	Zafira	Instrument	Body	X	X	X		
EUROPE	2003	Zafira	Airbag	Body	X	X	X		
EUROPE	2003	Zafira	Anti Theft Warning	Body	X	X	X		
EUROPE	2003	Zafira	Central Door Lock	Body	X	X	X		
EUROPE	2003	Zafira	Engine Cooling Module	Body	X	X	X		
EUROPE	2003	Zafira	Electronic Climate Control	Body	X	X	X		
EUROPE	2003	Zafira	Radio Car 300	Body	X	X	X		
EUROPE	2003	Zafira	Z 16 XE	Infotainment	X	X	X		
EUROPE	2002	Zafira	Z 16 YNG	Engine	X	X	X	X	
EUROPE	2002	Zafira	Z 18 XE	Engine	X	X	X		
EUROPE	2002	Zafira	Y 20 DTH	Engine	X	X	X	X	
EUROPE	2002	Zafira	Z 20 LET	Engine	X	X	X	X	Adjust Idle Speed
EUROPE	2002	Zafira	Y 22 DTR	Engine	X	X	X		
EUROPE	2002	Zafira	Z 22 SE	Engine	X	X	X		
EUROPE	2002	Zafira	AF 13-II/17/20/22 CAN	Engine	X	X	X		
EUROPE	2002	Zafira	ABS-5.3/5.4 (+TC)	Transmission	X	X	X	X	
EUROPE	2002	Zafira	ESP	Chassis	X	X	X	X	
EUROPE	2002	Zafira	Electronic Power Steering	Chassis	X	X	X		
EUROPE	2002	Zafira	Immobiliser	Chassis	X	X	X		
EUROPE	2002	Zafira	Instrument	Body	X	X	X		
EUROPE	2002	Zafira	Airbag	Body	X	X	X		
EUROPE	2002	Zafira	Anti Theft Warning	Body	X	X	X		
EUROPE	2002	Zafira	Central Door Lock	Body	X	X	X		
EUROPE	2002	Zafira	Engine Cooling Module	Body	X	X	X		
EUROPE	2002	Zafira	Radio Car 300	Body	X	X	X		
EUROPE	2002	Zafira	Z 16 XE	Infotainment	X	X	X		
EUROPE	2001	Zafira	Z 16 YNG	Engine	X	X	X	X	
EUROPE	2001	Zafira	Z 18 XE	Engine	X	X	X		
EUROPE	2001	Zafira	Y 20 DTH	Engine	X	X	X	X	
EUROPE	2001	Zafira	Z 22 SE	Engine	X	X	X	X	Adjust Idle Speed

EUROPE	2001	Zafira	AF 13-II/17/20/22 CAN	Engine	X	X	X		
EUROPE	2001	Zafira	ABS-5.3/5.4 (+TC)	Transmission	X	X	X	X	
EUROPE	2001	Zafira	ESP	Chassis	X	X	X	X	
EUROPE	2001	Zafira	Electronic Power Steering	Chassis	X	X	X		
EUROPE	2001	Zafira	Immobiliser	Chassis	X	X	X		
EUROPE	2001	Zafira	Instrument	Body	X	X	X		
EUROPE	2001	Zafira	Airbag	Body	X	X	X		
EUROPE	2001	Zafira	Anti Theft Warning	Body	X	X	X		
EUROPE	2001	Zafira	Central Door Lock	Body	X	X	X		
EUROPE	2001	Zafira	Engine Cooling Module	Body	X	X	X		
EUROPE	2001	Zafira	Radio Car 300	Body	X	X	X		
EUROPE	2001	Zafira	X 16 XEL	Infotainment	X	X	X		
EUROPE	2000	Zafira	X 18 XE1	Engine	X	X	X		Adjust Idle Speed
EUROPE	2000	Zafira	X 20 DTL	Engine	X	X	X	X	Adjust Idle Speed
EUROPE	2000	Zafira	AF 13-II/17/20/22	Engine	X	X	X		
EUROPE	2000	Zafira	ABS-5.3/5.4 (+TC)	Transmission	X	X	X	X	
EUROPE	2000	Zafira	ESP	Chassis	X	X	X	X	
EUROPE	2000	Zafira	Cruise Control	Chassis	X	X	X		
EUROPE	2000	Zafira	Electronic Power Steering	Chassis	X	X	X		
EUROPE	2000	Zafira	Immobiliser	Chassis	X	X	X		
EUROPE	2000	Zafira	Instrument	Body	X	X	X		
EUROPE	2000	Zafira	Airbag	Body	X	X	X		
EUROPE	2000	Zafira	Airbag SAB6	Body	X	X	X		
EUROPE	2000	Zafira	Anti Theft Warning	Body	X	X	X		
EUROPE	2000	Zafira	Central Door Lock	Body	X	X	X		
EUROPE	2000	Zafira	Engine Cooling Module	Body	X	X	X		
EUROPE	2000	Zafira	Radio Car 300	Body	X	X	X		
EUROPE	2000	Zafira	X 16 XEL	Infotainment	X	X	X		
EUROPE	1999	Zafira	X 18 XE1	Engine	X	X	X		Adjust Idle Speed
EUROPE	1999	Zafira	AF 13-II/17/20/22	Engine	X	X	X	X	Adjust Idle Speed
EUROPE	1999	Zafira	ABS-5.3/5.4 (+TC)	Transmission	X	X	X	X	
EUROPE	1999	Zafira	Cruise Control	Chassis	X	X	X	X	

EUROPE	1999	Zafira	Immobiliser	Chassis	X	X	X		
EUROPE	1999	Zafira	Instrument	Body	X	X	X		
EUROPE	1999	Zafira	Airbag SAB6	Body	X	X	X		
EUROPE	1999	Zafira	Anti Theft Warning	Body	X	X	X		
EUROPE	1999	Zafira	Central Door Lock	Body	X	X	X		
EUROPE	1999	Zafira	Engine Cooling Module	Body	X	X	X		
EUROPE	1999	Zafira	Radio Car 300	Body	X	X	X		
EUROPE	1999	Zafira	Vehicle DTC Information	Infotainment	X	X	X		
EUROPE	2011	Zafira-B	Z 16 XE1	Vehicle		X			
EUROPE	2011	Zafira-B	Z16XEP	Engine	X	X	X	X	
EUROPE	2011	Zafira-B	Z16XER	Engine	X	X	X	*	ECU Control Program Idle Speed Reset O2-Loop Block Learn Map Program High Speed CAN-Bus Configuration Reset ECU
EUROPE	2011	Zafira-B	Z18XER	Engine	X	X	X	*	ECU Control Program Idle Speed Reset Learned Values Program High Speed CAN-Bus Configuration Reset ECU
EUROPE	2011	Zafira-B	Z19DT	Engine	X	X	X	*	ECU Control Program Idle Speed Reset Learned Values Program High Speed CAN-Bus Configuration Reset ECU
EUROPE	2011	Zafira-B	Z 19 DTH	Engine	X	X	X	X	1.Replace Diesel Particulate Filter 2.Replace Mass air flow sensor 3.Replace Precatalyst 4.Replace Rail Progressure sensor 5.Reset Engine Oil Life 6.Regeneration Diesel Particulate Filter *7.Replace Injector *8.Program Injector *9.Program High Speed CAN-Bus Configuration *10.Reset ECU *11.Replace O2 Sensor

EUROPE	2011	Zafira-B	Z 20 LEH	Engine	X	X	X	X	1.Replace Diesel Particulate Filter 2.Replace Mass air flow sensor 3.Replace Precatalyst 4.Replace Rail Pressure sensor 5.Regeneration Diesel Particulate Filter 6.Reset engine oil sensor 7.Program High Speed Can Bus Config. 8.Replace O2 sensor 9.Program Idle Speed
EUROPE	2011	Zafira-B	Z 20 LER	Engine	X	X	X	X	
EUROPE	2011	Zafira-B	Z 22 YH	Engine	X	X	X	X	
EUROPE	2011	Zafira-B	MTA (Easytronic)	Engine	X	X	X	X	
EUROPE	2011	Zafira-B	AF 22-4	Transmission	X	X	X		
EUROPE	2011	Zafira-B	ABS/TC/ESP ECU (Electronic Control unit)	Transmission	X	X	X	X	
EUROPE	2011	Zafira-B	EHPS (Electro Hydraulic Power Steering)	Chassis	X	X	X	X	
EUROPE	2011	Zafira-B	CDC(Continuous Damping Control)	Chassis	X	X	X		
EUROPE	2011	Zafira-B	SDM (Airbag)	Chassis	X	X	X	X	
EUROPE	2011	Zafira-B	PAS(Park Pilot)	Body	X	X	X		
EUROPE	2011	Zafira-B	CIM(Steering Column Module)	Body	X	X	X	X	
EUROPE	2011	Zafira-B	IPC ECU (Instrument Control unit)	Body	X	X	X	X	Erase Transponder-Keys And Remote Program Transponder-Keys And Remote
EUROPE	2011	Zafira-B	PEPS(Open and Start)	Body	X	X	X		
EUROPE	2011	Zafira-B	REC (Rear Electrical Centre)	Body	X	X	X		
EUROPE	2011	Zafira-B	SLM(Shift Lever Module)	Body	X	X	X		
EUROPE	2011	Zafira-B	UEC (Underhood Electrical Centre)	Body	X	X	X	X	
EUROPE	2011	Zafira-B	Vehicle DTC Information	Body	X	X	X		
EUROPE	2010	Zafira-B	Z 16 XE1	Vehicle		X			
EUROPE	2010	Zafira-B	Z16XEP	Engine	X	X	X	X	

EUROPE	2010	Zafira-B	Z16XER	Engine	X	X	X	*	ECU Control Program Idle Speed Reset O2-Loop Block Learn Map Program High Speed CAN-Bus Configuration Reset ECU
EUROPE	2010	Zafira-B	Z18XER	Engine	X	X	X	*	ECU Control Program Idle Speed Reset Learned Values Program High Speed CAN-Bus Configuration Reset ECU
EUROPE	2010	Zafira-B	Z19DT	Engine	X	X	X	*	ECU Control Program Idle Speed Reset Learned Values Program High Speed CAN-Bus Configuration Reset ECU
EUROPE	2010	Zafira-B	Z 19 DTH	Engine	X	X	X	X	1.Replace Diesel Particulate Filter 2.Replace Mass air flow sensor 3.Replace Precatalyst 4.Replace Rail Progressure sensor 5.Reset Engine Oil Life 6.Regeneration Diesel Particulate Filter *7.Replace Injector *8.Program Injector *9.Program High Speed CAN-Bus Configuration *10.Reset ECU *11.Replace O2 Sensor
EUROPE	2010	Zafira-B	Z 20 LEH	Engine	X	X	X	X	1.Replace Diesel Particulate Filter 2.Replace Mass air flow sensor 3.Replace Precatalyst 4.Replace Rail Pressure sensor 5.Regeneration Diesel Particulate Filter 6.Reset engine oil sensor 7.Program High Speed Can Bus Config. 8.Replace O2 sensor 9.Program Idle Speed
EUROPE	2010	Zafira-B	Z 20 LER	Engine	X	X	X	X	
EUROPE	2010	Zafira-B	Z 22 YH	Engine	X	X	X	X	
EUROPE	2010	Zafira-B	MTA (Easytronic)	Engine	X	X	X	X	
EUROPE	2010	Zafira-B	AF 22-4	Transmission	X	X	X		
EUROPE	2010	Zafira-B	ABS/TC/ESP ECU (Electronic Control unit)	Transmission	X	X	X	X	

EUROPE	2010	Zafira-B	EHPS (Electro Hydraulic Power Steering)	Chassis	X	X	X	X	
EUROPE	2010	Zafira-B	CDC(Continuous Damping Control)	Chassis	X	X	X		
EUROPE	2010	Zafira-B	SDM (Airbag)	Chassis	X	X	X	X	
EUROPE	2010	Zafira-B	PAS(Park Pilot)	Body	X	X	X		
EUROPE	2010	Zafira-B	CIM(Steering Column Module)	Body	X	X	X	X	
EUROPE	2010	Zafira-B	IPC ECU (Instrument Control unit)	Body	X	X	X	X	Erase Transponder-Keys And Remote Program Transponder-Keys And Remote
EUROPE	2010	Zafira-B	PEPS(Open and Start)	Body	X	X	X		
EUROPE	2010	Zafira-B	REC (Rear Electrical Centre)	Body	X	X	X		
EUROPE	2010	Zafira-B	SLM(Shift Lever Module)	Body	X	X	X		
EUROPE	2010	Zafira-B	UEC (Underhood Electrical Centre)	Body	X	X	X	X	
EUROPE	2010	Zafira-B	Z 20 LEH	Body	X	X	X		
EUROPE	2009	Zafira-B	Z 22 YH	Engine	X	X	X	X	
EUROPE	2009	Zafira-B	Z16XEP	Engine	X	X	X	X	
EUROPE	2009	Zafira-B	Z18XER	Engine	X	X	X	*	Electronic Throttle Control Injector Cut off Test Program Idle Speed Reset Learn Values Program High Can Configuration Reset ECU
EUROPE	2009	Zafira-B	Z19DT	Engine	X	X	X	*	Program Idle Speed Reset Learn Values Program High Can Configuration Reset ECU
EUROPE	2009	Zafira-B	Z 19 DTH	Engine	X	X	X	X	Replace Injector Program Injector Program High Speed CAN-Bus Configuration Reset ECU Replace O2 Sensor

EUROPE	2009	Zafira-B	AF 22-4	Engine	X	X	X	X	1.Replace Diesel Particulate Filter 2.Replace Mass air flow sensor 3.Replace Precatalyst 4.Replace Rail Pressure sensor 5.Regeneration Diesel Particulate Filter 6.Reset engine oil sensor 7.Program High Speed Can Bus Config. 8.Replace O2 sensor 9.Program Idle Speed
EUROPE	2009	Zafira-B	MTA (Easytronic)	Transmission	X	X	X	X	
EUROPE	2009	Zafira-B	CDC(Continuous Damping Control)	Transmission	X	X	X		
EUROPE	2009	Zafira-B	ABS/TC/ESP ECU (Electronic Control unit)	Chassis	X	X	X	X	
EUROPE	2009	Zafira-B	EHPS (Electrohydraulic Power Steering)	Chassis	X	X	X	X	
EUROPE	2009	Zafira-B	PEPS(Open&Start)	Chassis	X	X	X		
EUROPE	2009	Zafira-B	PAS(Park Pilot)	Body	X	X	X		
EUROPE	2009	Zafira-B	SLM(Shift Lever Module)	Body	X	X	X	X	
EUROPE	2009	Zafira-B	SDM (Airbag)	Body	X	X	X	X	
EUROPE	2009	Zafira-B	CIM	Body	X	X	X		
EUROPE	2009	Zafira-B	IPC ECU (Instrument Control unit)	Body	X	X	X	X	Erase Remote Key Program Remote Key
EUROPE	2009	Zafira-B	REC (Rear Electrical Centre)	Body	X	X	X		
EUROPE	2009	Zafira-B	UEC (Underhood Electrical Centre)	Body	X	X	X		
EUROPE	2009	Zafira-B	Vehicle DTC Information	Body	X	X	X		
EUROPE	2008	Zafira-B	Z 16 XE1	Vehicle		X			
EUROPE	2008	Zafira-B	Z 20 LER	Engine	X	X	X	X	
EUROPE	2008	Zafira-B	Z 20 LEH	Engine	X	X	X	X	
EUROPE	2008	Zafira-B	Z 22 YH	Engine	X	X	X	X	
EUROPE	2008	Zafira-B	Z 16 XEP	Engine	X	X	X	X	
EUROPE	2008	Zafira-B	Z 16 XER	Engine	X	X	X		
EUROPE	2008	Zafira-B	Z 18 XER	Engine	X	X	X		Injector Cutoff Test
EUROPE	2008	Zafira-B	Z 19 DT	Engine	X	X	X		Injector Cutoff Test

EUROPE	2008	Zafira-B	Z 19 DTH	Engine	X	X	X	X	1.Replace Diesel Particulate Filter 2.Replace Mass air flow sensor 3.Replace Precatalyst 4.Replace Rail Progressure sensor 5.Reset Engine Oil Life 6.Regeneration D. Particulate Filter
EUROPE	2008	Zafira-B	AF 22-4	Engine	X	X	X	X	1.Replace Diesel Particulate Filter 2.Replace Mass air flow sensor 3.Replace Precatalyst 4.Replace Rail Pressure sensor 5.Regeneration Diesel Particulate Filter 6.Reset engine oil sensor 7.Program High Speed Can Bus Config. 8.Replace O2 sensor 9.Program Idle Speed
EUROPE	2008	Zafira-B	MTA (Easytronic)	Transmission	X	X	X	X	
EUROPE	2008	Zafira-B	CDC(Continuous Damping Control)	Transmission	X	X	X		
EUROPE	2008	Zafira-B	ABS/TC/ESP ECU (Electronic Control unit)	Chassis	X	X	X	X	
EUROPE	2008	Zafira-B	EHPS (Electrohydraulic Power Steering)	Chassis	X	X	X	X	
EUROPE	2008	Zafira-B	PEPS(Open&Start)	Chassis	X	X	X		
EUROPE	2008	Zafira-B	PAS(Park Pilot)	Body	X	X	X		
EUROPE	2008	Zafira-B	SLM(Shift Lever Module)	Body	X	X	X	X	
EUROPE	2008	Zafira-B	SDM (Airbag)	Body	X	X	X	X	
EUROPE	2008	Zafira-B	CIM (Steering Column Module)	Body	X	X	X		
EUROPE	2008	Zafira-B	IPC ECU (Instrument Control unit)	Body	X	X	X		
EUROPE	2008	Zafira-B	REC (Rear Electrical Centre)	Body	X	X	X		
EUROPE	2008	Zafira-B	UEC (Underhood Electrical Centre)	Body	X	X	X		
EUROPE	2008	Zafira-B	Vehicle DTC Information	Body	X	X	X		
EUROPE	2007	Zafira-B	Z 16 XEP	Vehicle		X			
EUROPE	2007	Zafira-B	Z 16 XER	Engine	X	X	X		

EUROPE	2007	Zafira-B	Z 18 XER	Engine	X	X	X		Injector Cutoff Test
EUROPE	2007	Zafira-B	Z 19 DT	Engine	X	X	X		Injector Cutoff Test
EUROPE	2007	Zafira-B	Z 19 DTH	Engine	X	X	X	X	1.Replace Diesel Particulate Filter 2.Replace Mass air flow sensor 3.Replace Precatalyst 4.Replace Rail Progressure sensor 5.Reset Engine Oil Life 6.Regeneration D. Particulate Filter
EUROPE	2007	Zafira-B	MTA (Easytronic)	Engine	X	X	X	X	1.Replace Diesel Particulate Filter 2.Replace Mass air flow sensor 3.Replace Precatalyst 4.Replace Rail Pressure sensor 5.Regeneration Diesel Particulate Filter 6.Reset engine oil sensor 7.Program High Speed Can Bus Config. 8.Replace O2 sensor 9.Program Idle Speed
EUROPE	2007	Zafira-B	ABS/TC/ESP ECU (Electronic Control unit)	Transmission	X	X	X		
EUROPE	2007	Zafira-B	EHPS (Electrohydraulic Power Steering)	Chassis	X	X	X	X	
EUROPE	2007	Zafira-B	SDM (Airbag)	Chassis	X	X	X		
EUROPE	2007	Zafira-B	CIM (Steering Column Module)	Body	X	X	X		
EUROPE	2007	Zafira-B	IPC ECU (Instrument Control unit)	Body	X	X	X		
EUROPE	2007	Zafira-B	REC (Rear Electrical Centre)	Body	X	X	X		
EUROPE	2007	Zafira-B	UEC (Underhood Electrical Centre)	Body	X	X	X		
EUROPE	2007	Zafira-B	Vehicle DTC Information	Body	X	X	X		
EUROPE	2006	Zafira-B	Z 16 XEP	Vehicle		X			
EUROPE	2006	Zafira-B	Z 18 XER	Engine	X	X	X		
EUROPE	2006	Zafira-B	Z 19 DT	Engine	X	X	X		Injector Cutoff Test
EUROPE	2006	Zafira-B	Z 19 DTH	Engine	X	X	X	X	1.Replace Diesel Particulate Filter 2.Replace Mass air flow sensor 3.Replace Precatalyst 4.Replace Rail Progressure sensor 5.Reset Engine Oil Life 6.Regeneration D. Particulate Filter

EUROPE	2006	Zafira-B	MTA (Easytronic)	Engine	X	X	X	X	1.Replace Diesel Particulate Filter 2.Replace Mass air flow sensor 3.Replace Precatalyst 4.Replace Rail Pressure sensor 5.Regeneration Diesel Particulate Filter 6.Reset engine oil sensor 7.Program High Speed Can Bus Config. 8.Replace O2 sensor 9.Program Idle Speed
EUROPE	2006	Zafira-B	ABS/TC/ESP ECU (Electronic Control unit)	Transmission	X	X	X		
EUROPE	2006	Zafira-B	EHPS (Electrohydraulic Power Steering)	Chassis	X	X	X	X	
EUROPE	2006	Zafira-B	SDM (Airbag)	Chassis	X	X	X		
EUROPE	2006	Zafira-B	CIM (Steering Column Module)	Body	X	X	X		
EUROPE	2006	Zafira-B	IPC ECU (Instrument Control unit)	Body	X	X	X		
EUROPE	2006	Zafira-B	REC (Rear Electrical Centre)	Body	X	X	X		
EUROPE	2006	Zafira-B	UEC (Underhood Electrical Centre)	Body	X	X	X		
EUROPE	2006	Zafira-B	Vehicle DTC Information	Body	X	X	X		
EUROPE	2005	Zafira-B	Z 16 XEP	Vehicle		X			
EUROPE	2005	Zafira-B	Z 18 XER	Engine	X	X	X		
EUROPE	2005	Zafira-B	Z 19 DT	Engine	X	X	X		Injector Cutoff Test
EUROPE	2005	Zafira-B	Z 19 DTH	Engine	X	X	X	X	1.Replace Diesel Particulate Filter 2.Replace Mass air flow sensor 3.Replace Precatalyst 4.Replace Rail Progressure sensor 5.Reset Engine Oil Life 6.Regeneration D. Particulate Filter

EUROPE	2005	Zafira-B	ABS/TC/ESP ECU (Electronic Control unit)	Engine	X	X	X	X	1.Replace Diesel Particulate Filter 2.Replace Mass air flow sensor 3.Replace Precatalyst 4.Replace Rail Pressure sensor 5.Regeneration Diesel Particulate Filter 6.Reset engine oil sensor 7.Program High Speed Can Bus Config. 8.Replace O2 sensor 9.Program Idle Speed
EUROPE	2005	Zafira-B	EHPS (Electrohydraulic Power Steering)	Chassis	X	X	X	X	
EUROPE	2005	Zafira-B	SDM (Airbag)	Chassis	X	X	X		
EUROPE	2005	Zafira-B	CIM (Steering Column Module)	Body	X	X	X		
EUROPE	2005	Zafira-B	IPC ECU (Instrument Control unit)	Body	X	X	X		
EUROPE	2005	Zafira-B	REC (Rear Electrical Centre)	Body	X	X	X		
EUROPE	2005	Zafira-B	UEC (Underhood Electrical Centre)	Body	X	X	X		
EUROPE	2005	Zafira-B	Z 12 XE	Body	X	X	X		
EUROPE	2011	Astra-G	Z 14 XE	Engine	X	X	X	X	
EUROPE	2011	Astra-G	Z 14 XEP	Engine	X	X	X		
EUROPE	2011	Astra-G	C 16 SEL	Engine	X	X	X	X	1.Reset Learn Values 2.Reset O2-Loop Block Lean Map 3. ECU Control-Electronic throttle control 4.Idle speed program. 5.ECU Reset
EUROPE	2011	Astra-G	Z 16 SE	Engine	X	X	X	X	
EUROPE	2011	Astra-G	Z 16 XE	Engine	X	X	X		
EUROPE	2011	Astra-G	Z 16 XEP	Engine	X	X	X	X	
EUROPE	2011	Astra-G	Z 16 YNG	Engine	X	X	X		
EUROPE	2011	Astra-G	Y 17 DT	Engine	X	X	X		
EUROPE	2011	Astra-G	Z 17 DTL	Engine	X	X	X	X	
EUROPE	2011	Astra-G	Z 18 XE	Engine	X	X	X		
EUROPE	2011	Astra-G	Z 18 XEL	Engine	X	X	X	X	
EUROPE	2011	Astra-G	Y 20 DTH	Engine	X	X	X		
EUROPE	2011	Astra-G	Z 20 LET	Engine	X	X	X	X	Adjust Idle Speed
EUROPE	2011	Astra-G	Y 22 DTR	Engine	X	X	X		
EUROPE	2011	Astra-G	Z 22 SE	Engine	X	X	X		Adjust Idle Speed
EUROPE	2011	Astra-G	AF 13-II/17/20/22	Engine	X	X	X	X	Programming ECU Control

EUROPE	2011	Astra-G	AF 13-II/17/20/22 CAN	Transmission	X	X	X	X	
EUROPE	2011	Astra-G	ABS-5.3/5.4 (+TC)	Transmission	X	X	X	X	
EUROPE	2011	Astra-G	ESP	Chassis	X	X	X	X	
EUROPE	2011	Astra-G	Cruise Control	Chassis	X	X	X		
EUROPE	2011	Astra-G	Electronic Power Steering	Chassis	X	X	X		
EUROPE	2011	Astra-G	Immobiliser	Chassis	X	X	X	X	
EUROPE	2011	Astra-G	Instrument	Body	X	X	X		Erase Key Set Program Transponder-Keys
EUROPE	2011	Astra-G	Airbag	Body	X	X	X	X	
EUROPE	2011	Astra-G	Anti Theft Warning	Body	X	X	X		
EUROPE	2011	Astra-G	Central Door Lock	Body	X	X	X		Erase Key Set Program Transponder-Keys
EUROPE	2011	Astra-G	Engine Cooling Module	Body	X	X	X		
EUROPE	2011	Astra-G	Electronic Climate Control	Body	X	X	X		
EUROPE	2011	Astra-G	HeadLamp Levelling Device	Body	X	X	X		
EUROPE	2011	Astra-G	Z 12 XE	Body	X	X	X	X	Calibration
EUROPE	2010	Astra-G	Z 14 XE	Engine	X	X	X	X	
EUROPE	2010	Astra-G	Z 14 XEP	Engine	X	X	X		
EUROPE	2010	Astra-G	C 16 SEL	Engine	X	X	X	X	1.Reset Learn Values 2.Reset O2-Loop Block Lean Map 3. ECU Control-Electronic throttle control 4.Idle speed program. 5.ECU Reset
EUROPE	2010	Astra-G	Z 16 SE	Engine	X	X	X	X	
EUROPE	2010	Astra-G	Z 16 YNG	Engine	X	X	X		
EUROPE	2010	Astra-G	Z 16 XE	Engine	X	X	X		
EUROPE	2010	Astra-G	Z 16 XEP	Engine	X	X	X	X	
EUROPE	2010	Astra-G	Y 17 DT	Engine	X	X	X		
EUROPE	2010	Astra-G	Z 17 DTL	Engine	X	X	X	X	
EUROPE	2010	Astra-G	Z 18 XE	Engine	X	X	X		
EUROPE	2010	Astra-G	Z 18 XEL	Engine	X	X	X	X	
EUROPE	2010	Astra-G	Y 20 DTH	Engine	X	X	X		
EUROPE	2010	Astra-G	Z 20 LET	Engine	X	X	X	X	Adjust Idle Speed
EUROPE	2010	Astra-G	Y 22 DTR	Engine	X	X	X		
EUROPE	2010	Astra-G	Z 22 SE	Engine	X	X	X		Adjust Idle Speed
EUROPE	2010	Astra-G	AF 13-II/17/20/22	Engine	X	X	X	X	Programming ECU Control

EUROPE	2010	Astra-G	AF 13-II/17/20/22 CAN	Transmission	X	X	X	X	
EUROPE	2010	Astra-G	ABS-5.3/5.4 (+TC)	Transmission	X	X	X	X	
EUROPE	2010	Astra-G	ESP	Chassis	X	X	X	X	
EUROPE	2010	Astra-G	Cruise Control	Chassis	X	X	X		
EUROPE	2010	Astra-G	Electronic Power Steering	Chassis	X	X	X		
EUROPE	2010	Astra-G	Immobiliser	Chassis	X	X	X	X	
EUROPE	2010	Astra-G	Instrument	Body	X	X	X		Erase Key Set Program Transponder-Keys
EUROPE	2010	Astra-G	Airbag	Body	X	X	X	X	
EUROPE	2010	Astra-G	Anti Theft Warning	Body	X	X	X		
EUROPE	2010	Astra-G	Central Door Lock	Body	X	X	X		Erase Key Set Program Transponder-Keys
EUROPE	2010	Astra-G	Engine Cooling Module	Body	X	X	X		
EUROPE	2010	Astra-G	Electronic Climate Control	Body	X	X	X		
EUROPE	2010	Astra-G	HeadLamp Levelling Device	Body	X	X	X		
EUROPE	2010	Astra-G	C 20 NE/C 20 SE (8V)(E0/E20)	Body	X	X	X	X	Calibration
BRAZIL	2009	Astra-G	C 20 SE/C 20 SEL(16V)(E0/E20)	Engine	X	X	X	X	
BRAZIL	2009	Astra-G	X 20 XE (E20-E100)	Engine	X	X	X	X	
BRAZIL	2009	Astra-G	X 24 SE	Engine	X	X	X	X	
BRAZIL	2009	Astra-G	AF 13-II/17/20/22	Engine	X	X	X		
BRAZIL	2009	Astra-G	AF 13-II/17/20/22 CAN	Transmission	X	X	X	X	
BRAZIL	2009	Astra-G	ABS-5.3/5.4 (+TC)	Transmission	X	X	X	X	
BRAZIL	2009	Astra-G	Cruise Control	Chassis	X	X	X	X	
BRAZIL	2009	Astra-G	Electronic Power Steering	Chassis	X	X	X		
BRAZIL	2009	Astra-G	Immobiliser	Chassis	X	X	X		
BRAZIL	2009	Astra-G	Airbag	Body	X	X	X		
BRAZIL	2009	Astra-G	C 20 NE/C 20 SE (8V)(E0/E20)	Body	X	X	X		

BRAZIL	2008	Astra-G	C 20 SE/C 20 SEL(16V)(E0/E20)	Engine	X	X	X	X	
BRAZIL	2008	Astra-G	X 20 XE (E20-E100)	Engine	X	X	X	X	
BRAZIL	2008	Astra-G	X 24 SE	Engine	X	X	X	X	
BRAZIL	2008	Astra-G	AF 13-II/17/20/22	Engine	X	X	X	X	
BRAZIL	2008	Astra-G	AF 13-II/17/20/22 CAN	Transmission	X	X	X	X	
BRAZIL	2008	Astra-G	ABS-5.3/5.4 (+TC)	Transmission	X	X	X	X	
BRAZIL	2008	Astra-G	Cruise Control	Chassis	X	X	X	X	
BRAZIL	2008	Astra-G	Electronic Power Steering	Chassis	X	X	X		
BRAZIL	2008	Astra-G	Immobiliser	Chassis	X	X	X		
BRAZIL	2008	Astra-G	Airbag	Body	X	X	X		
BRAZIL	2008	Astra-G	C 20 NE/C 20 SE (8V)(E0/E20)	Body	X	X	X		
BRAZIL	2007	Astra-G	C 20 SE/C 20 SEL(16V)(E0/E20)	Engine	X	X	X	X	
BRAZIL	2007	Astra-G	X 20 SE	Engine	X	X	X	X	
BRAZIL	2007	Astra-G	X 20 XE (E20-E100)	Engine	X	X	X	X	
BRAZIL	2007	Astra-G	X 24 SE	Engine	X	X	X	X	
BRAZIL	2007	Astra-G	AF 13-II/17/20/22	Engine	X	X	X	X	
BRAZIL	2007	Astra-G	AF 13-II/17/20/22 CAN	Transmission	X	X	X	X	
BRAZIL	2007	Astra-G	ABS-5.3/5.4 (+TC)	Transmission	X	X	X	X	
BRAZIL	2007	Astra-G	Cruise Control	Chassis	X	X	X	X	
BRAZIL	2007	Astra-G	Electronic Power Steering	Chassis	X	X	X		
BRAZIL	2007	Astra-G	Immobiliser	Chassis	X	X	X		
BRAZIL	2007	Astra-G	Airbag	Body	X	X	X		
BRAZIL	2007	Astra-G	C 20 NE/C 20 SE (8V)(E0/E20)	Body	X	X	X		
BRAZIL	2006	Astra-G	C 20 SE/C 20 SEL(16V)(E0/E20)	Engine	X	X	X	X	
BRAZIL	2006	Astra-G	X 20 SE	Engine	X	X	X	X	
BRAZIL	2006	Astra-G	X 20 XE (E20-E100)	Engine	X	X	X	X	
BRAZIL	2006	Astra-G	X 24 SE	Engine	X	X	X	X	

BRAZIL	2006	Astra-G	AF 13-II/17/20/22	Engine	X	X	X	X	
BRAZIL	2006	Astra-G	AF 13-II/17/20/22 CAN	Transmission	X	X	X	X	
BRAZIL	2006	Astra-G	ABS-5.3/5.4 (+TC)	Transmission	X	X	X	X	
BRAZIL	2006	Astra-G	Cruise Control	Chassis	X	X	X	X	
BRAZIL	2006	Astra-G	Electronic Power Steering	Chassis	X	X	X		
BRAZIL	2006	Astra-G	Immobiliser	Chassis	X	X	X		
BRAZIL	2006	Astra-G	Airbag	Body	X	X	X		
BRAZIL	2006	Astra-G	C 18 YE (E100)	Body	X	X	X		
BRAZIL	2005	Astra-G	C 20 NE/C 20 SE (8V)(E0/E20)	Engine	X	X	X	X	
BRAZIL	2005	Astra-G	C 20 SE/C 20 SEL(16V)(E0/E20)	Engine	X	X	X	X	
BRAZIL	2005	Astra-G	X 20 SE	Engine	X	X	X	X	
BRAZIL	2005	Astra-G	X 20 XE (E20-E100)	Engine	X	X	X	X	
BRAZIL	2005	Astra-G	X 24 SE	Engine	X	X	X	X	
BRAZIL	2005	Astra-G	AF 13-II/17/20/22	Engine	X	X	X	X	
BRAZIL	2005	Astra-G	AF 13-II/17/20/22 CAN	Transmission	X	X	X	X	
BRAZIL	2005	Astra-G	ABS-5.3/5.4 (+TC)	Transmission	X	X	X	X	
BRAZIL	2005	Astra-G	Cruise Control	Chassis	X	X	X	X	
BRAZIL	2005	Astra-G	Electronic Power Steering	Chassis	X	X	X		
BRAZIL	2005	Astra-G	Immobiliser	Chassis	X	X	X		
BRAZIL	2005	Astra-G	Airbag	Body	X	X	X		
BRAZIL	2005	Astra-G	C 18 YE (E100)	Body	X	X	X		
BRAZIL	2004	Astra-G	C 20 NE/C 20 SE (8V)(E0/E20)	Engine	X	X	X	X	
BRAZIL	2004	Astra-G	C 20 SE/C 20 SEL(16V)(E0/E20)	Engine	X	X	X	X	
BRAZIL	2004	Astra-G	X 24 SE	Engine	X	X	X	X	
BRAZIL	2004	Astra-G	AF 13-II/17/20/22	Engine	X	X	X	X	
BRAZIL	2004	Astra-G	AF 13-II/17/20/22 CAN	Transmission	X	X	X	X	
BRAZIL	2004	Astra-G	ABS-5.3/5.4 (+TC)	Transmission	X	X	X	X	
BRAZIL	2004	Astra-G	Cruise Control	Chassis	X	X	X	X	

BRAZIL	2004	Astra-G	Electronic Power Steering	Chassis	X	X	X		
BRAZIL	2004	Astra-G	Immobiliser	Chassis	X	X	X		
BRAZIL	2004	Astra-G	Airbag	Body	X	X	X		
BRAZIL	2004	Astra-G	C 18 NE (E0/E20)	Body	X	X	X		
BRAZIL	2003	Astra-G	C 18 YE (E100)	Engine	X	X	X	X	
BRAZIL	2003	Astra-G	C 20 NE/C 20 SE (8V)(E0/E20)	Engine	X	X	X	X	
BRAZIL	2003	Astra-G	C 20 SE/C 20 SEL(16V)(E0/E20)	Engine	X	X	X	X	
BRAZIL	2003	Astra-G	AF 13-II/17/20/22	Engine	X	X	X	X	
BRAZIL	2003	Astra-G	AF 13-II/17/20/22 CAN	Transmission	X	X	X	X	
BRAZIL	2003	Astra-G	ABS-5.3/5.4 (+TC)	Transmission	X	X	X	X	
BRAZIL	2003	Astra-G	Cruise Control	Chassis	X	X	X	X	
BRAZIL	2003	Astra-G	Electronic Power Steering	Chassis	X	X	X		
BRAZIL	2003	Astra-G	Immobiliser	Chassis	X	X	X		
BRAZIL	2003	Astra-G	Airbag	Body	X	X	X		
BRAZIL	2003	Astra-G	C 18 NE (E0/E20)	Body	X	X	X		
BRAZIL	2002	Astra-G	C 18 YE (E100)	Engine	X	X	X	X	
BRAZIL	2002	Astra-G	C 20 NE/C 20 SE (8V)(E0/E20)	Engine	X	X	X	X	
BRAZIL	2002	Astra-G	C 20 SE/C 20 SEL(16V)(E0/E20)	Engine	X	X	X	X	
BRAZIL	2002	Astra-G	AF 13-II/17/20/22	Engine	X	X	X	X	
BRAZIL	2002	Astra-G	ABS-5.3/5.4 (+TC)	Transmission	X	X	X	X	
BRAZIL	2002	Astra-G	Cruise Control	Chassis	X	X	X	X	
BRAZIL	2002	Astra-G	Electronic Power Steering	Chassis	X	X	X		
BRAZIL	2002	Astra-G	Immobiliser	Chassis	X	X	X		
BRAZIL	2002	Astra-G	Airbag	Body	X	X	X		
BRAZIL	2002	Astra-G	Airbag SAB6	Body	X	X	X		
BRAZIL	2002	Astra-G	C 18 NE (E0/E20)	Body	X	X	X		
BRAZIL	2001	Astra-G	C 18 YE (E100)	Engine	X	X	X	X	
BRAZIL	2001	Astra-G	C 20 NE/C 20 SE (8V)(E0/E20)	Engine	X	X	X	X	
BRAZIL	2001	Astra-G	C 20 SE/C 20 SEL(16V)(E0/E20)	Engine	X	X	X	X	

BRAZIL	2001	Astra-G	ABS-5.3/5.4 (+TC)	Engine	X	X	X	X	
BRAZIL	2001	Astra-G	Electronic Power Steering	Chassis	X	X	X	X	
BRAZIL	2001	Astra-G	Immobiliser	Chassis	X	X	X		
BRAZIL	2001	Astra-G	Airbag	Body	X	X	X		
BRAZIL	2001	Astra-G	Airbag SAB6	Body	X	X	X		
BRAZIL	2001	Astra-G	C 18 NE (E0/E20)	Body	X	X	X		
BRAZIL	2000	Astra-G	C 20 NE (E0/E20)	Engine	X	X	X	X	
BRAZIL	2000	Astra-G	C 20 SE (E0/20)	Engine	X	X	X	X	
BRAZIL	2000	Astra-G	ABS-5.3/5.4 (+TC)	Engine	X	X	X	X	
BRAZIL	2000	Astra-G	Electronic Power Steering	Chassis	X	X	X	X	
BRAZIL	2000	Astra-G	Immobiliser	Chassis	X	X	X		
BRAZIL	2000	Astra-G	Airbag	Body	X	X	X		
BRAZIL	2000	Astra-G	Airbag SAB6	Body	X	X	X		
BRAZIL	2000	Astra-G	C 18 NE (E0/E20)	Body	X	X	X		
BRAZIL	1999	Astra-G	C 20 NE (E0/E20)	Engine	X	X	X	X	
BRAZIL	1999	Astra-G	C 20 SE (E0/E20)	Engine	X	X	X	X	
BRAZIL	1999	Astra-G	ABS-5.3/5.4 (+TC)	Engine	X	X	X	X	
BRAZIL	1999	Astra-G	Immobiliser	Chassis	X	X	X	X	
BRAZIL	1999	Astra-G	Airbag SAB6	Body	X	X	X		
BRAZIL	1999	Astra-G	Immobiliser	Body	X	X	X		
BRAZIL	2009	Celta	Immobiliser	Body	X	X	X		
BRAZIL	2008	Celta	Immobiliser	Body	X	X	X		
BRAZIL	2007	Celta	Immobiliser	Body	X	X	X		
BRAZIL	2006	Celta	Immobiliser	Body	X	X	X		
BRAZIL	2005	Celta	Immobiliser	Body	X	X	X		
BRAZIL	2004	Celta	Immobiliser	Body	X	X	X		
BRAZIL	2003	Celta	Immobiliser	Body	X	X	X		
BRAZIL	2002	Celta	Immobiliser	Body	X	X	X		
BRAZIL	2001	Celta	Immobiliser	Body	X	X	X		
BRAZIL	2000	Celta	16 NE (E0/E20)	Body	X	X	X		
BRAZIL	2009	Corsa-B	C 16 NE (E0/E20)	Engine	X	X	X		
BRAZIL	2009	Corsa-B	AF 13II/20/22/30	Engine	X	X	X		
BRAZIL	2009	Corsa-B	ABS-5.3	Transmission	X	X	X		
BRAZIL	2009	Corsa-B	Immobiliser	Chassis	X	X	X		
BRAZIL	2009	Corsa-B	immobiliser-5bps	Body	X	X	X		
BRAZIL	2009	Corsa-B	Airbag-S	Body	X	X	X		
BRAZIL	2009	Corsa-B	16 NE (E0/E20)	Body	X	X	X		

BRAZIL	2008	Corsa-B	C 16 NE (E0/E20)	Engine	X	X	X		
BRAZIL	2008	Corsa-B	AF 13II/20/22/30	Engine	X	X	X		
BRAZIL	2008	Corsa-B	ABS-5.3	Transmission	X	X	X		
BRAZIL	2008	Corsa-B	Immobiliser	Chassis	X	X	X		
BRAZIL	2008	Corsa-B	immobiliser-5bps	Body	X	X	X		
BRAZIL	2008	Corsa-B	Airbag-S	Body	X	X	X		
BRAZIL	2008	Corsa-B	C 10 NE (E0/E20)	Body	X	X	X		
BRAZIL	2007	Corsa-B	C 10 YE (E100)	Engine	X	X	X		
BRAZIL	2007	Corsa-B	C 14 NE (E0/E20)	Engine	X	X	X		
BRAZIL	2007	Corsa-B	16 NE (E0/E20)	Engine	X	X	X		
BRAZIL	2007	Corsa-B	C 16 NE (E0/E20)	Engine	X	X	X		
BRAZIL	2007	Corsa-B	AF 13II/20/22/30	Engine	X	X	X		
BRAZIL	2007	Corsa-B	ABS-5.3	Transmission	X	X	X		
BRAZIL	2007	Corsa-B	Immobiliser	Chassis	X	X	X		
BRAZIL	2007	Corsa-B	immobiliser-5bps	Body	X	X	X		
BRAZIL	2007	Corsa-B	Airbag-S	Body	X	X	X		
BRAZIL	2007	Corsa-B	C 10 NE (E0/E20)	Body	X	X	X		
BRAZIL	2006	Corsa-B	C 10 YE (E100)	Engine	X	X	X		
BRAZIL	2006	Corsa-B	C 14 NE (E0/E20)	Engine	X	X	X		
BRAZIL	2006	Corsa-B	16 NE (E0/E20)	Engine	X	X	X		
BRAZIL	2006	Corsa-B	C 16 NE (E0/E20)	Engine	X	X	X		
BRAZIL	2006	Corsa-B	AF 13II/20/22/30	Engine	X	X	X		
BRAZIL	2006	Corsa-B	ABS-5.3	Transmission	X	X	X		
BRAZIL	2006	Corsa-B	Immobiliser	Chassis	X	X	X		
BRAZIL	2006	Corsa-B	immobiliser-5bps	Body	X	X	X		
BRAZIL	2006	Corsa-B	Airbag-S	Body	X	X	X		
BRAZIL	2006	Corsa-B	C 10 NE (E0/E20)	Body	X	X	X		
BRAZIL	2005	Corsa-B	C 10 YE (E100)	Engine	X	X	X		
BRAZIL	2005	Corsa-B	C 14 NE (E0/E20)	Engine	X	X	X		
BRAZIL	2005	Corsa-B	16 NE (E0/E20)	Engine	X	X	X		
BRAZIL	2005	Corsa-B	C 16 NE (E0/E20)	Engine	X	X	X		
BRAZIL	2005	Corsa-B	AF 13II/20/22/30	Engine	X	X	X		
BRAZIL	2005	Corsa-B	ABS-5.3	Transmission	X	X	X		
BRAZIL	2005	Corsa-B	Immobiliser	Chassis	X	X	X		
BRAZIL	2005	Corsa-B	Immobiliser-5bps	Body	X	X	X		
BRAZIL	2005	Corsa-B	Airbag-S	Body	X	X	X		
BRAZIL	2005	Corsa-B	C 10 NE (E0/E20)	Body	X	X	X		
BRAZIL	2004	Corsa-B	C 10 YE (E100)	Engine	X	X	X		
BRAZIL	2004	Corsa-B	C 14 NE (E0/E20)	Engine	X	X	X		
BRAZIL	2004	Corsa-B	16 NE (E0/E20)	Engine	X	X	X		
BRAZIL	2004	Corsa-B	C 16 NE (E0/E20)	Engine	X	X	X		
BRAZIL	2004	Corsa-B	AF 13II/20/22/30	Engine	X	X	X		
BRAZIL	2004	Corsa-B	ABS-5.3	Transmission	X	X	X		

BRAZIL	2004	Corsa-B	Immobiliser	Chassis	X	X	X		
BRAZIL	2004	Corsa-B	immobiliser-5bps	Body	X	X	X		
BRAZIL	2004	Corsa-B	Aribag-S	Body	X	X	X		
BRAZIL	2004	Corsa-B	C 10 NE (E0/E20)	Body	X	X	X		
BRAZIL	2003	Corsa-B	C 10 YE (E100)	Engine	X	X	X		
BRAZIL	2003	Corsa-B	C 14 NE (E0/E20)	Engine	X	X	X		
BRAZIL	2003	Corsa-B	16 NE (E0/E20)	Engine	X	X	X		
BRAZIL	2003	Corsa-B	C 16 NE (E0/E20)	Engine	X	X	X		
BRAZIL	2003	Corsa-B	AF 13II/20/22/30	Engine	X	X	X		
BRAZIL	2003	Corsa-B	ABS-5.3	Transmission	X	X	X		
BRAZIL	2003	Corsa-B	Immobiliser	Chassis	X	X	X		
BRAZIL	2003	Corsa-B	immobiliser-5bps	Body	X	X	X		
BRAZIL	2003	Corsa-B	Aribag-S	Body	X	X	X		
BRAZIL	2003	Corsa-B	C 10 NE (E0/E20)	Body	X	X	X		
BRAZIL	2002	Corsa-B	C 10 YE (E100)	Engine	X	X	X		
BRAZIL	2002	Corsa-B	C 14 NE (E0/E20)	Engine	X	X	X		
BRAZIL	2002	Corsa-B	16 NE (E0/E20)	Engine	X	X	X		
BRAZIL	2002	Corsa-B	C 16 NE (E0/E20)	Engine	X	X	X		
BRAZIL	2002	Corsa-B	AF 13II/20/22/30	Engine	X	X	X		
BRAZIL	2002	Corsa-B	ABS-5.3	Transmission	X	X	X		
BRAZIL	2002	Corsa-B	Immobiliser	Chassis	X	X	X		
BRAZIL	2002	Corsa-B	Aribag-S	Body	X	X	X		
BRAZIL	2002	Corsa-B	C 10 NE (E0/E20)	Body	X	X	X		
BRAZIL	2001	Corsa-B	C 10 YE (E100)	Engine	X	X	X		
BRAZIL	2001	Corsa-B	C 14 NE (E0/E20)	Engine	X	X	X		
BRAZIL	2001	Corsa-B	16 NE (E0/E20)	Engine	X	X	X		
BRAZIL	2001	Corsa-B	C 16 NE (E0/E20)	Engine	X	X	X		
BRAZIL	2001	Corsa-B	AF 13II/20/22/30	Engine	X	X	X		
BRAZIL	2001	Corsa-B	ABS-5.3	Transmission	X	X	X		
BRAZIL	2001	Corsa-B	Immobiliser	Chassis	X	X	X		
BRAZIL	2001	Corsa-B	Aribag-S	Body	X	X	X		
BRAZIL	2001	Corsa-B	C 10 NE (E0/E20)	Body	X	X	X		
BRAZIL	2000	Corsa-B	C 10 YE (E100)	Engine	X	X	X		
BRAZIL	2000	Corsa-B	C 14 NE (E0/E20)	Engine	X	X	X		
BRAZIL	2000	Corsa-B	16 NE (E0/E20)	Engine	X	X	X		
BRAZIL	2000	Corsa-B	C 16 NE (E0/E20)	Engine	X	X	X		
BRAZIL	2000	Corsa-B	AF 13II/20/22/30	Engine	X	X	X		
BRAZIL	2000	Corsa-B	ABS-5.3	Transmission	X	X	X		
BRAZIL	2000	Corsa-B	Immobiliser	Chassis	X	X	X		
BRAZIL	2000	Corsa-B	Aribag-S	Body	X	X	X		
BRAZIL	2000	Corsa-B	C 10 NE (E0/E20)	Body	X	X	X		
BRAZIL	1999	Corsa-B	C 10 YE (E100)	Engine	X	X	X		
BRAZIL	1999	Corsa-B	C 14 NE (E0/E20)	Engine	X	X	X		

BRAZIL	1999	Corsa-B	16 NE (E0/E20)	Engine	X	X	X		
BRAZIL	1999	Corsa-B	C 16 NE (E0/E20)	Engine	X	X	X		
BRAZIL	1999	Corsa-B	AF 13I/20/22/30	Engine	X	X	X		
BRAZIL	1999	Corsa-B	ABS-5.3	Transmission	X	X	X		
BRAZIL	1999	Corsa-B	Immobiliser	Chassis	X	X	X		
BRAZIL	1999	Corsa-B	Aribag-S	Body	X	X	X		
BRAZIL	1999	Corsa-B	C 18 NE (E0/E20)	Body	X	X	X		
BRAZIL	2009	Corsa-C	X 18 NE	Engine	X	X	X	X	
BRAZIL	2009	Corsa-C	X 18 XF (E20-E100)	Engine	X	X	X	X	
BRAZIL	2009	Corsa-C	X 18 XML	Engine	X	X	X	X	
BRAZIL	2009	Corsa-C	T 18 NE	Engine	X	X	X	X	
BRAZIL	2009	Corsa-C	MTA (Easytronic)	Engine	X	X	X	X	
BRAZIL	2009	Corsa-C	ABS-5.3/5.4 (+TC)	Transmission	X	X	X	X	
BRAZIL	2009	Corsa-C	Electronic Power Steering	Chassis	X	X	X	X	
BRAZIL	2009	Corsa-C	Body Control Module	Chassis	X	X	X		
BRAZIL	2009	Corsa-C	Immobiliser	Body	X	X	X	X	
BRAZIL	2009	Corsa-C	Immobiliser (without BCM)	Body	X	X	X		
BRAZIL	2009	Corsa-C	Airbag	Body	X	X	X		
BRAZIL	2009	Corsa-C	C 18 NE (E0/E20)	Body	X	X	X		
BRAZIL	2008	Corsa-C	X 18 NE	Engine	X	X	X	X	
BRAZIL	2008	Corsa-C	X 18 XF (E20-E100)	Engine	X	X	X	X	
BRAZIL	2008	Corsa-C	X 18 XML	Engine	X	X	X	X	
BRAZIL	2008	Corsa-C	T 18 NE	Engine	X	X	X	X	
BRAZIL	2008	Corsa-C	MTA (Easytronic)	Engine	X	X	X	X	
BRAZIL	2008	Corsa-C	ABS-5.3/5.4 (+TC)	Transmission	X	X	X	X	
BRAZIL	2008	Corsa-C	Electronic Power Steering	Chassis	X	X	X	X	
BRAZIL	2008	Corsa-C	Body Control Module	Chassis	X	X	X		
BRAZIL	2008	Corsa-C	Immobiliser	Body	X	X	X	X	
BRAZIL	2008	Corsa-C	Immobiliser (without BCM)	Body	X	X	X		
BRAZIL	2008	Corsa-C	Airbag	Body	X	X	X		
BRAZIL	2008	Corsa-C	C 18 NE (E0/E20)	Body	X	X	X		
BRAZIL	2007	Corsa-C	X 18 NE	Engine	X	X	X	X	

BRAZIL	2007	Corsa-C	X 18 XF (E20-E100)	Engine	X	X	X	X	
BRAZIL	2007	Corsa-C	X 18 XML	Engine	X	X	X	X	
BRAZIL	2007	Corsa-C	T 18 NE	Engine	X	X	X	X	
BRAZIL	2007	Corsa-C	MTA (Easytronic)	Engine	X	X	X	X	
BRAZIL	2007	Corsa-C	ABS-5.3/5.4 (+TC)	Transmission	X	X	X	X	
BRAZIL	2007	Corsa-C	Electronic Power Steering	Chassis	X	X	X	X	
BRAZIL	2007	Corsa-C	Body Control Module	Chassis	X	X	X		
BRAZIL	2007	Corsa-C	Immobiliser	Body	X	X	X	X	
BRAZIL	2007	Corsa-C	Immobiliser (without BCM)	Body	X	X	X		
BRAZIL	2007	Corsa-C	Airbag	Body	X	X	X		
BRAZIL	2007	Corsa-C	C 18 NE (E0/E20)	Body	X	X	X		
BRAZIL	2006	Corsa-C	X 18 NE	Engine	X	X	X	X	
BRAZIL	2006	Corsa-C	X 18 XF (E20-E100)	Engine	X	X	X	X	
BRAZIL	2006	Corsa-C	X 18 XML	Engine	X	X	X	X	
BRAZIL	2006	Corsa-C	T 18 NE	Engine	X	X	X	X	
BRAZIL	2006	Corsa-C	MTA (Easytronic)	Engine	X	X	X	X	
BRAZIL	2006	Corsa-C	ABS-5.3/5.4 (+TC)	Transmission	X	X	X	X	
BRAZIL	2006	Corsa-C	Electronic Power Steering	Chassis	X	X	X	X	
BRAZIL	2006	Corsa-C	Body Control Module	Chassis	X	X	X		
BRAZIL	2006	Corsa-C	Immobiliser	Body	X	X	X	X	
BRAZIL	2006	Corsa-C	Immobiliser (without BCM)	Body	X	X	X		
BRAZIL	2006	Corsa-C	Airbag	Body	X	X	X		
BRAZIL	2006	Corsa-C	C 18 NE (E0/E20)	Body	X	X	X		
BRAZIL	2005	Corsa-C	C 18 XE (E20-E100)	Engine	X	X	X	X	
BRAZIL	2005	Corsa-C	X 18 NE	Engine	X	X	X	X	
BRAZIL	2005	Corsa-C	X 18 XML	Engine	X	X	X	X	
BRAZIL	2005	Corsa-C	MTA (Easytronic)	Engine	X	X	X	X	
BRAZIL	2005	Corsa-C	ABS-5.3/5.4 (+TC)	Transmission	X	X	X	X	

BRAZIL	2005	Corsa-C	Electronic Power Steering	Chassis	X	X	X	X	
BRAZIL	2005	Corsa-C	Body Control Module	Chassis	X	X	X		
BRAZIL	2005	Corsa-C	Immobiliser	Body	X	X	X	X	
BRAZIL	2005	Corsa-C	Immobiliser (without BCM)	Body	X	X	X		
BRAZIL	2005	Corsa-C	Airbag	Body	X	X	X		
BRAZIL	2005	Corsa-C	C 18 NE (E0/E20)	Body	X	X	X		
BRAZIL	2004	Corsa-C	C 18 XE (E20-E100)	Engine	X	X	X	X	
BRAZIL	2004	Corsa-C	X 18 NE	Engine	X	X	X	X	
BRAZIL	2004	Corsa-C	MTA (Easytronic)	Engine	X	X	X	X	
BRAZIL	2004	Corsa-C	ABS-5.3/5.4 (+TC)	Transmission	X	X	X	X	
BRAZIL	2004	Corsa-C	Electronic Power Steering	Chassis	X	X	X	X	
BRAZIL	2004	Corsa-C	Body Control Module	Chassis	X	X	X		
BRAZIL	2004	Corsa-C	Immobiliser	Body	X	X	X	X	
BRAZIL	2004	Corsa-C	Immobiliser (without BCM)	Body	X	X	X		
BRAZIL	2004	Corsa-C	Airbag	Body	X	X	X		
BRAZIL	2004	Corsa-C	C 18 NE (E0/E20)	Body	X	X	X		
BRAZIL	2003	Corsa-C	ABS-5.3/5.4 (+TC)	Engine	X	X	X	X	
BRAZIL	2003	Corsa-C	Electronic Power Steering	Chassis	X	X	X	X	
BRAZIL	2003	Corsa-C	Body Control Module	Chassis	X	X	X		
BRAZIL	2003	Corsa-C	Immobiliser	Body	X	X	X	X	
BRAZIL	2003	Corsa-C	Airbag	Body	X	X	X		
BRAZIL	2003	Corsa-C	C 18 NE (E0/E20)	Body	X	X	X		
BRAZIL	2002	Corsa-C	ABS-5.3/5.4 (+TC)	Engine	X	X	X	X	
BRAZIL	2002	Corsa-C	Electronic Power Steering	Chassis	X	X	X	X	
BRAZIL	2002	Corsa-C	Body Control Module	Chassis	X	X	X		
BRAZIL	2002	Corsa-C	Immobiliser	Body	X	X	X	X	
BRAZIL	2002	Corsa-C	Airbag	Body	X	X	X		
BRAZIL	2002	Corsa-C	X 20 XE (E20-E100)	Body	X	X	X		

BRAZIL	2009	E-Lux	X 24 SFD (E20-E100)	Engine	X	X	X	X	
BRAZIL	2009	E-Lux	AF 13-II/17/20/22 CAN	Engine	X	X	X	X	
BRAZIL	2009	E-Lux	ABS-5.3/5.4 (+TC)	Transmission	X	X	X	X	
BRAZIL	2009	E-Lux	Electronic Power Steering	Chassis	X	X	X	X	
BRAZIL	2009	E-Lux	Immobiliser	Chassis	X	X	X		
BRAZIL	2009	E-Lux	X 20 XE (E20-E100)	Body	X	X	X		
BRAZIL	2008	E-Lux	X 24 SFD (E20-E100)	Engine	X	X	X	X	
BRAZIL	2008	E-Lux	AF 13-II/17/20/22 CAN	Engine	X	X	X	X	
BRAZIL	2008	E-Lux	ABS-5.3/5.4 (+TC)	Transmission	X	X	X	X	
BRAZIL	2008	E-Lux	Electronic Power Steering	Chassis	X	X	X	X	
BRAZIL	2008	E-Lux	Immobiliser	Chassis	X	X	X		
BRAZIL	2008	E-Lux	X 20 XE (E20-E100)	Body	X	X	X		
BRAZIL	2007	E-Lux	X 24 SFD (E20-E100)	Engine	X	X	X	X	
BRAZIL	2007	E-Lux	AF 13-II/17/20/22 CAN	Engine	X	X	X	X	
BRAZIL	2007	E-Lux	ABS-5.3/5.4 (+TC)	Transmission	X	X	X	X	
BRAZIL	2007	E-Lux	Electronic Power Steering	Chassis	X	X	X	X	
BRAZIL	2007	E-Lux	Immobiliser	Chassis	X	X	X		
BRAZIL	2007	E-Lux	X 20 XE (E20-E100)	Body	X	X	X		
BRAZIL	2006	E-Lux	X 24 SFD (E20-E100)	Engine	X	X	X	X	
BRAZIL	2006	E-Lux	AF 13-II/17/20/22 CAN	Engine	X	X	X	X	
BRAZIL	2006	E-Lux	ABS-5.3/5.4 (+TC)	Transmission	X	X	X	X	
BRAZIL	2006	E-Lux	Electronic Power Steering	Chassis	X	X	X	X	
BRAZIL	2006	E-Lux	Immobiliser	Chassis	X	X	X		
BRAZIL	2006	E-Lux	C 18 NE (E0/E20)	Body	X	X	X		

BRAZIL	2009	Meriva	X 18 XF (E20-E100)	Engine	X	X	X	X	
BRAZIL	2009	Meriva	T 18 NE	Engine	X	X	X	X	
BRAZIL	2009	Meriva	MTA (Easytronic)	Engine	X	X	X	X	
BRAZIL	2009	Meriva	ABS-5.3/5.4 (+TC)	Transmission	X	X	X	X	
BRAZIL	2009	Meriva	Electronic Power Steering	Chassis	X	X	X	X	
BRAZIL	2009	Meriva	Body Control Module	Chassis	X	X	X		
BRAZIL	2009	Meriva	Immobiliser	Body	X	X	X	X	
BRAZIL	2009	Meriva	Airbag	Body	X	X	X		
BRAZIL	2009	Meriva	C 18 NE (E0/E20)	Body	X	X	X		
BRAZIL	2008	Meriva	X 18 XF (E20-E100)	Engine	X	X	X	X	
BRAZIL	2008	Meriva	T 18 NE	Engine	X	X	X	X	
BRAZIL	2008	Meriva	MTA (Easytronic)	Engine	X	X	X	X	
BRAZIL	2008	Meriva	ABS-5.3/5.4 (+TC)	Transmission	X	X	X	X	
BRAZIL	2008	Meriva	Electronic Power Steering	Chassis	X	X	X	X	
BRAZIL	2008	Meriva	Body Control Module	Chassis	X	X	X		
BRAZIL	2008	Meriva	Immobiliser	Body	X	X	X	X	
BRAZIL	2008	Meriva	Airbag	Body	X	X	X		
BRAZIL	2008	Meriva	C 18 NE (E0/E20)	Body	X	X	X		
BRAZIL	2007	Meriva	X 18 XF (E20-E100)	Engine	X	X	X	X	
BRAZIL	2007	Meriva	T 18 NE	Engine	X	X	X	X	
BRAZIL	2007	Meriva	MTA (Easytronic)	Engine	X	X	X	X	
BRAZIL	2007	Meriva	ABS-5.3/5.4 (+TC)	Transmission	X	X	X	X	
BRAZIL	2007	Meriva	Electronic Power Steering	Chassis	X	X	X	X	
BRAZIL	2007	Meriva	Body Control Module	Chassis	X	X	X		
BRAZIL	2007	Meriva	Immobiliser	Body	X	X	X	X	
BRAZIL	2007	Meriva	Airbag	Body	X	X	X		
BRAZIL	2007	Meriva	C 18 NE (E0/E20)	Body	X	X	X		
BRAZIL	2006	Meriva	X 18 XF (E20-E100)	Engine	X	X	X	X	

BRAZIL	2006	Meriva	T 18 NE	Engine	X	X	X	X	
BRAZIL	2006	Meriva	MTA (Easytronic)	Engine	X	X	X	X	
BRAZIL	2006	Meriva	ABS-5.3/5.4 (+TC)	Transmission	X	X	X	X	
BRAZIL	2006	Meriva	Electronic Power Steering	Chassis	X	X	X	X	
BRAZIL	2006	Meriva	Body Control Module	Chassis	X	X	X		
BRAZIL	2006	Meriva	Immobiliser	Body	X	X	X	X	
BRAZIL	2006	Meriva	Airbag	Body	X	X	X		
BRAZIL	2006	Meriva	C 18 NE (E0/E20)	Body	X	X	X		
BRAZIL	2005	Meriva	C 18 SEL(E0/E20)	Engine	X	X	X	X	
BRAZIL	2005	Meriva	C 18 XE (E20-E100)	Engine	X	X	X	X	
BRAZIL	2005	Meriva	X 18 NE1	Engine	X	X	X	X	
BRAZIL	2005	Meriva	MTA (Easytronic)	Engine	X	X	X	X	
BRAZIL	2005	Meriva	ABS-5.3/5.4 (+TC)	Transmission	X	X	X	X	
BRAZIL	2005	Meriva	Electronic Power Steering	Chassis	X	X	X	X	
BRAZIL	2005	Meriva	Body Control Module	Chassis	X	X	X		
BRAZIL	2005	Meriva	Immobiliser	Body	X	X	X	X	
BRAZIL	2005	Meriva	Airbag	Body	X	X	X		
BRAZIL	2005	Meriva	C 18 NE (E0/E20)	Body	X	X	X		
BRAZIL	2004	Meriva	C 18 SEL(E0/E20)	Engine	X	X	X	X	
BRAZIL	2004	Meriva	C 18 XE (E20-E100)	Engine	X	X	X	X	
BRAZIL	2004	Meriva	X 18 NE1	Engine	X	X	X	X	
BRAZIL	2004	Meriva	MTA (Easytronic)	Engine	X	X	X	X	
BRAZIL	2004	Meriva	ABS-5.3/5.4 (+TC)	Transmission	X	X	X	X	
BRAZIL	2004	Meriva	Electronic Power Steering	Chassis	X	X	X	X	
BRAZIL	2004	Meriva	Body Control Module	Chassis	X	X	X		
BRAZIL	2004	Meriva	Immobiliser	Body	X	X	X	X	
BRAZIL	2004	Meriva	Airbag	Body	X	X	X		
BRAZIL	2004	Meriva	C 18 NE (E0/E20)	Body	X	X	X		

BRAZIL	2003	Meriva	C 18 SEL(E0/E20)	Engine	X	X	X	X	
BRAZIL	2003	Meriva	Body Control Module	Engine	X	X	X	X	
BRAZIL	2003	Meriva	Immobiliser	Body	X	X	X	X	
BRAZIL	2003	Meriva	Immobiliser	Body	X	X	X		
BRAZIL	2009	S-10 Truck/Blaze	immobiliser-5bps	Body	X	X	X		
BRAZIL	2009	S-10 Truck/Blaze	Immobiliser	Body	X	X	X		
BRAZIL	2008	S-10 Truck/Blaze	immobiliser-5bps	Body	X	X	X		
BRAZIL	2008	S-10 Truck/Blaze	Immobiliser	Body	X	X	X		
BRAZIL	2007	S-10 Truck/Blaze	immobiliser-5bps	Body	X	X	X		
BRAZIL	2007	S-10 Truck/Blaze	C 24 NE (E0/E20)	Body	X	X	X		
BRAZIL	2006	S-10 Truck/Blaze	Immobiliser	Engine	X	X	X		
BRAZIL	2006	S-10 Truck/Blaze	C 24 NE (E0/E20)	Body	X	X	X		
BRAZIL	2005	S-10 Truck/Blaze	Immobiliser	Engine	X	X	X		
BRAZIL	2005	S-10 Truck/Blaze	C 24 NE (E0/E20)	Body	X	X	X		
BRAZIL	2004	S-10 Truck/Blaze	Immobiliser	Engine	X	X	X		
BRAZIL	2004	S-10 Truck/Blaze	C 24 NE (E0/E20)	Body	X	X	X		

BRAZIL	2003	S-10 Truck/Blaze	Immobiliser	Engine	X	X	X		
BRAZIL	2003	S-10 Truck/Blaze	C 24 NE (E0/E20)	Body	X	X	X		
BRAZIL	2002	S-10 Truck/Blaze	Immobiliser	Engine	X	X	X		
BRAZIL	2002	S-10 Truck/Blaze	C 24 NE (E0/E20)	Body	X	X	X		
BRAZIL	2001	S-10 Truck/Blaze	Immobiliser	Engine	X	X	X		
BRAZIL	2001	S-10 Truck/Blaze	B 22 NZ (E0/E20)	Body	X	X	X		
BRAZIL	2000	S-10 Truck/Blaze	C 22 NE (E0/E20)	Engine	X	X	X		
BRAZIL	2000	S-10 Truck/Blaze	B 22 NZ (E0/E20)	Engine	X	X	X		
BRAZIL	1999	S-10 Truck/Blaze	C 22 NE (E0/E20)	Engine	X	X	X		
BRAZIL	1999	S-10 Truck/Blaze	C 41 GE (E0/E22)	Engine	X	X	X		
BRAZIL	2003	Silverado/G rand Blazer	C 41 GE (E0/E22)	Engine	X	X	X		
BRAZIL	2002	Silverado/G rand Blazer	C 41 GE (E0/E22)	Engine	X	X	X		
BRAZIL	2001	Silverado/G rand Blazer	C 41 GE (E0/E22)	Engine	X	X	X		
BRAZIL	2000	Silverado/G rand Blazer	C 41 GE (E0/E22)	Engine	X	X	X		

BRAZIL	1999	Silverado/G rand Blazer	ABS-5.3	Engine	X	X	X		
BRAZIL	2000	Tigra	Immobiliser	Chassis	X	X	X		
BRAZIL	2000	Tigra	Airbag-S	Body	X	X	X		
BRAZIL	2000	Tigra	Airbag SAB6	Body	X	X	X		
BRAZIL	2000	Tigra	ABS-5.3	Body	X	X	X		
BRAZIL	1999	Tigra	Immobiliser	Chassis	X	X	X		
BRAZIL	1999	Tigra	Airbag-S	Body	X	X	X		
BRAZIL	1999	Tigra	Airbag SAB6	Body	X	X	X		
BRAZIL	1999	Tigra	ABS-5.3	Body	X	X	X		
BRAZIL	1998	Tigra	Immobiliser	Chassis	X	X	X		
BRAZIL	1998	Tigra	Airbag-S	Body	X	X	X		
BRAZIL	1998	Tigra	ABS	Body	X	X	X		
BRAZIL	2009	Tracker	ABS	Chassis	X	X	X		
BRAZIL	2008	Tracker	ABS	Chassis	X	X	X		
BRAZIL	2007	Tracker	ABS	Chassis	X	X	X		
BRAZIL	2006	Tracker	ABS	Chassis	X	X	X		
BRAZIL	2005	Tracker	ABS	Chassis	X	X	X		
BRAZIL	2004	Tracker	ABS	Chassis	X	X	X		
BRAZIL	2003	Tracker	ABS	Chassis	X	X	X		
BRAZIL	2002	Tracker	ABS	Chassis	X	X	X		
BRAZIL	2001	Tracker	C 20 NE (E0/E20)	Chassis	X	X	X		
BRAZIL	2005	Vectra-B	C 22 NE (E0/E20)	Engine	X	X	X		
BRAZIL	2005	Vectra-B	C 22 SE (E0/E20)	Engine	X	X	X		
BRAZIL	2005	Vectra-B	AF 13II/20/22/30	Engine	X	X	X		
BRAZIL	2005	Vectra-B	ABS 430	Transmission	X	X	X		
BRAZIL	2005	Vectra-B	ABS-5.3	Chassis	X	X	X		
BRAZIL	2005	Vectra-B	ABS-5.3/5.4 (+TC)	Chassis	X	X	X		
BRAZIL	2005	Vectra-B	Cruise Control	Chassis	X	X	X	X	
BRAZIL	2005	Vectra-B	immobiliser	Chassis	X	X	X		
BRAZIL	2005	Vectra-B	Airbag	Body	X	X	X		
BRAZIL	2005	Vectra-B	C 20 NE (E0/E20)	Body	X	X	X		
BRAZIL	2004	Vectra-B	C 22 NE (E0/E20)	Engine	X	X	X		
BRAZIL	2004	Vectra-B	C 22 SE (E0/E20)	Engine	X	X	X		
BRAZIL	2004	Vectra-B	AF 13II/20/22/30	Engine	X	X	X		
BRAZIL	2004	Vectra-B	ABS 430	Transmission	X	X	X		
BRAZIL	2004	Vectra-B	ABS-5.3	Chassis	X	X	X		
BRAZIL	2004	Vectra-B	ABS-5.3/5.4 (+TC)	Chassis	X	X	X		
BRAZIL	2004	Vectra-B	Cruise Control	Chassis	X	X	X	X	
BRAZIL	2004	Vectra-B	immobiliser	Chassis	X	X	X		
BRAZIL	2004	Vectra-B	Airbag	Body	X	X	X		

BRAZIL	2004	Vectra-B	C 20 NE (E0/E20)	Body	X	X	X		
BRAZIL	2003	Vectra-B	C 22 NE (E0/E20)	Engine	X	X	X		
BRAZIL	2003	Vectra-B	C 22 SE (E0/E20)	Engine	X	X	X		
BRAZIL	2003	Vectra-B	AF 13II/20/22/30	Engine	X	X	X		
BRAZIL	2003	Vectra-B	ABS 430	Transmission	X	X	X		
BRAZIL	2003	Vectra-B	ABS-5.3	Chassis	X	X	X		
BRAZIL	2003	Vectra-B	ABS-5.3/5.4 (+TC)	Chassis	X	X	X		
BRAZIL	2003	Vectra-B	Cruise Control	Chassis	X	X	X	X	
BRAZIL	2003	Vectra-B	Immobiliser	Chassis	X	X	X		
BRAZIL	2003	Vectra-B	Airbag	Body	X	X	X		
BRAZIL	2003	Vectra-B	C 22 NE (E0/E20)	Body	X	X	X		
BRAZIL	2002	Vectra-B	C 22 SE (E0/E20)	Engine	X	X	X		
BRAZIL	2002	Vectra-B	AF 13II/20/22/30	Engine	X	X	X		
BRAZIL	2002	Vectra-B	ABS 430	Transmission	X	X	X		
BRAZIL	2002	Vectra-B	ABS-5.3	Chassis	X	X	X		
BRAZIL	2002	Vectra-B	ABS-5.3/5.4 (+TC)	Chassis	X	X	X		
BRAZIL	2002	Vectra-B	Cruise Control	Chassis	X	X	X	X	
BRAZIL	2002	Vectra-B	immobiliser	Chassis	X	X	X		
BRAZIL	2002	Vectra-B	Airbag	Body	X	X	X		
BRAZIL	2002	Vectra-B	C 22 NE (E0/E20)	Body	X	X	X		
BRAZIL	2001	Vectra-B	C 22 SE (E0/E20)	Engine	X	X	X		
BRAZIL	2001	Vectra-B	AF 13II/20/22/30	Engine	X	X	X		
BRAZIL	2001	Vectra-B	ABS 430	Transmission	X	X	X		
BRAZIL	2001	Vectra-B	ABS-5.3	Chassis	X	X	X		
BRAZIL	2001	Vectra-B	ABS-5.3/5.4 (+TC)	Chassis	X	X	X		
BRAZIL	2001	Vectra-B	Cruise Control	Chassis	X	X	X	X	
BRAZIL	2001	Vectra-B	immobiliser	Chassis	X	X	X		
BRAZIL	2001	Vectra-B	Airbag	Body	X	X	X		
BRAZIL	2001	Vectra-B	C 22 NE (E0/E20)	Body	X	X	X		
BRAZIL	2000	Vectra-B	C 22 SE (E0/E20)	Engine	X	X	X		
BRAZIL	2000	Vectra-B	AF 13II/20/22/30	Engine	X	X	X		
BRAZIL	2000	Vectra-B	ABS 430	Transmission	X	X	X		
BRAZIL	2000	Vectra-B	ABS-5.3	Chassis	X	X	X		
BRAZIL	2000	Vectra-B	ABS-5.3/5.4 (+TC)	Chassis	X	X	X		
BRAZIL	2000	Vectra-B	Cruise Control	Chassis	X	X	X	X	
BRAZIL	2000	Vectra-B	immobiliser	Chassis	X	X	X		
BRAZIL	2000	Vectra-B	Airbag	Body	X	X	X		
BRAZIL	2000	Vectra-B	C 22 NE (E0/E20)	Body	X	X	X		
BRAZIL	1999	Vectra-B	C 22 SE (E0/E20)	Engine	X	X	X		
BRAZIL	1999	Vectra-B	AF 13II/20/22/30	Engine	X	X	X		

BRAZIL	1999	Vectra-B	ABS 415	Transmission	X	X	X		
BRAZIL	1999	Vectra-B	ABS-5-TC	Chassis	X	X	X		
BRAZIL	1999	Vectra-B	ABS-5.3	Chassis	X	X	X		
BRAZIL	1999	Vectra-B	Cruise Control	Chassis	X	X	X		
BRAZIL	1999	Vectra-B	immobiliser	Chassis	X	X	X		
BRAZIL	1999	Vectra-B	Airbag	Body	X	X	X		
BRAZIL	1999	Vectra-B	C 20 NE (E0/E20)	Body	X	X	X		
BRAZIL	1998	Vectra-B	C 20 SEL (E0/E20)	Engine	X	X	X		
BRAZIL	1998	Vectra-B	C 22 NE (E0/E20)	Engine	X	X	X		
BRAZIL	1998	Vectra-B	C 22 SE (E0/E20)	Engine	X	X	X		
BRAZIL	1998	Vectra-B	AF 13II/20/22/30	Engine	X	X	X		
BRAZIL	1998	Vectra-B	ABS 415	Transmission	X	X	X		
BRAZIL	1998	Vectra-B	ABS-5-TC	Chassis	X	X	X		
BRAZIL	1998	Vectra-B	ABS-5.3	Chassis	X	X	X		
BRAZIL	1998	Vectra-B	Cruise Control	Chassis	X	X	X		
BRAZIL	1998	Vectra-B	immobiliser	Chassis	X	X	X		
BRAZIL	1998	Vectra-B	Airbag	Body	X	X	X		
BRAZIL	1998	Vectra-B	C 20 SE (8V) (E0/E20)	Body	X	X	X		
BRAZIL	2009	Zafira	C 20 SEL(16V) (E0/E20)	Engine	X	X	X	X	
BRAZIL	2009	Zafira	AF 13-II/17/20/22	Engine	X	X	X	X	
BRAZIL	2009	Zafira	AF 13-II/17/20/22 CAN	Transmission	X	X	X	X	
BRAZIL	2009	Zafira	ABS-5.3/5.4 (+TC)	Transmission	X	X	X	X	
BRAZIL	2009	Zafira	Cruise Control	Chassis	X	X	X	X	
BRAZIL	2009	Zafira	Immobiliser	Chassis	X	X	X		
BRAZIL	2009	Zafira	Airbag	Body	X	X	X		
BRAZIL	2009	Zafira	C 20 SE (8V) (E0/E20)	Body	X	X	X		
BRAZIL	2008	Zafira	C 20 SEL(16V) (E0/E20)	Engine	X	X	X	X	
BRAZIL	2008	Zafira	AF 13-II/17/20/22	Engine	X	X	X	X	
BRAZIL	2008	Zafira	AF 13-II/17/20/22 CAN	Transmission	X	X	X	X	
BRAZIL	2008	Zafira	ABS-5.3/5.4 (+TC)	Transmission	X	X	X	X	
BRAZIL	2008	Zafira	Cruise Control	Chassis	X	X	X	X	
BRAZIL	2008	Zafira	Immobiliser	Chassis	X	X	X		
BRAZIL	2008	Zafira	Airbag	Body	X	X	X		
BRAZIL	2008	Zafira	C 20 SE (8V) (E0/E20)	Body	X	X	X		

BRAZIL	2007	Zafira	C 20 SEL(16V) (E0/E20)	Engine	X	X	X	X	
BRAZIL	2007	Zafira	AF 13-II/17/20/22	Engine	X	X	X	X	
BRAZIL	2007	Zafira	AF 13-II/17/20/22 CAN	Transmission	X	X	X	X	
BRAZIL	2007	Zafira	ABS-5.3/5.4 (+TC)	Transmission	X	X	X	X	
BRAZIL	2007	Zafira	Cruise Control	Chassis	X	X	X	X	
BRAZIL	2007	Zafira	Immobiliser	Chassis	X	X	X		
BRAZIL	2007	Zafira	Airbag	Body	X	X	X		
BRAZIL	2007	Zafira	C 20 SE (8V) (E0/E20)	Body	X	X	X		
BRAZIL	2006	Zafira	C 20 SEL(16V) (E0/E20)	Engine	X	X	X	X	
BRAZIL	2006	Zafira	AF 13-II/17/20/22	Engine	X	X	X	X	
BRAZIL	2006	Zafira	AF 13-II/17/20/22 CAN	Transmission	X	X	X	X	
BRAZIL	2006	Zafira	ABS-5.3/5.4 (+TC)	Transmission	X	X	X	X	
BRAZIL	2006	Zafira	Cruise Control	Chassis	X	X	X	X	
BRAZIL	2006	Zafira	Immobiliser	Chassis	X	X	X		
BRAZIL	2006	Zafira	Airbag	Body	X	X	X		
BRAZIL	2006	Zafira	C 20 SE (8V) (E0/E20)	Body	X	X	X		
BRAZIL	2005	Zafira	C 20 SEL(16V) (E0/E20)	Engine	X	X	X	X	
BRAZIL	2005	Zafira	AF 13-II/17/20/22	Engine	X	X	X	X	
BRAZIL	2005	Zafira	AF 13-II/17/20/22 CAN	Transmission	X	X	X	X	
BRAZIL	2005	Zafira	ABS-5.3/5.4 (+TC)	Transmission	X	X	X	X	
BRAZIL	2005	Zafira	Cruise Control	Chassis	X	X	X	X	
BRAZIL	2005	Zafira	Immobiliser	Chassis	X	X	X		
BRAZIL	2005	Zafira	Airbag	Body	X	X	X		
BRAZIL	2005	Zafira	C 20 SE (8V) (E0/E20)	Body	X	X	X		
BRAZIL	2004	Zafira	C 20 SEL(16V)(E0/E20)	Engine	X	X	X	X	
BRAZIL	2004	Zafira	AF 13-II/17/20/22	Engine	X	X	X	X	
BRAZIL	2004	Zafira	AF 13-II/17/20/22 CAN	Transmission	X	X	X	X	
BRAZIL	2004	Zafira	ABS-5.3/5.4 (+TC)	Transmission	X	X	X	X	

BRAZIL	2004	Zafira	Cruise Control	Chassis	X	X	X	X	
BRAZIL	2004	Zafira	Immobiliser	Chassis	X	X	X		
BRAZIL	2004	Zafira	Airbag	Body	X	X	X		
BRAZIL	2004	Zafira	C 20 SE (8V) (E0/E20)	Body	X	X	X		
BRAZIL	2003	Zafira	C 20 SEL(16V) (E0/E20)	Engine	X	X	X	X	
BRAZIL	2003	Zafira	AF 13-II/17/20/22	Engine	X	X	X	X	
BRAZIL	2003	Zafira	ABS-5.3/5.4 (+TC)	Transmission	X	X	X	X	
BRAZIL	2003	Zafira	Cruise Control	Chassis	X	X	X	X	
BRAZIL	2003	Zafira	Electronic Power Steering	Chassis	X	X	X		
BRAZIL	2003	Zafira	Immobiliser	Chassis	X	X	X		
BRAZIL	2003	Zafira	Airbag	Body	X	X	X		
BRAZIL	2003	Zafira	C 20 SE (8V) (E0/E20)	Body	X	X	X		
BRAZIL	2002	Zafira	C 20 SEL(16V) (E0/E20)	Engine	X	X	X	X	
BRAZIL	2002	Zafira	AF 13-II/17/20/22	Engine	X	X	X	X	
BRAZIL	2002	Zafira	ABS-5.3/5.4 (+TC)	Transmission	X	X	X	X	
BRAZIL	2002	Zafira	Cruise Control	Chassis	X	X	X	X	
BRAZIL	2002	Zafira	Electronic Power Steering	Chassis	X	X	X		
BRAZIL	2002	Zafira	Immobiliser	Chassis	X	X	X		
BRAZIL	2002	Zafira	Airbag	Body	X	X	X		
BRAZIL	2002	Zafira	C 20 SE (8V) (E0/E20)	Body	X	X	X		
BRAZIL	2001	Zafira	C 20 SEL(16V) (E0/E20)	Engine	X	X	X	X	
BRAZIL	2001	Zafira	ABS-5.3/5.4 (+TC)	Engine	X	X	X	X	
BRAZIL	2001	Zafira	Electronic Power Steering	Chassis	X	X	X	X	
BRAZIL	2001	Zafira	Immobiliser	Chassis	X	X	X		
BRAZIL	2001	Zafira	Airbag	Body	X	X	X		
BRAZIL	2001	Zafira	Airbag	Body	X	X	X		
EUROPE	2001	Vivaro		Body	X	X	X		