

Note X: Covered *: New update

BMW V10.0								
Model Information				Diagnostic Function				
Market	Year	Model	System	ECU Info.	DTC	Data List	Active Test	Special Func.
All	2004-2010	1 Series_E87	CAS Car Access System	X	X	X	X	
All	2004-2010	1 Series_E87	DME/DDE Motor Electronics	X	X	X	X	
All	2004-2010	1 Series_E87	EGS transmission control	X	X	X	X	
All	2004-2010	1 Series_E87	EKP Fuel pump	X	X	X	X	
All	2004-2010	1 Series_E87	AL active steering	X	X	X	X	
All	2004-2010	1 Series_E87	ARS Dynamic Drive 2	X	X	X	X	
All	2004-2010	1 Series_E87	DSC Dynamic Stability Control	X	X	X	X	
All	2004-2010	1 Series_E87	RAD2-BO User interface	X	X	X	X	
All	2004-2010	1 Series_E87	RAD2-GW Gateway	X	X	X		
All	2004-2010	1 Series_E87	CDC CD Changer	X	X	X		
All	2004-2010	1 Series_E87	CID Central Information Display	X	X	X	X	
All	2004-2010	1 Series_E87	CON Controller	X	X	X	X	
All	2004-2010	1 Series_E87	DWA anti-theft alarm system	X	X	X	X	
All	2004-2010	1 Series_E87	SINE Siren with tilt sensor	X	X	X	X	
All	2004-2010	1 Series_E87	FRM/FRM2 Footwell module	X	X	X	X	
All	2004-2010	1 Series_E87	FZD Function centre,roof	X	X	X	X	
All	2004-2010	1 Series_E87	IHKA Integrated automatic heating/air conditioning	X	X	X	X	
All	2004-2010	1 Series_E87	JBE Junction-box electronics	X	X	X	X	
All	2004-2010	1 Series_E87	INSTR Instrument cluster	X	X	X	X	
All	2004-2010	1 Series_E87	M-ASK-NAV Navigation system	X	X	X	X	
All	2004-2010	1 Series_E87	MRS Multiple Restraint System	X	X	X		
All	2004-2010	1 Series_E87	PDC Park Distance Control	X	X	X	X	
All	2004-2010	1 Series_E87	RLSS Solar Rain/Light Sensor	X	X	X	X	
All	2004-2010	1 Series_E87	SMFA Seat module,driver	X	X	X	X	
All	2004-2010	1 Series_E87	SMBF Seat module,passenger	X	X	X	X	
All	2004-2010	1 Series_E87	TCU Telematic control unit	X	X	X	X	
All	2004-2010	1 Series_E87	SHD Sliding/tilting sunroof	X	X	X	X	
All	2004-2010	1 Series_E87	MOST-system analysis	X				
All	2004-2010	1 Series_E87	CAN /byteflight	X	X			
All	2004-2010	1 Series_E87	Maintenance\CBS reset					1 Engine oil X
All	2004-2010	1 Series_E87						2 Microfilter X
All	2004-2010	1 Series_E87						3 Front brake X
All	2004-2010	1 Series_E87						4 Rear brake X
All	2004-2010	1 Series_E87						5 Diesel filter X
All	2004-2010	1 Series_E87						6 Spark plugs X

All	2004-2010	1 Series_E87						8 Brake fluid X
All	2004-2010	1 Series_E87						9 Vehicle check X
All	2004-2010	1 Series_E87						10 Vehicle inspection: X
All	2004-2010	1 Series_E87						11 Exhaust emission inspection: X
All	2004-2010	1 Series_E87	Maintenance\Delete transport mode					Delete transport mode X
All	2004-2010	1 Series_E87	Drive\Digital Motor Electronics					Learning Valvetronic limit positions X
All	2004-2010	1 Series_E87	Drive\Diesel Electronics					Injector rate matching
All	2004-2010	1 Series_E87	Chassis\Wheel-slip control system					Adjustment,steering-angle sensor X
All	2004-2010	1 Series_E87	Body\IHKA Integrated automatic heating/air conditioning					Run-in protection for A/C compressor X
All	1988-1990	3 Series_E30	DME/DDE (Motor/Diesel Electronics)	X	X	X	X	
All	1988-1990	3 Series_E30	EML Electronic engine-power control	X	X			
All	1988-1990	3 Series_E30	EGS transmission control	X	X	X	X	
All	1988-1990	3 Series_E30	EWS Vehicle immobilizer	X	X	X		
All	1988-1990	3 Series_E30	GR Cruise control	X	X			
All	1988-1990	3 Series_E30	ABS/ASC/DSC (Dynamic Stability Control)	X	X	X	X	
All	1988-1990	3 Series_E30	LEW/LWS (Steering angle sensor)	X	X	X		
All	1988-1990	3 Series_E30	EDC Electroic Damper Control	X	X	X	X	
All	1988-1990	3 Series_E30	RDC/RDW Tyre pressure check	X	X			
All	1988-1990	3 Series_E30	EPS Electronic Power Steering	X	X	X		
All	1988-1990	3 Series_E30	MFL Multi-function steering wheel	X		X		
All	1988-1990	3 Series_E30	SVT Servotronic	X				
All	1988-1990	3 Series_E30	ZKE/GM (Central body electronics/GM base module)	X	X	X	X	
All	1988-1990	3 Series_E30	MRS/AirBag/SIM (Multiple Restraint System)	X	X			
All	1988-1990	3 Series_E30	IHKA/IHKB Integrated heating/air conditioning	X	X	X	X	
All	1988-1990	3 Series_E30	KOM/IKE/IKI/INSTR(Instrument cluster)	X	X	X	X	
All	1988-1990	3 Series_E30	LSZ/LCM (Lights switching center)	X	X	X	X	
All	1988-1990	3 Series_E30	LRA Automatic headlight vertical aim control	X	X			
All	1988-1990	3 Series_E30	CVM Convertible top module	X	X	X		
All	1988-1990	3 Series_E30	PDC Park Distance Control	X	X	X	X	
All	1988-1990	3 Series_E30	NAV Navigation computer	X	X	X		
All	1988-1990	3 Series_E30	SHD Sliding/titing sunroof	X	X			
All	1988-1990	3 Series_E30	SMF/SM/SLM (Seat memory,driver)	X	X	X	X	
All	1988-1990	3 Series_E30	MID Multi Information Display	X	X			
All	1988-1990	3 Series_E30	SZM Switching center,center console	X	X	X		
All	1988-1990	3 Series_E30	RLS/AIC (Rain/Light Sensor/Automatic interval Control)	X	X	X		
All	1988-1990	3 Series_E30	TCU/ULF/TEL/BIT (Telematic Control unit)	X	X			
All	1988-1990	3 Series_E30	BM/MIR (On-board monitor/Multi-Information Radio)	X	X	X	X	
All	1988-1990	3 Series_E30	VID Video module	X	X			
All	1988-1990	3 Series_E30	RAD Radio	X	X	X	X	
All	1988-1990	3 Series_E30	STH park heating	X				
All	1988-1990	3 Series_E30	DSP Digital Sound Processor	X				
All	1988-1990	3 Series_E30	SES Language-input system	X	X		X	

All	1988-1990	3 Series_E30	Digital Motor Electronics					1.Clear adaptations X
All	1988-1990	3 Series_E30						2.CO adjustment X
All	1988-1990	3 Series_E30	EGS transmission control					Clear adaptations X
All	1988-1990	3 Series_E30	Wheel-slip control system					Adjustment,steering-angle sensor X
All	1988-1990	3 Series_E30	Instrument cluster					Reset service interval indicator X
All	1988-1990	3 Series_E30	Light Check Module					Read out operating data X
All	1991-1998	3 Series_E36(With Z3)	DME/DDE (Motor/Diesel Electronics)	X	X	X	X	
All	1991-1998	3 Series_E36(With Z3)	EML Electronic engine-power control	X	X			
All	1991-1998	3 Series_E36(With Z3)	EGS transmission control	X	X	X	X	
All	1991-1998	3 Series_E36(With Z3)	EWS Vehicle immobilizer	X	X	X		
All	1991-1998	3 Series_E36(With Z3)	GR Cruise control	X	X			
All	1991-1998	3 Series_E36(With Z3)	ABS/ASC/DSC (Dynamic Stability Control)	X	X	X	X	
All	1991-1998	3 Series_E36(With Z3)	LEW/LWS (Steering angle sensor)	X	X	X		
All	1991-1998	3 Series_E36(With Z3)	EDC Electroic Damper Control	X	X	X	X	
All	1991-1998	3 Series_E36(With Z3)	RDC/RDW Tyre pressure check	X	X			
All	1991-1998	3 Series_E36(With Z3)	EPS Electronic Power Steering	X	X	X		
All	1991-1998	3 Series_E36(With Z3)	MFL Multi-function steering wheel	X		X		
All	1991-1998	3 Series_E36(With Z3)	SVT Servotronic	X				
All	1991-1998	3 Series_E36(With Z3)	ZKE/GM (Central body electronics/GM base module)	X	X	X	X	
All	1991-1998	3 Series_E36(With Z3)	MRS/AirBag/SIM (Multiple Restraint System)	X	X			
All	1991-1998	3 Series_E36(With Z3)	IHKA/IHKB Integrated heating/air conditioning	X	X	X	X	
All	1991-1998	3 Series_E36(With Z3)	KOM/IKE/IKI/INSTR(Instrument cluster)	X	X	X	X	
All	1991-1998	3 Series_E36(With Z3)	LSZ/LCM (Lights switching center)	X	X	X	X	
All	1991-1998	3 Series_E36(With Z3)	LRA Automatic headlight vertical aim control	X	X			
All	1991-1998	3 Series_E36(With Z3)	CVM Convertible top module	X	X	X		

All	1991-1998	3 Series_E36(With Z3)	PDC Park Distance Control	X	X	X	X	
All	1991-1998	3 Series_E36(With Z3)	NAV Navigation computer	X	X	X		
All	1991-1998	3 Series_E36(With Z3)	SHD Sliding/tilting sunroof	X	X			
All	1991-1998	3 Series_E36(With Z3)	SMF/SM/SLM (Seat memory,driver)	X	X	X	X	
All	1991-1998	3 Series_E36(With Z3)	MID Multi Information Display	X	X			
All	1991-1998	3 Series_E36(With Z3)	SZM Switching center,center console	X	X	X		
All	1991-1998	3 Series_E36(With Z3)	RLS/AIC (Rain/Light Sensor/Automatic interval Control)	X	X	X		
All	1991-1998	3 Series_E36(With Z3)	TCU/ULF/TEL/BIT (Telematic Control unit)	X	X			
All	1991-1998	3 Series_E36(With Z3)	BM/MIR (On-board monitor/Multi-Information Radio)	X	X	X	X	
All	1991-1998	3 Series_E36(With Z3)	VID Video module	X	X			
All	1991-1998	3 Series_E36(With Z3)	RAD Radio	X	X	X	X	
All	1991-1998	3 Series_E36(With Z3)	STH park heating	X				
All	1991-1998	3 Series_E36(With Z3)	DSP Digital Sound Processor	X				
All	1991-1998	3 Series_E36(With Z3)	SES Language-input system	X	X		X	
All	1991-1998	3 Series_E36(With Z3)	Digital Motor Electronics					1.Clear adaptations X
All	1991-1998	3 Series_E36(With Z3)						2.CO adjustment X
All	1991-1998	3 Series_E36(With Z3)	EGS transmission control					Clear adaptations X
All	1991-1998	3 Series_E36(With Z3)	Wheel-slip control system					Adjustment,steering-angle sensor X
All	1991-1998	3 Series_E36(With Z3)	Instrument cluster					Reset service interval indicator X
All	1991-1998	3 Series_E36(With Z3)	Light Check Module					Read out operating data X
All	1999-2006	3 Series_E46	DME/DDE (Motor/Diesel Electronics)	X	X	X	X	
All	1999-2006	3 Series_E46	EML Electronic engine-power control	X	X			
All	1999-2006	3 Series_E46	EGS transmission control	X	X	X	X	
All	1999-2006	3 Series_E46	EWS Vehicle immobilizer	X	X	X		

All	1999-2006	3 Series_E46	GR Cruise control	X	X			
All	1999-2006	3 Series_E46	ABS/ASC/DSC (Dynamic Stability Control)	X	X	X	X	
All	1999-2006	3 Series_E46	EDC Electronic Damper Control	X	X	X	X	
All	1999-2006	3 Series_E46	EHC/EHC2 (Electronic ride-level control)	X	X	X	X	
All	1999-2006	3 Series_E46	LEW/LWS (Steering angle sensor)	X	X	X		
All	1999-2006	3 Series_E46	MFL Multi-function steering wheel	X		X		
All	1999-2006	3 Series_E46	ZKE/GM (Central body electronics/GM base module)	X	X	X	X	
All	1999-2006	3 Series_E46	IHKA/IHKB Integrated heating/air conditioning	X	X	X	X	
All	1999-2006	3 Series_E46	MRS/AirBag (Multiple Restraint System)	X	X			
All	1999-2006	3 Series_E46	KOM/IKE/IKI/INSTR(Instrument cluster)	X	X	X	X	
All	1999-2006	3 Series_E46	LSZ/LCM (Lights switching center)	X	X	X	X	
All	1999-2006	3 Series_E46	PDC Park Distance Control	X	X	X	X	
All	1999-2006	3 Series_E46	FID Read-compartment information display	X	X			
All	1999-2006	3 Series_E46	NAV Navigation computer	X	X	X		
All	1999-2006	3 Series_E46	BM/MIR (On-board monitor/Multi-Information Radio)	X	X	X	X	
All	1999-2006	3 Series_E46	SZM Switching center,center console	X	X	X		
All	1999-2006	3 Series_E46	SMF/SM/SLM (Seat memory ,driver)	X	X	X	X	
All	1999-2006	3 Series_E46	SPMFT Mirror memory,driver	X	X	X	X	
All	1999-2006	3 Series_E46	SPMBT Mirror memory,passenger	X	X	X	X	
All	1999-2006	3 Series_E46	RAD Radio	X	X	X	X	
All	1999-2006	3 Series_E46	SES Language-input system	X	X		X	
All	1999-2006	3 Series_E46	SHD Sliding/tilting sunroof	X	X			
All	1999-2006	3 Series_E46	TCU/ULF/TEL/BIT (Telematic Control unit)	X	X			
All	1999-2006	3 Series_E46	VID Video module	X	X			
All	1999-2006	3 Series_E46	RLS Rain/Light Sensor	X	X	X		
All	1999-2006	3 Series_E46	CVM Convertible-top module	X	X	X		
All	1999-2006	3 Series_E46	Digital Motor Electronics					1.Clear adaptations X
All	1999-2006	3 Series_E46						2.CO adjustment X
All	1999-2006	3 Series_E46	EGS transmission control					Disable/enable key X
All	1999-2006	3 Series_E46	Electronic car immobilisation system					Clear adaptations X
All	1999-2006	3 Series_E46	Wheel-slip control system					Adjustment,steering-angle sensor X
All	1999-2006	3 Series_E46	Instrument cluster					Reset service interval indicator X
All	1999-2006	3 Series_E46	Light Check Module					Read out operating data X
All	2005-2009	3 Series_E90/E91/E92/E93	CAS Car Access System	X	X	X	X	
All	2005-2009	3 Series_E90/E91/E92/E93	DME/DDE Motor Electronics	X	X	X	X	
All	2005-2009	3 Series_E90/E91/E92/E93	EGS transmission control	X	X	X	X	

All	2005-2009	3 Series_E90/E91/E92/ E93	EKPS Fuel pump	X	X	X	X	
All	2005-2009	3 Series_E90/E91/E92/ E93	AL active steering	X	X	X	X	
All	2005-2009	3 Series_E90/E91/E92/ E93	ARS Dynamic Drive 2	X	X	X	X	
All	2005-2009	3 Series_E90/E91/E92/ E93	DSC Dynamic Stability Control	X	X	X	X	
All	2005-2009	3 Series_E90/E91/E92/ E93	EPS Electronic Power Steering	X	X	X	X	
All	2005-2009	3 Series_E90/E91/E92/ E93	RAD2-BO User interface	X	X	X	X	
All	2005-2009	3 Series_E90/E91/E92/ E93	RAD2-GW Gateway	X	X	X	X	
All	2005-2009	3 Series_E90/E91/E92/ E93	CIC User interface	X	X	X	X	
All	2005-2009	3 Series_E90/E91/E92/ E93	CIC-GW Gateway	X	X	X	X	
All	2005-2009	3 Series_E90/E91/E92/ E93	CDC CD Changer	X	X	X		
All	2005-2009	3 Series_E90/E91/E92/ E93	CID Central Information Display	X	X	X	X	
All	2005-2009	3 Series_E90/E91/E92/ E93	CON Controller	X	X	X	X	
All	2005-2009	3 Series_E90/E91/E92/ E93	DWA anti-theft alarm system	X	X	X	X	
All	2005-2009	3 Series_E90/E91/E92/ E93	SINE Siren with tilt sensor	X	X	X	X	

All	2005-2009	3 Series_E90/E91/E92/ E93	FRM/FRM2 Footwell module	X	X	X	X	
All	2005-2009	3 Series_E90/E91/E92/ E93	FZD Function centre,roof	X	X	X	X	
All	2005-2009	3 Series_E90/E91/E92/ E93	IHKA Integrated automatic heating/air conditioning	X	X	X	X	
All	2005-2009	3 Series_E90/E91/E92/ E93	JBE Junction-box electronics	X	X	X	X	
All	2005-2009	3 Series_E90/E91/E92/ E93	INSTR Instrument cluster	X	X	X	X	
All	2005-2009	3 Series_E90/E91/E92/ E93	M-ASK-NAV Navigation system	X	X	X	X	
All	2005-2009	3 Series_E90/E91/E92/ E93	MRS Multiple Restraint System	X	X	X		
All	2005-2009	3 Series_E90/E91/E92/ E93	PDC Park Distance Control	X	X	X	X	
All	2005-2009	3 Series_E90/E91/E92/ E93	RLSS Solar Rain/Light Sensor	X	X	X	X	
All	2005-2009	3 Series_E90/E91/E92/ E93	SMFA Seat module,driver	X	X	X	X	
All	2005-2009	3 Series_E90/E91/E92/ E93	SMBF Seat module,passenger	X	X	X	X	
All	2005-2009	3 Series_E90/E91/E92/ E93	TCU Telematic control unit	X	X	X	X	
All	2005-2009	3 Series_E90/E91/E92/ E93	SHD Sliding/tilting sunroof	X	X	X	X	
All	2005-2009	3 Series_E90/E91/E92/ E93	MOST-system analysis	X				

All	2005-2009	3 Series_E90/E91/E92/ E93	CAN /byteflight	X	X			
All	2005-2009	3 Series_E90/E91/E92/ E93	Maintenance\CBS reset					1 Engine oil X
All	2005-2009	3 Series_E90/E91/E92/ E93						2 Microfilter X
All	2005-2009	3 Series_E90/E91/E92/ E93						3 Front brake X
All	2005-2009	3 Series_E90/E91/E92/ E93						4 Rear brake X
All	2005-2009	3 Series_E90/E91/E92/ E93						5 Diesel filter X
All	2005-2009	3 Series_E90/E91/E92/ E93						6 Spark plugs X
All	2005-2009	3 Series_E90/E91/E92/ E93						8 Brake fluid X
All	2005-2009	3 Series_E90/E91/E92/ E93						9 Vehicle check X
All	2005-2009	3 Series_E90/E91/E92/ E93						10 Vehicle inspection: X
All	2005-2009	3 Series_E90/E91/E92/ E93						11 Exhaust emission inspection: X
All	2005-2009	3 Series_E90/E91/E92/ E93	Maintenance\Delete transport mode					Delete transport mode X
All	2005-2009	3 Series_E90/E91/E92/ E93	Drive\Digital Motor Electronics					Learning Valvetronic limit positions X
	2005-2009	3 Series_E90/E91/E92/ E93	Drive\Diesel Electronics					Injector rate matching X

All	2005-2009	3 Series_E90/E91/E92/E93	Chassis\Wheel-slip control system					Adjustment,steering-angle sensor X
All	2005-2009	3 Series_E90/E91/E92/E93	Body\IHKA Integrated automatic heating/air conditioning					Run-in protection for A/C compressor X
All	2005-2009	3 Series_E90/E91/E92/E93	Chassis\Wheel-slip control system					Lateral accleleration sensor adjustment
	2005-2009	3 Series_E90/E91/E92/E93	Chassis\Wheel-slip control system					Longitudinal acclereation sensor adjustment
All	2005-2009	3 Series_E90/E91/E92/E93	Chassis\Wheel-slip control system					Bleeding procedure
All	2005-2009	3 Series_E90/E91/E92/E93	Chassis\Wheel-slip control system					DSC unit adjustment
All	2005-2009	3 Series_E90/E91/E92/E93	Body\FZD function center, roof					Sunroof initialisation
All	2005-2009	3 Series_E90/E91/E92/E93	Body\FZD function center, roof					Rain/light sensor initialisation
All	2005-2009	3 Series_E90/E91/E92/E93	Body\JBE Junction-box electronics					Start windows initalisation
All	2005-2009	3 Series_E90/E91/E92/E93	Car key memory					Car key memory
All	2005-2009	3 Series_E90/E91/E92/E93	Driver\CAS Car access system					CAS_DME_DDE_Alignment
All	before 1988	5 Series_E28	DME/DDE (Motor/Diesel Electronics)	X	X	X	X	
All	before 1988	5 Series_E28	EML Electronic engine-power control	X	X			
All	before 1988	5 Series_E28	EGS transmission control	X	X	X	X	
All	before 1988	5 Series_E28	EWS Vehicle immobilizer	X	X	X		
All	before 1988	5 Series_E28	GR Cruise control	X	X			
All	before 1988	5 Series_E28	ABS/ASC/DSC (Dynamic Stability Control)	X	X	X	X	
All	before 1988	5 Series_E28	LEW/LWS (Steering angle sensor)	X	X	X		
All	before 1988	5 Series_E28	EDC Electroic Damper Control	X	X	X	X	
All	before 1988	5 Series_E28	RDC/RDW Tyre pressure check	X	X			
All	before 1988	5 Series_E28	EPS Electronic Power Steering	X	X	X		
All	before 1988	5 Series_E28	MFL Multi-function steering wheel	X		X		

All	before 1988	5 Series_E28	SVT Servotronic	X				
All	before 1988	5 Series_E28	ZKE/GM (Central body electronics/GM base module)	X	X	X	X	
All	before 1988	5 Series_E28	MRS/AirBag/SIM (Multiple Restraint System)	X	X			
All	before 1988	5 Series_E28	IHKA/IHKR Integrated heating/air conditioning	X	X	X	X	
All	before 1988	5 Series_E28	KOM/IKE/IKI/INSTR(Instrument cluster)	X	X	X	X	
All	before 1988	5 Series_E28	LSZ/LCM (Lights switching center)	X	X	X	X	
All	before 1988	5 Series_E28	LRA Automatic headlight vertical aim control	X	X			
All	before 1988	5 Series_E28	CVM Convertible top module	X	X	X		
All	before 1988	5 Series_E28	PDC Park Distance Control	X	X	X	X	
All	before 1988	5 Series_E28	NAV Navigation computer	X	X	X		
All	before 1988	5 Series_E28	SHD Sliding/tilting sunroof	X	X			
All	before 1988	5 Series_E28	SMF/SM/SLM (Seat memory,driver)	X	X	X	X	
All	before 1988	5 Series_E28	MID Multi Information Display	X	X			
All	before 1988	5 Series_E28	SZM Switching center,center console	X	X	X		
All	before 1988	5 Series_E28	RLS/AIC (Rain/Light Sensor/Automatic interval Control)	X	X	X		
All	before 1988	5 Series_E28	TCU/ULF/TEL/BIT (Telematic Control unit)	X	X			
All	before 1988	5 Series_E28	BM/MIR (On-board monitor/Multi-Information Radio)	X	X	X	X	
All	before 1988	5 Series_E28	VID Video module	X	X			
All	before 1988	5 Series_E28	RAD Radio	X	X	X	X	
All	before 1988	5 Series_E28	STH park heating	X				
All	before 1988	5 Series_E28	DSP Digital Sound Processor	X				
All	before 1988	5 Series_E28	SES Language-input system	X	X		X	
All	before 1988	5 Series_E28	Digital Motor Electronics					1.Clear adaptations X
All	before 1988	5 Series_E28						2.CO adjustment X
All	before 1988	5 Series_E28	EGS transmission control					Clear adaptations X
All	before 1988	5 Series_E28	Wheel-slip control system					Adjustment,steering-angle sensor X
All	before 1988	5 Series_E28	Instrument cluster					Reset service interval indicator X
All	before 1988	5 Series_E28	Light Check Module					Read out operating data X
All	1988-1996	5 Series_E34	DME/DDE (Motor/Diesel Electronics)	X	X	X	X	
All	1988-1996	5 Series_E34	EML Electronic engine-power control	X	X			
All	1988-1996	5 Series_E34	EGS transmission control	X	X	X	X	
All	1988-1996	5 Series_E34	EWS Vehicle immobilizer	X	X	X		
All	1988-1996	5 Series_E34	GR Cruise control	X	X			
All	1988-1996	5 Series_E34	ABS/ASC/DSC (Dynamic Stability Control)	X	X	X	X	
All	1988-1996	5 Series_E34	LEW/LWS (Steering angle sensor)	X	X	X		
All	1988-1996	5 Series_E34	EDC Electroic Damper Control	X	X	X	X	
All	1988-1996	5 Series_E34	RDC/RDW Tyre pressure check	X	X			
All	1988-1996	5 Series_E34	EPS Electronic Power Steering	X	X	X		
All	1988-1996	5 Series_E34	MFL Multi-function steering wheel	X		X		
All	1988-1996	5 Series_E34	SVT Servotronic	X				
All	1988-1996	5 Series_E34	ZKE/GM (Central body electronics/GM base module)	X	X	X	X	
All	1988-1996	5 Series_E34	MRS/AirBag/SIM (Multiple Restraint System)	X	X			
All	1988-1996	5 Series_E34	IHKA/IHKR Integrated heating/air conditioning	X	X	X	X	

All	1988-1996	5 Series_E34	KOM/IKE/IKI/INSTR(Instrument cluster)	X	X	X	X	
All	1988-1996	5 Series_E34	LSZ/LCM (Lights switching center)	X	X	X	X	
All	1988-1996	5 Series_E34	LRA Automatic headlight vertical aim control	X	X			
All	1988-1996	5 Series_E34	CVM Convertible top module	X	X	X		
All	1988-1996	5 Series_E34	PDC Park Distance Control	X	X	X	X	
All	1988-1996	5 Series_E34	NAV Navigation computer	X	X	X		
All	1988-1996	5 Series_E34	SHD Sliding/titing sunroof	X	X			
All	1988-1996	5 Series_E34	SMF/SM/SLM (Seat memory,driver)	X	X	X	X	
All	1988-1996	5 Series_E34	MID Multi Information Display	X	X			
All	1988-1996	5 Series_E34	SZM Switching center,center console	X	X	X		
All	1988-1996	5 Series_E34	RLS/AIC (Rain/Light Sensor/Automatic interval Control)	X	X	X		
All	1988-1996	5 Series_E34	TCU/ULF/TEL/BIT (Telematic Control unit)	X	X			
All	1988-1996	5 Series_E34	BM/MIR (On-board monitor/Multi-Information Radio)	X	X	X	X	
All	1988-1996	5 Series_E34	VID Video module	X	X			
All	1988-1996	5 Series_E34	RAD Radio	X	X	X	X	
All	1988-1996	5 Series_E34	STH park heating	X				
All	1988-1996	5 Series_E34	DSP Digital Sound Processor	X				
All	1988-1996	5 Series_E34	SES Language-input system	X	X		X	
All	1988-1996	5 Series_E34	Digital Motor Electronics					1.Clear adaptations X
All	1988-1996	5 Series_E34						2.CO adjustment X
All	1988-1996	5 Series_E34	EGS transmission control					Clear adaptations X
All	1988-1996	5 Series_E34	Wheel-slip control system					Adjustment,steering-angle sensor X
All	1988-1996	5 Series_E34	Instrument cluster					Reset service interval indicator X
All	1988-1996	5 Series_E34	Light Check Module					Read out operating data X
All	1996-2004	5 Series_E39	DME/DDE (Motor/Diesel Electronics)	X	X	X	X	
All	1996-2004	5 Series_E39	EML Electronic engine-power control	X	X			
All	1996-2004	5 Series_E39	EGS transmission control	X	X	X	X	
All	1996-2004	5 Series_E39	EWS Vehicle immobilizer	X	X	X		
All	1996-2004	5 Series_E39	GR Cruise control	X	X			
All	1996-2004	5 Series_E39	ABS/ASC/DSC (Dynamic Stability Control)	X	X	X	X	
All	1996-2004	5 Series_E39	LEW/LWS (Steering angle sensor)	X	X	X		
All	1996-2004	5 Series_E39	EDC Electroic Damper Control	X	X	X	X	
All	1996-2004	5 Series_E39	RDC/RDW Tyre pressure check	X	X			
All	1996-2004	5 Series_E39	EPS Electronic Power Steering	X	X	X		
All	1996-2004	5 Series_E39	MFL Multi-function steering wheel	X		X		
All	1996-2004	5 Series_E39	SVT Servotronic	X				
All	1996-2004	5 Series_E39	ZKE/GM (Central body electronics/GM base module)	X	X	X	X	
All	1996-2004	5 Series_E39	MRS/AirBag/SIM (Multiple Restraint System)	X	X			
All	1996-2004	5 Series_E39	IHKA/IHKR Integrated heating/air conditioning	X	X	X	X	
All	1996-2004	5 Series_E39	KOM/IKE/IKI/INSTR(Instrument cluster)	X	X	X	X	
All	1996-2004	5 Series_E39	LSZ/LCM (Lights switching center)	X	X	X	X	
All	1996-2004	5 Series_E39	LRA Automatic headlight vertical aim control	X	X			
All	1996-2004	5 Series_E39	CVM Convertible top module	X	X	X		

All	1996-2004	5 Series_E39	PDC Park Distance Control	X	X	X	X	
All	1996-2004	5 Series_E39	NAV Navigation computer	X	X	X		
All	1996-2004	5 Series_E39	SHD Sliding/tilting sunroof	X	X			
All	1996-2004	5 Series_E39	SMF/SM/SLM (Seat memory,driver)	X	X	X	X	
All	1996-2004	5 Series_E39	MID Multi Information Display	X	X			
All	1996-2004	5 Series_E39	SZM Switching center,center console	X	X	X		
All	1996-2004	5 Series_E39	RLS/AIC (Rain/Light Sensor/Automatic interval Control)	X	X	X		
All	1996-2004	5 Series_E39	TCU/ULF/TEL/BIT (Telematic Control unit)	X	X			
All	1996-2004	5 Series_E39	BM/MIR (On-board monitor/Multi-Information Radio)	X	X	X	X	
All	1996-2004	5 Series_E39	VID Video module	X	X			
All	1996-2004	5 Series_E39	RAD Radio	X	X	X	X	
All	1996-2004	5 Series_E39	STH park heating	X				
All	1996-2004	5 Series_E39	DSP Digital Sound Processor	X				
All	1996-2004	5 Series_E39	SES Language-input system	X	X		X	
All	1996-2004	5 Series_E39	Digital Motor Electronics					1.Clear adaptations X
All	1996-2004	5 Series_E39						2.CO adjustment X
All	1996-2004	5 Series_E39	EGS transmission control					Clear adaptations X
All	1996-2004	5 Series_E39	Wheel-slip control system					Adjustment,steering-angle sensor X
All	1996-2004	5 Series_E39	Instrument cluster					Reset service interval indicator X
All	1996-2004	5 Series_E39	Light Check Module					Read out operating data X
All	After 2004	5 Series_E60/E61	CAS Car Access System	X	X	X	X	
All	After 2004	5 Series_E60/E61	DME/DDE Motor Electronics	*	*	*	*	
All	After 2004	5 Series_E60/E61	EGS transmission control	*	*	*	*	
All	After 2004	5 Series_E60/E61	GWS Gear selector switch	X	X	X	X	
All	After 2004	5 Series_E60/E61	EKPS Fuel-pump control	X	X	X	X	
All	After 2004	5 Series_E60/E61	AL active steering	X	X	X	X	
All	After 2004	5 Series_E60/E61	ARS Dynamic Drive	X	X	X	X	
All	After 2004	5 Series_E60/E61	DSC Dynamic Stability Control	*	*	*	*	
All	After 2004	5 Series_E60/E61	AHL Adaptive directional headlights	X	X	X	X	
All	After 2004	5 Series_E60/E61	IHKA Integrated automatic heating/air conditioning	*	*	*	*	
All	After 2004	5 Series_E60/E61	INSTR Instrument cluster	X	X	X	X	
All	After 2004	5 Series_E60/E61	LM2 Lights module 2	*	*	*	*	
All	After 2004	5 Series_E60/E61	KBM Body basic module	X	X	X	X	
All	After 2004	5 Series_E60/E61	KGM Body Gateway Module	X	X	X	X	
All	After 2004	5 Series_E60/E61	ACSM/MRS Crash Safety Module	X	X	X		
All	After 2004	5 Series_E60/E61	M-ASK-GW Gateway	X	X	X	X	
All	After 2004	5 Series_E60/E61	CHAMP-GW Gateway	X	X	X	X	
All	After 2004	5 Series_E60/E61	M-ASK-BO User interface	X	X	X	X	
All	After 2004	5 Series_E60/E61	CHAMP-BO User interface	X	X	X	X	
All	After 2004	5 Series_E60/E61	M-ASK-NAV Navigation system	X	X	X	X	
All	After 2004	5 Series_E60/E61	MPM Micro-power module	X	X	X	X	
All	After 2004	5 Series_E60/E61	PDC Park Distance Control	X	X	X	X	
All	After 2004	5 Series_E60/E61	CDC CD Changer	X	X		X	

All	After 2004	5 Series_E60/E61	CID Central Information Display	X	X	X	X	
All	After 2004	5 Series_E60/E61	RLS Rain/Light Sensor	X	X	X		
All	After 2004	5 Series_E60/E61	SGM-SIM Safety and Gateway Module(SIM)	X	X	X	X	
All	After 2004	5 Series_E60/E61	SGM-ZGM Safety and Gateway Module(ZGM)	X	X			
All	After 2004	5 Series_E60/E61	SFZ Satellite vehicle center	X	X	X		
All	After 2004	5 Series_E60/E61	SBSL Satellite,B-pillar,left	X	X	X		
All	After 2004	5 Series_E60/E61	SBSR Satellite,B-pillar,right	X	X	X		
All	After 2004	5 Series_E60/E61	SZL Switch center,steering column	*	*	*	*	
All	After 2004	5 Series_E60/E61	SZM Switching center,center console	X	X	X	X	
All	After 2004	5 Series_E60/E61	SINE Siren and tilt sensor	X	X	X		
All	After 2004	5 Series_E60/E61	SHD Sliding/tilting sunroof	X	X	X	X	
All	After 2004	5 Series_E60/E61	SMFA Seat module,driver	X	X	X	X	
All	After 2004	5 Series_E60/E61	SMBF Seat module,passenger	X	X	X	X	
All	After 2004	5 Series_E60/E61	TCU Telematic control unit	X	X	X	X	
All	After 2004	5 Series_E60/E61	ULF Universal charging and hands-free facility	X	X	X	X	
All	After 2004	5 Series_E60/E61	TMFA Door module,driver	X	X	X	X	
All	After 2004	5 Series_E60/E61	TMBF Door module,front passenger	X	X	X	X	
All	After 2004	5 Series_E60/E61	CCC-GW Gateway	X	X	X	X	
All	After 2004	5 Series_E60/E61	CCC-ANT Aerial tuner	X		X	X	
All	After 2004	5 Series_E60/E61	CCC-ASK Audio system controller	X			X	
All	After 2004	5 Series_E60/E61	CCC-A Applications	X		X	X	
All	After 2004	5 Series_E60/E61	CON Controller	X	X	X	X	
All	After 2004	5 Series_E60/E61	DWA anti theft alarm system	X		X	X	
All	After 2004	5 Series_E60/E61	FZD function centre,roof	X	X	X	X	
All	After 2004	5 Series_E60/E61	HUD Head-Up Display	X	X	X	X	
All	After 2004	5 Series_E60/E61	ALBBF Active backrest width,front passenger	X	X	X		
All	After 2004	5 Series_E60/E61	ALBFA Active backrest width,driver	X	X	X		
All	After 2004	5 Series_E60/E61	SHZH Independent/auxiliary heater	X	X	X	X	
All	After 2004	5 Series_E60/E61	HKL Rear-lid module	X	X	X	X	
All	After 2004	5 Series_E60/E61	DAB Digital tuner	X	X	X	X	
All	After 2004	5 Series_E60/E61	JBE Junction-box electronics	X	X	X	X	
All	After 2004	5 Series_E60/E61	VM Video Module	X	X	X	X	
All	After 2004	5 Series_E60/E61	MOST system analysis					
All	After 2004	5 Series_E60/E61	CAN /byteflight		X			
All	After 2004	5 Series_E60/E61	Maintenance\CBS reset					1 Engine oil X
All	After 2004	5 Series_E60/E61						2 Microfilter X
All	After 2004	5 Series_E60/E61						3 Front brake X
All	After 2004	5 Series_E60/E61						4 Rear brake X
All	After 2004	5 Series_E60/E61						5 Diesel filter X
All	After 2004	5 Series_E60/E61						6 Spark plugs X
All	After 2004	5 Series_E60/E61						7 Coolant X
All	After 2004	5 Series_E60/E61						8 Brake fluid X
All	After 2004	5 Series_E60/E61						9 Vehicle check X
All	After 2004	5 Series_E60/E61						10 Vehicle inspection: X
All	After 2004	5 Series_E60/E61						11 Exhaust emission inspection: X

All	After 2004	5 Series_E60/E61	Maintenance\Delete transport mode					Delete transport mode X
All	After 2004	5 Series_E60/E61	Drive\Diesel Electronics					Injector rate matching
All	After 2004	5 Series_E60/E61	Body\IHKA Integrated automatic heating/air conditioning					Run-in protection for A/C compressor X
All	After 2004	5 Series_E60/E61	Chassis\Wheel-slip control system					Adjustment,steering-angle sensor X
All	After 2004	5 Series_E60/E61	Chassis\Wheel-slip control system					Bleed Routine
All	After 2004	5 Series_E60/E61	Chassis\Wheel-slip control system					Longitudinal acceleration sensor adjustment
All	After 2004	5 Series_E60/E61	Drive\Diesel Electronics					Regeneration Particular Filter
All	After 2004	5 Series_E60/E61	Drive\Diesel Electronics					Replacement particular filter
All	After 2004	5 Series_E60/E61	Body\PM Power module					Register battery replacement
All	after 2008	5 Series_F10/F11/18	DME/DDE (Motor/Diesel Electronics)	*	*	*	*	
All	after 2008	5 Series_F10/F11/18	DME2/DME2 Digital motor electronics 2	*	*	*	*	
All	after 2008	5 Series_F10/F11/18	CAS Car Access System	X	X	X	X	
All	after 2008	5 Series_F10/F11/18	EGS transmission control	X	X	X	X	
All	after 2008	5 Series_F10/F11/18	EKPS Fuel-pump control	X	X	X	X	
All	after 2008	5 Series_F10/F11/18	GWS Gear selector switch	X	X	X	X	
All	after 2008	5 Series_F10/F11/18	DSC(Bosch)Dynamic Stability Control	X	X	X	X	
All	after 2008	5 Series_F10/F11/18	EMF Parking brake	*	*	*	*	
All	after 2008	5 Series_F10/F11/18	EPS Electronic Power Steering	X	X	X	X	
All	after 2008	5 Series_F10/F11/18	ICM Integronic Power Steering	*	*	*	*	
All	after 2008	5 Series_F10/F11/18	EHC Electronic Ride-Height Control	*	*	*	*	
All	after 2008	5 Series_F10/F11/18	INSTR Instrument cluster	X	X	X	X	
All	after 2008	5 Series_F10/F11/18	ACSM Crash Safety Module	X	X	X	X	
All	after 2008	5 Series_F10/F11/18	FRM Footwell module	X	X	X	X	
All	after 2008	5 Series_F10/F11/18	JBE Junction-box electronics	X	X	X	X	
All	after 2008	5 Series_F10/F11/18	FZD function centre,roof	X	X	X	X	
All	after 2008	5 Series_F10/F11/18	IHKA Integrated automatic heating/air conditioning	*	*	*	*	
All	after 2008	5 Series_F10/F11/18	CID Central Information Display	*	*	*	*	
All	after 2008	5 Series_F10/F11/18	ZGM Central Gateway Module	X	X	X	X	
All	after 2008	5 Series_F10/F11/18	SZL Switch center,steering column	X	X	X	X	
All	after 2008	5 Series_F10/F11/18	CON Controller	X	X	X	X	
All	after 2008	5 Series_F10/F11/18	CIC/CHAMP Car headunit column	*	*	*	*	
All	after 2008	5 Series_F10/F11/18	PDC Park Distance Control	X	X	X	X	
All	after 2008	5 Series_F10/F11/18	DVDC DVD Changer	X	X	X	X	
All	after 2008	5 Series_F10/F11/18	SMFA Seat module,driver	X	X	X	X	
All	after 2008	5 Series_F10/F11/18	SMBF Seat module,passenger	X	X	X	X	
All	after 2008	5 Series_F10/F11/18	TRSVc All round view camera	*	*	*	*	
All	after 2008	5 Series_F10/F11/18	HKL Rear-lid module	*	*	*	*	
All	after 2008	5 Series_F10/F11/18	FKA Rear-cabin automatic A/C	*	*	*	*	
All	after 2008	5 Series_F10/F11/18	FD Rear-compartment display	*	*	*	*	
All	after 2008	5 Series_F10/F11/18	FD2 Rear-compartment display2	*	*	*	*	
All	after 2008	5 Series_F10/F11/18	VM Video Module	*	*	*	*	
All	after 2008	5 Series_F10/F11/18	VSW Video switch	*	*	*	*	

All	after 2008	5 Series_F10/F11/18	ACC Active cruise control	*	*	*	*	
All	after 2008	5 Series_F10/F11/18	RSE Rear seat entertainment	*	*	*	*	
All	after 2008	5 Series_F10/F11/18	Maintenance\CBS reset					1 Engine oil X
All	after 2008	5 Series_F10/F11/18						3 Front brake X
All	after 2008	5 Series_F10/F11/18						4 Rear brake X
All	after 2008	5 Series_F10/F11/18						8 Brake fluid X
All	after 2008	5 Series_F10/F11/18						10 Vehicle inspection: X
All	after 2008	5 Series_F10/F11/18						11 Exhaust emission inspection: X
All	after 2008	5 Series_F10/F11/18						12 Vehicle check-linked X
	after 2008	5 Series_F10/F11/18	Chassis\EMF Parking brake\					Renewal of an actuator on brake caliper
All	after 2008	5 Series_F10/F11/18	Chassis\EMF Parking brake\					Renewal of the brake caliper or brake pads
All	after 2008	5GT Series_F07	DME/DDE (Motor/Diesel Electronics)	X	X	X	X	
All	after 2008	5GT Series_F07	DME2/DME2 Digital motor electronics 2	*	*	*	*	
All	after 2008	5GT Series_F07	CAS Car Access System	X	X	X	X	
All	after 2008	5GT Series_F07	EGS transmission control	X	X	X	X	
All	after 2008	5GT Series_F07	EKPS Fuel-pump control	X	X	X	X	
All	after 2008	5GT Series_F07	GWS Gear selector switch	X	X	X	X	
All	after 2008	5GT Series_F07	DSC(Bosch)Dynamic Stability Control	X	X	X	X	
All	after 2008	5GT Series_F07	EMF Parking brake	X	X	X	X	
All	after 2008	5GT Series_F07	EPS Electronic Power Steering	X	X	X	X	
All	after 2008	5GT Series_F07	ICM Integronic Power Steering	X	X	X	X	
All	after 2008	5GT Series_F07	EHC Electronic Ride-Height Control	*	*	*	*	
All	after 2008	5GT Series_F07	INSTR Instrument cluster	X	X	X	X	
All	after 2008	5GT Series_F07	ACSM Crash Safety Module	X	X	X	X	
All	after 2008	5GT Series_F07	FRM Footwell module	X	X	X	X	
All	after 2008	5GT Series_F07	JBE Junction-box electronics	X	X	X	X	
All	after 2008	5GT Series_F07	FZD function centre,roof	X	X	X	X	
All	after 2008	5GT Series_F07	IHKA Integrated automatic heating/air conditioning	X	X	X	X	
All	after 2008	5GT Series_F07	CID Central Information Display	X	X	X	X	
All	after 2008	5GT Series_F07	ZGM Central Gateway Module	X	X	X	X	
All	after 2008	5GT Series_F07	SZL Switch center,steering column	X	X	X	X	
All	after 2008	5GT Series_F07	CON Controller	X	X	X	X	
All	after 2008	5GT Series_F07	CIC/CHAMP Car headunit column	X	X	X	X	
All	after 2008	5GT Series_F07	PDC Park Distance Control	X	X	X	X	
All	after 2008	5GT Series_F07	DVDC DVD Changer	X	X	X	X	
All	after 2008	5GT Series_F07	SMFA Seat module,driver	X	X	X	X	
All	after 2008	5GT Series_F07	SMBF Seat module,passenger	X	X	X	X	
All	after 2008	5GT Series_F07	TRVC All round view camera	*	*	*	*	
All	after 2008	5GT Series_F07	HKL Rear-lid module	*	*	*	*	
All	after 2008	5GT Series_F07	FKA Rear-cabin automatic A/C	*	*	*	*	
All	after 2008	5GT Series_F07	FD Rear-compartment display	*	*	*	*	
All	after 2008	5GT Series_F07	FD2 Rear-compartment display2	*	*	*	*	

All	after 2008	5GT Series_F07	VM Video Module	*	*	*	*	
All	after 2008	5GT Series_F07	VSW Video switch	*	*	*	*	
All	after 2008	5GT Series_F07	ACC Active cruise control	*	*	*	*	
All	after 2008	5GT Series_F07	RSE Rear seat entertainment	*	*	*	*	
All	after 2008	5GT Series_F07	Maintenance\CBS reset					1 Engine oil X
All	after 2008	5GT Series_F07						3 Front brake X
All	after 2008	5GT Series_F07						4 Rear brake X
All	after 2008	5GT Series_F07						8 Brake fluid X
All	after 2008	5GT Series_F07						10 Vehicle inspection: X
All	after 2008	5GT Series_F07						11 Exhaust emission inspection: X
All	after 2008	5GT Series_F07						12 Vehicle check-linked X
	after 2008	5GT Series_F07	Chassis\EMF Parking brake\					Renewal of an actuator on brake caliper
All	after 2008	5GT Series_F07	Chassis\EMF Parking brake\					Renewal of the brake caliper or brake pads
All	Before 1989	6 Series_E24	DME/DDE (Motor/Diesel Electronics)	X	X	X	X	
All	Before 1989	6 Series_E24	EML Electronic engine-power control	X	X			
All	Before 1989	6 Series_E24	EGS transmission control	X	X	X	X	
All	Before 1989	6 Series_E24	EWS Vehicle immobilizer	X	X	X		
All	Before 1989	6 Series_E24	GR Cruise control	X	X			
All	Before 1989	6 Series_E24	ABS/ASC/DSC (Dynamic Stability Control)	X	X	X	X	
All	Before 1989	6 Series_E24	LEW/LWS (Steering angle sensor)	X	X	X		
All	Before 1989	6 Series_E24	EDC Electroic Damper Control	X	X	X	X	
All	Before 1989	6 Series_E24	RDC/RDW Tyre pressure check	X	X			
All	Before 1989	6 Series_E24	EPS Electronic Power Steering	X	X	X		
All	Before 1989	6 Series_E24	MFL Multi-function steering wheel	X		X		
All	Before 1989	6 Series_E24	SVT Servotronic	X				
All	Before 1989	6 Series_E24	ZKE/GM (Central body electronics/GM base module)	X	X	X	X	
All	Before 1989	6 Series_E24	MRS/AirBag/SIM (Multiple Restraint System)	X	X			
All	Before 1989	6 Series_E24	IHKA/IHKB Integrated heating/air conditioning	X	X	X	X	
All	Before 1989	6 Series_E24	KOM/IKE/IKI/INSTR(Instrument cluster)	X	X	X	X	
All	Before 1989	6 Series_E24	LSZ/LCM (Lights switching center)	X	X	X	X	
All	Before 1989	6 Series_E24	LRA Automatic headlight vertical aim control	X	X			
All	Before 1989	6 Series_E24	CVM Convertible top module	X	X	X		
All	Before 1989	6 Series_E24	PDC Park Distance Control	X	X	X	X	
All	Before 1989	6 Series_E24	NAV Navigation computer	X	X	X		
All	Before 1989	6 Series_E24	SHD Sliding/titing sunroof	X	X			
All	Before 1989	6 Series_E24	SMF/SM/SLM (Seat memory,driver)	X	X	X	X	
All	Before 1989	6 Series_E24	MID Multi Information Display	X	X			
All	Before 1989	6 Series_E24	SZM Switching center,center console	X	X	X		
All	Before 1989	6 Series_E24	RLS/AIC (Rain/Light Sensor/Automatic interval Control)	X	X	X		
All	Before 1989	6 Series_E24	TCU/ULF/TEL/BIT (Telematic Control unit)	X	X			
All	Before 1989	6 Series_E24	BM/MIR (On-board monitor/Multi-Information Radio)	X	X	X	X	

All	Before 1989	6 Series_E24	VID Video module	X	X			
All	Before 1989	6 Series_E24	RAD Radio	X	X	X	X	
All	Before 1989	6 Series_E24	STH park heating	X				
All	Before 1989	6 Series_E24	DSP Digital Sound Processor	X				
All	Before 1989	6 Series_E24	SES Language-input system	X	X		X	
All	Before 1989	6 Series_E24	Digital Motor Electronics					1.Clear adaptations X
All	Before 1989	6 Series_E24						2.CO adjustment X
All	Before 1989	6 Series_E24	EGS transmission control					Clear adaptations X
All	Before 1989	6 Series_E24	Wheel-slip control system					Adjustment,steering-angle sensor X
All	Before 1989	6 Series_E24	Instrument cluster					Reset service interval indicator X
All	Before 1989	6 Series_E24	Light Check Module					Read out operating data X
All	After 2003	6 Series_E63/E64	CAS Car Access System	X	X	X		
All	After 2003	6 Series_E63/E64	DME Motor Electronics	X	X	X	X	
All	After 2003	6 Series_E63/E64	EGS transmission control	X	X	X	X	
All	After 2003	6 Series_E63/E64	VTC Valvetronic	X				
All	After 2003	6 Series_E63/E64	VTC2 Valvetronic 2	X				
All	After 2003	6 Series_E63/E64	EKP Fuel pump	X	X	X	X	
All	After 2003	6 Series_E63/E64	AL active steering	X	X	X		
All	After 2003	6 Series_E63/E64	ARS Dynamic Drive 2	X	X	X	X	
All	After 2003	6 Series_E63/E64	DSC Dynamic Stability Control	X	X	X	X	
All	After 2003	6 Series_E63/E64	AHL Adaptive directional headlights	X	X	X	X	
All	After 2003	6 Series_E63/E64	IHKA Integrated automatic heating/air conditioning	X	X	X	X	
All	After 2003	6 Series_E63/E64	INSTR Instrumint cluster	X	X	X	X	
All	After 2003	6 Series_E63/E64	LM Lights module 2	X	X	X	X	
All	After 2003	6 Series_E63/E64	KBM Body basic module	X	X	X	X	
All	After 2003	6 Series_E63/E64	MPM Micro-power module	X	X	X	X	
All	After 2003	6 Series_E63/E64	CVM Convertible top module	X	X	X		
All	After 2003	6 Series_E63/E64	CCC-GW Gateway	X	X	X	X	
All	After 2003	6 Series_E63/E64	CCC-ANT Aerial tuner	X		X	X	
All	After 2003	6 Series_E63/E64	CCC-ASK Audio system controller	X			X	
All	After 2003	6 Series_E63/E64	CCC-A Applications	X		X	X	
All	After 2003	6 Series_E63/E64	CID Central Information Display	X	X	X	X	
All	After 2003	6 Series_E63/E64	CON Controller	X	X	X	X	
All	After 2003	6 Series_E63/E64	DWA antitheft alarm system	X	X	X	X	
All	After 2003	6 Series_E63/E64	PDC Park Distance Control	X	X	X	X	
All	After 2003	6 Series_E63/E64	RLS Rain/Light Sensor	X	X	X		
All	After 2003	6 Series_E63/E64	SGM-SIM Safety and Gateway Module(SIM)	X	X	X	X	
All	After 2003	6 Series_E63/E64	SGM-ZGM Safety and Gateway Module(ZGM)	X	X			
All	After 2003	6 Series_E63/E64	SFZ Satellite vehicle center	X	X	X		
All	After 2003	6 Series_E63/E64	SBSL Satellite,B-pillar,left	X	X	X		
All	After 2003	6 Series_E63/E64	SBSR Satellite,B-pillar,right	X	X	X		
All	After 2003	6 Series_E63/E64	SZL Switch center,steering column	X	X	X	X	
All	After 2003	6 Series_E63/E64	SZM Switching center,center console	X	X	X	X	
All	After 2003	6 Series_E63/E64	TCU Telematic control unit	X	X	X	X	
All	After 2003	6 Series_E63/E64	TMFA Door module,driver	X	X	X	X	

All	After 2003	6 Series_E63/E64	TMBF Door module,front passenger	X	X	X	X	
All	After 2003	6 Series_E63/E64	VM Video Module	X	X	X	X	
All	After 2003	6 Series_E63/E64	SHD Slide/tilt sunroof 2	X	X	X	X	
All	After 2003	6 Series_E63/E64	CCC-BO User interface	X	X	X	X	
All	After 2003	6 Series_E63/E64	MOST system analysis					
All	After 2003	6 Series_E63/E64	AMP Amplifier					
All	After 2003	6 Series_E63/E64	HUD Head-Up Display	X	X	X		
All	After 2003	6 Series_E63/E64	CAN / byteflight		X			
All	After 2003	6 Series_E63/E64	Maintenance\CBS reset					1 Engine oil X
All	After 2003	6 Series_E63/E64						2 Microfilter X
All	After 2003	6 Series_E63/E64						3 Front brake X
All	After 2003	6 Series_E63/E64						4 Rear brake X
All	After 2003	6 Series_E63/E64						5 Diesel filter X
All	After 2003	6 Series_E63/E64						6 Spark plugs X
All	After 2003	6 Series_E63/E64						7 Coolant X
All	After 2003	6 Series_E63/E64						8 Brake fluid X
All	After 2003	6 Series_E63/E64						9 Vehicle check X
All	After 2003	6 Series_E63/E64						10 Vehicle inspection: X
All	After 2003	6 Series_E63/E64						11 Exhaust emission inspection: X
All	After 2003	6 Series_E63/E64	Maintenance\Delete transport mode					Delete transport mode X
All	After 2003	6 Series_E63/E64	Drive\Digital Motor Electronics					1.DME-CAS Adjustment X
All	After 2003	6 Series_E63/E64	Drive\Digital Motor Electronics					2.Idle speed Adjustment X
All	After 2003	6 Series_E63/E64	Drive\Digital Motor Electronics					3.Clear adaptations X
All	After 2003	6 Series_E63/E64	Drive\Digital Motor Electronics					4.Learning Valvetronic limit positions X
All	After 2003	6 Series_E63/E64	Drive\Digital Motor Electronics					5.CO adjustment X
All	After 2003	6 Series_E63/E64	Chassis\Wheel-slip control system					1.Adjustment,steering-angle sensor X
All	After 2003	6 Series_E63/E64	Chassis\Wheel-slip control system					2.Bleeding,DSC hydraulics X
All	After 2003	6 Series_E63/E64	Chassis\Wheel-slip control system					3.Mix-up checks,brake lines X
All	After 2003	6 Series_E63/E64	Chassis\Dynamic Drive					1.Start startup X
All	After 2003	6 Series_E63/E64	Chassis\Dynamic Drive					2.Learn sensor values X
All	1977–1986	7 Series_E23	DME/DDE (Motor/Diesel Electronics)	X	X	X	X	
All	1977–1986	7 Series_E23	EML Electronic engine-power control	X	X			
All	1977–1986	7 Series_E23	EGS transmission control	X	X	X	X	
All	1977–1986	7 Series_E23	EWS Vehicle immobilizer	X	X	X		
All	1977–1986	7 Series_E23	GR Cruise control	X	X			
All	1977–1986	7 Series_E23	ABS/ASC/DSC (Dynamic Stability Control)	X	X	X	X	
All	1977–1986	7 Series_E23	LEW/LWS (Steering angle sensor)	X	X	X		
All	1977–1986	7 Series_E23	EDC Electroic Damper Control	X	X	X	X	
All	1977–1986	7 Series_E23	RDC/RDW Tyre pressure check	X	X			
All	1977–1986	7 Series_E23	MFL Multi-function steering wheel	X		X		
All	1977–1986	7 Series_E23	SVT Servotronic	X				
All	1977–1986	7 Series_E23	ZKE/GM (Central body electronics/GM base module)	X	X	X	X	
All	1977–1986	7 Series_E23	MRS/AirBag/SIM (Multiple Restraint System)	X	X			
All	1977–1986	7 Series_E23	IHKA/IHKB Integrated heating/air conditioning	X	X	X	X	
All	1977–1986	7 Series_E23	KOM/IKE/IKI/INSTR(Instrument cluster)	X	X	X	X	

All	1977–1986	7 Series_E23	LSZ/LCM (Lights switching center)	X	X	X	X	
All	1977–1986	7 Series_E23	LRA Automatic headlight vertical aim control	X	X			
All	1977–1986	7 Series_E23	CVM Convertible top module	X	X	X		
All	1977–1986	7 Series_E23	PDC Park Distance Control	X	X	X	X	
All	1977–1986	7 Series_E23	NAV Navigation computer	X	X	X		
All	1977–1986	7 Series_E23	SHD Sliding/titing sunroof	X	X			
All	1977–1986	7 Series_E23	SMF/SM/SLM (Seat memory,driver)	X	X	X	X	
All	1977–1986	7 Series_E23	MID Multi Information Display	X	X			
All	1977–1986	7 Series_E23	SZM Switching center,center console	X	X	X		
All	1977–1986	7 Series_E23	RLS/AIC (Rain/Light Sensor/Automatic interval Control)	X	X	X		
All	1977–1986	7 Series_E23	TCU/ULF/TEL/BIT (Telematic Control unit)	X	X			
All	1977–1986	7 Series_E23	BM/MIR (On-board monitor/Multi-Information Radio)	X	X	X	X	
All	1977–1986	7 Series_E23	VID Video module	X	X			
All	1977–1986	7 Series_E23	RAD Radio	X	X	X	X	
All	1977–1986	7 Series_E23	STH park heating	X				
All	1977–1986	7 Series_E23	DSP Digital Sound Processor	X				
All	1977–1986	7 Series_E23	SES Language-input system	X	X		X	
All	1977–1986	7 Series_E23	Digital Motor Electronics					1.Clear adaptations X
All	1977–1986	7 Series_E23						2.CO adjustment X
All	1977–1986	7 Series_E23	EGS transmission control					Clear adaptations X
All	1977–1986	7 Series_E23	Wheel-slip control system					Adjustment,steering-angle sensor X
All	1977–1986	7 Series_E23	Instrument cluster					Reset service interval indicator X
All	1977–1986	7 Series_E23	Light Check Module					Read out operating data X
All	1987–1994	7 Series_E32	DME/DDE (Motor/Diesel Electronics)	X	X	X	X	
All	1987–1994	7 Series_E32	EML Electronic engine-power control	X	X			
All	1987–1994	7 Series_E32	EGS transmission control	X	X	X	X	
All	1987–1994	7 Series_E32	EWS Vehicle immobilizer	X	X	X		
All	1987–1994	7 Series_E32	GR Cruise control	X	X			
All	1987–1994	7 Series_E32	ABS/ASC/DSC (Dynamic Stability Control)	X	X	X	X	
All	1987–1994	7 Series_E32	LEW/LWS (Steering angle sensor)	X	X	X		
All	1987–1994	7 Series_E32	EDC Electroic Damper Control	X	X	X	X	
All	1987–1994	7 Series_E32	RDC/RDW Tyre pressure check	X	X			
All	1987–1994	7 Series_E32	MFL Multi-function steering wheel	X		X		
All	1987–1994	7 Series_E32	SVT Servotronic	X				
All	1987–1994	7 Series_E32	ZKE/GM (Central body electronics/GM base module)	X	X	X	X	
All	1987–1994	7 Series_E32	MRS/AirBag/SIM (Multiple Restraint System)	X	X			
All	1987–1994	7 Series_E32	IHKA/IHKR Integrated heating/air conditioning	X	X	X	X	
All	1987–1994	7 Series_E32	KOM/IKE/IKI/INSTR(Instrument cluster)	X	X	X	X	
All	1987–1994	7 Series_E32	LSZ/LCM (Lights switching center)	X	X	X	X	
All	1987–1994	7 Series_E32	LRA Automatic headlight vertical aim control	X	X			
All	1987–1994	7 Series_E32	CVM Convertible top module	X	X	X		
All	1987–1994	7 Series_E32	PDC Park Distance Control	X	X	X	X	
All	1987–1994	7 Series_E32	NAV Navigation computer	X	X	X		

All	1987–1994	7 Series_E32	SHD Sliding/titing sunroof	X	X			
All	1987–1994	7 Series_E32	SMF/SM/SLM (Seat memory,driver)	X	X	X	X	
All	1987–1994	7 Series_E32	MID Multi Information Display	X	X			
All	1987–1994	7 Series_E32	SZM Switching center,center console	X	X	X		
All	1987–1994	7 Series_E32	RLS/AIC (Rain/Light Sensor/Automatic interval Control)	X	X	X		
All	1987–1994	7 Series_E32	TCU/ULF/TEL/BIT (Telematic Control unit)	X	X			
All	1987–1994	7 Series_E32	BM/MIR (On-board monitor/Multi-Information Radio)	X	X	X	X	
All	1987–1994	7 Series_E32	VID Video module	X	X			
All	1987–1994	7 Series_E32	RAD Radio	X	X	X	X	
All	1987–1994	7 Series_E32	STH park heating	X				
All	1987–1994	7 Series_E32	DSP Digital Sound Processor	X				
All	1987–1994	7 Series_E32	SES Language-input system	X	X		X	
All	1987–1994	7 Series_E32	Digital Motor Electronics					1.Clear adaptations X
All	1987–1994	7 Series_E32						2.CO adjustment X
All	1987–1994	7 Series_E32	EGS transmission control					Clear adaptations X
All	1987–1994	7 Series_E32	Wheel-slip control system					Adjustment,steering-angle sensor X
All	1987–1994	7 Series_E32	Instrument cluster					Reset service interval indicator X
All	1987–1994	7 Series_E32	Light Check Module					Read out operating data X
All	1994–2001	7 Series_E38	DME/DDE (Motor/Diesel Electronics)	X	X	X	X	
All	1994–2001	7 Series_E38	EML Electronic engine-power control	X	X			
All	1994–2001	7 Series_E38	EGS transmission control	X	X	X	X	
All	1994–2001	7 Series_E38	EWS Vehicle immobilizer	X	X	X		
All	1994–2001	7 Series_E38	GR Cruise control	X	X			
All	1994–2001	7 Series_E38	ABS/ASC/DSC (Dynamic Stability Control)	X	X	X	X	
All	1994–2001	7 Series_E38	EHC Electronic Height Control	X	X	X	X	
All	1994–2001	7 Series_E38	EDC Electronic Damper Control	X	X	X	X	
All	1994–2001	7 Series_E38	LEW/LWS (Steering angle sensor)	X	X	X		
All	1994–2001	7 Series_E38	MFL Multi-function steering wheel	X		X		
All	1994–2001	7 Series_E38	SVT Servotronic	X				
All	1994–2001	7 Series_E38	MRS/AirBag (Multiple Restraint System)	X	X			
All	1994–2001	7 Series_E38	ZKE/GM (Central body electronics/GM base module)	X	X	X	X	
All	1994–2001	7 Series_E38	IHKA/IHKB Integrated heating/air conditioning	X	X	X	X	
All	1994–2001	7 Series_E38	KOM/IKE/IKI/INSTR(Instrument cluster)	X	X	X	X	
All	1994–2001	7 Series_E38	LSZ/LCM (Lights switching center)	X	X	X	X	
All	1994–2001	7 Series_E38	PDC Park Distance Control	X	X	X	X	
All	1994–2001	7 Series_E38	NAV Navigation computer	X	X	X		
All	1994–2001	7 Series_E38	SZM Switching center,center console	X	X	X		
All	1994–2001	7 Series_E38	AHL Adaptive directional headlights	X	X	X	X	
All	1994–2001	7 Series_E38	BM/MIR (On-board monitor/Multi-Information Radio)	X	X	X	X	
All	1994–2001	7 Series_E38	SHD Sliding/titing sunroof	X	X			
All	1994–2001	7 Series_E38	RLS/AIC (Rain/Light Sensor/Automatic interval Control)	X	X	X		
All	1994–2001	7 Series_E38	SMF/SM/SLM (Seat memory,driver)	X	X	X	X	

All	1994–2001	7 Series_E38	RAD Radio	X	X	X	X	
All	1994–2001	7 Series_E38	DSP Digital Sound Processor	X				
All	1994–2001	7 Series_E38	SES Language-input system	X	X		X	
All	1994–2001	7 Series_E38	TCU/ULF/TEL/BIT (Telematic Control unit)	X	X			
All	1994–2001	7 Series_E38	VID Video module	X	X			
All	1994–2001	7 Series_E38	Digital Motor Electronics					1.Clear adaptations X
All	1994–2001	7 Series_E38						2.CO adjustment X
All	1994–2001	7 Series_E38	Drive\EGS transmission control					Disable/enable key X
All	1994–2001	7 Series_E38	Drive\Electronic car immobilisation system					Clear adaptations X
All	1994–2001	7 Series_E38	Chassis\Wheel-slip control system					1.Adjustment,steering-angle sensor X
All	1994–2001	7 Series_E38						2.Adjust transversal-acceleration sensor X
All	1994–2001	7 Series_E38	Body\Instrument cluster					Reset service interval indicator X
All	1994–2001	7 Series_E38	Body\Light Check Module					Read out operating data X
All	2001–2008	7 Series_E65/E66/E67/E68	CAS Car Access System	X	X	X	X	
All	2001–2008	7 Series_E65/E66/E67/E68	DME Digital Motor Electronics	X	X	X	X	
All	2001–2008	7 Series_E65/E66/E67/E68	EGS transmission management	X	X	X	X	
All	2001–2008	7 Series_E65/E66/E67/E68	VTC Valvetronic	X		X		
All	2001–2008	7 Series_E65/E66/E67/E68	VTC2 Valvetronic 2	X		X		
All	2001–2008	7 Series_E65/E66/E67/E68	ACC/ACC2 Active Cruise Control	X	X			
All	2001–2008	7 Series_E65/E66/E67/E68	LRR Long Range Radar	X	X			
All	2001–2008	7 Series_E65/E66/E67/E68	ARS Dynamic Drive	X	X	X	X	
All	2001–2008	7 Series_E65/E66/E67/E68	EDC Damper Control	X	X	X	X	
All	2001–2008	7 Series_E65/E66/E67/E68	CIM Chassis integration Module	X	X	X	X	

All	2001–2008	7 Series_E65/E66/E67/ E68	DSC Dynamic Stability Control	X	X	X	X	
All	2001–2008	7 Series_E65/E66/E67/ E68	EHC Ride level(Height) Control	X	X	X	X	
All	2001–2008	7 Series_E65/E66/E67/ E68	EMF Parking brake	X	X	X	X	
All	2001–2008	7 Series_E65/E66/E67/ E68	RDC Tire pressure control	X	X	X		
All	2001–2008	7 Series_E65/E66/E67/ E68	AHM Trailer module	X	X	X	X	
All	2001–2008	7 Series_E65/E66/E67/ E68	AMP Amplifier	X	X	X	X	
All	2001–2008	7 Series_E65/E66/E67/ E68	ANT Antenna/antenna tuner	X	X	X	X	
All	2001–2008	7 Series_E65/E66/E67/ E68	ASK Audio system controller	X	X	X	X	
All	2001–2008	7 Series_E65/E66/E67/ E68	BZM Control center, center console	X	X	X	X	
All	2001–2008	7 Series_E65/E66/E67/ E68	FBZM Rear compartment,control center,center console	X	X	X	X	
All	2001–2008	7 Series_E65/E66/E67/ E68	CD Control Display	X	X		X	
All	2001–2008	7 Series_E65/E66/E67/ E68	CD-GW Control Display(Gateway)	X	X	X	X	
All	2001–2008	7 Series_E65/E66/E67/ E68	CDC CD Changer	X	X		X	
All	2001–2008	7 Series_E65/E66/E67/ E68	CON Controller	X	X	X	X	

All	2001–2008	7 Series_E65/E66/E67/ E68	DWA antitheft alarm system	X	X	X	X	
All	2001–2008	7 Series_E65/E66/E67/ E68	IHKA Integrated automatic heating/air conditioning	X	X	X	X	
All	2001–2008	7 Series_E65/E66/E67/ E68	HKL Rear-lid lift	X	X	X	X	
All	2001–2008	7 Series_E65/E66/E67/ E68	INSTR Instrument cluster	X	X	X	X	
All	2001–2008	7 Series_E65/E66/E67/ E68	LM Lights Module	X	X	X	X	
All	2001–2008	7 Series_E65/E66/E67/ E68	NAV Navigation system	X	X	X	X	
All	2001–2008	7 Series_E65/E66/E67/ E68	JNAV Navigation system,Japan	X	X	X	X	
All	2001–2008	7 Series_E65/E66/E67/ E68	KNAV Navigation system,Korea	X	X	X	X	
All	2001–2008	7 Series_E65/E66/E67/ E68	PDC Park distance control	X	X	X	X	
All	2001–2008	7 Series_E65/E66/E67/ E68	PM Power module	X	X	X	X	
All	2001–2008	7 Series_E65/E66/E67/ E68	RLS Rain/light sensor	X	X	X		
All	2001–2008	7 Series_E65/E66/E67/ E68	SASL Satellite,A-pillar,left	X	X	X		
All	2001–2008	7 Series_E65/E66/E67/ E68	SASR Satellite,A-pillar,right	X	X	X		
All	2001–2008	7 Series_E65/E66/E67/ E68	SBSL Satellite,B-pillar,left	X	X	X		

All	2001–2008	7 Series_E65/E66/E67/ E68	SBSR Satellite,B-pillar,right	X	X	X	X	
All	2001–2008	7 Series_E65/E66/E67/ E68	SFZ Satellite vehicle center	X	X	X		
All	2001–2008	7 Series_E65/E66/E67/ E68	SSBF Satellite,seat,passenger	X	X	X		
All	2001–2008	7 Series_E65/E66/E67/ E68	SSFA Satellite,seat,driver	X	X	X		
All	2001–2008	7 Series_E65/E66/E67/ E68	SSH Satellite,seat,rear	X	X	X	X	
All	2001–2008	7 Series_E65/E66/E67/ E68	STVL Satellite,door,front left	X	X	X		
All	2001–2008	7 Series_E65/E66/E67/ E68	STVR Satellite,door,front right	X	X	X		
All	2001–2008	7 Series_E65/E66/E67/ E68	SHD Sliding/tilting sunroof	X	X	X		
All	2001–2008	7 Series_E65/E66/E67/ E68	SINE Siren and tilt sensor	X	X	X		
All	2001–2008	7 Series_E65/E66/E67/ E68	SMFA Seat module,driver	X	X	X	X	
All	2001–2008	7 Series_E65/E66/E67/ E68	SMBF Seat module,passenger	X	X	X	X	
All	2001–2008	7 Series_E65/E66/E67/ E68	SMFAH Seat module,driver's side,rear	X	X	X	X	
All	2001–2008	7 Series_E65/E66/E67/ E68	SMBFH Seat module,passenger's side,rear	X	X	X	X	
All	2001–2008	7 Series_E65/E66/E67/ E68	SZL Switch center,steering column	X	X	X	X	

All	2001–2008	7 Series_E65/E66/E67/ E68	TEL Telephone	X	X		X	
All	2001–2008	7 Series_E65/E66/E67/ E68	TMBFT Door module,passenger door	X	X	X		
All	2001–2008	7 Series_E65/E66/E67/ E68	TMBFH Door module,passenger's side,rear	X	X	X		
All	2001–2008	7 Series_E65/E66/E67/ E68	TMFAT Door module,driver's door	X	X	X		
All	2001–2008	7 Series_E65/E66/E67/ E68	TMFAH Door module,driver's side,rear	X	X	X		
All	2001–2008	7 Series_E65/E66/E67/ E68	VM Video Module	X	X	X	X	
All	2001–2008	7 Series_E65/E66/E67/ E68	WIM Wiper module	X	X	X	X	
All	2001–2008	7 Series_E65/E66/E67/ E68	ZGM Central Gateway Module	X	X			
All	2001–2008	7 Series_E65/E66/E67/ E68	SIM Safety and information module	X	X	X	X	
All	2001–2008	7 Series_E65/E66/E67/ E68	CA Comfort Access	X	X	X		
All	2001–2008	7 Series_E65/E66/E67/ E68	FCON Rear compartment controller	X	X	X	X	
All	2001–2008	7 Series_E65/E66/E67/ E68	FKA Rear-compartment air conditioning	X	X	X	X	
All	2001–2008	7 Series_E65/E66/E67/ E68	FD Rear-compartment display	X	X	X	X	
All	2001–2008	7 Series_E65/E66/E67/ E68	SG-FD-GW Control unit,rear-compartment display(gateway)	X	X	X	X	

All	2001–2008	7 Series_E65/E66/E67/ E68	SG-FD Control unit,rear-compartment display	X	X		X	
All	2001–2008	7 Series_E65/E66/E67/ E68	SHZH Independent/auxiliary heater	X	X	X	X	
All	2001–2008	7 Series_E65/E66/E67/ E68	KHI Headphones interface	X	X	X	X	
All	2001–2008	7 Series_E65/E66/E67/ E68	SVS Language processing system	X	X		X	
All	2001–2008	7 Series_E65/E66/E67/ E68	DVD CD Changer	X	X		X	
All	2001–2008	7 Series_E65/E66/E67/ E68	FBI Flexible Bus Interface	X	X		X	
All	2001–2008	7 Series_E65/E66/E67/ E68	NVE Night Vision Electronics	X	X	X	X	
All	2001–2008	7 Series_E65/E66/E67/ E68	NVK Night vision camera	X	X	X	X	
All	2001–2008	7 Series_E65/E66/E67/ E68	CEM Clean Energy Module	X	X	X		
All	2001–2008	7 Series_E65/E66/E67/ E68	DAB Digital tuner	X	X		X	
All	2001–2008	7 Series_E65/E66/E67/ E68	SDARS Satellite tuner (US)	X	X	X	X	
All	2001–2008	7 Series_E65/E66/E67/ E68	SEC1 Supplementary control unit 1	X	X			
All	2001–2008	7 Series_E65/E66/E67/ E68	SEC2 Supplementary control unit 2	X	X			
All	2001–2008	7 Series_E65/E66/E67/ E68	MOST system analysis		X			

All	2001–2008	7 Series_E65/E66/E67/ E68	CAN /byteflight		X			
All	2001–2008	7 Series_E65/E66/E67/ E68	Maintenance\CBS reset					1 Engine oil X
All	2001–2008	7 Series_E65/E66/E67/ E68						2 Microfilter X
All	2001–2008	7 Series_E65/E66/E67/ E68						3 Front brake X
All	2001–2008	7 Series_E65/E66/E67/ E68						4 Rear brake X
All	2001–2008	7 Series_E65/E66/E67/ E68						5 Diesel filter X
All	2001–2008	7 Series_E65/E66/E67/ E68						6 Spark plugs X
All	2001–2008	7 Series_E65/E66/E67/ E68						7 Coolant X
All	2001–2008	7 Series_E65/E66/E67/ E68						8 Brake fluid X
All	2001–2008	7 Series_E65/E66/E67/ E68						9 Vehicle check X
All	2001–2008	7 Series_E65/E66/E67/ E68						10 Vehicle inspection: X
All	2001–2008	7 Series_E65/E66/E67/ E68						11 Exhaust emission inspection: X
All	2001–2008	7 Series_E65/E66/E67/ E68	Maintenance\Delete transport mode					Delete transport mode X
All	2001–2008	7 Series_E65/E66/E67/ E68	Drive\Digital Motor Electronics					1.DME-CAS Adjustment X

All	2001–2008	7 Series_E65/E66/E67/ E68						2.Idle speed Adjustment X
All	2001–2008	7 Series_E65/E66/E67/ E68						3.Clear adaptations X
All	2001–2008	7 Series_E65/E66/E67/ E68						4.Learning Valvetronic limit positions X
All	2001–2008	7 Series_E65/E66/E67/ E68						5.CO adjustment X
All	2001–2008	7 Series_E65/E66/E67/ E68	Drive\Diesel Electronics					Injector rate matching X
All	2001–2008	7 Series_E65/E66/E67/ E68	Drive\Diesel Electronics					DDE-CAS Adjustment X
All	2001–2008	7 Series_E65/E66/E67/ E68	Chassis\Wheel-slip control system					1.Adjustment,steering-angle sensor X
All	2001–2008	7 Series_E65/E66/E67/ E68						2.Bleeding,DSC hydraulics X
All	2001–2008	7 Series_E65/E66/E67/ E68						3.Mix-up checks,brake lines X
All	2001–2008	7 Series_E65/E66/E67/ E68	Chassis\Dynamic Drive					1.Start startup X
All	2001–2008	7 Series_E65/E66/E67/ E68						2.Learn sensor values X
All	2001–2008	7 Series_E65/E66/E67/ E68	Body\IHKA Integrated automatic heating/air conditioning					Run-in protection for A/C compressor X
All	2001–2008	7 Series_E65/E66/E67/ E68	Initialise power windows					Initialise power windows X

All	2001–2008	7 Series_E65/E66/E67/ E68	Drive\CAS Car Access System					1.CAS reset X 2.ELV steering lock fault counter reset X 3.Reset starter interlock X 4.Key number X 5.Enable/Disable key X
All	2001–2008	7 Series_E65/E66/E67/ E68	Car/Key memory X					Unlock,on removal of RC
All	2001–2008	7 Series_E65/E66/E67/ E68						Entrance aid,tilt direction
All	2001–2008	7 Series_E65/E66/E67/ E68						Automatic locking\car
All	2001–2008	7 Series_E65/E66/E67/ E68						Automatic locking\key 1
All	2001–2008	7 Series_E65/E66/E67/ E68						Automatic locking\key 2
All	2001–2008	7 Series_E65/E66/E67/ E68						Automatic locking\key 3
All	2001–2008	7 Series_E65/E66/E67/ E68						Automatic locking\key 4
All	2001–2008	7 Series_E65/E66/E67/ E68						Relock 2 minutes after unlocking if doors unopened\key 1
All	2001–2008	7 Series_E65/E66/E67/ E68						Relock 2 minutes after unlocking if doors unopened\key 2
All	2001–2008	7 Series_E65/E66/E67/ E68						Relock 2 minutes after unlocking if doors unopened\key 3
All	2001–2008	7 Series_E65/E66/E67/ E68						Relock 2 minutes after unlocking if doors unopened\key 4
All	2001–2008	7 Series_E65/E66/E67/ E68						Selective central locking/convenient access\car

All	2001–2008	7 Series_E65/E66/E67/ E68						Selective central locking/convenient access\key 1
All	2001–2008	7 Series_E65/E66/E67/ E68						Selective central locking/convenient access\key 2
All	2001–2008	7 Series_E65/E66/E67/ E68						Selective central locking/convenient access\key 3
All	2001–2008	7 Series_E65/E66/E67/ E68						Selective central locking/convenient access\key 4
All	2001–2008	7 Series_E65/E66/E67/ E68						Compartment sensor
All	2001–2008	7 Series_E65/E66/E67/ E68						Tilt sensor
All	2001–2008	7 Series_E65/E66/E67/ E68						Arming/disarming
All	2001–2008	7 Series_E65/E66/E67/ E68						Arm visually
All	2001–2008	7 Series_E65/E66/E67/ E68						Arm acoustically
All	2001–2008	7 Series_E65/E66/E67/ E68						Arm visually doors/lids closed
All	2001–2008	7 Series_E65/E66/E67/ E68						Arm acoustically doors/lids closed
All	2001–2008	7 Series_E65/E66/E67/ E68						Disarm visually
All	2001–2008	7 Series_E65/E66/E67/ E68						Disarm Acoustically
All	2001–2008	7 Series_E65/E66/E67/ E68						Daytime driving lights (ECE)

All	2001–2008	7 Series_E65/E66/E67/ E68						Daytime driving lights (US)
All	2001–2008	7 Series_E65/E66/E67/ E68						Home lightsduration
All	2001–2008	7 Series_E65/E66/E67/ E68						Automatic driving lights control
All	2001–2008	7 Series_E65/E66/E67/ E68						Soft on/off
All	2001–2008	7 Series_E65/E66/E67/ E68						Driver's window\One touch open
All	2001–2008	7 Series_E65/E66/E67/ E68						Driver's window\One touch close
All	2001–2008	7 Series_E65/E66/E67/ E68						Passenger's window\One touch open
All	2001–2008	7 Series_E65/E66/E67/ E68						Passenger's window\One touch close
All	2001–2008	7 Series_E65/E66/E67/ E68						Rear window driver's side\One touch open
All	2001–2008	7 Series_E65/E66/E67/ E68						Rear window driver's side\One touch close
All	2001–2008	7 Series_E65/E66/E67/ E68						Rear window passenger's side\One touch open
All	2001–2008	7 Series_E65/E66/E67/ E68						Rear window passenger's side\One touch close
All	2001–2008	7 Series_E65/E66/E67/ E68						Mirror folding
All	2001–2008	7 Series_E65/E66/E67/ E68						Convenient closing RC

All	2001–2008	7 Series_E65/E66/E67/ E68						Convenient opening RC
All	2001–2008	7 Series_E65/E66/E67/ E68						Key memory of heat/AC/ventilation
All	2001–2008	7 Series_E65/E66/E67/ E68						Recirculated air memory
All	2001–2008	7 Series_E65/E66/E67/ E68						Set fan power
All	2001–2008	7 Series_E65/E66/E67/ E68						Correction set temperature
All	2001–2008	7 Series_E65/E66/E67/ E68						A/C on with ignition on key 1
All	2001–2008	7 Series_E65/E66/E67/ E68						A/C on with ignition on key 2
All	2001–2008	7 Series_E65/E66/E67/ E68						A/C on with ignition on key 3
All	2001–2008	7 Series_E65/E66/E67/ E68						A/C on with ignition on key 4
All	2001–2008	7 Series_E65/E66/E67/ E68						Auto fan control on with ignition on Key 1
All	2001–2008	7 Series_E65/E66/E67/ E68						Auto fan control on with ignition on Key 2
All	2001–2008	7 Series_E65/E66/E67/ E68						Auto fan control on with ignition on Key 3
All	2001–2008	7 Series_E65/E66/E67/ E68						Auto fan control on with ignition on Key 4
All	2001–2008	7 Series_E65/E66/E67/ E68						Volume level

All	2001–2008	7 Series_E65/E66/E67/E68						Seat/memory position
All	2001–2008	7 Series_E65/E66/E67/E68						Easy entry steering wheel\Longitudinal
All	2001–2008	7 Series_E65/E66/E67/E68						Easy entry steering wheel\Tilting
All	2001–2008	7 Series_E65/E66/E67/E68	PM Power module					Display history of battery repalcement
All	2001–2008	7 Series_E65/E66/E67/E68						Reguster battery replacement
All	after 2008	7 Series_F01/F02	DME/DDE (Motor/Diesel Electronics)	*	*	*	*	
All	after 2008	7 Series_F01/F02	DME2/DME2 Digital motor electronics 2	*	*	*	*	
All	after 2008	7 Series_F01/F02	CAS Car Access System	X	X	X	X	
All	after 2008	7 Series_F01/F02	EGS transmission control	X	X	X	X	
All	after 2008	7 Series_F01/F02	EKPS Fuel-pump control	X	X	X	X	
All	after 2008	7 Series_F01/F02	GWS Gear selector switch	X	X	X	X	
All	after 2008	7 Series_F01/F02	DSC(Bosch)Dynamic Stability Control	X	X	X	X	
All	after 2008	7 Series_F01/F02	EMF Parking brake	*	*	*	*	
All	after 2008	7 Series_F01/F02	EPS Electronic Power Steering	X	X	X	X	
All	after 2008	7 Series_F01/F02	EHC Electronic Ride-Height Control	*	*	*	*	
All	after 2008	7 Series_F01/F02	ICM Integronic Power Steering	X	X	X	X	
All	after 2008	7 Series_F01/F02	INSTR Instrument cluster	X	X	X	X	
All	after 2008	7 Series_F01/F02	ACSM Crash Safety Module	X	X	X	X	
All	after 2008	7 Series_F01/F02	FRM Footwell module	X	X	X	X	
All	after 2008	7 Series_F01/F02	JBE Junction-box electronics	X	X	X	X	
All	after 2008	7 Series_F01/F02	FZD function centre,roof	X	X	X	X	
All	after 2008	7 Series_F01/F02	IHKA Integrated automatic heating/air conditioning	*	*	*	*	
All	after 2008	7 Series_F01/F02	CID Central Information Display	*	*	*	*	
All	after 2008	7 Series_F01/F02	ZGM Central Gateway Module	*	*	*	*	
All	after 2008	7 Series_F01/F02	SZL Switch center,steering column	X	X	X	X	
All	after 2008	7 Series_F01/F02	CON Controller	X	X	X	X	
All	after 2008	7 Series_F01/F02	CIC/CHAMP Car headunit column	*	*	*	*	
All	after 2008	7 Series_F01/F02	PDC Park Distance Control	X	X	X	X	
All	after 2008	7 Series_F01/F02	DVDC DVD Changer	X	X	X	X	
All	after 2008	7 Series_F01/F02	SMFA Seat module,driver	X	X	X	X	
All	after 2008	7 Series_F01/F02	SMBF Seat module,passenger	X	X	X	X	
All	after 2008	7 Series_F01/F02	TRSVIC All round view camera	*	*	*	*	
All	after 2008	7 Series_F01/F02	HKL Rear-lid module	*	*	*	*	
All	after 2008	7 Series_F01/F02	FKA Rear-cabin automatic A/C	*	*	*	*	

All	after 2008	7 Series_F01/F02	FD Rear-compartment display	*	*	*	*	
All	after 2008	7 Series_F01/F02	FD2 Rear-compartment display2	*	*	*	*	
All	after 2008	7 Series_F01/F02	VM Video Module	*	*	*	*	
All	after 2008	7 Series_F01/F02	VSW Video switch	*	*	*	*	
All	after 2008	7 Series_F01/F02	ACC Active cruise control	*	*	*	*	
All	after 2008	7 Series_F01/F02	RSE Rear seat entertainment	*	*	*	*	
All	after 2008	7 Series_F01/F02	Maintenance\CBS reset					1 Engine oil X
All	after 2008	7 Series_F01/F02						3 Front brake X
All	after 2008	7 Series_F01/F02						4 Rear brake X
All	after 2008	7 Series_F01/F02						8 Brake fluid X
All	after 2008	7 Series_F01/F02						10 Vehicle inspection: X
All	after 2008	7 Series_F01/F02						11 Exhaust emission inspection: X
All	after 2008	7 Series_F01/F02						12 Vehicle check-linked X
All	after 2008	7 Series_F01/F02	Chassis\EMF Parking brake\					Renewal of an actuator on brake caliper
All	after 2008	7 Series_F01/F02	Chassis\EMF Parking brake\					Renewal of the brake caliper or brake pads
All	1989–1999	8 Series_E31	DME/DDE (Motor/Diesel Electronics)	X	X	X	X	
All	1989–1999	8 Series_E31	EML Electronic engine-power control	X	X			
All	1989–1999	8 Series_E31	EGS transmission control	X	X	X	X	
All	1989–1999	8 Series_E31	EWS Vehicle immobilizer	X	X	X		
All	1989–1999	8 Series_E31	GR Cruise control	X	X			
All	1989–1999	8 Series_E31	ABS/ASC/DSC (Dynamic Stability Control)	X	X	X	X	
All	1989–1999	8 Series_E31	LEW/LWS (Steering angle sensor)	X	X	X		
All	1989–1999	8 Series_E31	EDC Electroic Damper Control	X	X	X	X	
All	1989–1999	8 Series_E31	MFL Multi-function steering wheel	X	X			
All	1989–1999	8 Series_E31	SVT Servotronic	X				
All	1989–1999	8 Series_E31	RDC/RDW Tyre pressure check	X		X		
All	1989–1999	8 Series_E31	EPS Electronic Power Steering	X	X	X		
All	1989–1999	8 Series_E31	ZKE/GM (Central body electronics/GM base module)	X	X	X	X	
All	1989–1999	8 Series_E31	MRS/AirBag/SIM (Multiple Restraint System)	X	X			
All	1989–1999	8 Series_E31	IHKA/IHKB Integrated heating/air conditioning	X	X	X	X	
All	1989–1999	8 Series_E31	KOM/IKE/IKI/INSTR(Instrument cluster)	X	X	X	X	
All	1989–1999	8 Series_E31	LSZ/LCM (Lights switching center)	X	X	X	X	
All	1989–1999	8 Series_E31	LRA Automatic headlight vertical aim control	X	X			
All	1989–1999	8 Series_E31	CVM Convertible top module	X	X	X		
All	1989–1999	8 Series_E31	PDC Park Distance Control	X	X	X	X	
All	1989–1999	8 Series_E31	NAV Navigation computer	X	X	X		
All	1989–1999	8 Series_E31	SHD Sliding/tilting sunroof	X	X			
All	1989–1999	8 Series_E31	SMF/SM/SLM (Seat memory,driver)	X	X	X	X	
All	1989–1999	8 Series_E31	MID Multi Information Display	X	X			
All	1989–1999	8 Series_E31	SZM Switching center,center console	X	X	X		
All	1989–1999	8 Series_E31	RLS/AIC (Rain/Light Sensor/Automatic interval Control)	X	X	X		

All	1989–1999	8 Series_E31	TCU/ULF/TEL/BIT (Telematic Control unit)	X	X			
All	1989–1999	8 Series_E31	BM/MIR (On-board monitor/Multi-Information Radio)	X	X	X	X	
All	1989–1999	8 Series_E31	VID Video module	X	X			
All	1989–1999	8 Series_E31	RAD Radio	X	X	X	X	
All	1989–1999	8 Series_E31	STH park heating	X				
All	1989–1999	8 Series_E31	DSP Digital Sound Processor	X				
All	1989–1999	8 Series_E31	SES Language-input system	X	X		X	
All	1989–1999	8 Series_E31	Drive\Digital Motor Electronics					1.Clear adaptations X
All	1989–1999	8 Series_E31	Drive\Digital Motor Electronics					2.CO adjustment X
All	1989–1999	8 Series_E31	Drive\EGS transmission control					Clear adaptations X
All	1989–1999	8 Series_E31	Chassis\Wheel-slip control system					Adjustment,steering-angle sensor X
All	1989–1999	8 Series_E31	Body\Instrument cluster					Reset service interval indicator X
All	1989–1999	8 Series_E31	Body\Light Check Module					Read out operating data X
All	After 2003	X Series_X3-E83	DME/DDE (Motor/Diesel Electronics)	X	X	X	X	
All	After 2003	X Series_X3-E83	EGS transmission control	X	X	X	X	
All	After 2003	X Series_X3-E83	EWS Vehicle immobilizer	X	X	X		
All	After 2003	X Series_X3-E83	VTG Transfer case	X	X	X	X	
All	After 2003	X Series_X3-E83	ABS/ASC/DSC (Dynamic Stability Control)	X	X	X	X	
All	After 2003	X Series_X3-E83	EHC Electronic Height Control	X	X	X	X	
All	After 2003	X Series_X3-E83	LEW/LWS (Steering angle sensor)	X	X	X		
All	After 2003	X Series_X3-E83	MFL Multi-function steering wheel	X		X		
All	After 2003	X Series_X3-E83	SVT Servotronic	X				
All	After 2003	X Series_X3-E83	ZKE/GM (Central body electronics/GM base module)	X	X	X	X	
All	After 2003	X Series_X3-E83	MRS/AirBag(Multiple Restraint System)	X	X			
All	After 2003	X Series_X3-E83	IHKA/IHKB Integrated heating/air conditioning	X	X	X	X	
All	After 2003	X Series_X3-E83	KOM/IKE/IKI/INSTR(Instrument cluster)	X	X	X	X	
All	After 2003	X Series_X3-E83	LSZ/LCM (Lights switching center)	X	X	X	X	
All	After 2003	X Series_X3-E83	LRA Automatic headlight vertical aim control	X	X			
All	After 2003	X Series_X3-E83	MID Multi Information Display	X	X			
All	After 2003	X Series_X3-E83	PDC Park Distance Control	X	X	X	X	
All	After 2003	X Series_X3-E83	NAV Navigation computer	X	X	X		
All	After 2003	X Series_X3-E83	AHL Adaptive directional headlights	X	X	X	X	
All	After 2003	X Series_X3-E83	BM/MIR (On-board monitor/Multi-Information Radio)	X	X	X	X	
All	After 2003	X Series_X3-E83	SZM Switching center,center console	X	X	X		
All	After 2003	X Series_X3-E83	SMF/SM/SLM (Seat memory,driver)	X	X	X	X	
All	After 2003	X Series_X3-E83	SHD Sliding/titing sunroof	X	X			
All	After 2003	X Series_X3-E83	SES Language-input system	X	X		X	
All	After 2003	X Series_X3-E83	RLS/AIC (Rain/Light Sensor/Automatic interval Control)	X	X	X		
All	After 2003	X Series_X3-E83	RAD Radio	X	X	X	X	
All	After 2003	X Series_X3-E83	DSP Digital Sound Processor	X				
All	After 2003	X Series_X3-E83	TCU/ULF/TEL/BIT (Telematic Control unit)	X	X			
All	After 2003	X Series_X3-E83	VID Video module	X	X			

All	After 2003	X Series_X3-E83	Drive\Digital Motor Electronics					1.Clear adaptations X 2.CO adjustment X
All	After 2003	X Series_X3-E83	Drive\EGS transmission control					Clear adaptations X
All	After 2003	X Series_X3-E83	Chassis\Wheel-slip control system					Adjustment,steering-angle sensor X
All	After 2003	X Series_X3-E83	Body\Instrument cluster					Reset service interval indicator X
All	After 2003	X Series_X3-E83	Body\Light Check Module					Read out operating data X
All	After 1999	X Series_X5-E53	DME/DDE (Motor/Diesel Electronics)	X	X	X	X	
All	After 1999	X Series_X5-E53	EGS transmission control	X	X	X	X	
All	After 1999	X Series_X5-E53	EWS Vehicle immobilizer	X	X	X		
All	After 1999	X Series_X5-E53	VTG Transfer case	X	X	X	X	
All	After 1999	X Series_X5-E53	ABS/ASC/DSC (Dynamic Stability Control)	X	X	X	X	
All	After 1999	X Series_X5-E53	EHC Electronic Height Control	X	X	X	X	
All	After 1999	X Series_X5-E53	LEW/LWS (Steering angle sensor)	X	X	X		
All	After 1999	X Series_X5-E53	MFL Multi-function steering wheel	X		X		
All	After 1999	X Series_X5-E53	SVT Servotronic	X				
All	After 1999	X Series_X5-E53	ZKE/GM (Central body electronics/GM base module)	X	X	X	X	
All	After 1999	X Series_X5-E53	MRS/AirBag(Multiple Restraint System)	X	X			
All	After 1999	X Series_X5-E53	IHKA/IHKR Integrated heating/air conditioning	X	X	X	X	
All	After 1999	X Series_X5-E53	KOM/IKE/IKI/INSTR(Instrument cluster)	X	X	X	X	
All	After 1999	X Series_X5-E53	LSZ/LCM (Lights switching center)	X	X	X	X	
All	After 1999	X Series_X5-E53	LRA Automatic headlight vertical aim control	X	X			
All	After 1999	X Series_X5-E53	MID Multi Information Display	X	X			
All	After 1999	X Series_X5-E53	PDC Park Distance Control	X	X	X	X	
All	After 1999	X Series_X5-E53	NAV Navigation computer	X	X	X		
All	After 1999	X Series_X5-E53	AHL Adaptive directional headlights	X	X	X	X	
All	After 1999	X Series_X5-E53	BM/MIR (On-board monitor/Multi-Information Radio)	X	X	X	X	
All	After 1999	X Series_X5-E53	SZM Switching center,center console	X	X	X		
All	After 1999	X Series_X5-E53	SMF/SM/SLM (Seat memory,driver)	X	X	X	X	
All	After 1999	X Series_X5-E53	SHD Sliding/titing sunroof	X	X			
All	After 1999	X Series_X5-E53	SES Language-input system	X	X		X	
All	After 1999	X Series_X5-E53	RLS/AIC (Rain/Light Sensor/Automatic interval Control)	X	X	X		
All	After 1999	X Series_X5-E53	RAD Radio	X	X	X	X	
All	After 1999	X Series_X5-E53	DSP Digital Sound Processor	X				
All	After 1999	X Series_X5-E53	TCU/ULF/TEL/BIT (Telematic Control unit)	X	X			
All	After 1999	X Series_X5-E53	VID Video module	X	X			
All	After 1999	X Series_X5-E53	Drive\Digital Motor Electronics					1.Clear adaptations X
All	After 1999	X Series_X5-E53	Drive\Digital Motor Electronics					2.CO adjustment X
All	After 1999	X Series_X5-E53	Drive\EGS transmission control					Disable/enable key X
All	After 1999	X Series_X5-E53	Drive\Electronic car immobilisation system					Clear adaptations X
All	After 1999	X Series_X5-E53	Chassis\Wheel-slip control system					Adjustment,steering-angle sensor X
All	After 1999	X Series_X5-E53	Body\Instrument cluster					Reset service interval indicator X
All	After 1999	X Series_X5-E53	Body\Light Check Module					Read out operating data X
All	After 1999	X Series_X5-E53	Body\Trsansport mode					Delete transport mode X

All	After 2006	X Series_X5-E70	CAS Car Access System	X	X	X	X	
All	After 2006	X Series_X5-E70	DME Motor Electronics	X	X	X	X	
All	After 2006	X Series_X5-E70	EGS 6HPTU transmission control	*	*	*	X	
All	After 2006	X Series_X5-E70	GWS Gear selector switch	X	X	X	X	
All	After 2006	X Series_X5-E70	VTG Transfer case	X	X	X	X	
All	After 2006	X Series_X5-E70	VTC Valvetronic	X				
All	After 2006	X Series_X5-E70	VTC2 Valvetronic 2	X				
All	After 2006	X Series_X5-E70	AL active front steering (AFS70)	X	X	X		
All	After 2006	X Series_X5-E70	DSC(Bosch)Dynamic Stability Control	X	X	X	X	
All	After 2006	X Series_X5-E70	ARS Dynamic Drive	X	X	X	X	
All	After 2006	X Series_X5-E70	EDCSHL Damper satellite, rear left	X	X	X	X	
All	After 2006	X Series_X5-E70	EDCSHR Damper satellite, rear right	X	X	X	X	
All	After 2006	X Series_X5-E70	EDCSVL Damper satellite, front left	X	X	X	X	
All	After 2006	X Series_X5-E70	EDCSVR Damper satellite, front right	X	X	X	X	
All	After 2006	X Series_X5-E70	EHC Electronic Ride-Height Control	X	X	X	X	
All	After 2006	X Series_X5-E70	VDM Vertical Dynamics Management	X	X	X	X	
All	After 2006	X Series_X5-E70	EMF Parking brake	X	X	X	X	
All	After 2006	X Series_X5-E70	RDC Type Pressure control	X	X	X		
All	After 2006	X Series_X5-E70	ACSM Crash Safety Module	X	X	X		
All	After 2006	X Series_X5-E70	AMPT Top Hi-Fi amplifier	X	X	X	X	
All	After 2006	X Series_X5-E70	CCC-BO User interface	X	X	X	X	
All	After 2006	X Series_X5-E70	CCC-GW Gateway	X	X	X	X	
All	After 2006	X Series_X5-E70	CCC-A Applications	X	X	X	X	
All	After 2006	X Series_X5-E70	CCC-ANT Aerial tuner	X	X	X	X	
All	After 2006	X Series_X5-E70	CCC-ASK Audio system controller	X	X	X	X	
All	After 2006	X Series_X5-E70	CDC CD Changer	X	X		X	
All	After 2006	X Series_X5-E70	CA Comfort access system	X	X	X		
All	After 2006	X Series_X5-E70	CID Central Information Display	X	X	X	X	
All	After 2006	X Series_X5-E70	FD Rear-cabin display	X	X	X		
All	After 2006	X Series_X5-E70	RSE Rear Seat Entertainment	X	X	X	X	
All	After 2006	X Series_X5-E70	CON Controller	X	X	X	X	
All	After 2006	X Series_X5-E70	FRM2 Footwell module 2	X	X	X	X	
All	After 2006	X Series_X5-E70	FLA High Beam Assist	X	X	X	X	
All	After 2006	X Series_X5-E70	HUD Head-Up Display	X	X	X	X	
All	After 2006	X Series_X5-E70	FZD Function centre,roof	X	X	X	X	
All	After 2006	X Series_X5-E70	IHKA Integrated automatic heating/air conditioning	X	X	X	X	
All	After 2006	X Series_X5-E70	FKA Rear heater/air conditioning	X	X	X	X	
All	After 2006	X Series_X5-E70	JBE2 Junction Box electronics 2	X	X	X	X	
All	After 2006	X Series_X5-E70	INSTR Instrument cluster	X	X	X	X	
All	After 2006	X Series_X5-E70	PDC Park Distance Control	X	X	X	X	
All	After 2006	X Series_X5-E70	RFK Reversing camera	X	X	X	X	
All	After 2006	X Series_X5-E70	RLSS Rain/light solar sensor	X	X	X		
All	After 2006	X Series_X5-E70	SMFA Seat module,driver	X	X	X	X	
All	After 2006	X Series_X5-E70	SMBF Seat module,passenger	X	X	X	X	
All	After 2006	X Series_X5-E70	TCU Telematic Control Unit	X	X	X	X	

All	After 2006	X Series_X5-E70	VM Video Module	X	X	X	X	
All	After 2006	X Series_X5-E70	MOST system analysis					
All	After 2006	X Series_X5-E70	CAN communication analysis		X			
All	After 2006	X Series_X5-E70	Maintenance\CBS reset					1 Engine oil X
All	After 2006	X Series_X5-E70						3 Front brake X
All	After 2006	X Series_X5-E70						4 Rear brake X
All	After 2006	X Series_X5-E70						8 Brake fluid X
All	After 2006	X Series_X5-E70						9 Vehicle check X
All	After 2006	X Series_X5-E70						10 Vehicle inspection: X
All	After 2006	X Series_X5-E70						11 Exhaust emission inspection: X
All	After 2006	X Series_X5-E70	Drive\CAS Car Access System					1.CAS reset X 2.ELV steering lock fault counter reset X 3.Reset starter interlock X 4.Key number X 5.Enable/Disable key X
All	After 2006	X Series_X5-E70	Drive\Diesel Electronics					Injector rate matching X
All	After 2006	X Series_X5-E70	Chassis\EMF Parking brake					Initialisation
All	After 2006	X Series_X5-E70	Chassis\Wheel-slip control system					Adjustment,steering-angle sensor X
All	After 2007	X Series_X6-E71	CAS Car Access System	X	X	X	X	
All	After 2007	X Series_X6-E71	DME Motor Electronics	X	X	X	X	
All	After 2007	X Series_X6-E71	DDE Diesel Electronics	X	X	X	X	
All	After 2007	X Series_X6-E71	EGS 6HPTU transmission control	X	X	X	X	
All	After 2007	X Series_X6-E71	GWS Gear selector switch	X	X	X	X	
All	After 2007	X Series_X6-E71	VTG Transfer case	X	X	X	X	
All	After 2007	X Series_X6-E71	QMVHL Lateral-moment distribution,rear axle	X	X	X	X	
All	After 2007	X Series_X6-E71	EKPS Fuel-pump control	X	X	X	X	
All	After 2007	X Series_X6-E71	AL active front steering (AFS70)	X	X	X		
All	After 2007	X Series_X6-E71	DSC(Bosch)Dynamic Stability Control	X	X	X	X	
All	After 2007	X Series_X6-E71	ARS Dynamic Drive	X	X	X	X	
All	After 2007	X Series_X6-E71	EDCSHL Damper satellite, rear left	X	X	X	X	
All	After 2007	X Series_X6-E71	EDCSHR Damper satellite, rear right	X	X	X	X	
All	After 2007	X Series_X6-E71	EDCSVL Damper satellite, front left	X	X	X	X	
All	After 2007	X Series_X6-E71	EDCSVR Damper satellite, front right	X	X	X	X	
All	After 2007	X Series_X6-E71	EHC Electronic Ride-Height Control	X	X	X	X	
All	After 2007	X Series_X6-E71	EMF Parking brake	X	X	X	X	
All	After 2007	X Series_X6-E71	VDM Vertical Dynamics Management	X	X	X	X	
All	After 2007	X Series_X6-E71	ICM Integrated Chassis Management	X	X	X	X	
All	After 2007	X Series_X6-E71	ACSM Crash Safety Module	X	X	X		
All	After 2007	X Series_X6-E71	AMPH Hi-Fi amplifier	X	X	X	X	
All	After 2007	X Series_X6-E71	CCC-BO User interface	X	X	X	X	
All	After 2007	X Series_X6-E71	CCC-GW Gateway	X	X	X	X	
All	After 2007	X Series_X6-E71	CCC-A Applications	X	X	X	X	
All	After 2007	X Series_X6-E71	CCC-ANT Aerial tuner	X	X	X	X	

All	After 2007	X Series_X6-E71	CCC-ASK Audio system controller	X	X	X	X	
All	After 2007	X Series_X6-E71	DAB Digital tuner	X	X	X	X	
All	After 2007	X Series_X6-E71	CDC CD Changer	X	X	X	X	
All	After 2007	X Series_X6-E71	DVD-C DVD changer	X	X	X	X	
All	After 2007	X Series_X6-E71	CID Central Information Display	X	X	X	X	
All	After 2007	X Series_X6-E71	CON Controller	X	X	X	X	
All	After 2007	X Series_X6-E71	FRM2 Footwell module 2	X	X	X	X	
All	After 2007	X Series_X6-E71	FLA High Beam Assist	X	X	X	X	
All	After 2007	X Series_X6-E71	HUD Head-Up Display	X	X	X	X	
All	After 2007	X Series_X6-E71	FZD Function centre,roof	X	X	X	X	
All	After 2007	X Series_X6-E71	IHKA Integrated automatic heating/air conditioning	X	X	X	X	
All	After 2007	X Series_X6-E71	JBE2 Junction Box electronics 2	X	X	X	X	
All	After 2007	X Series_X6-E71	INSTR Instrument cluster	X	X	X	X	
All	After 2007	X Series_X6-E71	PDC Park Distance Control	X	X	X	X	
All	After 2007	X Series_X6-E71	RFK Reversing camera	X	X	X	X	
All	After 2007	X Series_X6-E71	RLSS Rain/light solar sensor	X	X	X	X	
All	After 2007	X Series_X6-E71	SMFA Seat module,driver	X	X	X	X	
All	After 2007	X Series_X6-E71	SMBF Seat module,passenger	X	X	X	X	
All	After 2007	X Series_X6-E71	TCU Telematic Control Unit	X	X	X	X	
All	After 2007	X Series_X6-E71	ULF-SBX-H Interface box High	X	X	X	X	
All	After 2007	X Series_X6-E71	VM Video Module	X	X	X	X	
All	After 2007	X Series_X6-E71	MOST system analysis					
All	After 2007	X Series_X6-E71	CAN communication analysis		X			
All	After 2007	X Series_X6-E71	Maintenance\CBS reset					1 Engine oil X
All	After 2007	X Series_X6-E71						3 Front brake X
All	After 2007	X Series_X6-E71						4 Rear brake X
All	After 2007	X Series_X6-E71						8 Brake fluid X
All	After 2007	X Series_X6-E71						9 Vehicle check X
All	After 2007	X Series_X6-E71						10 Vehicle inspection: X
All	After 2007	X Series_X6-E71						11 Exhaust emission inspection: X
All	1989-1991	Z Series_Z1-E30	DME/DDE (Motor/Diesel Electronics)	X	X	X	X	
All	1989-1991	Z Series_Z1-E30	EML Electronic engine-power control	X	X			
All	1989-1991	Z Series_Z1-E30	EGS transmission control	X	X	X	X	
All	1989-1991	Z Series_Z1-E30	EWS Vehicle immobilizer	X	X	X		
All	1989-1991	Z Series_Z1-E30	GR Cruise control	X	X			
All	1989-1991	Z Series_Z1-E30	ABS/ASC/DSC (Dynamic Stability Control)	X	X	X	X	
All	1989-1991	Z Series_Z1-E30	LEW/LWS (Steering angle sensor)	X	X	X		
All	1989-1991	Z Series_Z1-E30	EDC Electroic Damper Control	X	X	X	X	
All	1989-1991	Z Series_Z1-E30	RDC/RDW Tyre pressure check	X	X			
All	1989-1991	Z Series_Z1-E30	EPS Electronic Power Steering	X	X	X		
All	1989-1991	Z Series_Z1-E30	MFL Multi-function steering wheel	X		X		
All	1989-1991	Z Series_Z1-E30	SVT Servotronic	X				
All	1989-1991	Z Series_Z1-E30	ZKE/GM (Central body electronics/GM base module)	X	X	X	X	
All	1989-1991	Z Series_Z1-E30	MRS/AirBag/SIM (Multiple Restraint System)	X	X			
All	1989-1991	Z Series_Z1-E30	IHKA/IHKR Integrated heating/air conditioning	X	X	X	X	

All	1989-1991	Z Series_Z1-E30	KOM/IKE/IKI/INSTR(Instrument cluster)	X	X	X	X	
All	1989-1991	Z Series_Z1-E30	LSZ/LCM (Lights switching center)	X	X	X	X	
All	1989-1991	Z Series_Z1-E30	LRA Automatic headlight vertical aim control	X	X			
All	1989-1991	Z Series_Z1-E30	CVM Convertible top module	X	X	X		
All	1989-1991	Z Series_Z1-E30	PDC Park Distance Control	X	X	X	X	
All	1989-1991	Z Series_Z1-E30	NAV Navigation computer	X	X	X		
All	1989-1991	Z Series_Z1-E30	SHD Sliding/titing sunroof	X	X			
All	1989-1991	Z Series_Z1-E30	SMF/SM/SLM (Seat memory,driver)	X	X	X	X	
All	1989-1991	Z Series_Z1-E30	MID Multi Information Display	X	X			
All	1989-1991	Z Series_Z1-E30	SZM Switching center,center console	X	X	X		
All	1989-1991	Z Series_Z1-E30	RLS/AIC (Rain/Light Sensor/Automatic interval Control)	X	X	X		
All	1989-1991	Z Series_Z1-E30	TCU/ULF/TEL/BIT (Telematic Control unit)	X	X			
All	1989-1991	Z Series_Z1-E30	BM/MIR (On-board monitor/Multi-Information Radio)	X	X	X	X	
All	1989-1991	Z Series_Z1-E30	VID Video module	X	X			
All	1989-1991	Z Series_Z1-E30	RAD Radio	X	X	X	X	
All	1989-1991	Z Series_Z1-E30	STH park heating	X				
All	1989-1991	Z Series_Z1-E30	DSP Digital Sound Processor	X				
All	1989-1991	Z Series_Z1-E30	SES Language-input system	X	X		X	
All	1989-1991	Z Series_Z1-E30	Drive\Digital Motor Electronics					1.Clear adaptations X
All	1989-1991	Z Series_Z1-E30	Drive\Digital Motor Electronics					2.CO adjustment X
All	1989-1991	Z Series_Z1-E30	Drive\EGS transmission control					Clear adaptations X
All	1989-1991	Z Series_Z1-E30	Chassis\Wheel-slip control system					Adjustment,steering-angle sensor X
All	1989-1991	Z Series_Z1-E30	Body\Instrument cluster					Reset service interval indicator X
All	1989-1991	Z Series_Z1-E30	Body\Light Check Module					Read out operating data X
All	1996-2002	Z Series_Z3-E36	DME/DDE (Motor/Diesel Electronics)	X	X	X	X	
All	1996-2002	Z Series_Z3-E36	EML Electronic engine-power control	X	X			
All	1996-2002	Z Series_Z3-E36	EGS transmission control	X	X	X	X	
All	1996-2002	Z Series_Z3-E36	EWS Vehicle immobilizer	X	X	X		
All	1996-2002	Z Series_Z3-E36	GR Cruise control	X	X			
All	1996-2002	Z Series_Z3-E36	ABS/ASC/DSC (Dynamic Stability Control)	X	X	X	X	
All	1996-2002	Z Series_Z3-E36	LEW/LWS (Steering angle sensor)	X	X	X		
All	1996-2002	Z Series_Z3-E36	EDC Electroic Damper Control	X	X	X	X	
All	1996-2002	Z Series_Z3-E36	RDC/RDW Tyre pressure check	X	X			
All	1996-2002	Z Series_Z3-E36	EPS Electronic Power Steering	X	X	X		
All	1996-2002	Z Series_Z3-E36	MFL Multi-function steering wheel	X		X		
All	1996-2002	Z Series_Z3-E36	SVT Servotronic	X				
All	1996-2002	Z Series_Z3-E36	ZKE/GM (Central body electronics/GM base module)	X	X	X	X	
All	1996-2002	Z Series_Z3-E36	MRS/AirBag/SIM (Multiple Restraint System)	X	X			
All	1996-2002	Z Series_Z3-E36	IHKA/IHKB Integrated heating/air conditioning	X	X	X	X	
All	1996-2002	Z Series_Z3-E36	KOM/IKE/IKI/INSTR(Instrument cluster)	X	X	X	X	
All	1996-2002	Z Series_Z3-E36	LSZ/LCM (Lights switching center)	X	X	X	X	
All	1996-2002	Z Series_Z3-E36	LRA Automatic headlight vertical aim control	X	X			
All	1996-2002	Z Series_Z3-E36	CVM Convertible top module	X	X	X		

All	1996-2002	Z Series_Z3-E36	PDC Park Distance Control	X	X	X	X	
All	1996-2002	Z Series_Z3-E36	NAV Navigation computer	X	X	X		
All	1996-2002	Z Series_Z3-E36	SHD Sliding/tilting sunroof	X	X			
All	1996-2002	Z Series_Z3-E36	SMF/SM/SLM (Seat memory,driver)	X	X	X	X	
All	1996-2002	Z Series_Z3-E36	MID Multi Information Display	X	X			
All	1996-2002	Z Series_Z3-E36	SZM Switching center,center console	X	X	X		
All	1996-2002	Z Series_Z3-E36	RLS/AIC (Rain/Light Sensor/Automatic interval Control)	X	X	X		
All	1996-2002	Z Series_Z3-E36	TCU/ULF/TEL/BIT (Telematic Control unit)	X	X			
All	1996-2002	Z Series_Z3-E36	BM/MIR (On-board monitor/Multi-Information Radio)	X	X	X	X	
All	1996-2002	Z Series_Z3-E36	VID Video module	X	X			
All	1996-2002	Z Series_Z3-E36	RAD Radio	X	X	X	X	
All	1996-2002	Z Series_Z3-E36	STH park heating	X				
All	1996-2002	Z Series_Z3-E36	DSP Digital Sound Processor	X				
All	1996-2002	Z Series_Z3-E36	SES Language-input system	X	X		X	
All	1996-2002	Z Series_Z3-E36	DriveDigital Motor Electronics					1.Clear adaptations X
All	1996-2002	Z Series_Z3-E36	DriveDigital Motor Electronics					2.CO adjustment X
All	1996-2002	Z Series_Z3-E36	DriveEGS transmission control					Clear adaptations X
All	1996-2002	Z Series_Z3-E36	Chassis\Wheel-slip control system					Adjustment,steering-angle sensor X
All	1996-2002	Z Series_Z3-E36	BodyInstrument cluster					Reset service interval indicator X
All	1996-2002	Z Series_Z3-E36	BodyLight Check Module					Read out operating data X
All	After 2002	Z Series_Z4-E85	DME/DDE (Motor/Diesel Electronics)	X	X	X	X	
All	After 2002	Z Series_Z4-E85	EML Electronic engine-power control	X	X			
All	After 2002	Z Series_Z4-E85	EGS transmission control	X	X	X	X	
All	After 2002	Z Series_Z4-E85	EWS Vehicle immobilizer	X	X	X		
All	After 2002	Z Series_Z4-E85	ABS/ASC/DSC (Dynamic Stability Control)	X	X	X	X	
All	After 2002	Z Series_Z4-E85	LEW/LWS (Steering angle sensor)	X	X	X		
All	After 2002	Z Series_Z4-E85	EPS Electronic Power Steering	X	X	X		
All	After 2002	Z Series_Z4-E85	MFL Multi-function steering wheel	X		X		
All	After 2002	Z Series_Z4-E85	ZKE/GM (Central body electronics/GM base module)	X	X	X	X	
All	After 2002	Z Series_Z4-E85	CVM Convertible top module	X	X	X		
All	After 2002	Z Series_Z4-E85	BM/MIR (On-board monitor/Multi-Information Radio)	X	X	X	X	
All	After 2002	Z Series_Z4-E85	IHKA/IHKB Integrated heating/air conditioning	X	X	X	X	
All	After 2002	Z Series_Z4-E85	KOM/IKE/IKI/INSTR(Instrument cluster)	X	X	X	X	
All	After 2002	Z Series_Z4-E85	LSZ/LCM (Lights switching center)	X	X	X	X	
All	After 2002	Z Series_Z4-E85	LRA Automatic headlight vertical aim control	X	X			
All	After 2002	Z Series_Z4-E85	SBSL Satellite,B-pillar,left	X	X	X		
All	After 2002	Z Series_Z4-E85	SBSR Satellite,B-pillar,right	X	X	X		
All	After 2002	Z Series_Z4-E85	MRS/AirBag/SIM (Multiple Restraint System)	X	X			
All	After 2002	Z Series_Z4-E85	PDC Park Distance Control	X	X	X	X	
All	After 2002	Z Series_Z4-E85	NAV Navigation computer	X	X	X		
All	After 2002	Z Series_Z4-E85	SMF/SM/SLM (Seat memory ,driver)	X	X	X	X	
All	After 2002	Z Series_Z4-E85	MID Multi Information Display	X	X			
All	After 2002	Z Series_Z4-E85	SZM Switching center,center console	X	X	X		

All	After 2002	Z Series_Z4-E85	RLS/AIC (Rain/Light Sensor/Automatic interval Control)	X	X	X		
All	After 2002	Z Series_Z4-E85	TCU/ULF/TEL/BIT (Telematic Control unit)	X	X			
All	After 2002	Z Series_Z4-E85	VID Video module	X	X			
All	After 2002	Z Series_Z4-E85	RAD Radio	X	X	X	X	
All	After 2002	Z Series_Z4-E85	STH park heating	X				
All	After 2002	Z Series_Z4-E85	DSP Digital Sound Processor	X				
All	After 2002	Z Series_Z4-E85	SES Language-input system	X	X		X	
All	After 2002	Z Series_Z4-E85	SHD Sliding/titing sunroof	X	X			
All	After 2002	Z Series_Z4-E85	Chassis\Wheel-slip control system					Adjustment,steering-angle sensor X
All	After 2002	Z Series_Z4-E85	Body\Instrument cluster					Reset service interval indicator X
All	After 2002	Z Series_Z4-E85	Body\Light Check Module					Read out operating data X
All	2009	Z Series_Z4-E89	DME/DDE (Motor/Diesel Electronics)	X	X	X	X	
	2009	Z Series_Z4-E89	CAS Car Access System	X	X	X		
All	2009	Z Series_Z4-E89	EGS transmission control	X	X	X	X	
All	2009	Z Series_Z4-E89	DSC Dynamic Stability Control	X	X	X		
All	2009	Z Series_Z4-E89	IHKA Integrated automatic heating/air conditioning	X	X	X	X	
All	2009	Z Series_Z4-E89	INSTR Instrument cluster	X	X	X	X	
All	2009	Z Series_Z4-E89	MRS/AirBag/SIM (Multiple Restraint System)	X	X	X	X	
All	2000-2003	Z Series_Z8-E52	DME/DDE (Motor/Diesel Electronics)	X	X	X	X	
All	2000-2003	Z Series_Z8-E52	EML Electronic engine-power control	X	X			
All	2000-2003	Z Series_Z8-E52	EGS transmission control	X	X	X	X	
All	2000-2003	Z Series_Z8-E52	EWS Vehicle immobilizer	X	X	X		
All	2000-2003	Z Series_Z8-E52	ABS/ASC/DSC (Dynamic Stability Control)	X	X	X	X	
All	2000-2003	Z Series_Z8-E52	LEW/LWS (Steering angle sensor)	X	X	X		
All	2000-2003	Z Series_Z8-E52	EPS Electronic Power Steering	X	X	X		
All	2000-2003	Z Series_Z8-E52	MFL Multi-function steering wheel	X		X		
All	2000-2003	Z Series_Z8-E52	ZKE/GM (Central body electronics/GM base module)	X	X	X	X	
All	2000-2003	Z Series_Z8-E52	CVM Convertible top module	X	X	X		
All	2000-2003	Z Series_Z8-E52	BM/MIR (On-board monitor/Multi-Information Radio)	X	X	X	X	
All	2000-2003	Z Series_Z8-E52	IHKA/IHKB Integrated heating/air conditioning	X	X	X	X	
All	2000-2003	Z Series_Z8-E52	KOM/IKE/IKI/INSTR(Instrument cluster)	X	X	X	X	
All	2000-2003	Z Series_Z8-E52	LSZ/LCM (Lights switching center)	X	X	X	X	
All	2000-2003	Z Series_Z8-E52	LRA Automatic headlight vertical aim control	X	X			
All	2000-2003	Z Series_Z8-E52	SBSL Satellite,B-pillar,left	X	X	X		
All	2000-2003	Z Series_Z8-E52	SBSR Satellite,B-pillar,right	X	X	X		
All	2000-2003	Z Series_Z8-E52	MRS/AirBag/SIM (Multiple Restraint System)	X	X			
All	2000-2003	Z Series_Z8-E52	PDC Park Distance Control	X	X	X	X	
All	2000-2003	Z Series_Z8-E52	NAV Navigation computer	X	X	X		
All	2000-2003	Z Series_Z8-E52	SMF/SM/SLM (Seat memory ,driver)	X	X	X	X	
All	2000-2003	Z Series_Z8-E52	MID Multi Information Display	X	X			
All	2000-2003	Z Series_Z8-E52	SZM Switching center,center console	X	X	X		
All	2000-2003	Z Series_Z8-E52	RLS/AIC (Rain/Light Sensor/Automatic interval Control)	X	X	X		

All	2000-2003	Z Series_Z8-E52	TCU/ULF/TEL/BIT (Telematic Control unit)	X	X			
All	2000-2003	Z Series_Z8-E52	VID Video module	X	X			
All	2000-2003	Z Series_Z8-E52	RAD Radio	X	X	X	X	
All	2000-2003	Z Series_Z8-E52	STH park heating	X				
All	2000-2003	Z Series_Z8-E52	DSP Digital Sound Processor	X				
All	2000-2003	Z Series_Z8-E52	SES Language-input system	X	X		X	
All	2000-2003	Z Series_Z8-E52	SHD Sliding/tilting sunroof	X	X			
All	2000-2003	Z Series_Z8-E52	Chassis\Wheel-slip control system					Adjustment,steering-angle sensor X
All	2000-2003	Z Series_Z8-E52	Body\Instrument cluster					Reset service interval indicator X
All	2000-2003	Z Series_Z8-E52	Body\Light Check Module					Read out operating data X
All	2001-2006	MINI_R50/R52/R53	Short test	X	X			
All	2001-2006	MINI_R50/R52/R53	DME Digital Engine/Gearbox Electronics 2	X	X	X	X	
All	2001-2006	MINI_R50/R52/R53	EWS Electronic immobilizer	X	X	X		
All	2001-2006	MINI_R50/R52/R53	ABS/ASC/DSC Dynamic Stability control	X	X	X	X	
All	2001-2006	MINI_R50/R52/R53	EHPS Electro-hydraulic steering assistance	X	X	X	X	
All	2001-2006	MINI_R50/R52/R53	LEW Steering-angle sensor	X	X	X		
All	2001-2006	MINI_R50/R52/R53	RLS/AIC (Rain/Light Sensor/Automatic interval Control)	X	X			
All	2001-2006	MINI_R50/R52/R53	BM On-board monitor	X				
All	2001-2006	MINI_R50/R52/R53	KOM Instrument cluster	X	X	X	X	
All	2001-2006	MINI_R50/R52/R53	KOMBI2 additional Instruments	X				
All	2001-2006	MINI_R50/R52/R53	IHKA Heater/automatic A/C control	X	X	X	X	
All	2001-2006	MINI_R50/R52/R53	MFL Multifunction steering wheel I	X	X	X		
All	2001-2006	MINI_R50/R52/R53	MRS Multiple Restraint System IV	X	X			
All	2001-2006	MINI_R50/R52/R53	LRA Headlight vertical aim control	X	X	X	X	
All	2001-2006	MINI_R50/R52/R53	NAV Navigation computer, Europe	X	X	X		
All	2001-2006	MINI_R50/R52/R53	PDC Park Distance Control	X	X	X	X	
All	2001-2006	MINI_R50/R52/R53	RAD Radio	X	X	X	X	
All	2001-2006	MINI_R50/R52/R53	CVM Convertible top module	X	X	X	X	
All	2001-2006	MINI_R50/R52/R53	STH park heating	X				
All	2001-2006	MINI_R50/R52/R53	SHD Sliding/tilting sunroof module	X	X			
All	2001-2006	MINI_R50/R52/R53	ZKE Central body electronics BC 1	X	X	X	X	
All	2001-2006	MINI_R50/R52/R53	Drive\Digital Motor Electronics					Clear adaptations X
All	2001-2006	MINI_R50/R52/R53	Drive\EGS transmission control					Clear adaptations X
All	2001-2006	MINI_R50/R52/R53	Drive\Electronic car immobilisation system					Disable/enable key X
All	2001-2006	MINI_R50/R52/R53	Body\Instrument cluster					Reset service interval indicator X
All	2007-2010	MINI_R55/R56/R57	CAS Car Access System	X	X	X	X	
All	2007-2010	MINI_R55/R56/R57	EGS transmission control	X	X	X	X	
All	2007-2010	MINI_R55/R56/R57	DME Motor Electronics	X	X	X	X	
All	2007-2010	MINI_R55/R56/R57	DDE Diesel Electronics	X	X	X	X	
All	2007-2010	MINI_R55/R56/R57	EPS Electronic Power Steering	X	X	X	X	
All	2007-2010	MINI_R55/R56/R57	DSC Dynamic Stability Control	X	X	X	X	
All	2007-2010	MINI_R55/R56/R57	RAD2-BO User interface	X	X	X	X	
All	2007-2010	MINI_R55/R56/R57	RAD2-GW Gateway	X	X	X	X	

All	2007-2010	MINI_R55/R56/R57	FRM/FRM2 Footwell module	X	X	X	X	
All	2007-2010	MINI_R55/R56/R57	IHKS Integrated heating/air-conditioning control	X	X	X	X	
All	2007-2010	MINI_R55/R56/R57	IHKA Integrated heating /air conditioning	X	X	X	X	
All	2007-2010	MINI_R55/R56/R57	IHS Heater control	X	X	X	X	
	2007-2010	MINI_R55/R56/R57	CA Comfort Access	X	X	X	X	
All	2007-2010	MINI_R55/R56/R57	JBE Junction-box electronics	X	X	X	X	
All	2007-2010	MINI_R55/R56/R57	INSTR Instrument cluster	X	X	X	X	
All	2007-2010	MINI_R55/R56/R57	MRS Multiple Restraint System	X	X	X		
All	2007-2010	MINI_R55/R56/R57	SZL Switch center,steering column	X	X	X		
All	2007-2010	MINI_R55/R56/R57	AMP Amplifier	X	X	X	X	
All	2007-2010	MINI_R55/R56/R57	SHD Sliding/tilting sunroof module	X	X	X	X	
All	2007-2010	MINI_R55/R56/R57	Maintenance\CBS reset					1 Engine oil X
All	2007-2010	MINI_R55/R56/R57						3 Front brake X
All	2007-2010	MINI_R55/R56/R57						4 Rear brake X
All	2007-2010	MINI_R55/R56/R57						8 Brake fluid X
All	2007-2010	MINI_R55/R56/R57						9 Vehicle check X
All	2007-2010	MINI_R55/R56/R57						10 Vehicle inspection: X
All	2007-2010	MINI_R55/R56/R57						11 Exhaust emission inspection: X
All	2007-2010	MINI_R55/R56/R57	Body\JBE Junction-box electronics					Start windows initalisation
All	2007-2010	MINI_R55/R56/R57	Chassis\SZL Switch center, steeing column					Steering angle sensor adjustment
All	2007-2010	Coding/Program	E31					Display coding code X
All	2007-2010	Coding/Program	E32					Display coding code X
All	2007-2010	Coding/Program	E34					Display coding code X
All	2007-2010	Coding/Program	E36(With Z3)					Display coding code X
All	2007-2010	Coding/Program	E38					Display coding code X
All	2007-2010	Coding/Program	E39					Display coding code X
All	2007-2010	Coding/Program	E46					Display coding code X
All	2007-2010	Coding/Program	X5-E53					Display coding code X
All	2007-2010	Coding/Program	ALIGNMENT EWS-DME					ALIGNMENT EWS-DME X