

Note X: Covered *: New update

Benz V10.0									
Model Information					Diagnostic Function				
Market	Year	Model	Type	System	ECU Info.	DTC	Data List	Active Test	Special Func.
All	1998-2004	A-Class	168	ECM - Engine control monolith	X	X	X	X	
All	1998-2004	A-Class	168	CDI - Common Rail Diesel Injection	X	X	X	X	
All	1998-2004	A-Class	168	ACS - Automatic clutch system	X	X	X	X	
All	1998-2004	A-Class	168	FTC - Front transmission control	X	X	X	X	Control module adaptations Diagnosis routiness
All	1998-2004	A-Class	168	GRM - Gear recognition module	X	X	X	X	
All	1998-2004	A-Class	168	ESP - Electronic stability program	X	X	X		
All	1998-2004	A-Class	168	AB - Airbag	X	X	X		
All	1998-2004	A-Class	168	LCP - Lower control panel	X	X	X	X	
All	1998-2004	A-Class	168	ATA - Anti-theft alarm system	X	X	X	X	
All	1998-2004	A-Class	168	RFL - Radio frequency locking/electric central locking	X	X	X	X	
All	1998-2004	A-Class	168	ICM - Instrument cluster with maintenance interval display	X	X	X	X	
All	1998-2004	A-Class	168	PTS - Parktronic system	X	X	X	X	Read coding and change if necessary
All	1998-2004	A-Class	168	D2B - AUDIO	X	X	X	X	Read coding and change if necessary
All	1998-2004	A-Class	168	CDC - CD changer	X	X			
All	1998-2004	A-Class	168	CTEL - Cellular telephone 1(fixed installation or portable)(D2B)	X	X			
All	1998-2004	A-Class	168	APS - Auto pilot system	X	X			
All	1998-2004	A-Class	168	DCM-FL - Door control module front left	X	X	X	X	
All	1998-2004	A-Class	168	DCM-FR - Door control module front right	X	X	X	X	
All	1998-2004	A-Class	168	DCM-RL - Door control module rear left	X	X	X	X	
All	1998-2004	A-Class	168	DCM-RR - Door control module rear right	X	X	X	X	
All	1998-2004	A-Class	168	HEAT/TAC - Automatic heater + PTC heater booster/Automatic temperature control	X	X	X	X	
All	1998-2004	A-Class	168	STH/HB - Stationary heater/Heater booster	X	X	X	X	
All	2004-2005	A-Class	169	ESM - Electronic selector module	X	X	X	X	Read coding and change if necessary

All	2004-2005	A-Class	169	FCVT - Continuously variable automatic transmission	X	X	X		
All	2004-2005	A-Class	169	ME-SFI - Motor electronics	X	X	X	X	
All	2004-2005	A-Class	169	CDI - Common Rail Diesel Injection	X	X	X	X	
All	2004-2005	A-Class	169	ESP - Electronic stability program	X	X	X		
All	2004-2005	A-Class	169	ES - Electrical power steering	X	X	X		
All	2004-2005	A-Class	169	AB - Airbag	X	X	X		
All	2004-2005	A-Class	169	CGW - Central gateway	X	X			
All	2004-2005	A-Class	169	EIS - Electronic ignition switch(Without Keyless Go)	X	X	X		
All	2004-2005	A-Class	169	HRA-FR - Front right headlamp range control	X	X	X		
All	2004-2005	A-Class	169	HRA-FL - Front left headlamp range control	X	X	X	X	
All	2004-2005	A-Class	169	OCP - Overhead control panel	X	X	X		
All	2004-2005	A-Class	169	UCP - Upper control panel	X	X	X	X	
All	2004-2005	A-Class	169	SAM - Signal acquisition and actuation module	X	X	X	X	
All	2004-2005	A-Class	169	AHE - Trailer recognition	X	X	X	X	
All	2004-2005	A-Class	169	SVMCM - Special vehicle multifunction control module	X	X			
All	2004-2005	A-Class	169	On-board electrical system(voltage supply)	X	X	X		
All	2004-2005	A-Class	169	ATA - Anti-theft alarm system	X	X	X	X	
All	2004-2005	A-Class	169	IC - Instrument cluster	X	X	X	X	
All	2004-2005	A-Class	169	ASSYST Active Service System	X	X	X		AssystSetting
All	2004-2005	A-Class	169	ASSYST PLUS - PLUS Active Service System	X	X	X		General servicing Control unit adaptations
All	2004-2005	A-Class	169	SCM - Steering column module	X	X	X	X	Initial startup
All	2004-2005	A-Class	169	PTS - Parktronic system	X	X	X	X	

All	2004-2005	A-Class	169	AGW - Audio gateway(MOST network management,diagnosis gateway,radio tuner)	X	X	X	X	
All	2004-2005	A-Class	169	COMAND/AUDIO - Audio50 or COMAND	X	X	X	X	
All	2004-2005	A-Class	169	CDC - CD changer	X	X	X		
All	2004-2005	A-Class	169	TV - TV tuner(Not valid for Japan and USA)	X	X	X	X	
All	2004-2005	A-Class	169	CTEL - Telephone adapter for portable CTCL	X	X	X		
All	2004-2005	A-Class	169	DCM-FL - Door control module front left	X	X	X	X	
All	2004-2005	A-Class	169	DCM-FR - Door control module front right	X	X	X	X	
All	2004-2005	A-Class	169	DCM-RL - Door control module rear left	X	X	X	X	
All	2004-2005	A-Class	169	DCM-RR - Door control module rear right	X	X	X	X	
All	2004-2005	A-Class	169	C-AAC/AAC/HEAT - Convenience automatic air conditioning	X	X	X	X	
All	2005-2009	A-Class	169	ESM - Electronic selector module	X	X	X	X	Read coding and change if necessary
All	2005-2009	A-Class	169	FCVT - Continuously variable automatic transmission	X	X	X		
All	2005-2009	A-Class	169	ME-SFI - Motor electronics	X	X	X	X	
All	2005-2009	A-Class	169	CDI - Common Rail Diesel Injection	X	X	X	X	
All	2005-2009	A-Class	169	ESP - Electronic stability program	X	X	X		
All	2005-2009	A-Class	169	ES - Electrical power steering	X	X	X		
All	2005-2009	A-Class	169	AB - Airbag	X	X	X		
All	2005-2009	A-Class	169	EIS - Electronic ignition switch(Without Keyless Go)	X	X			
All	2005-2009	A-Class	169	HRA-FR - Front right headlamp range control	X	X	X		
All	2005-2009	A-Class	169	HRA-FL - Front left headlamp range control	X	X	X		

All	2005-2009	A-Class	169	OCP - Overhead control panel	X	X	X	X	
All	2005-2009	A-Class	169	UCP - Upper control panel	X	X	X		
All	2005-2009	A-Class	169	SAM - Signal acquisition and actuation module	X	X	X	X	
All	2005-2009	A-Class	169	AHE - Trailer recognition	X	X	X	X	
All	2005-2009	A-Class	169	SVMCM - Special vehicle multifunction control module	X	X	X	X	
All	2005-2009	A-Class	169	On-board electrical system(voltage supply)	X	X			
All	2005-2009	A-Class	169	ATA - Anti-theft alarm system	X	X	X		
All	2005-2009	A-Class	169	ICM - Instrument cluster with maintenance interval display	X	X	X	X	General servicing
All	2005-2009	A-Class	169	SCM - Steering column module	X	X	X	X	Initial startup
All	2005-2009	A-Class	169	PTS - Parktronic system	X	X	X	X	
All	2005-2009	A-Class	169	AGW - Audio gateway(MOST network management,diagnosis gateway,radio tuner)	X	X	X	X	
All	2005-2009	A-Class	169	COMAND/AUDIO - Audio50 or COMAND	X	X	X	X	
All	2005-2009	A-Class	169	CDC - CD changer	X	X	X		
All	2005-2009	A-Class	169	TV - TV tuner(Not valid for Japan and USA)	X	X	X	X	
All	2005-2009	A-Class	169	CTEL - Telephone adapter for portable CTEL	X	X	X		
All	2005-2009	A-Class	169	DCM-FL - Door control module front left	X	X	X	X	

All	2005-2009	A-Class	169	DCM-FR - Door control module front right	X	X	X	X	
All	2005-2009	A-Class	169	DCM-RL - Door control module rear left	X	X	X	X	
All	2005-2009	A-Class	169	DCM-RR - Door control module rear right	X	X	X	X	
All	2005-2009	A-Class	169	C-AAC/AAC/HEAT - Convenience automatic air conditioning	X	X	X	X	
All	2005	B-Class	245	ESM - Electronic selector module	X	X	X	X	Read coding and change if necessary
All	2005	B-Class	245	CDI - Common Rail Diesel Injection	X	X	X	X	
All	2005	B-Class	245	FCVT - Continuously variable automatic transmission	X	X	X		
All	2005	B-Class	245	ME-SFI - Motor electronics	X	X	X	X	
All	2005	B-Class	245	ESP - Electronic stability program	X	X	X		
All	2005	B-Class	245	ES - Electrical power steering	X	X	X		
All	2005	B-Class	245	AB - Airbag	X	X	X		
All	2005	B-Class	245	CGW - Central gateway	X	X			
All	2005	B-Class	245	EIS - Electronic ignition switch(Without Keyless Go)	X	X	X		
All	2005	B-Class	245	XALWA-L - Xenon headlamp,left	X	X	X		
All	2005	B-Class	245	XALWA-R - Xenon headlamp,right	X	X	X		
All	2005	B-Class	245	OCP - Overhead control panel	X	X	X		
All	2005	B-Class	245	UCP - Upper control panel	X	X	X	X	
All	2005	B-Class	245	SAM - Signal acquisition and actuation module	X	X	X	X	
All	2005	B-Class	245	AHE - Trailer recognition	X	X	X	X	
All	2005	B-Class	245	SVMCM - Special vehicle multifunction control module	X	X			
All	2005	B-Class	245	On-board electrical system(voltage supply)	X	X	X		
All	2005	B-Class	245	ATA - Anti-theft alarm system	X	X	X	X	
All	2005	B-Class	245	IC - Instrument cluster	X	X	X	X	
All	2005	B-Class	245	ASSYST Active Service System	X	X	X		
All	2005	B-Class	245	ASSYST PLUS - PLUS Active Service System	X	X	X		

All	2005	B-Class	245	SCM - Steering column module	X	X	X	X	Initial startup
All	2005	B-Class	245	PTS - Parktronic system	X	X	X	X	
All	2005	B-Class	245	AGW - Audio gateway(MOST network management,diagnosis gateway,radio tuner)	X	X	X	X	
All	2005	B-Class	245	COMAND/AUDIO - Audio50 or COMAND	X	X	X	X	
All	2005	B-Class	245	CDC - CD changer	X	X	X		
All	2005	B-Class	245	TV - TV tuner(Not valid for Japan and USA)	X	X	X	X	
All	2005	B-Class	245	CTEL - Telephone adapter for portable CTCL	X	X	X		
All	2005	B-Class	245	DCM-FL - Door control module front left	X	X	X	X	
All	2005	B-Class	245	DCM-FR - Door control module front right	X	X	X	X	
All	2005	B-Class	245	DCM-RL - Door control module rear left	X	X	X	X	
All	2005	B-Class	245	DCM-RR - Door control module rear right	X	X	X	X	
All	2005	B-Class	245	C-AAC/AAC/HEAT - Convenience automatic air conditioning	X	X	X	X	
All	2005-2009	B-Class	245	ESM - Electronic selector module	X	X	X	X	Read coding and change if necessary
All	2005-2009	B-Class	245	CDI - Common Rail Diesel Injection	X	X	X	X	
All	2005-2009	B-Class	245	FCVT - Continuously variable automatic transmission	X	X	X		
All	2005-2009	B-Class	245	ME-SFI - Motor electronics	X	X	X	X	
All	2005-2009	B-Class	245	ESP - Electronic stability program	X	X	X		

All	2005-2009	B-Class	245	ES - Electrical power steering	X	X	X		
All	2005-2009	B-Class	245	AB - Airbag	X	X	X		
All	2005-2009	B-Class	245	CGW - Central gateway	X	X			
All	2005-2009	B-Class	245	EIS - Electronic ignition switch(Without Keyless Go)	X	X	X		
All	2005-2009	B-Class	245	XALWA-L - Xenon headlamp,left	X	X	X		
All	2005-2009	B-Class	245	XALWA-R - Xenon headlamp,right	X	X	X		
All	2005-2009	B-Class	245	OCP - Overhead control panel	X	X	X		
All	2005-2009	B-Class	245	UCP - Upper control panel	X	X	X	X	
All	2005-2009	B-Class	245	SAM - Signal acquisition and actuation module	X	X	X	X	
All	2005-2009	B-Class	245	AHE - Trailer recognition	X	X	X	X	
All	2005-2009	B-Class	245	SVMCM - Special vehicle multifunction control module	X	X			
All	2005-2009	B-Class	245	On-board electrical system(voltage supply)	X	X	X		
All	2005-2009	B-Class	245	ATA - Anti-theft alarm system	X	X	X	X	
All	2005-2009	B-Class	245	ICM - Instrument cluster with maintenance interval display	X	X	X	X	General servicing
All	2005-2009	B-Class	245	SCM - Steering column module	X	X	X	X	Initial startup
All	2005-2009	B-Class	245	PTS - Parktronic system	X	X	X	X	
All	2005-2009	B-Class	245	AGW - Audio gateway(MOST network management,diagnosis gateway,radio tuner)	X	X	X	X	
All	2005-2009	B-Class	245	COMAND/AUDIO - Audio50 or COMAND	X	X	X	X	
All	2005-2009	B-Class	245	CDC - CD changer	X	X	X		
All	2005-2009	B-Class	245	TV - TV tuner(Not valid for Japan and USA)	X	X	X	X	

All	2005-2009	B-Class	245	CTEL - Telephone adapter for portable CTCL	X	X	X		
All	2005-2009	B-Class	245	DCM-FL - Door control module front left	X	X	X	X	
All	2005-2009	B-Class	245	DCM-FR - Door control module front right	X	X	X	X	
All	2005-2009	B-Class	245	DCM-RL - Door control module rear left	X	X	X	X	
All	2005-2009	B-Class	245	DCM-RR - Door control module rear right	X	X	X	X	
All	2005-2009	B-Class	245	C-AAC/AAC/HEAT - Convenience automatic air conditioning	X	X		X	
All	1984-1993	C-CLASS	201	AB	X	X	X		
All	1994-1996	C-CLASS	202	HFM	X	X	X		
All	1994-1996	C-CLASS	202	ME2	X	X	X		
All	1994-1996	C-CLASS	202	PMS	X	X	X		
All	1994-1996	C-CLASS	202	ERE	X	X	X		
All	1994-1996	C-CLASS	202	ABS	X	X	X		
All	1994-1996	C-CLASS	202	ASR	X	X	X		
All	1994-1996	C-CLASS	202	ETS	X	X	X		
All	1994-1996	C-CLASS	202	ESP	X	X	X		
All	1994-1996	C-CLASS	202	BAS	X	X	X		
All	1994-1996	C-CLASS	202	EGS	X	X	X	X	
All	1994-1996	C-CLASS	202	RCL(DAS1/X)	X	X	X		
All	1994-1996	C-CLASS	202	RCL(DAS2/X)	X	X	X		
All	1994-1996	C-CLASS	202	ATA	X	X	X		
All	1994-1996	C-CLASS	202	AB	X	X	X		
All	1994-1996	C-CLASS	202	KI	X	X	X	X	
All	1994-1996	C-CLASS	202	LWR	X	X	X		
All	1994-1996	C-CLASS	202	TAC	X	X			
All	1997-2000	C-CLASS	202	ETC - Electronic transmission control	X	X	X	X	
All	1997-2000	C-CLASS	202	ESM - Electronic selector module	X	X	X	X	
All	1997-2000	C-CLASS	202	HFM-SFI - Hot film engine management	X	X	X		
All	1997-2000	C-CLASS	202	ME2-SFI - Motor electronics	X	X	X		
All	1997-2000	C-CLASS	202	CDI - Common Rail Diesel Injection	X	X	X	X	
All	1997-2000	C-CLASS	202	IFI - Electronic in-line injection system diesel/DFI - Electronic distributor injection system diesel	X	X	X	X	
All	1997-2000	C-CLASS	202	Traction systems ABS,ASR,ETS,ESP	X	X	X	X	Road test Learning processes Resetting of variant locking

All	1997-2000	C-CLASS	202	BAS - Brake assist	X	X	X		
All	1997-2000	C-CLASS	202	AB - Airbag	X	X	X		Read coding and change if necessary Coded vehicle data
All	1997-2000	C-CLASS	202	OCP - Overhead control panel	X	X	X	X	
All	1997-2000	C-CLASS	202	EIS - Electronic ignition switch / KG - keyless Go(Special equipment)	X	X	X		
All	1997-2000	C-CLASS	202	PSE - Pneumatic system equipment	X	X	X		Variant coding
All	1997-2000	C-CLASS	202	SAM - Signal acquisition and actuation module	X	X	X		
All	1997-2000	C-CLASS	202	LCP - Lower control panel	X	X	X		
All	1997-2000	C-CLASS	202	HRA - Headlamp rage adjustment	X	X	X		
All	1997-2000	C-CLASS	202	SVMCM - Special vehicle multifunction control module	X	X			
All	1997-2000	C-CLASS	202	ICM - Instrument cluster with maintenance interval display	X	X	X	X	Setting
All	1997-2000	C-CLASS	202	SCM - Steering column module(AS of model year 2002)	X	X	X	X	Initial startup
All	1997-2000	C-CLASS	202	PTS - Parktronic system	X	X	X	X	
All	1997-2000	C-CLASS	202	D2B - COMAND or AUDIO	X	X	X	X	Read coding and change if necessary
All	1997-2000	C-CLASS	202	CDC - CD changer	X	X			
All	1997-2000	C-CLASS	202	VCS - Voice control system	X	X			
All	1997-2000	C-CLASS	202	SOUND - Sound system	X	X			

All	1997-2000	C-CLASS	202	CTEL - Cellular telephone 1(fixed installation or portable)(D2B)	X	X			
All	1997-2000	C-CLASS	202	TELE AID,E-call or cellular telephone - Emergency call system(K-wire)	X	X	X	X	
All	1997-2000	C-CLASS	202	DN - Dynamic navigation by means of CTEL(K-wire)	X	X			
All	1997-2000	C-CLASS	202	APS - Auto pilot system	X	X			
All	1997-2000	C-CLASS	202	SDAR - Satellite radio(USA)	X	X	X	X	
All	1997-2000	C-CLASS	202	DCM1 - Door control module front driver side	X	X	X		
All	1997-2000	C-CLASS	202	DCM2 - Door control module front passenger side	X	X	X		
All	1997-2000	C-CLASS	202	DCM3 - Door control module rear driver side	X	X	X		
All	1997-2000	C-CLASS	202	DCM4 - Door control module rear passenger side	X	X	X		
All	1997-2000	C-CLASS	202	ESA-FL - Electric seat adjustment front left	X	X	X		
All	1997-2000	C-CLASS	202	ESA-FR - Electric seat adjustment front right	X	X	X		
All	1997-2000	C-CLASS	202	TAC - Automatic temperature control/AAC - Automatic air conditioning	X	X	X		Read coding and change if necessary
All	1997-2000	C-CLASS	202	STH - Stationary heater with remote control	X	X			
All	2001-2003	C-CLASS	203	Transmission	X	X	X	X	Initial startup Control unit adaptations Learn air conditioning Adaptations Diagnosis routiness Read coding and/or transfer download to new control unit
All	2001-2003	C-CLASS	203	ESM - Electronic selector module	X	X	X	X	

All	2001-2003	C-CLASS	203	DTR - DISTRONIC	X	X	X		Control unit adaptations
All	2001-2003	C-CLASS	203	ME-SFI - Motor electronics	X	X	X		
All	2001-2003	C-CLASS	203	ME-SFI 2.8 - Motor electronics 2.8	X	X	X	X	
All	2001-2003	C-CLASS	203	CDI2 - Common Rail Diesel Injection 2	X	X	X	X	Adjustment On temperature of heater booster(Electric heater booster) Injector classification/Injector shutoff
All	2001-2003	C-CLASS	203	CDI3 - Common Rail Diesel Injection 3	X	X	X	X	
All	2001-2003	C-CLASS	203	ESP - Electronic stability program	X	X	X	X	
All	2001-2003	C-CLASS	203	BAS - Brake assist	X	X	X	X	
All	2001-2003	C-CLASS	203	AB - Airbag	X	X	X		Read coding and change if necessary Chassis number
All	2001-2003	C-CLASS	203	OCP - Overhead control panel	X	X	X	X	Setting of limit position of excess force limiter
All	2001-2003	C-CLASS	203	EIS - Electronic ignition switch	X	X	X		
All	2001-2003	C-CLASS	203	HRA-FL - Front left headlamp range control	X	X	X		
All	2001-2003	C-CLASS	203	HRA-FR - Front right headlamp range control	X	X	X	X	Zero position adjustment
All	2001-2003	C-CLASS	203	LCP - Lower control panel	X	X	X	X	
All	2001-2003	C-CLASS	203	UCP - Upper control panel	X	X	X	X	Control unit adaptations
All	2001-2003	C-CLASS	203	SAM-F - Signal acquisition and actuation module front	X	X	X	X	
All	2001-2003	C-CLASS	203	REAR SAM - Rear signal acquisition and actuation module	X	X	X	X	Control unit adaptations
All	2001-2003	C-CLASS	203	AHE - Trailer recognition	X	X	X	X	
All	2001-2003	C-CLASS	203	SVMCM - Special vehicle multifunction control module	X	X			
All	2001-2003	C-CLASS	203	ICM - Instrument cluster with maintenance interval display	X	X	X	X	
All	2001-2003	C-CLASS	203	SCM - Steering column module(AS of model year 2002)	X	X	X	X	Initial startup
All	2001-2003	C-CLASS	203	PTS - Parktronic system	X	X	X	X	
All	2001-2003	C-CLASS	203	D2B - COMAND or AUDIO	X	X	X	X	Read coding and change if necessary

All	2001-2003	C-CLASS	203	CDC - CD changer	X	X			
All	2001-2003	C-CLASS	203	VCS - Voice control system	X	X	X		
All	2001-2003	C-CLASS	203	SOUND - Sound system	X	X			
All	2001-2003	C-CLASS	203	CTEL - Cellular telephone 1(fixed installation or portable)(D2B)	X	X			
All	2001-2003	C-CLASS	203	TELE AID,E-call or cellular telephone - Telematic system(K-wire)	X	X	X		
All	2001-2003	C-CLASS	203	TV - TV tuner(Not valid for Japan)	X	X	X		
All	2001-2003	C-CLASS	203	DCM-FL - Door control module front left	X	X	X	X	
All	2001-2003	C-CLASS	203	DCM-FR - Door control module front right	X	X	X	X	
All	2001-2003	C-CLASS	203	DCM-RL - Door control module rear left	X	X	X	X	
All	2001-2003	C-CLASS	203	DCM-RR - Door control module rear right	X	X	X	X	
All	2001-2003	C-CLASS	203	ESA driver - Electric seat adjustment front passenger(with memory)	X	X	X	X	
All	2001-2003	C-CLASS	203	ESA passenger - Electric seat adjustment front passenger(with memory)	X	X	X	X	
All	2001-2003	C-CLASS	203	C-AAC/AAC/HEAT - Convenience automatic air conditioning	X	X	X	X	Read coding and change if necessary Normalizing of position motors Check of adjustment range of positioning motors
All	2001-2003	C-CLASS	203	STH - Stationary heater with remote control	X	X	X	X	

All	2004-2007	C-CLASS	203	Transmission	X	X	X	X	Initial startup Control unit adaptations Adaptations Diagnosis routiness
All	2004-2007	C-CLASS	203	ESM - Electronic selector module	X	X	X	X	Read coding and change if necessary
All	2004-2007	C-CLASS	203	ME-SFI - Motor electronics	X	X	X		
All	2004-2007	C-CLASS	203	ME-SFI 2.8 - Motor electronics 2.8	X	X	X	X	
All	2004-2007	C-CLASS	203	ME 9.7 - Motor electronics 9.7	X	X	X	X	
All	2004-2007	C-CLASS	203	CDI2 - Common Rail Diesel Injection 2	X	X	X	X	Adjustment On temperature of heater booster(Electric heater booster) Injector classification/Injector shutoff
All	2004-2007	C-CLASS	203	CDI3 - Common Rail Diesel Injection 3	X	X	X	X	
All	2004-2007	C-CLASS	203	CDI4 - Common Rail Diesel Injection 4	X	X	X	X	
All	2004-2007	C-CLASS	203	ESP - Electronic stability program	X	X	X	X	Road test Erase zero point offset error of component N49(steering angle sensor)
All	2004-2007	C-CLASS	203	CGW - Central gateway	X	X			
All	2004-2007	C-CLASS	203	EIS - Electronic ignition switch / KG - keyless Go(Special equipment)	X	X	X		
All	2004-2007	C-CLASS	203	AB - Airbag	X	X	X		Read coding and change if necessary Chassis number
All	2004-2007	C-CLASS	203	WSS - Weight sensing system(USA)	X	X			
All	2004-2007	C-CLASS	203	SAM-F - Signal acquisition and actuation module front	X	X	X	X	
All	2004-2007	C-CLASS	203	REAR SAM - Rear signal acquisition and actuation module	X	X	X	X	
All	2004-2007	C-CLASS	203	HRA-FL - Front left headlamp range control	X	X	X		
All	2004-2007	C-CLASS	203	HRA-FR - Front right headlamp range control	X	X	X	X	Zero position adjustment
All	2004-2007	C-CLASS	203	OCP - Overhead control panel	X	X	X	X	Read coding and change if necessary
All	2004-2007	C-CLASS	203	LCP - Lower control panel	X	X	X	X	
All	2004-2007	C-CLASS	203	UCP - Upper control panel	X	X	X	X	
All	2004-2007	C-CLASS	203	System diagnosis	X	X	X		
All	2004-2007	C-CLASS	203	AHE - Trailer recognition	X	X	X	X	
All	2004-2007	C-CLASS	203	On-board electrical system(voltage supply)	X	X	X		
All	2004-2007	C-CLASS	203	ICM - Instrument cluster with maintenance interval display	X	X	X	X	

All	2004-2007	C-CLASS	203	SCM[MRM] - Steering column module	X	X	X	X	Initial startup
All	2004-2007	C-CLASS	203	PTS - Parktronic system	X	X	X	X	
All	2004-2007	C-CLASS	203	AGW - Audio gateway(MOST network management,diagnosis gateway,radio tuner)	X	X	X	X	
All	2004-2007	C-CLASS	203	COMAND/AUDIO - Audio50 or COMAND	X	X	X	X	Read coding and change if necessary
All	2004-2007	C-CLASS	203	CDC - CD changer	X	X	X		
All	2004-2007	C-CLASS	203	TV - TV tuner(Not valid for Japan and USA)	X	X	X	X	
All	2004-2007	C-CLASS	203	CTEL - Telephone adapter for portable CTCL	X	X	X		
All	2004-2007	C-CLASS	203	VCS - Voice control system	X	X			
All	2004-2007	C-CLASS	203	SOUND - Sound system	X	X			
All	2004-2007	C-CLASS	203	TELE AID,E-call or cellular telephone - Telematic system(K-wire)	X	X	X	X	
All	2004-2007	C-CLASS	203	DCM-FL - Door control module front left	X	X	X	X	Read coding and change if necessary Normalize left power window
All	2004-2007	C-CLASS	203	DCM-FR - Door control module front right	X	X	X	X	

All	2004-2007	C-CLASS	203	DCM-RL - Door control module rear left	X	X	X	X	
All	2004-2007	C-CLASS	203	DCM-RR - Door control module rear right	X	X	X	X	
All	2004-2007	C-CLASS	203	ESA driver - Electric seat adjustment front passenger(with memory)	X	X	X	X	
All	2004-2007	C-CLASS	203	ESA passenger - Electric seat adjustment front passenger(with memory)	X	X	X	X	
All	2004-2007	C-CLASS	203	C-AAC/AAC/HEAT - Convenience automatic air conditioning	X	X	X	X	
All	2004-2007	C-CLASS	203	STH - Stationary heater with remote control	X	X	X		
All	2009	CLC	203	Transmission	X	X	X	X	
All	2009	CLC	203	ESM - Electronic selector module	X	X	X	X	
All	2009	CLC	203	ME-SFI - Motor electronics	X	X	X	X	
All	2009	CLC	203	ME 9.7 - Motor electronic 9.7	X	X	X	X	
All	2009	CLC	203	CDI D2 - Common Rail Diesel Injection(Chassis CAN bus)	X	X	X	X	
All	2009	CLC	203	ESP - Electronic stability program	X	X	X	X	
All	2009	CLC	203	EIS - Electronic ignition switch	X	X	X		
All	2009	CLC	203	AB - Airbag	X	X	X		
All	2009	CLC	203	SAM-F - Signal acquisition and actuation module front	X	X	X	X	
All	2009	CLC	203	REAR SAM - Rear signal acquisition and actuation module	X	X	X	X	
All	2009	CLC	203	XALWA-L - Xenon headlamp,left(Front end CAN bus)	X	X	X	X	
All	2009	CLC	203	XALWA-R - Xenon headlamp,right(Front end CAN bus)	X	X	X	X	
All	2009	CLC	203	OCP - Overhead control panel	X	X	X	X	
All	2009	CLC	203	LCP - Lower control panel	X	X	X	X	
All	2009	CLC	203	UCP - Upper control panel	X	X	X	X	
All	2009	CLC	203	On-board electrical system(voltage supply)	X	X	X		
All	2009	CLC	203	ICM - Instrument cluster with maintenance interval display	X	X	X	X	
All	2009	CLC	203	SCM[MRM] - Steering column module	X	X	X	X	

All	2009	CLC	203	PTS - Parktronic system	X	X	X	X	
All	2009	CLC	203	AGW - Audio gateway(MOST network management,diagnosis gateway,radio tuner)	X	X	X	X	
All	2009	CLC	203	COMAND/AUDIO - Audio50 or COMAND	X	X	X	X	
All	2009	CLC	203	CDC - CD changer	X	X	X		
All	2009	CLC	203	TV - TV tuner(Not valid for Japan and USA)	X	X	X	X	
All	2009	CLC	203	CTEL - Telephone adapter for portable CTEL	X	X			
All	2009	CLC	203	VCS - Voice control system	X	X			
All	2009	CLC	203	SOUND - Sound system	X	X			
All	2009	CLC	203	TELE AID,E-call or cellular telephone - Telematic system(K-wire)	X	X	X		
All	2009	CLC	203	DCM-FL - Door control module front left	X	X	X	X	
All	2009	CLC	203	DCM-FR - Door control module front right	X	X	X	X	
All	2009	CLC	203	ESA driver - Electric seat adjustment front passenger(with memory)	X	X	X	X	
All	2009	CLC	203	ESA passenger - Electric seat adjustment front passenger(with memory)	X	X	X	X	

All	2009	CLC	203	C-AAC/AAC/HEAT - Convenience automatic air conditioning	X	X	X	X	
All	2009	CLC	203	STH - Stationary heater with remote control	X	X	X		
All	2008-2009	C-CLASS	204	ME-SFI - Motor electronics(Chassis CAN bus)	X	X	X	X	
All	2008-2009	C-CLASS	204	ME 9.7 - Motor electronics 9.7(Chassis CAN bus)	X	X	X	X	
All	2008-2009	C-CLASS	204	CDI D - Common Rail Diesel Injection(Chassis CAN bus)	X	X	X	X	
All	2008-2009	C-CLASS	204	CDI D2 - Common Rail Diesel Injection(Chassis CAN bus)	X	X	X	X	
All	2008-2009	C-CLASS	204	CDI 6 - Common Rail Diesel Injection(Chassis CAN bus)	X	X	X	X	Replace component Y74 (Pressure control valve) Replace component B28/8 (Pressure differential sensor (DPF)) Reset quantity mean value adaptation data Reset values for HFM drift compensation Resetting air filter learned values after air filter replacement Teaching in the diesel particulate filter after replacing the engine control unit Activate fuel pump Rapid teach-in of zero quantity calibration values
All	2008-2009	C-CLASS	204	ME - Motor electronic 'SIM271DE20' for combustion engine 'M271EVO' (N3/10)	X	X	X	X	
All	2008-2009	C-CLASS	204	FSCU - Fuel Pump(Drive train CAN bus)	X	X	X	X	
All	2008-2009	C-CLASS	204	Transmission	X	X	X	X	
All	2008-2009	C-CLASS	204	ESM - Electronic selector module(Drive train CAN bus)	X	X	X	X	
All	2008-2009	C-CLASS	204	ABR - Adaptive Brake(Chassis CAN bus)	X	X	X		
All	2008-2009	C-CLASS	204	Suspension(Chassis CAN bus)	X	X	X	X	
All	2008-2009	C-CLASS	204	TPC - Tire pressure monitor(Interior CAN bus)	X	X	X	X	
All	2008-2009	C-CLASS	204	CGW - Central gateway(Central CAN bus)	X	X	X		
All	2008-2009	C-CLASS	204	EZS - Electronic ignition switch(Interior CAN bus)	X	X	X		
All	2008-2009	C-CLASS	204	KG - Keyless Go(Interior CAN bus)	X	X			
All	2008-2009	C-CLASS	204	XALWA-L - Xenon headlamp,left(Front end CAN bus)	X	X	X	X	
All	2008-2009	C-CLASS	204	XALWA-R - Xenon headlamp,right(Front end CAN bus)	X	X	X	X	
All	2008-2009	C-CLASS	204	AB - Airbag	X	X	X		

All	2008-2009	C-CLASS	204	WSS - Weight sensor system (USA)(Interior CAN bus)	X	X			
All	2008-2009	C-CLASS	204	System 'Dr-side SAM' with connected LIN components(Interior CAN bus)	X	X	X	X	
All	2008-2009	C-CLASS	204	System 'REAR SAM' with connected LIN components(Interior CAN bus)	X	X	X	X	
All	2008-2009	C-CLASS	204	OCP - Overhead control panel(Interior CAN bus)	X	X	X	X	
All	2008-2009	C-CLASS	204	COU[ZBE] - Central operating unit(Telematic CAN bus)	X	X	X	X	
All	2008-2009	C-CLASS	204	RevETR-LF - Left front reversible emergency tensinoing retrator(Chassis CAN bus)	X	X	X		
All	2008-2009	C-CLASS	204	RevETR-RF - Right front reversible emergency tensinoing retrator(Chassis CAN bus)	X	X	X		
All	2008-2009	C-CLASS	204	ICM - Instrument cluster with maintenance interval display(Interior CAN bus)	X	X	X	X	confirm overall maintenance
All	2008-2009	C-CLASS	204	SCM[MRM] - Steering column module(Chassis CAN bus)	X	X	X	X	
All	2008-2009	C-CLASS	204	PTS - Parktronic(Interior CAN bus)	X	X	X	X	
All	2008-2009	C-CLASS	204	RFK - Backup camera Janpan(Interior CAN bus)	X	X	X		
All	2008-2009	C-CLASS	204	COMAND - COMAND with integral telematics gateway(MOST network management, diagnosis gateway)	X	X	X	X	
All	2008-2009	C-CLASS	204	Tuner - Radio tuner with amplifier	X	X			
All	2008-2009	C-CLASS	204	CTEL - Mobile telephone adapter with universal interface	X	X	X	X	

All	2008-2009	C-CLASS	204	VCS - Voice control(Linguatronic)	X	X	X	X	
All	2008-2009	C-CLASS	204	TV - TV tuner(Not valid for Japan and USA)	X	X	X		
All	2008-2009	C-CLASS	204	SDAR - Satellite radio (Valid for USA)	X	X	X	X	
All	2008-2009	C-CLASS	204	ZAN - Central Display	X	X	X	X	
All	2008-2009	C-CLASS	204	COU[ZBE] - Central operating unit(Telematic CAN bus)	X	X	X	X	
All	2008-2009	C-CLASS	204	KBE-H -Rear A/C operating unit	X	X			
All	2008-2009	C-CLASS	204	System 'Door control module front left' with connected LIN components(Interior CAN bus)	X	X	X	X	
All	2008-2009	C-CLASS	204	System 'Door control module front right' with connected LIN components(Interior CAN bus)	X	X	X	X	
All	2008-2009	C-CLASS	204	DCM-RL - Door control module rear left(Interior CAN bus)	X	X	X	X	
All	2008-2009	C-CLASS	204	DCM-RR - Door control module rear right(Interior CAN bus)	X	X	X	X	
All	2008-2009	C-CLASS	204	ESA driver - Electric seat adjustment driver(Interior CAN bus)	X	X	X	X	
All	2008-2009	C-CLASS	204	AAC - Automatic air conditioning(Interior CAN bus)	X	X	X	X	

All	1998-2002	CLK	208	Transmission	X	X	X	X	Initial startup Control unit adaptations Learn air conditioning Adaptations Diagnosis routiness Read coding and/or transfer download to new control unit
All	1998-2002	CLK	208	ESM - Electronic selector module	X	X	X	X	
All	1998-2002	CLK	208	HFM-SFI - Hot film engine management	X	X	X		
All	1998-2002	CLK	208	ME2-SFI - Motor electronics	X	X	X	X	
All	1998-2002	CLK	208	Traction systems ABS,ASR,ETS,ESP	X	X	X	X	
All	1998-2002	CLK	208	BAS - Brake assist	X	X	X	X	
All	1998-2002	CLK	208	VP-Vacuum pump braker booster	X	X	X	X	
All	1998-2002	CLK	208	AB - Airbag	X	X	X		Read coding and change if necessary Coded vehicle data
All	1998-2002	CLK	208	OCP - Overhead control panel	X	X	X	X	
All	1998-2002	CLK	208	EIS - Electronic ignition switch ELCODE	X	X	X	X	
All	1998-2002	CLK	208	PSE -Pneumatic system equipment	X	X	X	X	Variant coding
All	1998-2002	CLK	208	SAM - Signal acquisition and actuation module	X	X	X		
All	1998-2002	CLK	208	LCP - Lower control panel	X	X	X		
All	1998-2002	CLK	208	HRA - Headlamp range adjustment	X	X	X	X	
All	1998-2002	CLK	208	ICM - Instrument cluster with maintenance interval display	X	X	X	X	Clock Reset odometer to 0 km Oil change
All	1998-2002	CLK	208	D2B - COMAND or AUDIO	X	X	X	X	Read coding and change if necessary
All	1998-2002	CLK	208	CDC - CD changer	X	X			
All	1998-2002	CLK	208	VCS - Voice control system	X	X			
All	1998-2002	CLK	208	CTEL - Cellular telephone 1(fixed installation or portable)(D2B)	X	X			

All	1998-2002	CLK	208	APS - Auto pilot system	X	X			
All	1998-2002	CLK	208	PTS - Parktronic system	X	X	X	X	
All	1998-2002	CLK	208	TELE AID,E-call or cellular telephone - Telematic system(K-wire)	X	X			
All	1998-2002	CLK	208	DN - Dynamic navigation by means of CTCL(K- wire)	X	X			
All	1998-2002	CLK	208	TV - TV tuner	X	X			
All	1998-2002	CLK	208	DCM1 - Door control module front driver side	X	X	X	X	
All	1998-2002	CLK	208	DCM2 - Door control module front passenger side	X	X	X	X	
All	1998-2002	CLK	208	ESA-FL - Electric seat adjustment front left	X	X	X		
All	1998-2002	CLK	208	ESA-FR - Electric seat adjustment front right	X	X	X		
All	1998-2002	CLK	208	TAC-Automatic temperature control/AAC - Automatic air conditioning	X	X	X	X	Variant coding
All	1998-2002	CLK	208	STH - Stationary heater	X	X	X	X	
All	2003-2004	CLK	209	Transmission	X	X	X	X	Initial startup Control unit adaptations Learn air conditioning Adaptations Diagnosis routiness Read coding and/or transfer download to new control unit
All	2003-2004	CLK	209	ESM - Electronic selector module	X	X	X	X	
All	2003-2004	CLK	209	DTR - DISTRONIC	X	X	X		Control unit adaptations
All	2003-2004	CLK	209	ME-SFI - Motor electronics	X	X	X	X	
All	2003-2004	CLK	209	ME-SFI 2.8 - Motor electronics 2.8	X	X	X	X	

All	2003-2004	CLK	209	CDI2 - Common Rail Diesel Injection	X	X	X	X	Adjustment On temperature of heater booster(Electric heater booster) Injector classification/Injector shutoff
All	2003-2004	CLK	209	ESP - Electronic stability program	X	X	X	X	Road test Erase zero point offset error of component N49(steering angle sensor)
All	2003-2004	CLK	209	AB - Airbag	X	X	X		
All	2003-2004	CLK	209	OCP - Overhead control panel	X	X	X		Setting of limit position of excess force limiter
All	2003-2004	CLK	209	EIS - Electronic ignition switch/KG - Keyless GO(Special equipment)	X	X	X		
All	2003-2004	CLK	209	HRA-FL - Front left headlamp range control	X	X	X		
All	2003-2004	CLK	209	HRA-FR - Front right headlamp range control	X	X	X	X	Zero position adjustment
All	2003-2004	CLK	209	LCP - Lower control panel	X	X	X	X	
All	2003-2004	CLK	209	UCP - Upper control panel	X	X	X	X	Control unit adaptations
All	2003-2004	CLK	209	SAM-F - Signal acquisition and actuation module front	X	X	X	X	
All	2003-2004	CLK	209	REAR SAM - Rear signal acquisition and actuation module	X	X	X	X	
All	2003-2004	CLK	209	RVC - Rollover bar soft top control module	X	X	X	X	
All	2003-2004	CLK	209	AHE - Trailer recognition	X	X	X	X	
All	2003-2004	CLK	209	ICM - Instrument cluster with maintenance interval display	X	X	X	X	
All	2003-2004	CLK	209	SCM - Steering column module(AS of model year 2002)	X	X	X	X	initial startup
All	2003-2004	CLK	209	PTS - Parktronic system	X	X	X	X	
All	2003-2004	CLK	209	D2B - COMAND or AUDIO	X	X	X	X	
All	2003-2004	CLK	209	CDC - CD changer	X	X			

All	2003-2004	CLK	209	VCS - Voice control system	X	X			
All	2003-2004	CLK	209	SOUND - Sound system	X	X	X		
All	2003-2004	CLK	209	CTEL - Cellular telephone 1(fixed installation or portable)(D2B)	X	X	X		
All	2003-2004	CLK	209	TELE-AID,E-call or cellular telephone - Telematic system (K-wire)	X	X			
All	2003-2004	CLK	209	TV - TV tuner(Not valid for Japan)	X	X			
All	2003-2004	CLK	209	DCM-L - Door control module left	X	X	X	X	
All	2003-2004	CLK	209	DCM-R - Door control module right	X	X	X	X	
All	2003-2004	CLK	209	ESA driver - Electric seat adjustment front passenger(with memory)	X	X	X	X	
All	2003-2004	CLK	209	ESA passenger - Electric seat adjustment front passenger(with memory)	X	X	X	X	
All	2003-2004	CLK	209	C-AAC/AAC/HEAT - Convenience automatic air conditioning	X	X	X	X	Read coding and change if necessary Normalizing of position motors Check of adjustment range of positioning motors Teaching-in of rotary potentiometer for center nozzle and side outlets
All	2005-2009	CLK	209	Transmission	X	X	X	X	Initial startup Control unit adaptations Learn air conditioning Adaptations Diagnosis routiness Read coding and/or transfer download to new control unit
All	2005-2009	CLK	209	ESM - Electronic selector module	X	X	X	X	
All	2005-2009	CLK	209	ME-SFI - Motor electronics	X	X	X		
All	2005-2009	CLK	209	ME-SFI 2.8 - Motor electronics 2.8	X	X	X	X	
All	2005-2009	CLK	209	ME9.7-Motor electronics 9.7	X	X	X	X	

All	2005-2009	CLK	209	ME9.7(AMG) - Motor electronics 9.7(AMG)	X	X	X	X	
All	2005-2009	CLK	209	CDI2 - Common Rail Diesel Injection	X	X	X	X	Adjustment On temperature of heater booster(Electric heater booster) Injector classification/Injector shutoff
All	2005-2009	CLK	209	CDI3 - Common Rail Diesel Injection 3	X	X	X	X	
All	2005-2009	CLK	209	CDI4 - Common Rail Diesel Injection 4	X	X	X	X	
All	2005-2009	CLK	209	ESP - Electronic stability program	X	X	X	X	Road test
All	2005-2009	CLK	209	TPC - Tire pressure monitor	X	X	X	X	
All	2005-2009	CLK	209	AB - Airbag	X	X	X		
All	2005-2009	CLK	209	OCP - Overhead control panel	X	X	X	X	Read coding and change if necessary
All	2005-2009	CLK	209	EIS - Electronic ignition switch/KG -Keyless Go(Special equipment)	X	X	X	X	
All	2005-2009	CLK	209	HRA - Headlamp range adjustment	X	X	X	X	Read coding and change if necessary Zero position adjustment of axle or level sensors
All	2005-2009	CLK	209	LCP - Lower control panel	X	X	X	X	Initial startup
All	2005-2009	CLK	209	UCP - Upper control panel	X	X	X	X	
All	2005-2009	CLK	209	SAM-F - Signal acquisition and actuation module front	X	X	X	X	
All	2005-2009	CLK	209	REAR SAM - Rear signal acquisition and actuation module	X	X	X	X	
All	2005-2009	CLK	209	RVC - Rollover bar soft top control module	X	X	X	X	
All	2005-2009	CLK	209	AHE - Trailer recognition	X	X	X	X	
All	2005-2009	CLK	209	On-board electrical system (voltage supply)	X	X	X		
All	2005-2009	CLK	209	ICM - Instrument cluster with maintenance interval display	X	X	X	X	
All	2005-2009	CLK	209	SCM - Steering column module(AS of model year 2002)	X	X	X	X	Initial startup
All	2005-2009	CLK	209	PTS - Parktronic system	X	X	X	X	
All	2005-2009	CLK	209	AGW - Audio gateway	X	X	X	X	

All	2005-2009	CLK	209	COMAND/AUDIO - Audio50 or COMAND	X	X	X	X	Read coding and change if necessary
All	2005-2009	CLK	209	CDC - CD changer	X	X	X		
All	2005-2009	CLK	209	HFS - Hands free system and microphone	X	X	X		
All	2005-2009	CLK	209	CTEL - Telephone adapter for portable CTEL	X	X	X	X	
All	2005-2009	CLK	209	DCM-L - Door control module left	X	X	X	X	
All	2005-2009	CLK	209	DCM-R - Door control module right	X	X	X	X	
All	2005-2009	CLK	209	ESA driver - Electric seat adjustment front passenger(with memory)	X	X	X	X	
All	2005-2009	CLK	209	ESA passenger - Electric seat adjustment front passenger(with memory)	X	X	X	X	
All	2005-2009	CLK	209	TLC - Trunk lid control	X	X	X	X	
All	2005-2009	CLK	209	C-AAC/AAC/HEAT - Convenience automatic air conditioning	X	X	X	X	
All	2005-2009	CLK	209	STH - Stationary heater with remote control	X	X	X	X	
All	1984-1995	E-CLASS	124	HFM	X	X	X		
All	1984-1995	E-CLASS	124	PMS	X	X	X		
All	1984-1995	E-CLASS	124	DM(Diagntic Module)	X	X	X		
All	1984-1995	E-CLASS	124	EFP	X	X	X	X	
All	1984-1995	E-CLASS	124	TPM	X	X	X	X	
All	1984-1995	E-CLASS	124	ISC	X	X	X	X	
All	1984-1995	E-CLASS	124	EAG	X	X	X	X	
All	1984-1995	E-CLASS	124	RCL(DAS1/X)	X	X	X		
All	1984-1995	E-CLASS	124	RCL(DAS2/X)	X	X	X		
All	1984-1995	E-CLASS	124	ATA(Anti-Theft Alarm)	X	X	X		
All	1984-1995	E-CLASS	124	AB(Air bag)	X	X	X		
All	1984-1995	E-CLASS	124 034/036	LH1	X	X	X		
All	1984-1995	E-CLASS	124 034/036	DM(Diagntic Module)	X	X	X		
All	1984-1995	E-CLASS	124 034/036	EFP	X	X	X	X	

All	1984-1995	E-CLASS	124 034/036	TPM	X	X	X	X	
All	1984-1995	E-CLASS	124 034/036	ISC	X	X	X	X	
All	1984-1995	E-CLASS	124 034/036	GM	X	X	X		
All	1984-1995	E-CLASS	124 034/036	ASR	X	X	X		
All	1984-1995	E-CLASS	124 034/036	ABS	X	X	X		
All	1984-1995	E-CLASS	124 034/036	ATA(Anti-Theft Alarm)	X	X	X		
All	1984-1995	E-CLASS	124 034/036	AB(Air bag)	X	X	X		
All	1984-1995	E-CLASS	124 034/036	RCL(DAS1)	X	X	X		
All	1996-1997	E-CLASS	210	HFM	X	X	X		
All	1996-1997	E-CLASS	210	ME2	X	X	X		
All	1996-1997	E-CLASS	210	ME1RE	X	X	X		
All	1996-1997	E-CLASS	210	DM	X	X	X		
All	1996-1997	E-CLASS	210	EVE	X	X	X	X	
All	1996-1997	E-CLASS	210	EFP	X	X	X	X	
All	1996-1997	E-CLASS	210	TPM	X	X	X	X	
All	1996-1997	E-CLASS	210	ISC	X	X	X	X	
All	1996-1997	E-CLASS	210	ABS	X	X	X		
All	1996-1997	E-CLASS	210	ASR	X	X	X		
All	1996-1997	E-CLASS	210	ETS	X	X	X		
All	1996-1997	E-CLASS	210	ESP	X	X	X		
All	1996-1997	E-CLASS	210	BAS	X	X	X		
All	1996-1997	E-CLASS	210	ADS	X	X	X		
All	1996-1997	E-CLASS	210	EGS	X	X	X	X	
All	1996-1997	E-CLASS	210	EAG	X	X	X	X	
All	1996-1997	E-CLASS	210	PML	X	X	X		
All	1996-1997	E-CLASS	210	RFL	X	X	X		
All	1996-1997	E-CLASS	210	RCL(DAS1/X)	X	X	X		
All	1996-1997	E-CLASS	210	RCL(DAS2/X)	X	X	X		
All	1996-1997	E-CLASS	210	KFB	X	X	X		
All	1996-1997	E-CLASS	210	PSE	X	X	X		
All	1996-1997	E-CLASS	210	ATA	X	X	X		
All	1996-1997	E-CLASS	210	AB	X	X	X		
All	1996-1997	E-CLASS	210	KI	X	X	X	X	
All	1996-1997	E-CLASS	210	PTS	X	X	X	X	
All	1996-1997	E-CLASS	210	LWR	X	X	X		
All	1996-1997	E-CLASS	210	APS	X	X			
All	1996-1997	E-CLASS	210	Audio,COMMAND	X	X	X	X	
All	1996-1997	E-CLASS	210	Tele-AID	X	X			
All	1996-1997	E-CLASS	210	CDC	X	X	X	X	
All	1996-1997	E-CLASS	210	E-Call	X	X	X	X	
All	1996-1997	E-CLASS	210	SKF	X	X	X	X	
All	1996-1997	E-CLASS	210	Air Conditioning	X	X	X	X	

All	1996-1997	E-CLASS	210	STH	X	X	X	X	
All	1998-2002	E-CLASS	210	Transmission	X	X	X	X	
All	1998-2002	E-CLASS	210	ESM - Electronic selector module	X	X	X	X	Initial startup
All	1998-2002	E-CLASS	210	HFM-SFI - Hot film engine management	X	X	X		
All	1998-2002	E-CLASS	210	ME2-SFI - Motor electronics	X	X	X		
All	1998-2002	E-CLASS	210	IFI- Electronic in-line injection system diesel/DFI- Electronic distributor injection system diesel	X	X	X		
All	1998-2002	E-CLASS	210	CDI - Common Rail Diesel Injection	X	X	X		
All	1998-2002	E-CLASS	210	ABS	X	X	X	X	
All	1998-2002	E-CLASS	210	ASR	X	X	X	X	Road test Learning processes Resetting of variant locking
All	1998-2002	E-CLASS	210	ETS	X	X	X	X	
All	1998-2002	E-CLASS	210	ESP	X	X	X	X	
All	1998-2002	E-CLASS	210	ADS - Adaptive damping system	X	X	X		
All	1998-2002	E-CLASS	210	BAS - Brake assist	X	X	X		
All	1998-2002	E-CLASS	210	VP - Vacuum pump brake booster	X	X	X	X	
All	1998-2002	E-CLASS	210	SPS - Speed-sensitive power steering	X	X			
All	1998-2002	E-CLASS	210	AB - Airbag	X	X	X		Read coding and change if necessary Coded vehicle data
All	1998-2002	E-CLASS	210	OCP - Overhead control panel	X	X	X	X	
All	1998-2002	E-CLASS	210	EIS - Electronic ignition switch ELCODE	X	X	X		
All	1998-2002	E-CLASS	210	PSE - Pneumatic system equipment	X	X	X		Variant coding
All	1998-2002	E-CLASS	210	SAM - Signal acquisition and actuation module	X	X	X		
All	1998-2002	E-CLASS	210	LCP - Lower control panel	X	X	X		
All	1998-2002	E-CLASS	210	HRA - Headlamp range adjustment	X	X	X		
All	1998-2002	E-CLASS	210	SVMCM - Special vehicle multifunction control module	X	X			
All	1998-2002	E-CLASS	210	ICM - Instrument cluster	X	X	X	X	Clock Reset odometer to 0 km Oil change
All	1998-2002	E-CLASS	210	D2B - COMAND or AUDIO	X	X	X	X	Read coding and change if necessary
All	1998-2002	E-CLASS	210	CDC - CD changer	X	X	X	X	

All	1998-2002	E-CLASS	210	VCS - Voice control system	X	X			
All	1998-2002	E-CLASS	210	CTEL - Cellular telephone 1(fixed installation or portable)(D2B)	X	X			
All	1998-2002	E-CLASS	210	APS - Auto pilot system	X	X			
All	1998-2002	E-CLASS	210	PTS - Parktronic system	X	X	X	X	
All	1998-2002	E-CLASS	210	TELE AID,E-call or cellular telephone	X	X	X	X	
All	1998-2002	E-CLASS	210	DN - Dynamic navigation by means of CTCL(K-wire)	X	X			
All	1998-2002	E-CLASS	210	TV - TV tuner	X	X			
All	1998-2002	E-CLASS	210	DCM1 - Door control module front driver side	X	X	X		
All	1998-2002	E-CLASS	210	DCM2 - Door control module front passenger side	X	X	X		
All	1998-2002	E-CLASS	210	DCM3 - Door control module rear driver side	X	X	X		
All	1998-2002	E-CLASS	210	DCM4 - Door control module rear passenger side	X	X	X		
All	1998-2002	E-CLASS	210	ESA-FL - Electric seat adjustment front left	X	X	X		
All	1998-2002	E-CLASS	210	ESA-FR - Electric seat adjustment front right	X	X	X		
All	1998-2002	E-CLASS	210	TAC - Automatic temperature control/AAC - Automatic air conditioning	X	X	X		Read coding and change if necessary
All	1998-2002	E-CLASS	210	STH - Stationary heater	X	X			

All	2003-2005	E-CLASS	211	Transmission	X	X	X	X	Initial startup Control unit adaptations Adaptations Diagnosis routiness
All	2003-2005	E-CLASS	211	ESM - Electronic selector module	X	X	X	X	Read coding and change if necessary
All	2003-2005	E-CLASS	211	DTR - DISTRONIC	X	X	X		
All	2003-2005	E-CLASS	211	ME-SFI - Motor electronics	X	X	X	X	
All	2003-2005	E-CLASS	211	ME-SFI 2.8- Motor electronics 2.8	X	X	X	X	
All	2003-2005	E-CLASS	211	CDI 3 - Common Rail Diesel Injection 3	X	X	X	X	
All	2003-2005	E-CLASS	211	SBC - Sensotronic Brake Control	X	X	X		Deactive system Active system bleed brake system Control unit adaptations
All	2003-2005	E-CLASS	211	ESP - Electronic stability program	X	X	X	X	
All	2003-2005	E-CLASS	211	Suspension	X	X	X	X	Initial startup
All	2003-2005	E-CLASS	211	TPC - Tire pressure monitor	X	X	X	X	Initial startup Control unit adaptations
All	2003-2005	E-CLASS	211	AB - Airbag	X	X	X		Read coding and change if necessary Chassis number
All	2003-2005	E-CLASS	211	WSS - Weight sensor system	X	X			
All	2003-2005	E-CLASS	211	RevETR-LF - Left front reversible emergency tensioning retractor	X	X	X		
All	2003-2005	E-CLASS	211	RevETR-RF - Right front reversible emergency tensioning retractor	X	X	X		
All	2003-2005	E-CLASS	211	CGW - Central gateway	X	X			
All	2003-2005	E-CLASS	211	EIS - Electronic ignition switch/KG - Keyless GO(Special equipment)	X	X	X	X	
All	2003-2005	E-CLASS	211	HRA - Headlamp range adjustment	X	X	X	X	Initial startup Read coding and change if necessary Zero position adjustment of axle or level sensors
All	2003-2005	E-CLASS	211	OCP - Overhead control panel	X	X	X	X	Read coding and change if necessary Panoramic sliding roof
All	2003-2005	E-CLASS	211	UCP - Upper control panel	X	X	X	X	
All	2003-2005	E-CLASS	211	LCP - Lower control panel	X	X	X	X	
All	2003-2005	E-CLASS	211	Dr-side SAM - Dr. signal acquisition and actuation	X	X	X	X	
All	2003-2005	E-CLASS	211	Pass-side SAM - Pass-side signal acquisition and actuation	X	X	X	X	
All	2003-2005	E-CLASS	211	REAR SAM - Rear signal acquisition and actuation module	X	X	X	X	
All	2003-2005	E-CLASS	211	System diagnosis	X	X	X		
All	2003-2005	E-CLASS	211	BCM - Battery control module	X	X	X	X	
All	2003-2005	E-CLASS	211	AHE - Trailer recognition	X	X	X	X	

All	2003-2005	E-CLASS	211	SVMCM -Special vehicle multifunction control	X	X			
All	2003-2005	E-CLASS	211	On-board electrical system (voltage supply)	X	X	X		
All	2003-2005	E-CLASS	211	IC - Instrument cluster	X	X	X	X	
All	2003-2005	E-CLASS	211	ASSYST Active Service System	X	X	X		AssystSetting
All	2003-2005	E-CLASS	211	ASSYST PLUS - PLUS Active Service System	X	X	X		General servicing Control unit adaptations
All	2003-2005	E-CLASS	211	SCM[MRM] - Steering column module	X	X	X	X	Initail startup
All	2003-2005	E-CLASS	211	PTS - Parktronic system	X	X	X	X	
All	2003-2005	E-CLASS	211	AGW - Audio gateway	X	X	X	X	
All	2003-2005	E-CLASS	211	COMAND/AUDIO - Audio50 or COMAND	X	X	X	X	Read coding and change if necessary
All	2003-2005	E-CLASS	211	NAVI - Navigation(Only in combination with COMAND)(Not valid for Japan)	X	X	X	X	
All	2003-2005	E-CLASS	211	CDC - CD changer	X	X	X		
All	2003-2005	E-CLASS	211	HFS - Hands free system and microphone	X	X			

All	2003-2005	E-CLASS	211	TV - TV tuner(Not valid for Japan and USA)	X	X	X	X	
All	2003-2005	E-CLASS	211	CTEL - Telephone adapter for portable CTCL	X	X	X	X	
All	2003-2005	E-CLASS	211	MB Portal - Telematic services WAP,E-mail,Mercedes-Benz Portal	X	X			
All	2003-2005	E-CLASS	211	DCM-FL - Door control module front left	X	X	X	X	Read coding and change if necessary
All	2003-2005	E-CLASS	211	DCM-FR - Door control module front right	X	X	X	X	Read coding and change if necessary
All	2003-2005	E-CLASS	211	DCM-RL - Door control module rear left	X	X	X	X	Read coding and change if necessary
All	2003-2005	E-CLASS	211	DCM-RR - Door control module rear right	X	X	X	X	Read coding and change if necessary
All	2003-2005	E-CLASS	211	ESA driver - Electric seat adjustment driver	X	X	X	X	
All	2003-2005	E-CLASS	211	ESA passenger - Electric seat adjustment FR. Pass.	X	X	X	X	
All	2003-2005	E-CLASS	211	DS-LF - Left front dynamic seat	X	X	X	X	
All	2003-2005	E-CLASS	211	DS-RF - Right front dynamic seat	X	X	X	X	
All	2003-2005	E-CLASS	211	DSP - Pneumatic pump for dynamic seat	X	X	X	X	
All	2003-2005	E-CLASS	211	TLC - Trunk lid control	X	X	X	X	
All	2003-2005	E-CLASS	211	HS - Seat heater	X	X			
All	2003-2005	E-CLASS	211	C-AAC - Convenience automatic air conditioning	X	X	X	X	Read coding and change if necessary Normalizing of position motors Check of adjustment range of positioning motors
All	2003-2005	E-CLASS	211	STH - Stationary heater with remote control	X	X	X	X	
All	2003-2005	E-CLASS	211	HSW - Heated steering wheel	X	X	X	X	

All	2005-2006	E-CLASS	211	Transmission	X	X	X	X	Initial startup Control unit adaptations Adaptations Diagnosis routiness
All	2005-2006	E-CLASS	211	ESM - Electronic selector module	X	X	X	X	Read coding and change if necessary
All	2005-2006	E-CLASS	211	DTR - DISTRONIC	X	X	X	X	
All	2005-2006	E-CLASS	211	ME-SFI - Motor electronics	X	X	X	X	
All	2005-2006	E-CLASS	211	ME-SFI 2.8- Motor electronics 2.8	X	X	X	X	
All	2005-2006	E-CLASS	211	ME 9.7 - Motor electronics 9.7	X	X	X	X	Learning of the throttle valve stop
All	2005-2006	E-CLASS	211	CDI 3 - Common Rail Diesel Injection 3	X	X	X	X	
All	2005-2006	E-CLASS	211	CDI 4 - Common Rail Diesel Injection 4	X	X	X	X	
All	2005-2006	E-CLASS	211	CDI 5 - Common Rail Diesel Injection 5	X	X	X	X	
All	2005-2006	E-CLASS	211	SBC - Sensotronic Brake Control	X	X	X		Deactive system Active system bleed brake system Control unit adaptations
All	2005-2006	E-CLASS	211	ESP - Electronic stability program	X	X	X	X	Road test
All	2005-2006	E-CLASS	211	Suspension	X	X	X	X	Initial startup
All	2005-2006	E-CLASS	211	TPC - Tire pressure monitor	X	X	X	X	Initial startup Control unit adaptations
All	2005-2006	E-CLASS	211	AB - Airbag	X	X	X		Read coding and change if necessary Chassis number
All	2005-2006	E-CLASS	211	WSS - Weight sensor system	X	X			
All	2005-2006	E-CLASS	211	RevETR-LF - Left front revesible emergency tensioning retractor	X	X	X		
All	2005-2006	E-CLASS	211	RevETR-RF - Right front revesible emergency tensioning retractor	X	X	X		
All	2005-2006	E-CLASS	211	CGW - Central gateway	X	X			
All	2005-2006	E-CLASS	211	EIS - Electronic ignition switch/KG - Keyless GO(Special equipment)	X	X	X	X	
All	2005-2006	E-CLASS	211	HRA - Headlamp range adjustment	X	X	X	X	Initial startup Read coding and change if necessary Zero position adjustment of axle or level sensors
All	2005-2006	E-CLASS	211	OCP - Overhead control panel	X	X	X	X	Read coding and change if necessary Panoramic sliding roof
All	2005-2006	E-CLASS	211	UCP - Upper control panel	X	X	X	X	
All	2005-2006	E-CLASS	211	LCP - Lower control panel	X	X	X	X	
All	2005-2006	E-CLASS	211	Dr-side SAM - Dr. signal acquisition and actuation	X	X	X	X	
All	2005-2006	E-CLASS	211	Pass-side SAM - Pass-side signal acquisition and actuation	X	X	X	X	
All	2005-2006	E-CLASS	211	REAR SAM - Rear signal acquisition and actuation module	X	X	X	X	
All	2005-2006	E-CLASS	211	System diagnosis	X	X	X		

All	2005-2006	E-CLASS	211	BCM - Battery control module	X	X	X	X	
All	2005-2006	E-CLASS	211	AHE - Trailer recognition	X	X	X	X	
All	2005-2006	E-CLASS	211	SVMCM -Special vehicle multifunction control	X	X			
All	2005-2006	E-CLASS	211	On-board electrical system (voltage supply)	X	X	X		
All	2005-2006	E-CLASS	211	IC - Instrument cluster	X	X	X	X	
All	2005-2006	E-CLASS	211	ASSYST Active Service System	X	X	X		AssystSetting
All	2005-2006	E-CLASS	211	ASSYST PLUS - PLUS Active Service System	X	X	X		General servicing Control unit adaptations
All	2005-2006	E-CLASS	211	SCM[MRM] - Steering column module	X	X	X	X	
All	2005-2006	E-CLASS	211	PTS - Parktronic system	X	X	X	X	
All	2005-2006	E-CLASS	211	AGW - Audio gateway	X	X	X	X	
All	2005-2006	E-CLASS	211	COMAND/AUDIO - Audio50 or COMAND	X	X	X	X	Read coding and change if necessary
All	2005-2006	E-CLASS	211	NAVI - Navigation(Only in combination with COMAND)(Not valid for Japan)	X	X	X	X	
All	2005-2006	E-CLASS	211	CDC - CD changer	X	X	X		

All	2005-2006	E-CLASS	211	HFS - Hands free system and microphone	X	X			
All	2005-2006	E-CLASS	211	TV - TV tuner(Not valid for Japan and USA)	X	X	X	X	
All	2005-2006	E-CLASS	211	CTEL - Telephone adapter for portable CTCL	X	X	X	X	
All	2005-2006	E-CLASS	211	MB Portal - Telematic services WAP,E-mail,Mercedes-Benz Portal	X	X			
All	2005-2006	E-CLASS	211	DCM-FL - Door control module front left	X	X	X	X	Read coding and change if necessary
All	2005-2006	E-CLASS	211	DCM-FR - Door control module front right	X	X	X	X	Read coding and change if necessary
All	2005-2006	E-CLASS	211	DCM-RL - Door control module rear left	X	X	X	X	Read coding and change if necessary
All	2005-2006	E-CLASS	211	DCM-RR - Door control module rear right	X	X	X	X	Read coding and change if necessary
All	2005-2006	E-CLASS	211	ESA driver - Electric seat adjustment driver	X	X	X	X	
All	2005-2006	E-CLASS	211	ESA passenger - Electric seat adjustment FR. Pass.	X	X	X	X	
All	2005-2006	E-CLASS	211	DS-LF - Left front dynamic seat	X	X	X	X	
All	2005-2006	E-CLASS	211	DS-RF - Right front dynamic seat	X	X	X	X	
All	2005-2006	E-CLASS	211	DSP - Pneumatic pump for dynamic seat	X	X	X	X	
All	2005-2006	E-CLASS	211	TLC - Trunk lid control	X	X	X	X	
All	2005-2006	E-CLASS	211	HS - Seat heater	X	X			
All	2005-2006	E-CLASS	211	C-AAC - Convenience automatic air conditioning/AAC	X	X	X	X	Read coding and change if necessary Normalizing of position motors Check of adjustment range of postioning motors
All	2005-2006	E-CLASS	211	STH - Stationary heater with remote control	X	X	X	X	

All	2005-2006	E-CLASS	211	HSW - Heated steering wheel	X	X	X	X	
All	2006-2008	E-CLASS	211	Transmission	X	X	X	X	Initial startup Control unit adaptations Adaptations Diagnosis routiness
All	2006-2008	E-CLASS	211	ESM - Electronic selector module	X	X	X	X	
All	2006-2008	E-CLASS	211	DTR - Distronic	X	X	X	X	
All	2006-2008	E-CLASS	211	ME-SFI - Motor electronics	X	X	X	X	
All	2006-2008	E-CLASS	211	ME 9.7	X	X	X	X	Learning of the throttle valve stop
All	2006-2008	E-CLASS	211	ME 9.7(AMG)	X	X	X	X	
All	2006-2008	E-CLASS	211	CDI D-Common Rail Diesel Injection	X	X	X	X	
All	2006-2008	E-CLASS	211	CDI 4 - Common Rail Diesel Injection 4	X	X	X	X	
All	2006-2008	E-CLASS	211	CDI 5 - Common Rail Diesel Injection 5	X	X	X	X	
All	2006-2008	E-CLASS	211	ABR - Adaptive Brake	X	X	X	X	
All	2006-2008	E-CLASS	211	Suspension	X	X	X	X	Initial startup
All	2006-2008	E-CLASS	211	TPC - Tire pressure monitor	X	X	X	X	Initial startup Control unit adaptations
All	2006-2008	E-CLASS	211	AB - Airbag	X	X	X		Read coding and change if necessary Chassis number
All	2006-2008	E-CLASS	211	WSS - Weight sensor system	X	X			
All	2006-2008	E-CLASS	211	RevETR-LF - Left front revesible emergency tensioning retractor	X	X	X		
All	2006-2008	E-CLASS	211	RevETR-RF - Right front revesible emergency tensioning retractor	X	X	X		
All	2006-2008	E-CLASS	211	CGW - Central gateway	X	X			
All	2006-2008	E-CLASS	211	EIS - Electronic ignition switch/KG - Keyless GO(Special equipment)	X	X	X	X	
All	2006-2008	E-CLASS	211	HRA - Headlamp range adjustment	X	X	X	X	Initial startup Read coding and change if necessary Zero position adjustment of axle or level sensors
All	2006-2008	E-CLASS	211	XALWA-L - Xenon headlamp, left	X	X	X	X	
All	2006-2008	E-CLASS	211	XALWA-R - Xenon headlamp, right	X	X	X	X	
All	2006-2008	E-CLASS	211	OCP - Overhead control panel	X	X	X	X	Read coding and change if necessary Panornamic sliding roof
All	2006-2008	E-CLASS	211	UCP - Upper control panel	X	X	X	X	
All	2006-2008	E-CLASS	211	LCP - Lower control panel	X	X	X	X	
All	2006-2008	E-CLASS	211	Dr-side SAM - Dr. signal acquisition and actuation	X	X	X	X	
All	2006-2008	E-CLASS	211	Pass-side SAM - Pass-side signal acquisition and actuation	X	X	X	X	
All	2006-2008	E-CLASS	211	REAR SAM - Rear signal acquisition and actuation module	X	X	X	X	
All	2006-2008	E-CLASS	211	System diagnosis	X	X	X		

All	2006-2008	E-CLASS	211	AHE - Trailer recognition	X	X	X	X	
All	2006-2008	E-CLASS	211	SVMCM -Special vehicle multifunction control	X	X			
All	2006-2008	E-CLASS	211	On-board electrical system (voltage supply)	X	X	X	X	
All	2006-2008	E-CLASS	211	IC - Instrument cluster	X	X	X	X	
All	2006-2008	E-CLASS	211	ASSYST Active Service System	X	X	X		AssystSetting
All	2006-2008	E-CLASS	211	ASSYST PLUS - PLUS Active Service System	X	X	X		General servicing Control unit adaptations
All	2006-2008	E-CLASS	211	SCM[MRM] - Steering column module	X	X	X	X	
All	2006-2008	E-CLASS	211	PTS - Parktronic system	X	X	X	X	
All	2006-2008	E-CLASS	211	AGW - Audio gateway	X	X	X	X	
All	2006-2008	E-CLASS	211	COMAND/AUDIO - Audio50 or COMAND	X	X	X	X	Read coding and change if necessary
All	2006-2008	E-CLASS	211	NAVI - Navigation(Only in combination with COMAND)(Not valid for Japan)	X	X	X	X	
All	2006-2008	E-CLASS	211	CDC - CD changer	X	X	X		

All	2006-2008	E-CLASS	211	HFS - Hands free system and microphone	X	X			
All	2006-2008	E-CLASS	211	TV - TV tuner(Not valid for Japan and USA)	X	X	X	X	
All	2006-2008	E-CLASS	211	CTEL - Telephone adapter for portable CTCL	X	X	X	X	
All	2006-2008	E-CLASS	211	MB Portal - Telematic services WAP,E-mail,Mercedes-Benz Portal	X	X			
All	2006-2008	E-CLASS	211	DCM-FL - Door control module front left	X	X	X	X	Read coding and change if necessary
All	2006-2008	E-CLASS	211	DCM-FR - Door control module front right	X	X	X	X	Read coding and change if necessary
All	2006-2008	E-CLASS	211	DCM-RL - Door control module rear left	X	X	X	X	Read coding and change if necessary
All	2006-2008	E-CLASS	211	DCM-RR - Door control module rear right	X	X	X	X	Read coding and change if necessary
All	2006-2008	E-CLASS	211	ESA driver - Electric seat adjustment driver	X	X	X	X	
All	2006-2008	E-CLASS	211	ESA passenger - Electric seat adjustment FR. Pass.	X	X	X	X	
All	2006-2008	E-CLASS	211	DS-LF - Left front dynamic seat	X	X	X	X	
All	2006-2008	E-CLASS	211	DS-RF - Right front dynamic seat	X	X	X	X	
All	2006-2008	E-CLASS	211	DSP - Pneumatic pump for dynamic seat	X	X	X	X	
All	2006-2008	E-CLASS	211	TLC - Trunk lid control	X	X	X	X	
All	2006-2008	E-CLASS	211	HS - Seat heater	X	X			
All	2006-2008	E-CLASS	211	C-AAC - Convenience automatic air conditioning/AAC	X	X	X	X	Read coding and change if necessary Normalizing of position motors Check of adjustment range of postioning motors
All	2006-2008	E-CLASS	211	STH - Stationary heater with remote control	X	X	X	X	

All	2006-2008	E-CLASS	211	HSW - Heated steering wheel	X	X	X	X	
All	2005	CLS	219	Transmission	X	X	X	X	Initial startup Control unit adaptations Adaptations Diagnosis routiness Learn process y3/8s1
All	2005	CLS	219	ESM - Electronic selector module	X	X	X	X	Read coding and change if necessary
All	2005	CLS	219	DTR - DISTRONIC	X	X	X		Control module adaptations
All	2005	CLS	219	ME 9.7 - Motor electronics 9.7	X	X	X	X	
All	2005	CLS	219	ME 9.7(AMG) - Motor electronics 9.7(AMG)	X	X	X	X	
All	2005	CLS	219	ME-SFI 2.8 - Motor electronics 2.8	X	X	X	X	
All	2005	CLS	219	CDI 4 - Common Rail Diesel Injection 4	X	X	X	X	
All	2005	CLS	219	SBC - Sensotronic Brake Control	X	X	X		Deactive system Active system bleed brake system Control unit adaptations
All	2005	CLS	219	ESP - Electronic stability program	X	X	X	X	Road test
All	2005	CLS	219	AIRmatic	X	X	X	X	Initial startup
All	2005	CLS	219	TPC - Tire pressure monitor	X	X	X	X	Initial startup Control unit adaptations
All	2005	CLS	219	AB - Airbag	X	X	X		Read coding and change if necessary Chassis number
All	2005	CLS	219	WSS - Weight sensor system (USA)	X	X			
All	2005	CLS	219	RevETR-LF - Left front reversible emergency tensioning retractor	X	X	X		
All	2005	CLS	219	RevETR-RF - Right front reversible emergency tensioning retractor	X	X	X		
All	2005	CLS	219	CGW - Central gateway	X	X			
All	2005	CLS	219	EIS - Electronic ignition switch/KG - Keyless GO(Special equipment)	X	X	X	X	
All	2005	CLS	219	HRA - Headlamp range adjustment	X	X	X	X	Initial startup Read coding and change if necessary Zero position adjustment of axle or level sensors
All	2005	CLS	219	OCP - Overhead control panel	X	X	X	X	Read coding and change if necessary Panoramic sliding roof
All	2005	CLS	219	UCP - Upper control panel	X	X	X	X	
All	2005	CLS	219	LCP - Lower control panel	X	X	X	X	
All	2005	CLS	219	Dr-side SAM - Dr. signal acquisition and actuation	X	X	X	X	
All	2005	CLS	219	Pass-side SAM - Pass-side signal acquisition and actuation	X	X	X	X	

All	2005	CLS	219	REAR SAM - Rear signal acquisition and actuation module	X	X	X	X	
All	2005	CLS	219	System diagnosis	X	X	X		
All	2005	CLS	219	BCM - Battery control module	X	X	X	X	
All	2005	CLS	219	On-board electrical system (voltage supply)	X	X	X	X	
All	2005	CLS	219	IC - Instrument cluster	X	X	X		
All	2005	CLS	219	ASSYST Active Service System	X	X	X		AssystSetting
All	2005	CLS	219	ASSYST PLUS - PLUS Active Service System	X	X	X		General servicing Control unit adaptations
All	2005	CLS	219	SCM[MRM] - Steering column module	X	X	X	X	Initial startup
All	2005	CLS	219	PTS - Parktronic system	X	X	X	X	
All	2005	CLS	219	AGW - Audio gateway(MOST network management,diagnosis gateway,radio tuner)	X	X	X	X	
All	2005	CLS	219	COMAND/AUDIO - Audio50 or COMAND	X	X	X	X	Read coding and change if necessary
All	2005	CLS	219	CDC - CD changer	X	X	X		
All	2005	CLS	219	TV - TV tuner(Not valid for Japan and USA)	X	X	X	X	

All	2005	CLS	219	CTEL - Telephone adapter for portable CTEL	X	X	X		
All	2005	CLS	219	DCM-FL - Door control module front left	X	X	X	X	Read coding and change if necessary
All	2005	CLS	219	DCM-FR - Door control module front right	X	X	X	X	Read coding and change if necessary
All	2005	CLS	219	DCM-RL - Door control module rear left	X	X	X	X	Read coding and change if necessary
All	2005	CLS	219	DCM-RR - Door control module rear right	X	X	X	X	Read coding and change if necessary
All	2005	CLS	219	ESA driver - Electric seat adjustment driver(with memory)	X	X	X	X	
All	2005	CLS	219	ESA passenger - Electric seat adjustment FR. Pass.(with memory)	X	X	X	X	
All	2005	CLS	219	DS-LF - Left front dynamic seat	X	X	X	X	
All	2005	CLS	219	DS-RF - Right front dynamic seat	X	X	X	X	
All	2005	CLS	219	DSP - Pneumatic pump for dynamic seat	X	X	X	X	
All	2005	CLS	219	TLC - Trunk lid control	X	X	X	X	
All	2005	CLS	219	HS - Seat heater	X	X	X	X	
All	2005	CLS	219	C-AAC - Convenience automatic air conditioning/AAC - Automatic air conditioning	X	X	X	X	Read coding and change if necessary Normalizing of position motors Check of adjustment range of positioning motors
All	2005	CLS	219	STH - Stationary heater with remote control	X	X	X	X	
All	2005	CLS	219	HSW - Heated steering wheel	X	X	X	X	
All	2005-2006	CLS	219	Transmission	X	X	X	X	Initial startup Control unit adaptations Adaptations Diagnosis routiness
All	2005-2006	CLS	219	ESM - Electronic selector module	X	X	X	X	
All	2005-2006	CLS	219	DTR - Distronic	X	X	X		
All	2005-2006	CLS	219	ME 9.7 - Motor electronics 9.7	X	X	X	X	
All	2005-2006	CLS	219	ME 9.7(AMG) - Motor electronics 9.7(AMG)	X	X	X	X	
All	2005-2006	CLS	219	ME-SFI 2.8 - Motor electronics 2.8	X	X	X	X	
All	2005-2006	CLS	219	CDI 4 - Common Rail Diesel Injection 4	X	X	X	X	

All	2005-2006	CLS	219	SBC - Sensotronic Brake Control	X	X	X		Deactive system Active system bleed brake system Control unit adaptations
All	2005-2006	CLS	219	ESP - Electronic stability program	X	X	X	X	Road test
All	2005-2006	CLS	219	AIRmatic	X	X	X	X	Initial startup
All	2005-2006	CLS	219	TPC - Tire pressure monitor	X	X	X	X	Initial startup Control unit adaptations
All	2005-2006	CLS	219	AB - Airbag	X	X	X		Read coding and change if necessary Chassis number
All	2005-2006	CLS	219	WSS - Weight sensor system (USA)	X	X			
All	2005-2006	CLS	219	RevETR-LF - Left front reversible emergency tensinoing retrator	X	X	X		
All	2005-2006	CLS	219	RevETR-RF - Right front reversible emergency tensinoing retrator	X	X	X		
All	2005-2006	CLS	219	CGW - Central gateway	X	X			
All	2005-2006	CLS	219	EIS - Electronic ignition switch/KG - Keyless GO(Special equipment)	X	X	X	X	
All	2005-2006	CLS	219	HRA - Headlamp range adjustment	X	X	X	X	Initial startup Read coding and change if necessary Zero position adjustment of axle or level sensors
All	2005-2006	CLS	219	OCP - Overhead control panel	X	X	X	X	Read coding and change if necessary Panornamic sliding roof
All	2005-2006	CLS	219	UCP - Upper control panel	X	X	X	X	
All	2005-2006	CLS	219	LCP - Lower control panel	X	X	X	X	
All	2005-2006	CLS	219	Dr-side SAM - Dr. signal acquisition and actuation	X	X	X	X	
All	2005-2006	CLS	219	Pass-side SAM - Pass-side signal acquisition and actuation	X	X	X	X	
All	2005-2006	CLS	219	REAR SAM - Rear signal acquisition and actuation module	X	X	X	X	
All	2005-2006	CLS	219	System diagnosis	X	X	X		
All	2005-2006	CLS	219	BCM - Battery control module	X	X	X	X	
All	2005-2006	CLS	219	On-board electrical system (voltage supply)	X	X	X	X	
All	2005-2006	CLS	219	IC - Instrument cluster	X	X	X		
All	2005-2006	CLS	219	ASSYST Active Service System	X	X	X		AssystSetting

All	2005-2006	CLS	219	ASSYST PLUS - PLUS Active Service System	X	X	X		General servicing Control unit adaptations
All	2005-2006	CLS	219	SCM[MRM] - Steering column module	X	X	X	X	
All	2005-2006	CLS	219	PTS - Parktronic system	X	X	X	X	
All	2005-2006	CLS	219	AGW - Audio gateway(MOST network management,diagnosis gateway,radio tuner)	X	X	X	X	
All	2005-2006	CLS	219	COMAND/AUDIO - Audio50 or COMAND	X	X	X	X	Read coding and change if necessary
All	2005-2006	CLS	219	CDC - CD changer	X	X	X		
All	2005-2006	CLS	219	TV - TV tuner(Not valid for Japan and USA)	X	X	X	X	
All	2005-2006	CLS	219	CTEL - Telephone adapter for portable CTCL	X	X	X		
All	2005-2006	CLS	219	DCM-FL - Door control module front left	X	X	X	X	Read coding and change if necessary
All	2005-2006	CLS	219	DCM-FR - Door control module front right	X	X	X	X	Read coding and change if necessary
All	2005-2006	CLS	219	DCM-RL - Door control module rear left	X	X	X	X	Read coding and change if necessary
All	2005-2006	CLS	219	DCM-RR - Door control module rear right	X	X	X	X	Read coding and change if necessary
All	2005-2006	CLS	219	ESA driver - Electric seat adjustment driver(with memory)	X	X	X	X	
All	2005-2006	CLS	219	ESA passenger - Electric seat adjustment FR. Pass.(with memory)	X	X	X	X	

All	2005-2006	CLS	219	DS-LF - Left front dynamic seat	X	X	X	X	
All	2005-2006	CLS	219	DS-RF - Right front dynamic seat	X	X	X	X	
All	2005-2006	CLS	219	DSP - Pneumatic pump for dynamic seat	X	X	X	X	
All	2005-2006	CLS	219	TLC - Trunk lid control	X	X	X	X	
All	2005-2006	CLS	219	HS - Seat heater	X	X	X	X	
All	2005-2006	CLS	219	C-AAC - Convenience automatic air conditioning/AAC - Automatic air conditioning	X	X	X	X	Read coding and change if necessary Normalizing of position motors Check of adjustment range of positioning motors
All	2005-2006	CLS	219	STH - Stationary heater with remote control	X	X	X	X	
All	2005-2006	CLS	219	HSW - Heated steering wheel	X	X	X	X	
All	2006-2009	CLS	219	Transmission	X	X	X	X	Initial startup Control unit adaptations Adaptations Diagnosis routiness
All	2006-2009	CLS	219	ESM - Electronic selector module	X	X	X	X	
All	2006-2009	CLS	219	DTR - Distronic	X	X	X	X	
All	2006-2009	CLS	219	ME 9.7	X	X	X	X	
All	2006-2009	CLS	219	ME 9.7(AMG)	X	X	X	X	
All	2006-2009	CLS	219	ME-SFI 2.8 - Motor electronics 2.8	X	X	X	X	
All	2006-2009	CLS	219	CDI 4 - Common Rail Diesel Injection 4	X	X	X	X	
All	2006-2009	CLS	219	ABR - Adaptive Brake	X	X	X	X	
All	2006-2009	CLS	219	Suspension	X	X	X	X	Initial startup
All	2006-2009	CLS	219	TPC - Tire pressure monitor	X	X	X	X	Initial startup Control unit adaptations
All	2006-2009	CLS	219	AB - Airbag	X	X	X		Read coding and change if necessary Chassis number
All	2006-2009	CLS	219	WSS - Weight sensor system (USA)	X	X			
All	2006-2009	CLS	219	RevETR-LF - Left front reversible emergency tensioning retrator	X	X	X		
All	2006-2009	CLS	219	RevETR-RF - Right front reversible emergency tensioning retrator	X	X	X		
All	2006-2009	CLS	219	CGW - Central gateway	X	X			
All	2006-2009	CLS	219	EIS - Electronic ignition switch/KG - Keyless GO(Special equipment)	X	X	X	X	
All	2006-2009	CLS	219	HRA - Headlamp range adjustment	X	X	X	X	Initial startup Read coding and change if necessary Zero position adjustment of axle or level sensors

All	2006-2009	CLS	219	OCP - Overhead control panel	X	X	X	X	Read coding and change if necessary Panoramic sliding roof
All	2006-2009	CLS	219	UCP - Upper control panel	X	X	X	X	
All	2006-2009	CLS	219	LCP - Lower control panel	X	X	X	X	
All	2006-2009	CLS	219	Dr-side SAM - Dr. signal acquisition and actuation	X	X	X	X	
All	2006-2009	CLS	219	Pass-side SAM - Pass-side signal acquisition and actuation	X	X	X	X	
All	2006-2009	CLS	219	REAR SAM - Rear signal acquisition and actuation module	X	X	X	X	
All	2006-2009	CLS	219	System diagnosis	X	X	X		
All	2006-2009	CLS	219	BCM - Battery control module	X	X	X	X	
All	2006-2009	CLS	219	On-board electrical system (voltage supply)	X	X	X	X	
All	2006-2009	CLS	219	IC - Instrument cluster	X	X	X		
All	2006-2009	CLS	219	ASSYST Active Service System	X	X	X		AssystSetting
All	2006-2009	CLS	219	ASSYST PLUS - PLUS Active Service System	X	X	X		General servicing Control unit adaptations
All	2006-2009	CLS	219	SCM[MRM] - Steering column module	X	X	X	X	
All	2006-2009	CLS	219	PTS - Parktronic system	X	X	X	X	
All	2006-2009	CLS	219	AGW - Audio gateway(MOST network management,diagnosis gateway,radio tuner)	X	X	X	X	
All	2006-2009	CLS	219	COMAND/AUDIO - Audio50 or COMAND	X	X	X	X	Read coding and change if necessary

All	2006-2009	CLS	219	CDC - CD changer	X	X	X		
All	2006-2009	CLS	219	TV - TV tuner(Not valid for Japan and USA)	X	X	X	X	
All	2006-2009	CLS	219	CTEL - Telephone adapter for portable CTCL	X	X	X		
All	2006-2009	CLS	219	DCM-FL - Door control module front left	X	X	X	X	Read coding and change if necessary
All	2006-2009	CLS	219	DCM-FR - Door control module front right	X	X	X	X	Read coding and change if necessary
All	2006-2009	CLS	219	DCM-RL - Door control module rear left	X	X	X	X	Read coding and change if necessary
All	2006-2009	CLS	219	DCM-RR - Door control module rear right	X	X	X	X	Read coding and change if necessary
All	2006-2009	CLS	219	ESA driver - Electric seat adjustment driver(with memory)	X	X	X	X	
All	2006-2009	CLS	219	ESA passenger - Electric seat adjustment FR. Pass.(with memory)	X	X	X	X	
All	2006-2009	CLS	219	DS-LF - Left front dynamic seat	X	X	X	X	
All	2006-2009	CLS	219	DS-RF - Right front dynamic seat	X	X	X	X	
All	2006-2009	CLS	219	DSP - Pneumatic pump for dynamic seat	X	X	X	X	
All	2006-2009	CLS	219	TLC - Trunk lid control	X	X	X	X	
All	2006-2009	CLS	219	HS - Seat heater	X	X	X	X	
All	2006-2009	CLS	219	C-AAC - Convenience automatic air conditioning/AAC	X	X	X	X	Read coding and change if necessary Normalizing of position motors Check of adjustment range of positioning motors
All	2006-2009	CLS	219	STH - Stationary heater with remote control	X	X	X	X	
All	2006-2009	CLS	219	HSW - Heated steering wheel	X	X	X	X	
All	1984-1991	S-CLASS	126	AB	X	X	X		
All	1992-1999	S-CLASS	140	HFM	X	X	X		
All	1992-1999	S-CLASS	140	ME2	X	X	X		

All	1992-1999	S-CLASS	140	ME1RE	X	X	X		
All	1992-1999	S-CLASS	140	ME1LI	X	X	X		
All	1992-1999	S-CLASS	140	LH1	X	X	X		
All	1992-1999	S-CLASS	140	LH2	X	X	X		
All	1992-1999	S-CLASS	140	DM	X	X	X		
All	1992-1999	S-CLASS	140	ERE	X	X	X		
All	1992-1999	S-CLASS	140	EFP	X	X	X		
All	1992-1999	S-CLASS	140	TPM	X	X	X		
All	1992-1999	S-CLASS	140	ISC	X	X	X		
All	1992-1999	S-CLASS	140	GM	X	X	X		
All	1992-1999	S-CLASS	140	ABS	X	X	X		
All	1992-1999	S-CLASS	140	ASR	X	X	X		
All	1992-1999	S-CLASS	140	ETS	X	X	X		
All	1992-1999	S-CLASS	140	ESP	X	X	X		
All	1992-1999	S-CLASS	140	BAS	X	X	X		
All	1992-1999	S-CLASS	140	ADS	X	X	X		
All	1992-1999	S-CLASS	140	EGS	X	X	X	X	
All	1992-1999	S-CLASS	140	EAG	X	X	X	X	
All	1992-1999	S-CLASS	140	PML	X	X	X		
All	1992-1999	S-CLASS	140	RFL	X	X	X		
All	1992-1999	S-CLASS	140	RCL(DAS1/X)	X	X	X		
All	1992-1999	S-CLASS	140	RCL(DAS2/X)	X	X	X		
All	1992-1999	S-CLASS	140	KFB	X	X	X		
All	1992-1999	S-CLASS	140	PSE	X	X	X		
All	1992-1999	S-CLASS	140	ATA	X	X	X		
All	1992-1999	S-CLASS	140	AB	X	X	X		
All	1992-1999	S-CLASS	140	KI	X	X	X	X	
All	1992-1999	S-CLASS	140	PTS	X	X	X	X	
All	1992-1999	S-CLASS	140	LWR	X	X	X		
All	1992-1999	S-CLASS	140	APS	X	X			
All	1992-1999	S-CLASS	140	Audio,COMMAND	X	X			
All	1992-1999	S-CLASS	140	Tele-AID	X	X			
All	1992-1999	S-CLASS	140	CDC	X	X			
All	1992-1999	S-CLASS	140	E-Call	X	X			
All	1992-1999	S-CLASS	140	ICS	X	X			
All	1992-1999	S-CLASS	140	Air Conditioning	X	X	X		
All	1992-1999	S-CLASS	140	STH	X	X			

All	2000-2003	S-CLASS	220	Transmission	X	X	X	X	Initial startup Control unit adaptations Learn air conditioning Adaptations Diagnosis routiness Read coding and/or transfer download to new control unit
All	2000-2003	S-CLASS	220	ESM - Electronic selector module	X	X	X	X	Detach the transport protection of control module N15/5(electronic selector lever module control module),personalizer or activate the control module.
All	2000-2003	S-CLASS	220	DTR - Distronic	X	X	X		Control unit adaptations
All	2000-2003	S-CLASS	220	ME2- SFI - Motor electronics	X	X	X	X	
All	2000-2003	S-CLASS	220	ME- SFI 2.7 - Motor electronics 2.7	X	X	X	X	
All	2000-2003	S-CLASS	220	CDI 3- Common Rail Diesel Injection 3	X	X	X		
All	2000-2003	S-CLASS	220	CDI-V - Common Rail Diesel Injection	X	X	X		
All	2000-2003	S-CLASS	220	ESP - Electronic stability program	X	X	X	X	Road test Learning processes Resetting of variant locking
All	2000-2003	S-CLASS	220	Suspension-Airmatic	X	X	X	X	Initial startup Level calibration
All	2000-2003	S-CLASS	220	TPC - Tire pressor monitor	X	X	X	X	Control unit adaptations
All	2000-2003	S-CLASS	220	ABC - ABC active body control	X	X	X	X	Calibration of the plunger travel sensors Level calibration Load adjustment
All	2000-2003	S-CLASS	220	AB - Airbag	X	X	X	X	Read coding and change if necessary Coded vehicle data
All	2000-2003	S-CLASS	220	OCP - Overhead control panel	X	X	X	X	Setting of limit position of excess force limiter Read coding and change if necessary
All	2000-2003	S-CLASS	220	EIS - Electronic ignition switch ELCODE(DAS 3)	X	X	X	X	
All	2000-2003	S-CLASS	220	HRA - Headlamp range adjustment	X	X	X	X	
All	2000-2003	S-CLASS	220	UCP - Upper control panel	X	X	X	X	
All	2000-2003	S-CLASS	220	PSE - Pneumatic system equipment	X	X	X	X	Lower or raise head restraints Read coding and change if necessary
All	2000-2003	S-CLASS	220	SAM-FL - Front left signal acquisition and actuation module	X	X	X	X	
All	2000-2003	S-CLASS	220	SAM-FR - Front right signal acquisition and actuation module	X	X	X	X	
All	2000-2003	S-CLASS	220	REAR SAM - Rear signal acquisition and actuation module	X	X	X	X	
All	2000-2003	S-CLASS	220	AHE - Trailer recognition	X	X	X	X	Control unit adaptations
All	2000-2003	S-CLASS	220	KG - Keyless Go	X	X	X	X	

All	2000-2003	S-CLASS	220	SVMCM - Special vehicle multifunction control module	X	X			
All	2000-2003	S-CLASS	220	ICM - Instrument cluster with maintenance interval display	X	X	X	X	ASSYST settings
All	2000-2003	S-CLASS	220	SCM - Steering column module	X	X	X	X	Initial startup
All	2000-2003	S-CLASS	220	PTS - Parktronic system	X	X	X	X	
All	2000-2003	S-CLASS	220	D2B - COMAND or AUDIO	X	X	X	X	Read coding and change if necessary
All	2000-2003	S-CLASS	220	CDC - CD changer	X	X			
All	2000-2003	S-CLASS	220	VCS - Voice control system	X	X			
All	2000-2003	S-CLASS	220	SOUND - Sound system	X	X	X		
All	2000-2003	S-CLASS	220	CTEL - Cellular telephone 1(fixed installation or portable)(D2B)	X	X			
All	2000-2003	S-CLASS	220	TV - TV tuner	X	X			
All	2000-2003	S-CLASS	220	TELE AID,E-call or cellular telephone - Telematic system(K-wire)	X	X	X	X	

All	2000-2003	S-CLASS	220	DN - Dynamic navigation by means of CTCL(K-wire)	X	X			
All	2000-2003	S-CLASS	220	DCM-FL - Door control module front left	X	X	X	X	
All	2000-2003	S-CLASS	220	DCM-FR - Door control module front right	X	X	X	X	
All	2000-2003	S-CLASS	220	DCM-RL - Door control module rear left	X	X	X	X	
All	2000-2003	S-CLASS	220	DCM-RR - Door control module rear right	X	X	X	X	
All	2000-2003	S-CLASS	220	ESA-FL - Electric seat adjustment front left	X	X	X	X	
All	2000-2003	S-CLASS	220	ESA-FR - Electric seat adjustment front right	X	X	X	X	
All	2000-2003	S-CLASS	220	ESA-R - Electric seat adjustment rear	X	X		X	
All	2000-2003	S-CLASS	220	OSB-FL - Multicontour backrest front left	X	X	X	X	
All	2000-2003	S-CLASS	220	OSB-FR - Multicontour backrest front right	X	X	X	X	
All	2000-2003	S-CLASS	220	OSB-R - Multiicontour backrest rear	X	X	X		
All	2000-2003	S-CLASS	220	AAC - Automatic air conditioning	X	X	X	X	Initial startup Read coding and change if necessary
All	2000-2003	S-CLASS	220	REAR AC - Rear air conditioning	X	X	X	X	
All	2000-2003	S-CLASS	220	STH - Stationary heater(Up to 05/2000)	X	X	X	X	
All	2000-2003	S-CLASS	220	STH - Stationary heater(As of 05/2000)	X	X	X	X	
All	2000-2003	S-CLASS	220	HSW - Heated steering wheel	X	X			
All	2004-2006	S-CLASS	220	Transmission	X	X	X	X	Initial startup Control unit adaptations Adaptations Diagnosis routiness
All	2004-2006	S-CLASS	220	ESM - Electronic selector module	X	X	X	X	Detach the transport protection of control module N15/5(electronic selector lever module control module),personalizer or activate the control module.
All	2004-2006	S-CLASS	220	DTR - Distronic	X	X	X		Control unit adaptations
All	2004-2006	S-CLASS	220	ME2- SFI - Motor electronics	X	X	X	X	

All	2004-2006	S-CLASS	220	ME- SFI 2.7 - Motor electronics 2.7	X	X	X	X	
All	2004-2006	S-CLASS	220	CDI 3- Common Rail Diesel Injection 3	X	X	X		
All	2004-2006	S-CLASS	220	CDI-V - Common Rail Diesel Injection	X	X	X		
All	2004-2006	S-CLASS	220	ESP - Electronic stability program	X	X	X	X	Road test Learning processes Resetting of variant locking
All	2004-2006	S-CLASS	220	AIRmatic	X	X	X	X	Initial startup Level calibration
All	2004-2006	S-CLASS	220	TPC - Tire pressor monitor	X	X	X	X	Control unit adaptations
All	2004-2006	S-CLASS	220	ABC - ABC active body control	X	X	X	X	Calibration of the plunger travel sensors Level calibration Load adjustment
All	2004-2006	S-CLASS	220	AB - Airbag	X	X	X	X	Read coding and change if necessary Chassis number
All	2004-2006	S-CLASS	220	CGW - Central gateway	X	X			
All	2004-2006	S-CLASS	220	RevETR-LF - Left front reversible emergency tensing retrator	X	X	X		
All	2004-2006	S-CLASS	220	RevETR-RF - Right front reversible emergency tensing retrator	X	X	X		
All	2004-2006	S-CLASS	220	OCP - Overhead control panel	X	X	X	X	
All	2004-2006	S-CLASS	220	EIS - Electronic ignition switch ELCODE(DAS 3)	X	X	X	X	
All	2004-2006	S-CLASS	220	HRA - Headlamp range adjustment	X	X	X	X	
All	2004-2006	S-CLASS	220	HLCM-L - Left headlamp control module	X	X	X	X	
All	2004-2006	S-CLASS	220	HLCM-R - Right headlamp control module	X	X	X		
All	2004-2006	S-CLASS	220	UCP - Upper control panel	X	X	X	X	
All	2004-2006	S-CLASS	220	PSE - Pneumatic system equipment	X	X	X	X	Lower or raise head restraints Read coding and change if necessary
All	2004-2006	S-CLASS	220	SAM-FL - Front left signal acquisition and actuation module	X	X	X	X	
All	2004-2006	S-CLASS	220	SAM-FR - Front right signal acquisition and actuation module	X	X	X	X	
All	2004-2006	S-CLASS	220	REAR SAM - Rear signal acquisition and actuation module	X	X	X	X	
All	2004-2006	S-CLASS	220	System diagnosis(Only interior CAN fault)	X	X	X		
All	2004-2006	S-CLASS	220	AHE - Trailer recognition	X	X	X	X	Control unit adaptations
All	2004-2006	S-CLASS	220	KG - Keyless Go	X	X	X	X	
All	2004-2006	S-CLASS	220	SVMCM - Special vehicle multifunction control module	X	X			
All	2004-2006	S-CLASS	220	ICM - Instrument cluster with maintenance interval display	X	X	X	X	ASSYST settings

All	2004-2006	S-CLASS	220	SCM - Steering column module	X	X	X	X	Initial startup
All	2004-2006	S-CLASS	220	PTS - Parktronic system	X	X	X	X	
All	2004-2006	S-CLASS	220	AGW/D2B - Audio gateway(MOST network manage ment,diagnosis gateway,radio tuner)/COMAND or AUDIO	X	X	X	X	
All	2004-2006	S-CLASS	220	COMAND/SOUND - COMAND(Displaly and operating unit)/Sound system	X	X	X		
All	2004-2006	S-CLASS	220	CDC - CD changer	X	X	X		
All	2004-2006	S-CLASS	220	HFS - Handsfree system and microphone	X	X		X	
All	2004-2006	S-CLASS	220	TV - TV tuner(Not valid for Japan and USA)	X	X	X		
All	2004-2006	S-CLASS	220	CTEL - Fixed installation cellular telephone/Cellular telephone 1	X	X	X		
All	2004-2006	S-CLASS	220	NAVI - Navigation (Only in combination with COMAND) (Not valid for Japan)	X	X			
All	2004-2006	S-CLASS	220	VCS - Voice control system	X	X			
All	2004-2006	S-CLASS	220	TELE AID,E-call or cellular telephone - Telematic system(K-wire)	X	X	X	X	

All	2004-2006	S-CLASS	220	DCM-FL - Door control module front left	X	X	X	X	
All	2004-2006	S-CLASS	220	DCM-FR - Door control module front right	X	X	X	X	
All	2004-2006	S-CLASS	220	DCM-RL - Door control module rear left	X	X	X	X	
All	2004-2006	S-CLASS	220	DCM-RR - Door control module rear right	X	X	X	X	
All	2004-2006	S-CLASS	220	ESA-FL - Electric seat adjustment front left	X	X	X	X	
All	2004-2006	S-CLASS	220	ESA-FR - Electric seat adjustment front right	X	X	X	X	
All	2004-2006	S-CLASS	220	ESA-R - Electric seat adjustment rear	X	X	X	X	
All	2004-2006	S-CLASS	220	DS-LF - Left front dynamic seat	X	X	X	X	
All	2004-2006	S-CLASS	220	DS-RF - Right front dynamic seat	X	X	X	X	
All	2004-2006	S-CLASS	220	OSB-FL - Multicontour backrest front left	X	X	X	X	
All	2004-2006	S-CLASS	220	OSB-FR - Multicontour backrest front right	X	X	X	X	
All	2004-2006	S-CLASS	220	OSB-R - Multiicontour backrest rear	X	X	X		
All	2004-2006	S-CLASS	220	AAC - Automatic air conditioning	X	X	X	X	Initial startup Read coding and change if necessary
All	2004-2006	S-CLASS	220	REAR AC - Rear air conditioning	X	X	X	X	
All	2004-2006	S-CLASS	220	STH - Stationary heater	X	X	X	X	
All	2004-2006	S-CLASS	220	HSW - Heated steering wheel	X	X			
All	2007-2009	S-CLASS	221	Transmission(Drive train CAN bus)	X	X	X	X	Initial startup Control unit adaptations Adaptations Diagnosis routiness
All	2007-2009	S-CLASS	221	ISM - Intelligent servo module(Drive train CAN bus)	X	X	X	X	
All	2007-2009	S-CLASS	221	ME 9.7 - Motor electronics 9.7(Chassis CAN bus)	X	X	X	X	
All	2007-2009	S-CLASS	221	CDI 5 - Common Rail Diesel Injection(Chassis CAN bus)	X	X	X		
All	2007-2009	S-CLASS	221	DTR - Distronic(Vehicle dynamics CAN bus)	X	X	X		

All	2007-2009	S-CLASS	221	SGR - Rader sensors control unit(Chassis CAN bus)	X	X	X	X	
All	2007-2009	S-CLASS	221	ABR - Adaptive Brake(Chassis CAN bus)	X	X	X	X	
All	2007-2009	S-CLASS	221	Electronic parking brake - Electric parking brake(Front end CAN bus)	X	X	X	X	
All	2007-2009	S-CLASS	221	Suspension(Chassis CAN bus)	X	X	X	X	
All	2007-2009	S-CLASS	221	ABC - ABC active body control	X	X	X	X	Initial startup
All	2007-2009	S-CLASS	221	TPC - Tire pressure monitor(Interior CAN bus)	X	X	X	X	
All	2007-2009	S-CLASS	221	CGW - Central gateway(Central CAN bus)	X	X			
All	2007-2009	S-CLASS	221	EIS - Electronic ignition switch(Interior CAN bus)	X	X	X	X	
All	2007-2009	S-CLASS	221	KG - Keyless Go(Interior CAN bus)	X	X	X	X	
All	2007-2009	S-CLASS	221	AB - Airbag(Chassis CAN bus)	X	X	X	X	
All	2007-2009	S-CLASS	221	WSS - Weight sensing system(USA)(Interior CAN bus)	X	X			
All	2007-2009	S-CLASS	221	Dr-side SAM - Driver signal acquisition and actuation module(Interior CAN bus)	X	X	X	X	
All	2007-2009	S-CLASS	221	REAR SAM - Rear signal acquisition and actuation module(Interior CAN bus)	X	X	X		
All	2007-2009	S-CLASS	221	XALWA-L - Xenon headlamp,left(Front end CAN bus)	X	X	X	X	
All	2007-2009	S-CLASS	221	XALWA-R - Xenon headlamp,right(Front end CAN bus)	X	X	X	X	
All	2007-2009	S-CLASS	221	OCP - Overhead control panel(Interior CAN bus)	X	X	X	X	
All	2007-2009	S-CLASS	221	UCP - Upper control panel(Interior CAN bus)	X	X	X	X	
All	2007-2009	S-CLASS	221	RevETR-LF - Left front reversible emergency tensioning retractor(Chassis CAN bus)	X	X	X		
All	2007-2009	S-CLASS	221	RevETR-RF - Right front reversible emergency tensioning retractor(Chassis CAN bus)	X	X	X		
All	2007-2009	S-CLASS	221	System diagnosis(Diagnose CAN bus)	X	X			
All	2007-2009	S-CLASS	221	BNS - Vehicle power supply control module(Chassis CAN bus)	X	X	X	X	
All	2007-2009	S-CLASS	221	IC - Instrument cluster(Central CAN bus)	X	X	X	X	Setting main odometer forward and back Setting days since initial registration Resetting menu settings to manufacturer default settings

All	2007-2009	S-CLASS	221	ASSYST Active Service System(Diagnose CAN bus)	X	X	X	X	AssystSetting
All	2007-2009	S-CLASS	221	ASSYST PLUS - PLUS Active Service System(Diagnose CAN bus)	X	X	X	X	General servicing Internal Assyst plus data(Reading of main odometer) Internal Assyst plus data(Days since initial registration) Average mileage per day
All	2007-2009	S-CLASS	221	SCM - Steering column module(Chassis CAN bus)	X	X	X	X	
All	2007-2009	S-CLASS	221	NSA - Night vision assist(Vehicle dynamics CAN bus)	X	X	X	X	
All	2007-2009	S-CLASS	221	PTS - Parktronic system(Interior CAN bus)	X	X	X	X	
All	2007-2009	S-CLASS	221	RFK - Backup column module(Interior CAN bus)	X	X	X		
All	2007-2009	S-CLASS	221	COMAND - COMAND with integral telematics gateway(MOST network management, diagnosis gateway)	X	X	X	X	
All	2007-2009	S-CLASS	221	Tuner - Radio tuner with amplifier	X	X			
All	2007-2009	S-CLASS	221	CTEL - Mobile telephone adapter with universal interface	X	X	X	X	
All	2007-2009	S-CLASS	221	VCS - Voice control(Linguatronic)	X	X	X	X	

All	2007-2009	S-CLASS	221	TV - TV tuner(Not valid for Japan and USA)	X	X	X		
All	2007-2009	S-CLASS	221	SDAR - Satellite radio (Valid for USA)	X	X	X	X	
All	2007-2009	S-CLASS	221	ZAN - Central Display	X	X			
All	2007-2009	S-CLASS	221	COU[ZBE] - Central operating unit(Telematic CAN bus)	X	X	X	X	
All	2007-2009	S-CLASS	221	DCM-FL - Door control module front left(Interior CAN bus)	X	X	X	X	Initialization of power closing
All	2007-2009	S-CLASS	221	DCM-FR - Door control module front right(Interior CAN bus)	X	X	X	X	Initialization of power closing
All	2007-2009	S-CLASS	221	DCM-RL - Door control module rear left(Interior CAN bus)	X	X	X	X	Initialization of power closing
All	2007-2009	S-CLASS	221	DCM-RR - Door control module rear right(Interior CAN bus)	X	X	X	X	Initialization of power closing
All	2007-2009	S-CLASS	221	ESA-FL - Electric seat adjustment front left(Interior CAN bus)	X	X	X	X	
All	2007-2009	S-CLASS	221	ESA-FR - Electric seat adjustment front right(Interior CAN bus)	X	X	X	X	
All	2007-2009	S-CLASS	221	ESA-R - Electric seat adjustment rear(Interior CAN bus)	X	X	X	X	
All	2007-2009	S-CLASS	221	DS-LF - Left front dynamic seat(Interior CAN bus)	X	X	X		
All	2007-2009	S-CLASS	221	DS-RF - Right front dynamic seat(Interior CAN bus)	X	X	X		
All	2007-2009	S-CLASS	221	DSP - Pneumatic pump for dynamic seat(Interior CAN bus)	X	X	X		
All	2007-2009	S-CLASS	221	TLC - Trunk lid control(Interior CAN bus)	X	X	X	X	
All	2007-2009	S-CLASS	221	AAC - Automatic air conditioning(Interior CAN bus)	X	X	X	X	
All	2007-2009	S-CLASS	221	KBE-H - Rear A/C operating unit(Telematic CAN bus)	X	X			

All	1999-2002	CL	215	Transmission	X	X	X	X	Initial startup Control unit adaptations Learn air conditioning Adaptations Diagnosis routiness Read coding and/or transfer download to new control unit
All	1999-2002	CL	215	ESM - Electronic selector module	X	X	X	X	Detach the transport protection of control module N15/5(electronic selector lever module control module),personalizer or activate the control module.
All	1999-2002	CL	215	DTR - Distronic	X	X	X		Control unit adaptations
All	1999-2002	CL	215	ME2- SFI - Motor electronics	X	X	X	X	
All	1999-2002	CL	215	ME- SFI 2.7 - Motor electronics 2.7	X	X	X	X	
All	1999-2002	CL	215	ESP - Electronic stability program	X	X	X	X	Road test Learning processes Resetting of variant locking
All	1999-2002	CL	215	ABC - ABC active body control	X	X	X	X	Calibration of the plunger travel sensors Level calibration Load adjustment
All	1999-2002	CL	215	TPC - Tire pressure monitor	X	X	X	X	Control unit adaptations
All	1999-2002	CL	215	AB - Airbag	X	X	X		Read coding and change if necessary Coded vehicle data
All	1999-2002	CL	215	OCP - Overhead control panel	X	X	X	X	Setting of limit position of excess force limiter Read coding and change if necessary
All	1999-2002	CL	215	EIS - Electronic ignition switch ELCODE(DAS 3)	X	X	X		
All	1999-2002	CL	215	UCP - Upper control panel	X	X	X	X	
All	1999-2002	CL	215	PSE - Pneumatic system equipment	X	X	X	X	Lower or raise head restraints Read coding and change if necessary
All	1999-2002	CL	215	SAM-FL - Front left signal acquisition and actuation module	X	X	X	X	
All	1999-2002	CL	215	SAM-FR - Front right signal acquisition and actuation module	X	X	X	X	
All	1999-2002	CL	215	REAR SAM - Rear signal acquisition and actuation module	X	X	X	X	
All	1999-2002	CL	215	AHE - Trailer recognition	X	X	X	X	Control unit adaptations
All	1999-2002	CL	215	KG - Keyless Go	X	X	X	X	
All	1999-2002	CL	215	SVMCM - Special vehicle multifunction control module	X	X			
All	1999-2002	CL	215	ICM - Instrument cluster with maintenance interval display	X	X	X	X	ASSYST settings

All	1999-2002	CL	215	SCM - Steering column module	X	X	X	X	Initial startup
All	1999-2002	CL	215	PTS - Parktronic system	X	X	X	X	
All	1999-2002	CL	215	D2B - COMAND or AUDIO	X	X	X	X	Read coding and change if necessary
All	1999-2002	CL	215	CDC - CD changer	X	X			
All	1999-2002	CL	215	VCS - Voice control system	X	X			
All	1999-2002	CL	215	SOUND - Sound system	X	X	X		
All	1999-2002	CL	215	CTEL - Cellular telephone 1(fixed installation or portable)(D2B)	X	X			
All	1999-2002	CL	215	TV - TV tuner	X	X			
All	1999-2002	CL	215	TELE AID,E-call or cellular telephone - Telematic system(K-wire)	X	X	X	X	
All	1999-2002	CL	215	DN - Dynamic navigation by means of CTEL(K-wire)	X	X			
All	1999-2002	CL	215	DCM-FL - Door control module front left	X	X	X	X	
All	1999-2002	CL	215	DCM-FR - Door control module front right	X	X	X	X	

All	1999-2002	CL	215	RCM - Rear control module	X	X	X	X	
All	1999-2002	CL	215	ESA-FL - Electric seat adjustment front left	X	X	X	X	
All	1999-2002	CL	215	ESA-FR - Electric seat adjustment front right	X	X	X	X	
All	1999-2002	CL	215	OSB-FL - Multicontour backrest front left	X	X	X	X	
All	1999-2002	CL	215	OSB-FR - Multicontour backrest front right	X	X	X	X	
All	1999-2002	CL	215	AAC - Automatic air conditioning	X	X	X	X	Initial startup Read coding and change if necessary
All	1999-2002	CL	215	STH - Stationary heater(Up to 05/2000)	X	X	X	X	
All	1999-2002	CL	215	STH - Stationary heater(As of 05/2000)	X	X	X	X	
All	1999-2002	CL	215	HSW - Heated steering wheel	X	X			
All	2003-2006	CL	215	Transmission	X	X	X	X	Initial startup Control unit adaptations Adaptations Diagnosis routiness
All	2003-2006	CL	215	ESM - Electronic selector module	X	X	X	X	Detach the transport protection of control module N15/5(electronic selector lever module control module),personalizer or activate the control module.
All	2003-2006	CL	215	DTR - Distronic	X	X	X		Control unit adaptations
All	2003-2006	CL	215	ME-SFI 2.8 - Motor electronics 2.8	X	X	X	X	
All	2003-2006	CL	215	ME-SFI 2.7.1	X	X	X	X	
All	2003-2006	CL	215	ESP - Electronic stability program	X	X	X	X	Road test Learning processes Resetting of variant locking
All	2003-2006	CL	215	ABC - ABC active body control	X	X	X	X	Calibration of the plunger travel sensors Level calibration Load adjustment
All	2003-2006	CL	215	TPC - Tire pressure monitor	X	X	X	X	Control unit adaptations
All	2003-2006	CL	215	AB - Airbag	X	X	X		Read coding and change if necessary Chassis number
All	2003-2006	CL	215	CGW - Central gateway	X	X			
All	2003-2006	CL	215	OCP - Overhead control panel	X	X	X	X	
All	2003-2006	CL	215	EIS - Electronic ignition switch ELCODE(DAS 3)	X	X	X		
All	2003-2006	CL	215	HLCM-L - Left headlamp control module	X	X	X	X	
All	2003-2006	CL	215	HLCM-R - Right headlamp control module	X	X	X		

All	2003-2006	CL	215	UCP - Upper control panel	X	X	X	X	
All	2003-2006	CL	215	PSE - Pneumatic system equipment	X	X	X	X	Lower or raise head restraints Read coding and change if necessary
All	2003-2006	CL	215	SAM-FL - Front left signal acquisition and actuation module	X	X	X	X	
All	2003-2006	CL	215	SAM-FR - Front right signal acquisition and actuation module	X	X	X	X	
All	2003-2006	CL	215	REAR SAM - Rear signal acquisition and actuation module	X	X	X	X	
All	2003-2006	CL	215	System diagnosis(Only interior CAN fault)	X	X	X		
All	2003-2006	CL	215	AHE - Trailer recognition	X	X	X	X	Control unit adaptations
All	2003-2006	CL	215	KG - Keyless Go	X	X	X	X	
All	2003-2006	CL	215	SVMCM - Special vehicle multifunction control module	X	X			
All	2003-2006	CL	215	ICM - Instrument cluster with maintenance interval display	X	X	X	X	ASSYST settings
All	2003-2006	CL	215	SCM - Steering column module	X	X	X	X	initial startup
All	2003-2006	CL	215	PTS - Parktronic system	X	X	X	X	
All	2003-2006	CL	215	AGW - Audio gateway(MOST network management,diagnosis gateway,radio tuner)	X	X	X	X	
All	2003-2006	CL	215	COMAND - COMAND(Displaly and operating unit)	X	X	X		
All	2003-2006	CL	215	CDC - CD changer	X	X	X		
All	2003-2006	CL	215	HFS - Handsfree system and microphone	X	X		X	

All	2003-2006	CL	215	TV - TV tuner(Not valid for Japan and USA)	X	X	X		
All	2003-2006	CL	215	CTEL - Fixed installation cellular telephone	X	X	X		
All	2003-2006	CL	215	NAVI - Navigation (Only in combination with COMAND) (Not valid for Japan)	X	X	X	X	
All	2003-2006	CL	215	DCM-FL - Door control module front left	X	X	X	X	
All	2003-2006	CL	215	DCM-FR - Door control module front right	X	X	X	X	
All	2003-2006	CL	215	RCM - Rear control module	X	X	X	X	
All	2003-2006	CL	215	ESA-FL - Electric seat adjustment front left	X	X	X	X	
All	2003-2006	CL	215	ESA-FR - Electric seat adjustment front right	X	X	X	X	
All	2003-2006	CL	215	OSB-FL - Multicontour backrest front left	X	X	X	X	
All	2003-2006	CL	215	OSB-FR - Multicontour backrest front right	X	X	X	X	
All	2003-2006	CL	215	AAC - Automatic air conditioning	X	X	X	X	Initial startup Read coding and change if necessary
All	2003-2006	CL	215	REAR AC - Rear air conditioning	X	X	X	X	
All	2003-2006	CL	215	STH - Stationary heater	X	X	X	X	
All	2003-2006	CL	215	HSW - Heated steering wheel	X	X			
All	2008-2009	CL	216	Transmission(Drive train CAN bus)	X	X	X	X	
All	2008-2009	CL	216	ISM - Intelligent servo module(Drive train CAN bus)	X	X	X	X	
All	2008-2009	CL	216	ME 9.7 - Motor electronics 9.7(Chassis CAN bus)	X	X	X	X	
All	2008-2009	CL	216	ME 2.7.2 - Motor electronics 2.7.2(Chassis CAN bus)	X	X	X	X	
All	2008-2009	CL	216	FSCU - Fuel pump(Drive train CAN bus)	X	X	X	X	
All	2008-2009	CL	216	DTR - Distronic(Vehicle dynamics CAN bus)	X	X	X		

All	2008-2009	CL	216	SGR - Rader sensors control unit(Chassis CAN bus)	X	X	X	X	
All	2008-2009	CL	216	ABR - Adaptive Brake(Chassis CAN bus)	X	X	X		
All	2008-2009	CL	216	Electronic parking brake - Electric parking brake(Front end CAN bus)	X	X	X	X	
All	2008-2009	CL	216	TPC - Tire pressure monitor(Interior CAN bus)	X	X	X	X	
All	2008-2009	CL	216	Suspension(Chassis CAN bus)	X	X	X	X	
All	2008-2009	CL	216	AB - Airbag(Chassis CAN bus)	X	X	X		
All	2008-2009	CL	216	WSS - Weight sensing system(USA)(Interior CAN bus)	X	X			
All	2008-2009	CL	216	CGW - Central gateway(Central CAN bus)	X	X			
All	2008-2009	CL	216	EZS - Electronic ignition switch(Interior CAN bus)	X	X	X		
All	2008-2009	CL	216	KG - Keyless Go(Interior CAN bus)	X	X	X	X	
All	2008-2009	CL	216	XALWA-L - Xenon headlamp,left(Front end CAN bus)	X	X	X	X	
All	2008-2009	CL	216	XALWA-R - Xenon headlamp,right(Front end CAN bus)	X	X	X	X	
All	2008-2009	CL	216	OCP - Overhead control panel(Interior CAN bus)	X	X	X	X	
All	2008-2009	CL	216	UCP - Upper control panel(Interior CAN bus)	X	X	X	X	
All	2008-2009	CL	216	COU[ZBE] - Central operating unit(Telematic CAN bus)	X	X	X	X	
All	2008-2009	CL	216	HBf(Rear control panel) - Rear control field(Telematic CAN bus)	X	X	X	X	
All	2008-2009	CL	216	Dr-side SAM - Driver signal acquisition and actuation module(Interior CAN bus)	X	X	X	X	
All	2008-2009	CL	216	REAR SAM - Rear signal acquisition and actuation module(Interior CAN bus)	X	X	X		
All	2008-2009	CL	216	System diagnosis(Diagnose CAN bus)	X	X			
All	2008-2009	CL	216	BNS - Vehicle power supply control module(Chassis CAN bus)	X	X	X	X	
All	2008-2009	CL	216	AHE - Trailer recognition(Interior CAN bus)	X	X	X	X	
All	2008-2009	CL	216	NSA - Night vision assist(Vehicle dynamics CAN bus)	X	X	X	X	

All	2008-2009	CL	216	IC - Instrument cluster(Central CAN bus)	X	X	X	X	
All	2008-2009	CL	216	ASSYST Active Service System(Diagnose CAN bus)	X	X	X		
All	2008-2009	CL	216	ASSYST PLUS - PLUS Active Service System(Diagnose CAN bus)	X	X	X		
All	2008-2009	CL	216	SCM - Steering column module(Chassis CAN bus)	X	X	X	X	
All	2008-2009	CL	216	RFK - Backup column module(Interior CAN bus)	X	X	X	X	
All	2008-2009	CL	216	PTS - Parktronic system(Interior CAN bus)	X	X	X	X	
All	2008-2009	CL	216	COMAND - COMAND with integral telematics gateway(MOST network management, diagnosis gateway)	X	X	X	X	
All	2008-2009	CL	216	Tuner - Radio tuner with amplifier	X	X			
All	2008-2009	CL	216	CTEL - Mobile telephone adapter with universal interface	X	X	X	X	
All	2008-2009	CL	216	VCS - Voice control(Linguatronic)	X	X	X	X	
All	2008-2009	CL	216	TV - TV tuner(Not valid for Japan and USA)	X	X	X	X	

All	2008-2009	CL	216	SDAR - Satellite radio (Valid for USA)	X	X	X	X	
All	2008-2009	CL	216	ZAN - Central Display	X	X			
All	2008-2009	CL	216	COU[ZBE] - Central operating unit(Telematic CAN bus)	X	X	X	X	
All	2008-2009	CL	216	KBE-H -Rear A/C operating unit	X	X	X	X	
All	2008-2009	CL	216	DCM-FL - Door control module front left(Interior CAN bus)	X	X	X	X	
All	2008-2009	CL	216	DCM-FR - Door control module front right(Interior CAN bus)	X	X	X	X	
All	2008-2009	CL	216	ESA-FL - Electric seat adjustment front left(Interior CAN bus)	X	X	X	X	
All	2008-2009	CL	216	ESA-FR - Electric seat adjustment front right(Interior CAN bus)	X	X	X	X	
All	2008-2009	CL	216	DS-LF - Left front dynamic seat(Interior CAN bus)	X	X	X		
All	2008-2009	CL	216	DS-RF - Right front dynamic seat(Interior CAN bus)	X	X	X		
All	2008-2009	CL	216	DSP - Pneumatic pump for dynamic seat(Interior CAN bus)	X	X	X		
All	2008-2009	CL	216	TLC - Trunk lid control(Interior CAN bus)	X	X	X	X	
All	2008-2009	CL	216	RCM - Rear control module(Interior CAN bus)	X	X	X	X	
All	2008-2009	CL	216	AAC - Automatic air conditioning(Interior CAN bus)	X	X	X	X	
All	2000-2009	Maybach	240	Transmission	X	X	X	X	Initial startup Control unit adaptations Learn air conditioning Adaptations Diagnosis routiness Read coding and/or transfer download to new control unit
All	2000-2009	Maybach	240	ESM - Electronic selector module	X	X	X	X	

All	2000-2009	Maybach	240	DTR - Distronic	X	X			
All	2000-2009	Maybach	240	ME-SFI 2.7.1 - Motor electronics 2.7.1	X	X	X	X	
All	2000-2009	Maybach	240	ME-SFI 2.7.2 - Motor electronics 2.7.2	X	X	X	X	
All	2000-2009	Maybach	240	SGR - Radar sensors control unit	X	X	X	X	
All	2000-2009	Maybach	240	SBCL - Sensotronic Brake Control Left	X	X	X		Deactive system Active system Control unit adaptations
All	2000-2009	Maybach	240	SBCR - Sensotronic Brake Control Right	X	X	X		
All	2000-2009	Maybach	240	ESP - Electronic stability program	X	X	X	X	
All	2000-2009	Maybach	240	AIRmatic - AIRmatic	X	X	X	X	
All	2000-2009	Maybach	240	TPC - Tire pressor monitor	X	X	X		
All	2000-2009	Maybach	240	AB - Airbag	X	X	X		Read coding and change if necessary Chassis number
All	2000-2009	Maybach	240	BNS - Vehicle power supply control module	X	X			
All	2000-2009	Maybach	240	CGW - Central gateway	X	X			
All	2000-2009	Maybach	240	EIS - Electronic ignition switch/KG - Keyless Go(Special equipment)	X	X	X	X	
All	2000-2009	Maybach	240	HRA - Headlamp range adjustment	X	X	X	X	
All	2000-2009	Maybach	240	OCP - Overhead control panel	X	X	X	X	
All	2000-2009	Maybach	240	CRN - Center roof node	X	X			
All	2000-2009	Maybach	240	VBF(Front control panel) - Front control panel	X	X	X		
All	2000-2009	Maybach	240	HBF(Rear control panel) - Rear control field	X	X	X		
All	2000-2009	Maybach	240	PSE - Pneumatic system equipment	X	X			
All	2000-2009	Maybach	240	Dr-side SAM - Dr. signal acquisition and actuation moduel	X	X	X	X	
All	2000-2009	Maybach	240	Pass-side SAM - Pass-side signal acquisition and actuation module	X	X	X	X	
All	2000-2009	Maybach	240	REAR SAM 1 - Rear signal acquisition and actuation module 1	X	X	X	X	
All	2000-2009	Maybach	240	REAR SAM 2 - Rear signal acquisition and actuation module 2	X	X	X	X	
All	2000-2009	Maybach	240	System diagnosis(only interior CAN fault)	X	X	X		
All	2000-2009	Maybach	240	SVMCM - Special vehicle multifunction control module	X	X	X	X	
All	2000-2009	Maybach	240	ICM - Instrument cluster	X	X	X		

All	2000-2009	Maybach	240	SCM[MRM] - Steering column module	X	X	X		initial startup
All	2000-2009	Maybach	240	PTS - Parktronic system	X	X	X	X	
All	2000-2009	Maybach	240	AGW - Audio gateway	X	X	X		
All	2000-2009	Maybach	240	COMAND/AUDIO - Audio50 or COMAND	X	X	X	X	
All	2000-2009	Maybach	240	CDC - CD changer	X	X	X		
All	2000-2009	Maybach	240	CTEL - Telephone adapter for portable CTEL	X	X	X		
All	2000-2009	Maybach	240	NAVI - Navigation (Valid for China and Korea)	X	X			
All	2000-2009	Maybach	240	VCS -Voice control	X	X			
All	2000-2009	Maybach	240	TV - TV tuner	X	X			
All	2000-2009	Maybach	240	SOUND - Bose sound system	X	X			
All	2000-2009	Maybach	240	TELE - TELE AID	X	X			

All	2000-2009	Maybach	240	DCM-FL - Door control module front left	X	X	X	X	
All	2000-2009	Maybach	240	DCM-FR - Door control module front right	X	X	X	X	
All	2000-2009	Maybach	240	DCM-RL - Door control module rear left	X	X	X	X	
All	2000-2009	Maybach	240	DCM-RR - Door control module rear right	X	X	X	X	
All	2000-2009	Maybach	240	PWC - Partition wall control module	X	X			
All	2000-2009	Maybach	240	LDCA - Electric left door closing assist	X	X			
All	2000-2009	Maybach	240	RDCA - Electric right door closing assist	X	X			
All	2000-2009	Maybach	240	ESA-FL - Electric seat adjustment front left	X	X	X	X	
All	2000-2009	Maybach	240	ESA-FR - Electric seat adjustment front right	X	X	X	X	
All	2000-2009	Maybach	240	ESA-LR - Left rear electrical seat adjustment	X	X			
All	2000-2009	Maybach	240	ESA-RR - Right rear electrical seat adjustment	X	X			
All	2000-2009	Maybach	240	OSB-FL - Multicontour backrest front left	X	X			
All	2000-2009	Maybach	240	OSB-FR - Multicontour backrest front right	X	X			
All	2000-2009	Maybach	240	MKL-HL - Rear left multicontour backrest	X	X			
All	2000-2009	Maybach	240	MKL-HR - Rear right multicontour backrest	X	X			
All	2000-2009	Maybach	240	TLC - Trunk lid control	X	X	X	X	
All	2000-2009	Maybach	240	C-AAC - Convenience automatic air conditioning/AAC	X	X	X	X	
All	2000-2009	Maybach	240	REAR AC - Rear air conditioning	X	X			
All	2000-2009	Maybach	240	STH - Stationary heater with remote control	X	X	X	X	
All	2000-2009	Maybach	240	HSW - Heated steering wheel	X	X			
All	1984-1988	SL	107	AB	X	X	X		
All	1989-1998	SL	129	HFM	X	X	X		
All	1989-1998	SL	129	ME1RE	X	X	X		
All	1989-1998	SL	129	ME1LI	X	X	X		

All	1989-1998	SL	129	LH1	X	X	X		
All	1989-1998	SL	129	LH2	X	X	X		
All	1989-1998	SL	129	DM	X	X	X		
All	1989-1998	SL	129	EFP	X	X	X		
All	1989-1998	SL	129	TPM	X	X	X		
All	1989-1998	SL	129	ISC	X	X	X		
All	1989-1998	SL	129	GM	X	X	X		
All	1989-1998	SL	129	ABS	X	X	X		
All	1989-1998	SL	129	ASR	X	X	X		
All	1989-1998	SL	129	ETS	X	X	X		
All	1989-1998	SL	129	ESP	X	X	X		
All	1989-1998	SL	129	BAS	X	X	X		
All	1989-1998	SL	129	ADS	X	X	X		
All	1989-1998	SL	129	EGS	X	X	X	X	
All	1989-1998	SL	129	EAG	X	X	X	X	
All	1989-1998	SL	129	RFL	X	X	X		
All	1989-1998	SL	129	RCL(DAS2/X)	X	X	X		
All	1989-1998	SL	129	ATA	X	X	X		
All	1989-1998	SL	129	AB	X	X	X		
All	1989-1998	SL	129	KI	X	X	X	X	
All	1989-1998	SL	129	LWR	X	X	X	X	
All	1989-1998	SL	129	APS	X	X	X		
All	1989-1998	SL	129	Audio,COMMAND	X	X	X		
All	1989-1998	SL	129	TELE-AID	X	X	X		
All	1989-1998	SL	129	CDC	X	X	X		
All	1989-1998	SL	129	E-Call	X	X	X		
All	1989-1998	SL	129	Air Conditioning	X	X			
All	1989-1998	SL	129	STH	X	X			
All	1999-2002	SL	129	ME2-SFI	X	X	X	X	
All	1999-2002	SL	129	ME1RE	X	X	X		
All	1999-2002	SL	129	ME1LI	X	X	X		
All	1999-2002	SL	129	ETC	X	X	X	X	
All	1999-2002	SL	129	ABS,ASR,ETS,ESP	X	X	X	X	Control unit adaptations
All	1999-2002	SL	129	BAS	X	X	X		
All	1999-2002	SL	129	ADS	X	X	X		
All	1999-2002	SL	129	AB	X	X	X		Control unit adaptations
All	1999-2002	SL	129	HRA	X	X	X		
All	1999-2002	SL	129	ATA	X	X	X	X	
All	1999-2002	SL	129	RFL	X	X	X	X	
All	1999-2002	SL	129	RS	X	X	X	X	

All	1999-2002	SL	129	ICM	X	X	X	X	Setting
All	1999-2002	SL	129	TELE AID,E-call	X	X	X	X	
All	1999-2002	SL	129	DN	X	X			
All	1999-2002	SL	129	D2B	X	X	X	X	Read coding and change if necessary
All	1999-2002	SL	129	CDC	X	X			
All	1999-2002	SL	129	VCS	X	X			
All	1999-2002	SL	129	CTEL	X	X			
All	1999-2002	SL	129	APS	X	X			
All	1999-2002	SL	129	STH	X	X	X		
All	1999-2002	SL	129	AAC	X	X	X		Read coding and change if necessary
All	Up to 08/2003	SL	230	Transmission	X	X	X	X	Initial startup Control unit adaptations Learn air conditioning Adaptations Diagnosis routiness Read coding and/or transfer download to new control unit

All	Up to 08/2003	SL	230	ESM - Electronic selector module	X	X	X	X	
All	Up to 08/2003	SL	230	DTR - DISTRONIC	X	X	X	X	Control unit adaptations
All	Up to 08/2003	SL	230	ME-SFI 2.8 - Motor electronics 2.8	X	X	X	X	
All	Up to 08/2003	SL	230	SBC - Sensotronic Brake Control	X	X	X		Deactive system Active system Control unit adaptations
All	Up to 08/2003	SL	230	ESP - Electronic stability program	X	X	X	X	Road test Erase zero point offset error of component N49(steering angle sensor)
All	Up to 08/2003	SL	230	ABC - ABC active body control	X	X	X	X	Calibration of the plunger travel sensors Level calibration Load adjustment
All	Up to 08/2003	SL	230	TPC - Tire pressure monitor	X	X	X	X	Control unit adaptations
All	Up to 08/2003	SL	230	AB - Airbag	X	X	X		Read coding and change if necessary Coded vehicle data
All	Up to 08/2003	SL	230	BNS - Vehicle power supply control module	X	X	X		
All	Up to 08/2003	SL	230	OCP - Overhead control panel	X	X	X	X	
All	Up to 08/2003	SL	230	EIS - Electronic ignition switch	X	X	X		
All	Up to 08/2003	SL	230	HRA-FL - Front left headlamp range control	X	X	X	X	
All	Up to 08/2003	SL	230	HRA-FR - Front right headlamp range control	X	X	X		
All	Up to 08/2003	SL	230	LCP - Lower control panel	X	X	X	X	
All	Up to 08/2003	SL	230	PSE - Pneumatic system equipment	X	X	X	X	Read coding and change if necessary
All	Up to 08/2003	SL	230	Dr-side SAM - Dr. signal acquisition and actuation module	X	X	X	X	
All	Up to 08/2003	SL	230	Pass-side SAM - Pass-side signal acquisition and actuation module	X	X	X	X	
All	Up to 08/2003	SL	230	REAR SAM - Rear signal acquisition and actuation module	X	X	X	X	
All	Up to 08/2003	SL	230	RVC - Rollover bar/vario roof control module	X	X	X	X	
All	Up to 08/2003	SL	230	KG - Keyless Go	X	X	X	X	

All	Up to 08/2003	SL	230	System diagnosis	X	X			
All	Up to 08/2003	SL	230	ICM - Instrument cluster with maintenance interval display	X	X	X	X	ASSYST settings
All	Up to 08/2003	SL	230	SCM - Steering column module	X	X	X	X	initial startup
All	Up to 08/2003	SL	230	PTS - Parktronic system	X	X	X	X	
All	Up to 08/2003	SL	230	D2B - COMAND or AUDIO	X	X	X	X	Read coding and change if necessary
All	Up to 08/2003	SL	230	CDC - CD changer	X	X			
All	Up to 08/2003	SL	230	VCS - Voice control system	X	X			
All	Up to 08/2003	SL	230	SOUND - Sound system	X	X			
All	Up to 08/2003	SL	230	CTEL - Cellular telephone 1(fixed installation or portable)(D2B)	X	X			
All	Up to 08/2003	SL	230	TELE AID,E-call or cellular telephone - Telematic system(K-wire)	X	X	X		
All	Up to 08/2003	SL	230	TV - TV tuner(Not valid for Japan)	X	X		X	
All	Up to 08/2003	SL	230	DCM-L - Door control module left	X	X	X	X	

All	Up to 08/2003	SL	230	DCM-R - Door control module right	X	X	X	X	
All	Up to 08/2003	SL	230	RCM - Rear control module	X	X	X	X	
All	Up to 08/2003	SL	230	ESA-FL - Electric seat adjustment front left	X	X	X	X	
All	Up to 08/2003	SL	230	ESA-FR - Electric seat adjustment front right	X	X	X	X	
All	Up to 08/2003	SL	230	OSB-FL - Multicontour backrest front left	X	X	X	X	
All	Up to 08/2003	SL	230	OSB-FR - Multicontour backrest front right	X	X	X	X	
All	Up to 08/2003	SL	230	AAC - Automatic air conditioning	X	X	X	X	Read coding and change if necessary Normalizing of position motors Check of adjustment range of positioning motors Teaching-in of rotary potentiometer for center nozzle and side outlets
All	Up to 08/2003	SL	230	STH - Stationary heater with remote control	X	X	X	X	
All	Up to 08/2003	SL	230	HSW - Heated steering wheel	X	X			
All	09/2003- 05/2006	SL	230	Transmission	X	X	X	X	Initial startup Control unit adaptations Adaptations Diagnosis routiness
All	09/2003- 05/2006	SL	230	ESM - Electronic selector module	X	X	X	X	
All	09/2003- 05/2006	SL	230	DTR - DISTRONIC	X	X	X	X	Control unit adaptations
All	09/2003- 05/2006	SL	230	ME-SFI 2.8 - Motor electronics 2.8	X	X	X	X	
All	09/2003- 05/2006	SL	230	ME 9.7 - Motor electronics 9.7	X	X	X	X	
All	09/2003- 05/2006	SL	230	ME-SFI 2.7.1 - Motor electronics 2.7.1	X	X	X	X	
All	09/2003- 05/2006	SL	230	SBC - Sensotronic Brake Control	X	X	X		Deactive system Active system Control unit adaptations
All	09/2003- 05/2006	SL	230	ESP - Electronic stability program	X	X	X	X	Road test Erase zero point offset error of component N49(steering angle sensor)
All	09/2003- 05/2006	SL	230	ABC - ABC active body control	X	X	X	X	Calibration of the plunger travel sensors Level calibration Load adjustment

All	09/2003-05/2006	SL	230	TPC - Tire pressure monitor	X	X	X	X	Control unit adaptations
All	09/2003-05/2006	SL	230	AB - Airbag	X	X	X	X	Read coding and change if necessary Chassis number
All	09/2003-05/2006	SL	230	WSS - Weight sensor system(USA)	X	X			
All	09/2003-05/2006	SL	230	CGW - Central gateway	X	X			
All	09/2003-05/2006	SL	230	BNS - Vehicle power supply control module	X	X	X		
All	09/2003-05/2006	SL	230	OCP - Overhead control panel	X	X	X	X	
All	09/2003-05/2006	SL	230	EIS - Electronic ignition switch	X	X	X		
All	09/2003-05/2006	SL	230	HRA-FL - Front left headlamp range control	X	X	X	X	
All	09/2003-05/2006	SL	230	HRA-FR - Front right headlamp range control	X	X	X		
All	09/2003-05/2006	SL	230	LCP - Lower control panel	X	X	X	X	
All	09/2003-05/2006	SL	230	PSE - Pneumatic system equipment	X	X	X	X	Read coding and change if necessary
All	09/2003-05/2006	SL	230	Dr-side SAM - Dr. signal acquisition and actuation module	X	X	X	X	
All	09/2003-05/2006	SL	230	Pass-side SAM - Pass-side signal acquisition and actuation module	X	X	X	X	
All	09/2003-05/2006	SL	230	REAR SAM - Rear signal acquisition and actuation module	X	X	X	X	
All	09/2003-05/2006	SL	230	RVC - Rollover bar/vario roof control module	X	X	X	X	
All	09/2003-05/2006	SL	230	KG - Keyless Go	X	X	X	X	
All	09/2003-05/2006	SL	230	System diagnosis	X	X	X		
All	09/2003-05/2006	SL	230	ICM - Instrument cluster with maintenance interval display	X	X	X		
All	09/2003-05/2006	SL	230	SCM - Steering column module	X	X	X	X	initial startup

All	09/2003-05/2006	SL	230	PTS - Parktronic system	X	X	X	X	
All	09/2003-05/2006	SL	230	AGW - Audio gateway(MOST network management,diagnosis gateway,radio tuner)	X	X	X		
All	09/2003-05/2006	SL	230	COMAND - COMAND(Displaly and operating unit)	X	X	X	X	
All	09/2003-05/2006	SL	230	CDC - CD changer	X	X	X		
All	09/2003-05/2006	SL	230	HFS - Handsfree system and microphone	X	X	X		
All	09/2003-05/2006	SL	230	TV - TV tuner(Not valid for Japan and USA)	X	X	X		
All	09/2003-05/2006	SL	230	CTEL - Fixed installation cellular telephone	X	X	X		
All	09/2003-05/2006	SL	230	MB Portal - Telematic services WAP,E-mail,Mercedes-Benz Portal	X	X			
All	09/2003-05/2006	SL	230	VCS - Voice control system	X	X			
All	09/2003-05/2006	SL	230	TELE AID,E-call or cellular telephone - Telematic system(K-wire)	X	X	X		
All	09/2003-05/2006	SL	230	DCM-L - Door control module left	X	X	X	X	
All	09/2003-05/2006	SL	230	DCM-R - Door control module right	X	X	X	X	

All	09/2003-05/2006	SL	230	RCM - Rear control module	X	X	X	X	
All	09/2003-05/2006	SL	230	ESA-FL - Electric seat adjustment front left	X	X	X	X	
All	09/2003-05/2006	SL	230	ESA-FR - Electric seat adjustment front right	X	X	X	X	
All	09/2003-05/2006	SL	230	OSB-FL - Multicontour backrest front left	X	X	X	X	
All	09/2003-05/2007	SL	230	OSB-FR - Multicontour backrest front right	X	X	X	X	
All	09/2003-05/2008	SL	230	AAC - Automatic air conditioning	X	X	X	X	Read coding and change if necessary Normalizing of position motors Check of adjustment range of positioning motors Teaching-in of rotary potentiometer for center nozzle and side outlets
All	09/2003-05/2009	SL	230	STH - Stationary heater with remote control	X	X	X	X	
All	09/2003-05/2010	SL	230	HSW - Heated steering wheel	X	X			
All	06/2006-02/2008	SL	230	Transmission	X	X	X	X	
All	06/2006-02/2008	SL	230	ESM - Electronic selector module	X	X	X	X	
All	06/2006-02/2008	SL	230	DTR - Distronic	X	X	X	X	Control unit adaptations
All	06/2006-02/2008	SL	230	ME-SFI 2.8 - Motor electronics 2.8	X	X	X	X	
All	06/2006-02/2008	SL	230	ME 9.7 - Motor electronics 9.7	X	X	X	X	
All	06/2006-02/2008	SL	230	ME-SFI 2.7.1 - Motor electronics 2.7.1	X	X	X	X	
All	06/2006-02/2008	SL	230	ME-SFI 2.7.2 - Motor electronics 2.7.2	X	X	X	X	
All	06/2006-02/2008	SL	230	SBC - Sensotronic Brake Control	X	X	X	X	
All	06/2006-02/2008	SL	230	ESP - Electronic stability program	X	X	X	X	Replacement of component B24/15 Road test
All	06/2006-02/2008	SL	230	ABC - ABC active body control	X	X	X	X	Calibration of the plunger travel sensors Level calibration Load adjustment
All	06/2006-02/2008	SL	230	TPC - Tire pressure monitor	X	X	X	X	Control unit adaptations
All	06/2006-02/2008	SL	230	AB - Airbag	X	X	X		Display coded vehicle data

All	06/2006-02/2008	SL	230	WSS - Weight sensor system(USA)	X	X			
All	06/2006-02/2008	SL	230	CGW - Central gateway	X	X			
All	06/2006-02/2008	SL	230	BNS - Vehicle power supply control module	X	X	X		
All	06/2006-02/2008	SL	230	OCP - Overhead control panel	X	X	X	X	
All	06/2006-02/2008	SL	230	EIS - Electronic ignition switch	X	X	X		
All	06/2006-02/2008	SL	230	HRA-FL - Front left headlamp range control	X	X	X	X	
All	06/2006-02/2008	SL	230	HRA-FR - Front right headlamp range control	X	X	X	X	
All	06/2006-02/2008	SL	230	LCP - Lower control panel	X	X	X	X	
All	06/2006-02/2008	SL	230	PSE - Pneumatic system equipment	X	X	X	X	
All	06/2006-02/2008	SL	230	Dr-side SAM - Dr. signal acquisition and actuation module	X	X	X	X	
All	06/2006-02/2008	SL	230	Pass-side SAM - Pass-side signal acquisition and actuation module	X	X	X	X	
All	06/2006-02/2008	SL	230	REAR SAM - Rear signal acquisition and actuation module	X	X	X	X	Flashing stop lamp/Rear foglight
All	06/2006-02/2008	SL	230	RVC - Rollover bar/vario roof control module	X	X	X	X	
All	06/2006-02/2008	SL	230	KG - Keyless Go	X	X	X	X	
All	06/2006-02/2008	SL	230	System diagnosis	X	X	X		
All	06/2006-02/2008	SL	230	ICM - Instrument cluster with maintenance interval display	X	X	X		
All	06/2006-02/2008	SL	230	SCM - Steering column module	X	X	X	X	
All	06/2006-02/2008	SL	230	PTS - Parktronic system	X	X	X	X	

All	06/2006-02/2008	SL	230	AGW - Audio gateway(MOST network management,diagnosis gateway,radio tuner)	X	X	X	X	1.Specified configuration of MOST components 2.Apply actual configuration of the MOST components as the specifed configuration 3.Restart of optical ring
All	06/2006-02/2008	SL	230	COMAND - COMAND(Displaly and operating unit)	X	X	X	X	1.Radio parameters 2.TV parameters(Shut off criteria) 3.Restart of optical ring
All	06/2006-02/2008	SL	230	CDC - CD changer	X	X	X		
All	06/2006-02/2008	SL	230	HFS - Handsfree system and microphone	X	X	X		
All	06/2006-02/2008	SL	230	TV - TV tuner(Not valid for Japan and USA)	X	X	X		
All	06/2006-02/2008	SL	230	CTEL - Fixed installation cellular telephone	X	X	X		
All	06/2006-02/2008	SL	230	MB Portal - Telematic services WAP,E-mail,Mercedes-Benz Portal	X	X			
All	06/2006-02/2008	SL	230	VCS - Voice control system	X	X			
All	06/2006-02/2008	SL	230	TELE AID,E-call or cellular telephone - Telematic system(K-wire)	X	X	X		
All	06/2006-02/2008	SL	230	NAVI - Navigation(Only in combination with COMAND)(Not valid for Japan)	X	X	X		
All	06/2006-02/2008	SL	230	DCM-L - Door control module left	X	X	X	X	
All	06/2006-02/2008	SL	230	DCM-R - Door control module right	X	X	X	X	

All	06/2006-02/2008	SL	230	RCM - Rear control module	X	X	X	X	
All	06/2006-02/2008	SL	230	ESA-FL - Electric seat adjustment front left	X	X	X	X	
All	06/2006-02/2008	SL	230	ESA-FR - Electric seat adjustment front right	X	X	X	X	
All	06/2006-02/2008	SL	230	OSB-FL - Multicontour backrest front left	X	X	X	X	
All	06/2006-02/2008	SL	230	OSB-FR - Multicontour backrest front right	X	X	X	X	
All	06/2006-02/2008	SL	230	AAC - Automatic air conditioning	X	X	X	X	
All	06/2006-02/2008	SL	230	STH - Stationary heater with remote control	X	X	X	X	
All	06/2006-02/2008	SL	230	HSW - Heated steering wheel	X	X			
All	2002-2009	SLR	199	Transmission	X	X	X	X	Initial startup Control unit adaptations Learn air conditioning Adaptations Diagnosis routiness Read coding and/or transfer download to new control unit
All	2002-2009	SLR	199	ESM - Electronic selector module	X	X	X	X	
All	2002-2009	SLR	199	ME-SFI 2.8 - Motor electronics 2.8	X	X	X	X	
All	2002-2009	SLR	199	SBC - Sensotronic Brake Control	X	X	X		Deactive system Active system Control unit adaptations
All	2002-2009	SLR	199	ESP - Electronic stability program	X	X	X		
All	2002-2009	SLR	199	TPC - Tire pressure monitor	X	X	X	X	Read coding and change if necessary
All	2002-2009	SLR	199	AB - Airbag	X	X	X		
All	2002-2009	SLR	199	CGW - Central gateway	X	X			
All	2002-2009	SLR	199	BNS - Vehicle power supply control module	X	X	X		
All	2002-2009	SLR	199	OCP - Overhead control panel	X	X	X	X	
All	2002-2009	SLR	199	EIS - Electronic ignition switch	X	X	X		
All	2002-2009	SLR	199	HRA-FR - Front right headlamp range control	X	X	X	X	
All	2002-2009	SLR	199	HRA-FL - Front left headlamp range control	X	X	X	X	
All	2002-2009	SLR	199	LCP - Lower control panel	X	X	X	X	
All	2002-2009	SLR	199	Dr-side SAM - Driver signal acquisition and actuation moduel	X	X	X	X	

All	2002-2009	SLR	199	Pass-side SAM - Passenger-side signal acquisition and actuation module	X	X	X	X	
All	2002-2009	SLR	199	REAR SAM - Rear signal acquisition and actuation module	X	X	X	X	
All	2002-2009	SLR	199	ACL[ZLB] - Air brake(spoiler)and central locking control unit	X	X			
All	2002-2009	SLR	199	ICM - Instrument cluster with maintenance interval display	X	X	X	X	
All	2002-2009	SLR	199	SCM - Steering column module	X	X	X	X	initial startup
All	2002-2009	SLR	199	D2B - AUDIO	X	X	X	X	
All	2002-2009	SLR	199	CDC - CD changer	X	X			
All	2002-2009	SLR	199	SOUND - Sound system	X	X	X		
All	2002-2009	SLR	199	CTEL - Cellular telephone 1(fixed installation or portable)(D2B)	X	X			
All	2002-2009	SLR	199	TELE AID - Telematic system(K-wrie)	X	X	X		
All	2002-2009	SLR	199	DCM-L - Door control module left	X	X	X	X	
All	2002-2009	SLR	199	DCM-R - Door control module right	X	X	X	X	
All	2002-2009	SLR	199	AAC - Automatic air conditioning	X	X	X	X	

All	1996-1998	SLK	170(38-PIN)	ETC - Electronic transmission control	X	X	X	X	Initial startup Control unit adaptations Learn air conditioning Adaptations Diagnosis routiness Read coding and/or transfer download to new control unit
All	1996-1998	SLK	170(38-PIN)	HFM-SFI - Hot film engine management	X	X	X		
All	1996-1998	SLK	170(38-PIN)	ME2-SFI - Motor electronics	X	X	X		
All	1996-1998	SLK	170(38-PIN)	Traction systems ABS,ASR,ETS,ESP	X	X	X	X	Road test Learning processes Resetting of variant locking
All	1996-1998	SLK	170(38-PIN)	BAS - Brake assist	X	X	X	X	
All	1996-1998	SLK	170(38-PIN)	AB - Airbag	X	X	X		Read coding and change if necessary Coded vehicle data
All	1996-1998	SLK	170(38-PIN)	RFL - Radio frequency locking/electric central locking	X	X	X	X	
All	1996-1998	SLK	170(38-PIN)	RFL(DAS2) - Radio frequency locking(drive authorization stage 2)	X	X	X	X	
All	1996-1998	SLK	170(38-PIN)	PSE - Pneumatic system equipment	X	X	X	X	
All	1996-1998	SLK	170(38-PIN)	CCM - Multifunction control module	X	X	X	X	
All	1996-1998	SLK	170(38-PIN)	VR - Vario roof	X	X	X	X	
All	1996-1998	SLK	170(38-PIN)	ATA - Anti-theft alarm system	X	X	X	X	
All	1996-1998	SLK	170(38-PIN)	ICM - Instrument cluster with maintenance interval display	X	X	X	X	
All	1996-1998	SLK	170(38-PIN)	D2B - AUDIO	X	X	X	X	Read coding and change if necessary
All	1996-1998	SLK	170(38-PIN)	CDC - CD changer	X	X			
All	1996-1998	SLK	170(38-PIN)	VCS - Voice control system	X	X			
All	1996-1998	SLK	170(38-PIN)	CTEL - Cellular telephone 1(fixed installation or portable)(D2B)	X	X			

All	1996-1998	SLK	170(38-PIN)	TAC - Automatic temperature control/AAC - Automatic air conditioning	X	X	X	X	
All	1999-2004	SLK	170(16-PIN)	Transmission	X	X	X	X	Initial startup Control unit adaptations Learn air conditioning Adaptations Diagnosis routiness Read coding and/or transfer download to new control unit
All	1999-2004	SLK	170(16-PIN)	ESM - Electronic selector module	X	X	X	X	
All	1999-2004	SLK	170(16-PIN)	ME-SFI - Motor electronics	X	X	X	X	
All	1999-2004	SLK	170(16-PIN)	ESP - Electronic stability program	X	X	X	X	
All	1999-2004	SLK	170(16-PIN)	BAS - Brake assist	X	X	X	X	
All	1999-2004	SLK	170(16-PIN)	VP - Vacumm pump brake booster	X	X	X	X	
All	1999-2004	SLK	170(16-PIN)	AB - Airbag	X	X	X		Read coding and change if necessary Coded vehicle data
All	1999-2004	SLK	170(16-PIN)	RFL - Radio frequency locking/electric central locking	X	X	X	X	
All	1999-2004	SLK	170(16-PIN)	PSE - Pneumatic system equipment	X	X	X	X	
All	1999-2004	SLK	170(16-PIN)	CCM - Multifunction control module	X	X	X	X	
All	1999-2004	SLK	170(16-PIN)	VR - Vario roof	X	X	X	X	
All	1999-2004	SLK	170(16-PIN)	ATA - Anti-theft alarm system	X	X	X	X	
All	1999-2004	SLK	170(16-PIN)	HRA - Headlamp range adjust ment	X	X	X	X	
All	1999-2004	SLK	170(16-PIN)	ICM - Instrument cluster with maintenance interval display	X	X	X	X	
All	1999-2004	SLK	170(16-PIN)	D2B - AUDIO	X	X	X	X	Read coding and change if necessary
All	1999-2004	SLK	170(16-PIN)	CDC - CD changer	X	X			
All	1999-2004	SLK	170(16-PIN)	VCS - Voice control,hands-free system and microphones	X	X			
All	1999-2004	SLK	170(16-PIN)	CTEL - Cellular telephone 1(fixed installation or portable)(D2B)	X	X			

All	1999-2004	SLK	170(16-PIN)	TELE AID, E-call or cellular telephone - Telematic system(K-wrie)	X	X			
All	1999-2004	SLK	170(16-PIN)	TAC - Automatic temperature control/AAC - Automatic air conditioning	X	X	X	X	
All	1999-2004	SLK	170(16-PIN)	STH - Stationary heater	X	X			
All	2005	SLK	171	Transmission	X	X	X	X	Initial startup Control unit adaptations Adaptations Diagnosis routiness
All	2005	SLK	171	ESM - Electronic selector module	X	X	X	X	
All	2005	SLK	171	ME-SFI - Motor electronics	X	X	X	X	
All	2005	SLK	171	ME-SFI 2.8 - Motor electronics 2.8	X	X	X	X	
All	2005	SLK	171	ME 9.7 - Motor electronics 9.7	X	X	X	X	
All	2005	SLK	171	ESP - Electronic stability program	X	X	X	X	Road test
All	2005	SLK	171	AB - Airbag	X	X	X		Read coding and change if necessary Chassis number
All	2005	SLK	171	CGW - Central gateway	X	X			
All	2005	SLK	171	EIS - Electronic ignition switch/KG - Keyless GO(Special equipment)	X	X	X		
All	2005	SLK	171	VR - Vario roof	X	X	X	X	
All	2005	SLK	171	HRA - Headlamp range adjustment	X	X	X	X	Initial startup Read coding and change if necessary Zero position adjustment of axle or level sensors
All	2005	SLK	171	OCP - Overhead control panel	X	X	X	X	Read coding and change if necessary Panornamic sliding roof
All	2005	SLK	171	UCP - Upper control panel	X	X	X	X	
All	2005	SLK	171	SAM-F - Signal acquisition and actuation module front	X	X	X	X	
All	2005	SLK	171	REAR SAM - Rear signal acquisition and actuation module	X	X	X	X	
All	2005	SLK	171	On-board electrical system(voltage supply)	X	X	X		
All	2005	SLK	171	System diagnosis	X	X	X		
All	2005	SLK	171	IC - Instrument cluster	X	X	X	X	
All	2005	SLK	171	ASSYST Active Service System	X	X	X		AssystSetting

All	2005	SLK	171	ASSYST PLUS - PLUS Active Service System	X	X	X		General servicing Control unit adaptations
All	2005	SLK	171	SCM[MRM] - Steering column module	X	X	X	X	initial startup
All	2005	SLK	171	PTS - Parktronic system	X	X	X	X	
All	2005	SLK	171	AGW - Audio gateway(MOST network management,diagnosis gateway,radio tuner)	X	X	X	X	
All	2005	SLK	171	COMAND/AUDIO - Audio50 or COMAND	X	X	X	X	Read coding and change if necessary
All	2005	SLK	171	CDC - CD changer	X	X	X		
All	2005	SLK	171	TV - TV tuner(Not valid for Japan and USA)	X	X	X	X	
All	2005	SLK	171	CTEL - Telephone adapter for portable CTEL	X	X	X		
All	2005	SLK	171	DCM-L - Door control module left	X	X	X	X	Read coding and change if necessary
All	2005	SLK	171	DCM-R - Door control module right	X	X	X	X	Read coding and change if necessary
All	2005	SLK	171	ESA driver - Electric seat adjustment driver(with memory)	X	X	X	X	
All	2005	SLK	171	ESA passenger-Electric seat adjustment FR. Pass.(with memory)	X	X	X	X	
All	2005	SLK	171	HS - Seat heater	X	X	X	X	

All	2005	SLK	171	C-AAC - Convenience automatic air conditioning/AAC - Automatic air conditioning/HEAT - Automatic heater	X	X	X	X	Read coding and change if necessary Normalizing of position motors Check of adjustment range of positioning motors
All	2005	SLK	171	HSW - Heated steering wheel	X	X	X	X	
All	2006-2009	SLK	171	Transmission	X	X	X	X	Initial startup Control unit adaptations Adaptations Diagnosis routiness
All	2006-2009	SLK	171	ESM - Electronic selector module	X	X	X	X	
All	2006-2009	SLK	171	ME-SFI - Motor electronics	X	X	X	X	
All	2006-2009	SLK	171	ME-SFI 2.8 - Motor electronics 2.8	X	X	X	X	
All	2006-2009	SLK	171	ME 9.7 - Motor electronics 9.7	X	X	X	X	
All	2006-2009	SLK	171	ESP - Electronic stability program	X	X	X	X	Road test
All	2006-2009	SLK	171	AB - Airbag	X	X	X		Read coding and change if necessary Chassis number
All	2006-2009	SLK	171	WSS - Weight sensor system (USA)	X	X			
All	2006-2009	SLK	171	CGW - Central gateway	X	X			
All	2006-2009	SLK	171	EIS - Electronic ignition switch/KG - Keyless GO(Special equipment)	X	X	X		
All	2006-2009	SLK	171	VR - Vario roof	X	X	X	X	
All	2006-2009	SLK	171	HRA - Headlamp range adjustment	X	X	X	X	Initial startup Read coding and change if necessary Zero position adjustment of axle or level sensors
All	2006-2009	SLK	171	OCP - Overhead control panel	X	X	X	X	Read coding and change if necessary Panoramic sliding roof
All	2006-2009	SLK	171	UCP - Upper control panel	X	X	X	X	
All	2006-2009	SLK	171	SAM-F - Signal acquisition and actuation module front	X	X	X	X	
All	2006-2009	SLK	171	REAR SAM - Rear signal acquisition and actuation module	X	X	X	X	
All	2006-2009	SLK	171	On-board electrical system(voltage supply)	X	X	X		
All	2006-2009	SLK	171	System diagnosis	X	X	X		
All	2006-2009	SLK	171	IC - Instrument cluster	X	X	X	X	
All	2006-2009	SLK	171	ASSYST Active Service System	X	X	X		AssystSetting

All	2006-2009	SLK	171	ASSYST PLUS - PLUS Active Service System	X	X	X		General servicing Control unit adaptations
All	2006-2009	SLK	171	SCM[MRM] - Steering column module	X	X	X	X	
All	2006-2009	SLK	171	PTS - Parktronic system	X	X	X	X	
All	2006-2009	SLK	171	AGW - Audio gateway(MOST network management,diagnosis gateway,radio tuner)	X	X	X	X	
All	2006-2009	SLK	171	COMAND/AUDIO - Audio50 or COMAND	X	X	X	X	Read coding and change if necessary
All	2006-2009	SLK	171	CDC - CD changer	X	X	X		
All	2006-2009	SLK	171	TV - TV tuner(Not valid for Japan and USA)	X	X	X	X	
All	2006-2009	SLK	171	CTEL - Telephone adapter for portable CTEL	X	X	X		
All	2006-2009	SLK	171	DCM-L - Door control module left	X	X	X	X	
All	2006-2009	SLK	171	DCM-R - Door control module right	X	X	X	X	
All	2006-2009	SLK	171	ESA driver - Electric seat adjustment driver(with memory)	X	X	X	X	
All	2006-2009	SLK	171	ESA passenger-Electric seat adjustment FR. Pass.(with memory)	X	X	X	X	
All	2006-2009	SLK	171	HS - Seat heater	X	X	X	X	

All	2006-2009	SLK	171	C-AAC - Convenience automatic air conditioning/AAC - Automatic air conditioning/HEAT - Automatic heater	X	X	X	X	Read coding and change if necessary Normalizing of position motors Check of adjustment range of positioning motors
All	2006-2009	SLK	171	HSW - Heated steering wheel	X	X	X	X	
All	1998-2005	M-CLASS	163	Transmission	X	X	X	X	Initial startup Control unit adaptations Learn air conditioning Adaptations Diagnosis routiness Read coding and/or transfer download to new control unit
All	1998-2005	M-CLASS	163	ESM - Electronic selector module	X	X	X	X	
All	1998-2005	M-CLASS	163	ME2-SFI - Motor electronics 2	X	X	X	X	
All	1998-2005	M-CLASS	163	CDI - Common Rail Diesel Injection	X	X	X		
All	1998-2005	M-CLASS	163	CDI-V1 - Common Rail Diesel Injection	X	X	X		
All	1998-2005	M-CLASS	163	VG - Transfer case	X	X	X		
All	1998-2005	M-CLASS	163	Traction system ABS,ASR,ETS,ESP	X	X	X	X	
All	1998-2005	M-CLASS	163	BAS - Brake assist	X	X	X	X	
All	1998-2005	M-CLASS	163	AB - Airbag	X	X	X		Read coding and change if necessary Coded vehicle data
All	1998-2005	M-CLASS	163	AAM - All Activity Module	X	X	X	X	
All	1998-2005	M-CLASS	163	EAM - Extended activity module(As of module year 2000)	X	X	X	X	
All	1998-2005	M-CLASS	163	DAS - Drive authorization system(As of module year 2000)	X	X	X		
All	1998-2005	M-CLASS	163	LCP - Lower perating panel with power window function(As of module year 2002)	X	X	X	X	initial startup
All	1998-2005	M-CLASS	163	SEM - Security Module(Up to module year 1999)	X	X			
All	1998-2005	M-CLASS	163	HRA - Headlamp range adjustment(As of module year 2000)	X	X	X	X	
All	1998-2005	M-CLASS	163	ICM - Instrument cluster with maintenance interval display	X	X	X	X	
All	1998-2005	M-CLASS	163	PTS - Parktronic system	X	X	X	X	Read coding and change if necessary

All	1998-2005	M-CLASS	163	D2B - COMAIND,MCS or AUDIO	X	X	X	X	Read coding and change if necessary
All	1998-2005	M-CLASS	163	MCS navigation in MCS	X	X			
All	1998-2005	M-CLASS	163	MCS CD - CD player in MCS	X	X			
All	1998-2005	M-CLASS	163	CDC - CD changer	X	X			
All	1998-2005	M-CLASS	163	VCS - Voice control system	X	X			
All	1998-2005	M-CLASS	163	SOUND - Sound system	X	X	X		
All	1998-2005	M-CLASS	163	CTEL - Cellular telephone 1(fixed installation or portable)(D2B)	X	X			
All	1998-2005	M-CLASS	163	TELE AID,E-call or cellular telephone - Telematic system(K-wire)	X	X	X		
All	1998-2005	M-CLASS	163	ESA-FL - Electric seat adjustment front left	X	X	X	X	
All	1998-2005	M-CLASS	163	ESA-FR - Electric seat adjustment front right	X	X	X	X	
All	1998-2005	M-CLASS	163	AAC - Automatic air conditioning(As of model year 2002)	X	X	X	X	
All	1998-2005	M-CLASS	163	STH - Stationary heater	X	X	X		
All	2006-2009	M-CLASS	164	Transmission	X	X	X	X	Initial startup Control unit adaptations Adaptations Diagnosis routiness

All	2006-2009	M-CLASS	164	VG - Transfer case	X	X	X	X	
All	2006-2009	M-CLASS	164	ISM - Intelligent servo module	X	X	X		
All	2006-2009	M-CLASS	164	ME-SFI 2.8 - Motor electronics 2.8	X	X	X	X	
All	2006-2009	M-CLASS	164	ME9.7-Motor electronics 9.7	X	X	X	X	
All	2006-2009	M-CLASS	164	ME 9.7(AMG) - Motor electronics 9.7(AMG)	X	X	X	X	
All	2006-2009	M-CLASS	164	CDI 4 - Common Rail Diesel Injection	X	X	X	X	
All	2006-2009	M-CLASS	164	CDI 5 - Common Rail Diesel Injection	X	X	X	X	
All	2006-2009	M-CLASS	164	AIRmatic	X	X	X	X	
All	2006-2009	M-CLASS	164	ESP - Electronic stability program	X	X	X	X	
All	2006-2009	M-CLASS	164	TPC - Tire pressure monitor	X	X	X		
All	2006-2009	M-CLASS	164	AB-Airbag	X	X	X		
All	2006-2009	M-CLASS	164	WSS - Weight sensor system (USA)	X	X	X		
All	2006-2009	M-CLASS	164	RevETR-LF - Left front reversible emergency tensioning retractor	X	X	X	X	
All	2006-2009	M-CLASS	164	RevETR-RF - Right front reversible emergency tensioning retractor	X	X	X	X	
All	2006-2009	M-CLASS	164	EIS - Electronic ignition switch/KG - Keyless Go(Special equipment)	X	X	X		
All	2006-2009	M-CLASS	164	CGW - Central gateway	X	X			
All	2006-2009	M-CLASS	164	KG - Keyless Go	X	X	X	X	
All	2006-2009	M-CLASS	164	HRA - Headlamp range adjustment	X	X	X	X	
All	2006-2009	M-CLASS	164	OCP - Overhead control panel	X	X	X	X	
All	2006-2009	M-CLASS	164	UCP - Upper control panel	X	X	X	X	
All	2006-2009	M-CLASS	164	HBf(Rear control panel) - Rear control field	X	X	X	X	
All	2006-2009	M-CLASS	164	SAM-F - Signal acquisition and actuation module front	X	X	X	X	
All	2006-2009	M-CLASS	164	REAR SAM - Rear signal acquisition and actuation module	X	X	X	X	
All	2006-2009	M-CLASS	164	System diagnosis(only interior CAN fault)	X	X	X		
All	2006-2009	M-CLASS	164	IC - Instrument cluster	X	X	X	X	
All	2006-2009	M-CLASS	164	ASSYST - Active Service System	X	X	X		AssystSetting
All	2006-2009	M-CLASS	164	ASSYST PLUS - PLUS Active Service System	X	X	X		General servicing Control unit adaptations

All	2006-2009	M-CLASS	164	CM - Compass module	X	X	X		
All	2006-2009	M-CLASS	164	SCM - Steering column module	X	X	X	X	
All	2006-2009	M-CLASS	164	PTS - Parktronic system	X	X	X	X	
All	2006-2009	M-CLASS	164	AGW - Audio gateway(MOST network management,diagnosis gateway,radio tuner)	X	X	X	X	
All	2006-2009	M-CLASS	164	COMAND /AUDIO - Audio 50(Display and operating unit with navigation) or COMAND(Display and operating unit with navigation)	X	X	X	X	
All	2006-2009	M-CLASS	164	NAVI - Navigation(Only in combination with COMAND)(Valid for USA)	X	X	X		
All	2006-2009	M-CLASS	164	CDC - CD changer	X	X	X		
All	2006-2009	M-CLASS	164	SOUND - Sound system	X	X	X		
All	2006-2009	M-CLASS	164	CTEL - Mobile phone adapter with universal interface	X	X	X		
All	2006-2009	M-CLASS	164	DCM-FL - Door control module front left	X	X	X	X	
All	2006-2009	M-CLASS	164	DCM-FR - Door control module front right	X	X	X	X	
All	2006-2009	M-CLASS	164	REDC - Rear-end door closing control module	X	X	X	X	
All	2006-2009	M-CLASS	164	ESA driver - Electric seat adjustment driver(with memory)	X	X	X	X	

All	2006-2009	M-CLASS	164	ESA passenger - Electric seat adjustment front passenger(with memory)	X	X	X	X	
All	2006-2009	M-CLASS	164	DS-LF - Left front dynamic seat	X	X	X	X	
All	2006-2009	M-CLASS	164	DS-RF - Right front dynamic seat	X	X	X	X	
All	2006-2009	M-CLASS	164	DSP - Pneumatic pump for dynamic seat	X	X	X	X	
All	2006-2009	M-CLASS	164	HS - Seat heater	X	X			
All	2006-2009	M-CLASS	164	AAC - Automatic air conditioning	X	X	X	X	
All	2006-2009	M-CLASS	164	STH - Stationary heater with remote control	X	X	X	X	
All	2006-2009	M-CLASS	164	HSW - Heated steering wheel	X	X	X	X	
All	2006-2009	R-CLASS	251	Transmission	X	X	X	X	Initial startup Control unit adaptations Adaptations Diagnosis routiness
All	2006-2009	R-CLASS	251	ISM - Intelligent servo module	X	X	X		
All	2006-2009	R-CLASS	251	ME-SFI 2.8 - Motor electronics 2.8	X	X	X	X	
All	2006-2009	R-CLASS	251	ME9.7-Motor electronics 9.7	X	X	X	X	Learning of the throttle valve stop
All	2006-2009	R-CLASS	251	ME 9.7(AMG) - Motor electronics 9.7(AMG)	X	X	X	X	
All	2006-2009	R-CLASS	251	CDI 4 - Common Rail Diesel Injection	X	X	X	X	
All	2006-2009	R-CLASS	251	Suspension	X	X	X	X	
All	2006-2009	R-CLASS	251	ESP - Electronic stability program	X	X	X	X	
All	2006-2009	R-CLASS	251	TPC - Tire pressure monitor	X	X	X		
All	2006-2009	R-CLASS	251	AB-Airbag	X	X	X		
All	2006-2009	R-CLASS	251	WSS - Weight sensing system	X	X	X		
All	2006-2009	R-CLASS	251	RevETR-LF - Left front reversible emergency tensioning retractor	X	X	X	X	
All	2006-2009	R-CLASS	251	RevETR-RF - Right front reversible emergency tensioning retractor	X	X	X	X	
All	2006-2009	R-CLASS	251	EIS - Electronic ignition switch/KG - Keyless Go(Special equipment)	X	X	X		
All	2006-2009	R-CLASS	251	CGW - Central gateway	X	X			
All	2006-2009	R-CLASS	251	KG - Keyless Go	X	X	X	X	
All	2006-2009	R-CLASS	251	HRA - Headlamp range adjustment	X	X	X	X	
All	2006-2009	R-CLASS	251	OCP - Overhead control panel	X	X	X	X	
All	2006-2009	R-CLASS	251	UCP - Upper control panel	X	X	X	X	
All	2006-2009	R-CLASS	251	HBf(Rear control panel) - Rear control field	X	X	X	X	

All	2006-2009	R-CLASS	251	SAM-F - Signal acquisition and actuation module front	X	X	X	X	
All	2006-2009	R-CLASS	251	REAR SAM - Rear signal acquisition and actuation module	X	X	X	X	
All	2006-2009	R-CLASS	251	System diagnosis (only interior CAN fault)	X	X	X		
All	2006-2009	R-CLASS	251	IC - Instrument cluster	X	X	X	X	
All	2006-2009	R-CLASS	251	ASSYST - Active Service System	X	X	X		AssystSetting
All	2006-2009	R-CLASS	251	ASSYST PLUS - PLUS Active Service System	X	X	X		General servicing Control unit adaptations
All	2006-2009	R-CLASS	251	CM - Compass module	X	X	X		
All	2006-2009	R-CLASS	251	SCM - Steering column module	X	X	X	X	
All	2006-2009	R-CLASS	251	PTS - Parktronic system	X	X	X		
All	2006-2009	R-CLASS	251	AGW - Audio 20 with integrated gateway(display and operating unit,MOST network management,diagnosis gateway,radio tuner)	X	X	X		
All	2006-2009	R-CLASS	251	CDC - CD changer	X	X	X		
All	2006-2009	R-CLASS	251	SOUND - Sound system	X	X	X		

All	2006-2009	R-CLASS	251	CTEL - Telephone adapter for portable CTEL	X	X	X		
All	2006-2009	R-CLASS	251	DCM-FL - Door control module front left	X	X	X	X	
All	2006-2009	R-CLASS	251	DCM-FR - Door control module front right	X	X	X	X	
All	2006-2009	R-CLASS	251	REDC - Rear-end door closing control module	X	X	X	X	
All	2006-2009	R-CLASS	251	ESA driver - Electric seat adjustment driver(with memory)	X	X	X	X	
All	2006-2009	R-CLASS	251	ESA passenger-Electric seat adjustment FR. Pass.(with memory)	X	X	X	X	
All	2006-2009	R-CLASS	251	DS-LF - Left front dynamic seat	X	X	X	X	
All	2006-2009	R-CLASS	251	DS-RF - Right front dynamic seat	X	X	X	X	
All	2006-2009	R-CLASS	251	DSP - Pneumatic pump for dynamic seat	X	X	X	X	
All	2006-2009	R-CLASS	251	HS - Seat heater	X	X	X	X	
All	2006-2009	R-CLASS	251	AAC - Automatic air conditioning	X	X	X	X	
All	2006-2009	R-CLASS	251	STH - Stationary heater with remote control	X	X	X	X	
All	2006-2009	R-CLASS	251	HSW - Heated steering wheel	X	X	X	X	
All	1991-2001	G-CLASS	461(38Pin)	ABS	X	X	X		
All	1991-2001	G-CLASS	461(38Pin)	ASR	X	X	X		
All	1991-2001	G-CLASS	461(38Pin)	ETS	X	X	X		
All	1991-2001	G-CLASS	461(38Pin)	ESP	X	X	X		
All	1991-2001	G-CLASS	461(38Pin)	RFL(DAS2)	X	X	X		
All	1991-2001	G-CLASS	461(38Pin)	AB	X	X	X		
All	1991-2001	G-CLASS	461(38Pin)	KI	X	X	X	X	
All	1991-2001	G-CLASS	461(38Pin)	STH	X	X			
All	2002-2007	G-CLASS	461(16PIN)	ETC - Electronic transmission control	X	X	X	X	
All	2002-2007	G-CLASS	461(16PIN)	ESM - Electronic selector module	X	X	X	X	
All	2002-2007	G-CLASS	461(16PIN)	VG - Transfer case	X	X	X		
All	2002-2007	G-CLASS	461(16PIN)	CDI 2 - Common Rail Diesel Injection	X	X	X		
All	2002-2007	G-CLASS	461(16PIN)	AB - Airbag	X	X	X	X	

All	2002-2007	G-CLASS	461(16PIN)	IC - Instrument cluster	X	X	X	X	
All	2002-2007	G-CLASS	461(16PIN)	AUDIO	X	X	X	X	
All	2002-2007	G-CLASS	461(16PIN)	Air conditioning	X	X	X	X	
All	2002-2007	G-CLASS	461(16PIN)	STH - Stationary heater	X	X	X		
All	1991-1997	G-CLASS	463(4Pin)	HFM	X	X	X		
All	1991-1997	G-CLASS	463(4Pin)	EFP	X	X	X		
All	1991-1997	G-CLASS	463(4Pin)	TPM	X	X	X		
All	1991-1997	G-CLASS	463(4Pin)	ISC	X	X	X		
All	1991-1997	G-CLASS	463(4Pin)	RCL(DAS1/X)	X	X	X		
All	1991-1997	G-CLASS	463(4Pin)	RCL(DAS2/X)	X	X	X		
All	1991-1997	G-CLASS	463(4Pin)	ATA(Anti-Theft Alarm)	X	X	X		
All	1991-1997	G-CLASS	463(4Pin)	AB(Air Bag)	X	X	X		
All	1997-	G-CLASS	463(38Pin)	ETC - Electronic transmission control	X	X	X	X	Initial startup Control unit adaptations Learn air conditioning Adaptations Diagnosis routiness Read coding and/or transfer download to new control unit
All	1997-	G-CLASS	463(38Pin)	ESM - Electronic selector module	X	X	X	X	
All	1997-	G-CLASS	463(38Pin)	HFM-SFI- Hot film engine management	X	X	X		
All	1997-	G-CLASS	463(38Pin)	ME2-SFI - Motor electronics	X	X	X		
All	1997-	G-CLASS	463(38Pin)	Traction systems ABS,ASR,ETS,ESP	X	X	X	X	
All	1997-	G-CLASS	463(38Pin)	AB - Airbag	X	X	X	X	Control unit adaptations
All	1997-	G-CLASS	463(38Pin)	RFL(DAS2) - Radio frequency locking(drive authorization stage 2)	X	X	X	X	
All	1997-	G-CLASS	463(38Pin)	ATA - Anti-theft alarm system	X	X	X	X	
All	1997-	G-CLASS	463(38Pin)	ICM - Instrument cluster with maintenance interval display	X	X	X	X	Clock Reset odometer to 0 km Oil change
All	1997-	G-CLASS	463(38Pin)	D2B - AUDIO	X	X	X	X	Read coding and change if necessary

All	1997-	G-CLASS	463(38Pin)	CDC - CD changer	X	X			
All	1997-	G-CLASS	463(38Pin)	VCS - Voice control system	X	X			
All	1997-	G-CLASS	463(38Pin)	CTEL - Cellular telephone 1(fixed installation or portable)(D2B)	X	X			
All	1997-	G-CLASS	463(38Pin)	APS - Auto pilot system	X	X			
All	1997-	G-CLASS	463(38Pin)	Air conditioning	X	X	X		Read coding and change if necessary
All	1997-	G-CLASS	463(38Pin)	STH - Stationary heater	X	X			
All	-2004	G-CLASS	463(16Pin)	ETC - Electronic transmission control	X	X	X	X	Initial startup Control unit adaptations Learn air conditioning Adaptations Diagnosis routiness Read coding and/or transfer download to new control unit
All	-2004	G-CLASS	463(16Pin)	ESM - Electronic selector module	X	X	X	X	
All	-2004	G-CLASS	463(16Pin)	ME-SFI 2.8 - Motor electronics 2.8	X	X	X	X	
All	-2004	G-CLASS	463(16Pin)	CDI-V1 - Common Rail Diesel Injection	X	X	X	X	
All	-2004	G-CLASS	463(16Pin)	CDI 2 - Common Rail Diesel Injection	X	X	X	X	
All	-2004	G-CLASS	463(16Pin)	VG - Transfer case	X	X	X	X	
All	-2004	G-CLASS	463(16Pin)	Traction systems ABS,ASR,ETS,ESP	X	X	X	X	
All	-2004	G-CLASS	463(16Pin)	AB - Airbag	X	X	X		
All	-2004	G-CLASS	463(16Pin)	EIS - Electronic ignition switch	X	X	X		
All	-2004	G-CLASS	463(16Pin)	UCP - Upper control panel	X	X	X	X	
All	-2004	G-CLASS	463(16Pin)	SAM-F - Signal acquisition and actuation module front	X	X	X	X	
All	-2004	G-CLASS	463(16Pin)	REAR SAM - Rear signal acquisition and actuation module	X	X	X	X	
All	-2004	G-CLASS	463(16Pin)	AHE - Trailer recognition	X	X	X	X	
All	-2004	G-CLASS	463(16Pin)	OCP - Overhead control panel	X	X	X	X	
All	-2004	G-CLASS	463(16Pin)	VR - Electrohydraulic soft top	X	X	X	X	

All	-2004	G-CLASS	463(16Pin)	MSS - Special vehicle multifunction control module	X	X			
All	-2004	G-CLASS	463(16Pin)	ICM - Instrument cluster with maintenance interval display	X	X	X	X	
All	-2004	G-CLASS	463(16Pin)	SCM[MRM] - Steering column module(As of model year 2002)	X	X	X	X	
All	-2004	G-CLASS	463(16Pin)	D2B - COMAND or AUDIO	X	X	X	X	Read coding and change if necessary
All	-2004	G-CLASS	463(16Pin)	CDC - CD changer	X	X			
All	-2004	G-CLASS	463(16Pin)	VCS - Voice control system	X	X	X		
All	-2004	G-CLASS	463(16Pin)	CTEL - Cellular telephone 1(fixed installation or portable)(D2B)	X	X			
All	-2004	G-CLASS	463(16Pin)	TELE AID,E-call or cellular telephone - Telematic system(K-write)	X	X	X		
All	-2004	G-CLASS	463(16Pin)	TV - TV tuner	X	X			
All	-2004	G-CLASS	463(16Pin)	DCM-FL - Door control module front left	X	X	X	X	
All	-2004	G-CLASS	463(16Pin)	DCM-FR - Door control module front right	X	X	X	X	
All	-2004	G-CLASS	463(16Pin)	DCM-RL - Door control module rear left	X	X	X	X	
All	-2004	G-CLASS	463(16Pin)	DCM-RR - Door control module rear right	X	X	X	X	
All	-2004	G-CLASS	463(16Pin)	ESA driver - Electric seat adjustment driver(with memory)	X	X	X	X	

All	-2004	G-CLASS	463(16Pin)	ESA passenger - Electric seat adjustment front passenger(with memory)	X	X	X	X	
All	-2004	G-CLASS	463(16Pin)	AAC- Automatic air conditioning	X	X	X	X	Read coding and change if necessary Normalizing of position motors Check of adjustment range of positioning motors Teaching-in of rotary potentiometer for center nozzle and side outlets
All	-2004	G-CLASS	463(16Pin)	STH - Stationary heater with remote control	X	X	X	X	
All	-2004	G-CLASS	463(16Pin)	HSW - Heated steering wheel	X	X			
All	2004-2006	G-CLASS	463(16Pin)	ETC - Electronic transmission control	X	X	X	X	Initial startup Control unit adaptations Learn air conditioning Adaptations Diagnosis routiness Read coding and/or transfer download to new control unit
All	2004-2006	G-CLASS	463(16Pin)	ESM - Electronic selector module	X	X	X	X	
All	2004-2006	G-CLASS	463(16Pin)	ME-SFI 2.8 - Motor electronics 2.8	X	X	X	X	
All	2004-2006	G-CLASS	463(16Pin)	CDI-V1 - Common Rail Diesel Injection	X	X	X	X	
All	2004-2006	G-CLASS	463(16Pin)	CDI 2 - Common Rail Diesel Injection	X	X	X	X	
All	2004-2006	G-CLASS	463(16Pin)	VG - Transfer case	X	X	X	X	
All	2004-2006	G-CLASS	463(16Pin)	Traction systems ABS,ASR,ETS,ESP	X	X	X	X	
All	2004-2006	G-CLASS	463(16Pin)	AB - Airbag	X	X	X		
All	2004-2006	G-CLASS	463(16Pin)	EIS - Electronic ignition switch	X	X	X		
All	2004-2006	G-CLASS	463(16Pin)	UCP - Upper control panel	X	X	X	X	
All	2004-2006	G-CLASS	463(16Pin)	SAM-F - Signal acquisition and actuation module front	X	X	X	X	
All	2004-2006	G-CLASS	463(16Pin)	REAR SAM - Rear signal acquisition and actuation module	X	X	X	X	
All	2004-2006	G-CLASS	463(16Pin)	AHE - Trailer recognition	X	X	X	X	
All	2004-2006	G-CLASS	463(16Pin)	OCP - Overhead control panel	X	X	X	X	
All	2004-2006	G-CLASS	463(16Pin)	VR - Electrohydraulic soft top	X	X	X	X	
All	2004-2006	G-CLASS	463(16Pin)	MSS - Special vehicle multifunction control module	X	X			
All	2004-2006	G-CLASS	463(16Pin)	ICM - Instrument cluster with maintenance interval display	X	X	X	X	
All	2004-2006	G-CLASS	463(16Pin)	SCM[MRM] - Steering column module(As of model year 2002)	X	X	X	X	

All	2004-2006	G-CLASS	463(16Pin)	D2B - COMAND or AUDIO	X	X	X	X	Read coding and change if necessary
All	2004-2006	G-CLASS	463(16Pin)	CDC - CD changer	X	X			
All	2004-2006	G-CLASS	463(16Pin)	VCS - Voice control system	X	X	X		
All	2004-2006	G-CLASS	463(16Pin)	CTEL - Cellular telephone 1(fixed installation or portable)(D2B)	X	X			
All	2004-2006	G-CLASS	463(16Pin)	TELE AID,E-call or cellular telephone - Telematic system(K-write)	X	X	X		
All	2004-2006	G-CLASS	463(16Pin)	TV - TV tuner	X	X			
All	2004-2006	G-CLASS	463(16Pin)	DCM-FL - Door control module front left	X	X	X	X	
All	2004-2006	G-CLASS	463(16Pin)	DCM-FR - Door control module front right	X	X	X	X	
All	2004-2006	G-CLASS	463(16Pin)	DCM-RL - Door control module rear left	X	X	X	X	
All	2004-2006	G-CLASS	463(16Pin)	DCM-RR - Door control module rear right	X	X	X	X	
All	2004-2006	G-CLASS	463(16Pin)	ESA driver - Electric seat adjustment driver(with memory)	X	X	X	X	
All	2004-2006	G-CLASS	463(16Pin)	ESA passenger - Electric seat adjustment front passenger(with memory)	X	X	X	X	
All	2004-2006	G-CLASS	463(16Pin)	AAC- Automatic air conditioning	X	X	X	X	Read coding and change if necessary Normalizing of position motors Check of adjustment range of positioning motors Teaching-in of rotary potentiometer for center nozzle and side outlets
All	2004-2006	G-CLASS	463(16Pin)	STH - Stationary heater with remote control	X	X	X	X	

All	2004-2006	G-CLASS	463(16Pin)	HSW - Heated steering wheel	X	X			
All	2006-2007	G-CLASS	463(16Pin)	ETC - Electronic transmission control	X	X	X	X	Initial startup Control unit adaptations Adaptations Diagnosis routiness
All	2006-2007	G-CLASS	463(16Pin)	ESM - Electronic selector module	X	X	X	X	
All	2006-2007	G-CLASS	463(16Pin)	ME-SFI 2.8 - Motor electronics 2.8	X	X	X	X	
All	2006-2007	G-CLASS	463(16Pin)	CDI 4 - Common Rail Diesel Injection	X	X	X	X	
All	2006-2007	G-CLASS	463(16Pin)	VG - Transfer case	X	X	X	X	
All	2006-2007	G-CLASS	463(16Pin)	ESP - Electronic stability program	X	X	X	X	Road test
All	2006-2007	G-CLASS	463(16Pin)	TPC - Tire pressure monitor	X	X	X	X	Read coding and change if necessary
All	2006-2007	G-CLASS	463(16Pin)	AB - Airbag	X	X	X		
All	2006-2007	G-CLASS	463(16Pin)	EIS - Electronic ignition switch	X	X	X	X	
All	2006-2007	G-CLASS	463(16Pin)	UCP - Upper control panel	X	X	X	X	
All	2006-2007	G-CLASS	463(16Pin)	SAM-F - Signal acquisition and actuation module front	X	X	X	X	
All	2006-2007	G-CLASS	463(16Pin)	REAR SAM - Rear signal acquisition and actuation module	X	X	X	X	
All	2006-2007	G-CLASS	463(16Pin)	AHE - Trailer recognition	X	X	X	X	
All	2006-2007	G-CLASS	463(16Pin)	OCP - Overhead control panel	X	X	X	X	Read coding and change if necessary
All	2006-2007	G-CLASS	463(16Pin)	ALWR - Headlamp range adjustment	X	X	X	X	
All	2006-2007	G-CLASS	463(16Pin)	MSS - Special vehicle multifunction control module	X	X			
All	2006-2007	G-CLASS	463(16Pin)	ICM - Instrument cluster with maintenance interval display	X	X	X	X	Oil change
All	2006-2007	G-CLASS	463(16Pin)	SCM[MRM] - Steering column module(As of model year 2002)	X	X	X	X	
All	2006-2007	G-CLASS	463(16Pin)	AGW - Audio gateway	X	X	X	X	
All	2006-2007	G-CLASS	463(16Pin)	COMAND/AUDIO - Audio50 or COMAND	X	X	X	X	Read coding and change if necessary
All	2006-2007	G-CLASS	463(16Pin)	CDC - CD changer	X	X	X		

All	2006-2007	G-CLASS	463(16Pin)	HFS - Hands free system and microphone	X	X			
All	2006-2007	G-CLASS	463(16Pin)	CTEL - Telephone adapter for portable CTEL	X	X	X	X	
All	2006-2007	G-CLASS	463(16Pin)	DCM-FL - Door control module front left	X	X	X	X	
All	2006-2007	G-CLASS	463(16Pin)	DCM-FR - Door control module front right	X	X	X	X	
All	2006-2007	G-CLASS	463(16Pin)	DCM-RL - Door control module rear left	X	X	X	X	
All	2006-2007	G-CLASS	463(16Pin)	DCM-RR - Door control module rear right	X	X	X	X	
All	2006-2007	G-CLASS	463(16Pin)	ESA driver - Electric seat adjustment front passenger(with memory)	X	X	X	X	
All	2006-2007	G-CLASS	463(16Pin)	ESA passenger - Electric seat adjustment front passenger(with memory)	X	X	X	X	
All	2006-2007	G-CLASS	463(16Pin)	AAC- Automatic air conditioning	X	X	X	X	
All	2006-2007	G-CLASS	463(16Pin)	STH - Stationary heater with remote control	X	X	X	X	
All	2006-2007	G-CLASS	463(16Pin)	HSW - Heated steering wheel	X	X	X	X	
All	2007-2009	G-CLASS	463(16Pin)	ETC - Electronic transmission control	X	X	X	X	Initial startup Control unit adaptations Adaptations Diagnosis routiness
All	2007-2009	G-CLASS	463(16Pin)	ESM - Electronic selector module	X	X	X	X	
All	2007-2009	G-CLASS	463(16Pin)	ME-SFI 2.8 - Motor electronics 2.8	X	X	X	X	
All	2007-2009	G-CLASS	463(16Pin)	CDI 2 - Common Rail Diesel Injection	X	X	X	X	
All	2007-2009	G-CLASS	463(16Pin)	CDI-V1 - Common Rail Diesel Injection	X	X	X		
All	2007-2009	G-CLASS	463(16Pin)	VG - Transfer case	X	X	X	X	
All	2007-2009	G-CLASS	463(16Pin)	ESP - Electronic stability program	X	X	X	X	Road test
All	2007-2009	G-CLASS	463(16Pin)	TPC - Tire pressure monitor	X	X	X	X	Read coding and change if necessary
All	2007-2009	G-CLASS	463(16Pin)	AB - Airbag	X	X	X		
All	2007-2009	G-CLASS	463(16Pin)	EIS - Electronic ignition switch	X	X	X	X	
All	2007-2009	G-CLASS	463(16Pin)	UCP - Upper control panel	X	X	X	X	
All	2007-2009	G-CLASS	463(16Pin)	SAM-F - Signal acquisition and actuation module front	X	X	X	X	
All	2007-2009	G-CLASS	463(16Pin)	REAR SAM - Rear signal acquisition and actuation module	X	X	X	X	

All	2007-2009	G-CLASS	463(16Pin)	AHE - Trailer recognition	X	X	X	X	
All	2007-2009	G-CLASS	463(16Pin)	OCF - Overhead control panel	X	X	X	X	Read coding and change if necessary
All	2007-2009	G-CLASS	463(16Pin)	MSS - Special vehicle multifunction control module	X	X	X	X	
All	2007-2009	G-CLASS	463(16Pin)	ALWR - Headlamp range adjustment	X	X			
All	2007-2009	G-CLASS	463(16Pin)	ICM - Instrument cluster with maintenance interval display	X	X	X	X	Oil change
All	2007-2009	G-CLASS	463(16Pin)	SCM[MRM] - Steering column module(As of model year 2002)	X	X	X	X	
All	2007-2009	G-CLASS	463(16Pin)	AGW - Audio gateway	X	X	X	X	
All	2007-2009	G-CLASS	463(16Pin)	COMAND/AUDIO - Audio50 or COMAND	X	X	X	X	Read coding and change if necessary
All	2007-2009	G-CLASS	463(16Pin)	CDC - CD changer	X	X	X		
All	2007-2009	G-CLASS	463(16Pin)	HFS - Hands free system and microphone	X	X			
All	2007-2009	G-CLASS	463(16Pin)	CTEL - Telephone adapter for portable CTEL	X	X	X	X	
All	2007-2009	G-CLASS	463(16Pin)	DCM-FL - Door control module front left	X	X	X	X	
All	2007-2009	G-CLASS	463(16Pin)	DCM-FR - Door control module front right	X	X	X	X	
All	2007-2009	G-CLASS	463(16Pin)	DCM-RL - Door control module rear left	X	X	X	X	
All	2007-2009	G-CLASS	463(16Pin)	DCM-RR - Door control module rear right	X	X	X	X	
All	2007-2009	G-CLASS	463(16Pin)	ESA driver - Electric seat adjustment front passenger(with memory)	X	X	X	X	

All	2007-2009	G-CLASS	463(16Pin)	ESA passenger - Electric seat adjustment front passenger(with memory)	X	X	X	X	
All	2007-2009	G-CLASS	463(16Pin)	AAC- Automatic air conditioning	X	X	X	X	
All	2007-2009	G-CLASS	463(16Pin)	STH - Stationary heater with remote control	X	X	X	X	
All	2007-2009	G-CLASS	463(16Pin)	HSW - Heated steering wheel	X	X	X	X	
All	2006-2009	GL-CLASS	X164	Transmission	X	X	X	X	
All	2006-2009	GL-CLASS	X164	VG - Transfer case	X	X	X	X	
All	2006-2009	GL-CLASS	X164	ISM - Intelligent servo module	X	X	X		
All	2006-2009	GL-CLASS	X164	ME 9.7 - Motor electronics 9.7	X	X	X	X	
All	2006-2009	GL-CLASS	X164	CDI 4 - Common Rail Diesel Injection	X	X	X	X	
All	2006-2009	GL-CLASS	X164	CDI 5 - Common Rail Diesel Injection	X	X	X	X	
All	2006-2009	GL-CLASS	X164	AIRmatic	X	X	X	X	
All	2006-2009	GL-CLASS	X164	ESP - Electronic stability program	X	X	X	X	
All	2006-2009	GL-CLASS	X164	TPC - Tire pressure monitor	X	X	X		
All	2006-2009	GL-CLASS	X164	AB-Airbag	X	X	X		
All	2006-2009	GL-CLASS	X164	WSS - Weight sensor system	X	X	X		
All	2006-2009	GL-CLASS	X164	RevETR-LF - Left front reversible emergency tensioning retractor	X	X	X	X	
All	2006-2009	GL-CLASS	X164	RevETR-RF - Right front reversible emergency tensioning retractor	X	X	X	X	
All	2006-2009	GL-CLASS	X164	EIS - Electronic ignition switch/KG - Keyless Go(Special equipment)	X	X	X		
All	2006-2009	GL-CLASS	X164	CGW - Central gateway	X	X			
All	2006-2009	GL-CLASS	X164	KG - Keyless Go	X	X	X	X	
All	2006-2009	GL-CLASS	X164	HRA - Headlamp range adjustment	X	X	X	X	
All	2006-2009	GL-CLASS	X164	OCP - Overhead control panel	X	X	X	X	
All	2006-2009	GL-CLASS	X164	UCP - Upper control panel	X	X	X	X	
All	2006-2009	GL-CLASS	X164	HBF(Rear control panel) - Rear control field	X	X	X	X	
All	2006-2009	GL-CLASS	X164	SAM-F - Signal acquisition and actuation module front	X	X	X	X	
All	2006-2009	GL-CLASS	X164	REAR SAM - Rear signal acquisition and actuation module	X	X	X	X	
All	2006-2009	GL-CLASS	X164	System diagnosis(only interior CAN fault)	X	X	X		
All	2006-2009	GL-CLASS	X164	IC - Instrument cluster	X	X	X	X	

All	2006-2009	GL-CLASS	X164	ASSYST - Active Service System	X	X	X		AssystSetting
All	2006-2009	GL-CLASS	X164	ASSYST PLUS - PLUS Active Service System	X	X	X		General servicing Control unit adaptations
All	2006-2009	GL-CLASS	X164	CM - Compass module	X	X	X		
All	2006-2009	GL-CLASS	X164	SCM - Steering column module	X	X	X	X	
All	2006-2009	GL-CLASS	X164	PTS - Parktronic system	X	X	X		
All	2006-2009	GL-CLASS	X164	AGW - Audio gateway(MOST network management,diagnosis gateway,radio tuner)	X	X	X	X	
All	2006-2009	GL-CLASS	X164	COMAND/AUDIO - Audio50 or COMAND	X	X	X		
All	2006-2009	GL-CLASS	X164	CDC - CD changer	X	X	X		
All	2006-2009	GL-CLASS	X164	TV - TV tuner(Not valid for Japan and USA)	X	X	X	X	
All	2006-2009	GL-CLASS	X164	CTEL - Telephone adapter for portable CTCL	X	X	X	X	
All	2006-2009	GL-CLASS	X164	DCM-FL - Door control module front left	X	X	X	X	
All	2006-2009	GL-CLASS	X164	DCM-FR - Door control module front right	X	X	X	X	

All	2006-2009	GL-CLASS	X164	REDC - Rear-end door closing control module	X	X	X	X	
All	2006-2009	GL-CLASS	X164	ESA driver - Electric seat adjustment driver(with memory)	X	X	X	X	
All	2006-2009	GL-CLASS	X164	ESA passenger - Electric seat adjustment front passenger(with memory)	X	X	X	X	
All	2006-2009	GL-CLASS	X164	DS-LF - Left front dynamic seat	X	X	X	X	
All	2006-2009	GL-CLASS	X164	DS-RF - Right front dynamic seat	X	X	X	X	
All	2006-2009	GL-CLASS	X164	DSP - Pneumatic pump for dynamic seat	X	X	X	X	
All	2006-2009	GL-CLASS	X164	ERA - Electric fold-down backrest system(3rd seat row)	X	X	X	X	
All	2006-2009	GL-CLASS	X164	HS - Seat heater	X	X			
All	2006-2009	GL-CLASS	X164	AAC - Automatic air conditioning	X	X	X	X	
All	2006-2009	GL-CLASS	X164	STH - Stationary heater with remote control	X	X	X	X	
All	2006-2009	GL-CLASS	X164	HSW - Heated steering wheel	X	X	X	X	
All	2008-2009	GLK	X204	ME 9.7 - Motor electronics 9.7(Chassis CAN bus)	X	X	X	X	
All	2008-2009	GLK	X204	CDI 6 - Common Rail Diesel Injection(Chassis CAN bus)	X	X	X	X	Replace component Y74 (Pressure control valve) Replace component B28/8 (Pressure differential sensor (DPF)) Reset quantity mean value adaptation data Reset values for HFM drift compensation Resetting air filter learned values after air filter replacement Teaching in the diesel particulate filter after replacing the engine control unit Activate fuel pump Rapid teach-in of zero quantity calibration balues
All	2008-2009	GLK	X204	FSCU - Fuel Pump(Drive train CAN bus)	X	X	X	X	
All	2008-2009	GLK	X204	Transmission	X	X	X	X	
All	2008-2009	GLK	X204	ESM - Electronic selector module(Drive train CAN bus)	X	X	X	X	
All	2008-2009	GLK	X204	ABR - Adaptive Brake(Chassis CAN bus)	X	X	X		

All	2008-2009	GLK	X204	Suspension(Chassis CAN bus)	X	X	X	X	
All	2008-2009	GLK	X204	TPC - Tire pressure monitor(Interior CAN bus)	X	X	X	X	
All	2008-2009	GLK	X204	CGW - Central gateway(Central CAN bus)	X	X	X		
All	2008-2009	GLK	X204	EZS - Electronic ignition switch(Interior CAN bus)	X	X	X		
All	2008-2009	GLK	X204	KG - Keyless Go(Interior CAN bus)	X	X			
All	2008-2009	GLK	X204	XALWA-L - Xenon headlamp,left(Front end CAN bus)	X	X	X	X	
All	2008-2009	GLK	X204	XALWA-R - Xenon headlamp,right(Front end CAN bus)	X	X	X	X	
All	2008-2009	GLK	X204	AB - Airbag	X	X	X		
All	2008-2009	GLK	X204	WSS - Weight sensor system (USA)(Interior CAN bus)	X	X			
All	2008-2009	GLK	X204	System 'Dr-side SAM' with connected LIN components(Interior CAN bus)	X	X	X	X	
All	2008-2009	GLK	X204	System 'REAR SAM' with connected LIN components(Interior CAN bus)	X	X	X	X	
All	2008-2009	GLK	X204	OCP - Overhead control panel(Interior CAN bus)	X	X	X	X	
All	2008-2009	GLK	X204	COU[ZBE] - Central operating unit(Telematic CAN bus)	X	X	X	X	
All	2008-2009	GLK	X204	RevETR-LF - Left front reversible emergency tensinoing retrator(Chassis CAN bus)	X	X	X		
All	2008-2009	GLK	X204	RevETR-RF - Right front reversible emergency tensinoing retrator(Chassis CAN bus)	X	X	X		
All	2008-2009	GLK	X204	ICM - Instrument cluster with maintenance interval display(Interior CAN bus)	X	X	X	X	
All	2008-2009	GLK	X204	SCM[MRM] - Steering column module(Chassis CAN bus)	X	X	X	X	
All	2008-2009	GLK	X204	PTS - Parktronic(Interior CAN bus)	X	X	X	X	

All	2008-2009	GLK	X204	RFK - Backup camera Janpan(Interior CAN bus)	X	X	X		
All	2008-2009	GLK	X204	COMAND - COMAND with integral telematics gateway(MOST network management, diagnosis gateway)	X	X	X	X	
All	2008-2009	GLK	X204	Tuner - Radio tuner with amplifier	X	X			
All	2008-2009	GLK	X204	CTEL - Mobile telephone adapter with universal interface	X	X	X	X	
All	2008-2009	GLK	X204	VCS - Voice control(Linguatronic)	X	X	X	X	
All	2008-2009	GLK	X204	TV - TV tuner(Not valid for Japan and USA)	X	X	X		
All	2008-2009	GLK	X204	SDAR - Satellite radio (Valid for USA)	X	X	X	X	
All	2008-2009	GLK	X204	ZAN - Central Display	X	X	X	X	
All	2008-2009	GLK	X204	COU[ZBE] - Central operating unit(Telematic CAN bus)	X	X	X	X	
All	2008-2009	GLK	X204	KBE-H -Rear A/C operating unit	X	X	X		
All	2008-2009	GLK	X204	System 'Door control module front left' with connected LIN components(Interior CAN bus)	X	X	X	X	

All	2008-2009	GLK	X204	System 'Door control module front right' with connected LIN components(Interior CAN bus)	X	X	X	X	
All	2008-2009	GLK	X204	DCM-RL - Door control module rear left(Interior CAN bus)	X	X	X	X	
All	2008-2009	GLK	X204	DCM-RR - Door control module rear right(Interior CAN bus)	X	X	X	X	
All	2008-2009	GLK	X204	ESA driver - Electric seat adjustment driver(Interior CAN bus)	X	X	X	X	
All	2008-2009	GLK	X204	AAC - Automatic air conditioning(Interior CAN bus)	X	X	X	X	
All	1996-2003	VITO/V-CLASS	638	ME2 - Fuel injection and ignition system	X	X	X		
All	1996-2003	VITO/V-CLASS	638	V6 - 6-cylinder gasoline engine	X	X	X		
All	1996-2003	VITO/V-CLASS	638	CDI - Common rail diesel injection	X	X	X	X	
All	1996-2003	VITO/V-CLASS	638	ABS - Anti-lock brake system	X	X	X		
All	1996-2003	VITO/V-CLASS	638	WSP - Immobilizer	X	X	X		
All	1996-2003	VITO/V-CLASS	638	AB - Airbag	X	X	X		
All	1996-2003	VITO/V-CLASS	638	AG - Automatic transmission for V6 engines	X	X	X		
All	1996-2003	VITO/V-CLASS	638	AGN - Automatic transmission	X	X	X		
All	1996-2003	VITO/V-CLASS	638	KR - Combination relay	X	X	X		
All	1996-2003	VITO/V-CLASS	638	HZR - Heating control	X	X	X		
All	1996-2003	VITO/V-CLASS	638	ATA - Anti-theft alarm system	X	X	X	X	
All	1996-2003	VITO/V-CLASS	638	ENR - Electronic level control	X	X			
All	1996-2003	VITO/V-CLASS	638	ERE - Electronic inline	X	X	X	X	
All	1996-2003	VITO/V-CLASS	638	EVE - Evecronic distributor injection	X	X	X	X	
All	1996-2003	VITO/V-CLASS	638	APS - Auto pilot system	X	X			
All	1996-2003	VITO/V-CLASS	638	KI - Instrument cluster	X	X	X		

All	2004-2007	VITO/VIANO	639	ETC - Electronic transmission control	X	X	X	X	ETC52: Coding according to plant data Display adaptation data Resetting of adaptation data Performing adaptation Actual values : Oil level check Transmission oil temperature Emergency running Shift points ETC53: Coding according to plant data Display adaptation data Resetting of adaptation data Performing adaptation Actual values : Oil level check Transmission oil temperature Emergency running Shift points PWM solenoid valve 'Torque converter lockup clutch' : Shut off Switch off the incline recognition for dynamometer mode
All	2004-2007	VITO/VIANO	639	ESM - Electronic selector module	X	X	X	X	
All	2004-2007	VITO/VIANO	639	ME-SFI - Motor electronics	X	X	X	X	
All	2004-2007	VITO/VIANO	639	CDI - Common Rail	X	X			
All	2004-2007	VITO/VIANO	639	ENR - Electronic level control	X	X			
All	2004-2007	VITO/VIANO	639	ESP - Electronic stability program	X	X	X		
All	2004-2007	VITO/VIANO	639	TPC - Tire pressure monitor	X	X			
All	2004-2007	VITO/VIANO	639	AAG - Trailer connection unit	X	X	X		
All	2004-2007	VITO/VIANO	639	OCP - Overhead control panel	X	X	X		
All	2004-2007	VITO/VIANO	639	EIS - Electronic ignition switch	X	X	X		
All	2004-2007	VITO/VIANO	639	CGW - Central gateway	X	X			
All	2004-2007	VITO/VIANO	639	UCP - Upper control panel	X	X	X		
All	2004-2007	VITO/VIANO	639	SAM - Signal acquisition and actuation module	X	X	X		
All	2004-2007	VITO/VIANO	639	SDE-H - Rear sliding/tilting sunroof unit	X	X	X	X	
All	2004-2007	VITO/VIANO	639	SRS - Supplemental restraint system	X	X		X	Transmit key ID to control unit N2/11 (Supplemental restraint system (SRS)) Read coding Interlock control module

All	2004-2007	VITO/VIANO	639	IC - Instrument cluster	X	X	X	X	ASSYST settings Perform oil change
All	2004-2007	VITO/VIANO	639	PTS - Parktronic system	X	X			
All	2004-2007	VITO/VIANO	639	AGW Audio gateway(MOST master),COMAND,AUDIO,SOUND	X	X	X	X	
All	2004-2007	VITO/VIANO	639	ESA passenger - Electric seat adjustment passenger	X	X			
All	2004-2007	VITO/VIANO	639	ESA driver - Electric seat adjustment driver	X	X			
All	2004-2007	VITO/VIANO	639	DCM-FL - Door control module front left	X	X	X	X	
All	2004-2007	VITO/VIANO	639	DCM-FR - Door control module front right	X	X	X	X	
All	2004-2007	VITO/VIANO	639	AAC - Automatic air conditioning/automatic temperature control/Heating-ventilation	X	X	X	X	Control unit reset Perform normalizing of component M16/8(Blending air flap actuator motor)
All	2004-2007	VITO/VIANO	639	PTC - Electric heater booster	X	X	X	X	Control unit reset
All	2004-2007	VITO/VIANO	639	REAR AC - Rear air conditioning/Rear heater	X	X	X	X	
All	2004-2007	VITO/VIANO	639	STH - Stationary heater/Heater booster	X	X	X	X	
All	2002-2005	VANEO	414	ECM - Engine control monolith	X	X	X		
All	2002-2005	VANEO	414	ACS - Automatic clutch system	X	X	X	X	
All	2002-2005	VANEO	414	FTC - Front transmission control	X	X	X	X	
All	2002-2005	VANEO	414	ESM - Electronic selector module	X	X	X	X	
All	2002-2005	VANEO	414	CDI - Common Rail	X	X			
All	2002-2005	VANEO	414	ESP - Electronic stability program	X	X	X		
All	2002-2005	VANEO	414	AB - Airbag	X	X	X	X	
All	2002-2005	VANEO	414	ATA - Anti-theft alarm system	X	X	X	X	
All	2002-2005	VANEO	414	DAS - Drive authorization system	X	X	X	X	

All	2002-2005	VANEO	414	ICM - Instrument cluster with maintenance interval display	X	X	X	X	
All	2002-2005	VANEO	414	PTS - Parktronic system	X	X	X	X	
All	2002-2005	VANEO	414	D2B - AUDIO	X	X	X	X	
All	2002-2005	VANEO	414	CDC - CD changer	X	X			
All	2002-2005	VANEO	414	CTEL - Cellular telephone 1(fixed installation or portable)(D2B)	X	X			
All	2002-2005	VANEO	414	CL - Central locking	X	X	X	X	
All	2002-2005	VANEO	414	TAC - Automatic temperature control	X	X			
All	2002-2005	VANEO	414	STH - Stationary heater	X	X	X	X	
All	2006-2009	Sprinter	906	ETC - Electronic transmission control	X	X	X		
All	2006-2009	Sprinter	906	ESM - Electronic selector module	X	X	X	X	
All	2006-2009	Sprinter	906	ME Motor electronics(4 Cylinder ,M271)	X	X	X	X	
All	2006-2009	Sprinter	906	ME Motor electronics(6 Cylinder ,M272)	X	X	X	X	Learning of the throttle valve stop
All	2006-2009	Sprinter	906	CDI 4 Common Rail Diesel Injection(EURO4,EU4)	X	X	X	X	

All	2006-2009	Sprinter	906	CDI 6 Common Rail Diesel Injection (OM642 EURO5)	X	X	X	X	Replace component Y74 (Pressure control valve) Replace component B28/8 (Pressure differential sensor (DPF)) Reset quantity mean value adaptation data Reset values for HFM drift compensation Resetting air filter learned values after air filter replacement Teaching in the diesel particulate filter after replacing the engine control unit Activate fuel pump Rapid teach-in of zero quantity calibration values
All	2006-2009	Sprinter	906	VG Transfer case	X	X	X	X	
All	2006-2009	Sprinter	906	ENR - Electronic level control	X	X			
All	2006-2009	Sprinter	906	ESP - Electronic stability program	X	X	X		
All	2006-2009	Sprinter	906	EIS - Electronic ignition switch	X	X	X		
All	2006-2009	Sprinter	906	KE - Keyless Entry	X	X	X	X	
All	2006-2009	Sprinter	906	HRA - Headlamp range adjustment	X	X	X	X	
All	2006-2009	Sprinter	906	SCM - Steering column module	X	X	X	X	
All	2006-2009	Sprinter	906	UCP - Upper control panel	X	X	X	X	
All	2006-2009	Sprinter	906	SAM - Signal acquisition and actuation module	X	X	X	X	
All	2006-2009	Sprinter	906	SRS - Supplemental restraint system	X	X	X		Reset ECU
All	2006-2009	Sprinter	906	CDC - CD changer	X	X	X		
All	2006-2009	Sprinter	906	KI - Instrument cluster	X	X	X	X	Reset of maintenance interval display (Oil change)
All	2006-2009	Sprinter	906	NAVI - Navigation system	X	X	X		
All	2006-2009	Sprinter	906	PTS - Parktronic system	X	X	X		
All	2006-2009	Sprinter	906	RADIO Sound5	X	X	X	X	

All	2006-2009	Sprinter	906	TEL Telephone control unit	X	X	X	X	
All	2006-2009	Sprinter	906	TSG Door control module	X	X	X	X	
All	2006-2009	Sprinter	906	AAC - Automatic air conditioning/automatic temperature control/Heating-ventilation	X	X			
All	2000-2006	Sprinter	901.6,902.6,903.6,904.6,905.6	CR - Common rail	X	X	X		
All	2000-2006	Sprinter	901.6,902.6,903.6,904.6,905.6	ME - Fuel injection and ignition system	X	X	X		
All	2000-2006	Sprinter	901.6,902.6,903.6,904.6,905.6	KI - Instrument cluster	X	X	X	X	
All	2000-2006	Sprinter	901.6,902.6,903.6,904.6,905.6	WSP - Immobilizer	X	X	X		
All	2000-2006	Sprinter	901.6,902.6,903.6,904.6,905.6	AB - Airbag	X	X	X		
All	2000-2006	Sprinter	901.6,902.6,903.6,904.6,905.6	ABS - Anti-lock brake system	X	X	X		
All	2000-2006	Sprinter	901.6,902.6,903.6,904.6,905.6	ESP - Electronic Stability Program	X	X	X	X	
All	2000-2006	Sprinter	901.6,902.6,903.6,904.6,905.6	HZR heating control	X	X			
All	2000-2006	Sprinter	901.6,902.6,903.6,904.6,905.6	SSG Sprintshift transmission	X	X	X	X	
All	2000-2006	Sprinter	901.6,902.6,903.6,904.6,905.6	Radio	X	X	X	X	
All	2000-2006	Sprinter	901.0/3/4,902.0/3/4,903.0/3/4,904.0/3/4	ME - Fuel injection and ignition system	X	X	X		
All	2000-2006	Sprinter	901.0/3/4,902.0/3/4,903.0/3/4,904.0/3/4	V6 - 6-cylinder gasoline engine	X	X	X		
All	2000-2006	Sprinter	901.0/3/4,902.0/3/4,903.0/3/4,904.0/3/4	CDI - Common rail diesel injection	X	X	X		
All	2000-2006	Sprinter	901.0/3/4,902.0/3/4,903.0/3/4,904.0/3/4	KI - Instrument cluster	X	X	X	X	
All	2000-2006	Sprinter	901.0/3/4,902.0/3/4,903.0/3/4,904.0/3/4	ABS - Anti-lock brake system	X	X	X		
All	2000-2006	Sprinter	901.0/3/4,902.0/3/4,903.0/3/4,904.0/3/4	WSP - Immobilizer	X	X	X		
All	2000-2006	Sprinter	901.0/3/4,902.0/3/4,903.0/3/4,904.0/3/4	AB - Airbag	X	X	X	X	

All	2000-2006	Sprinter	901.0/3/4,902.0/3/4,903.0/3/4,904.0/3/4	AG - Automatic transmission for V6 engines	X	X	X		
All	2000-2006	Sprinter	901.0/3/4,902.0/3/4,903.0/3/4,904.0/3/4	AGN - Automatic transmission	X	X	X		
All	2000-2006	Sprinter	901.0/3/4,902.0/3/4,903.0/3/4,904.0/3/4	KR - Combination relay	X	X	X		
All	2000-2006	Sprinter	901.0/3/4,902.0/3/4,903.0/3/4,904.0/3/4	HZR - Heating control	X	X			
All	2000-2006	Sprinter	901.0/3/4,902.0/3/4,903.0/3/4,904.0/3/4	ATA - Anti-theft alarm system	X	X	X	X	
All	2000-2006	Sprinter	901.0/3/4,902.0/3/4,903.0/3/4,904.0/3/4	ENR - Electronic level control	X	X			
All	2000-2006	Sprinter	901.0/3/4,902.0/3/4,903.0/3/4,904.0/3/4	ERE - Electronic inline	X	X	X	X	
All	2000-2006	Sprinter	901.0/3/4,902.0/3/4,903.0/3/4,904.0/3/4	APS - Auto pilot system	X	X			
All	2000-2006	Sprinter	690.6	CR - Common rail	X	X	X		
All	2000-2006	Sprinter	690.6	ME - Fuel injection and ignition system	X	X	X		
All	2000-2006	Sprinter	690.6	KI - Instrument cluster	X	X	X	X	
All	2000-2006	Sprinter	690.6	WSP - Immobilizer	X	X	X		
All	2000-2006	Sprinter	690.6	AB - Airbag	X	X	X		
All	2000-2006	Sprinter	690.6	ABS - Anti-lock brake system	X	X	X	X	
All	2000-2006	Sprinter	690.6	ESP - Electronic Stability Program	X	X	X	X	
All	2000-2006	Sprinter	690.6	HZR heating control	X	X			
All	2000-2006	Sprinter	690.6	SSG Sprintshift transmission	X	X			
All	2000-2006	Sprinter	690.6	Radio	X	X	X	X	
All	2009-2011	E-Class	212	CGW [ZGW] - Central gateway (CGW [ZGW])	X	X	X		
All	2009-2011	E-Class	212	CDI - Motor electronics 'CDI6' for combustion engine 'OM642' (N3/9)	X	X	X	X	Replace component Y74 (Pressure control valve) Replace component B28/8 (Pressure differential sensor (DPF)) Reset quantity mean value adaptation data Reset values for HFM drift compensation Resetting air filter learned values after air filter replacement Teaching in the diesel particulate filter after replacing the engine control unit Activate fuel pump Rapid teach-in of zero quantity calibration values

All	2009-2011	E-Class	212	CDI - Motor electronics 'CDI60LS' for combustion engine 'OM642' (N3/9)	X	X	X	X	Replace component Y74 (Pressure control valve) Replace component B28/8 (Pressure differential sensor (DPF)) Reset quantity mean value adaptation data Reset values for HFM drift compensation Resetting air filter learned values after air filter replacement Teaching in the diesel particulate filter after replacing the engine control unit Activate fuel pump Rapid teach-in of zero quantity calibration values
All	2009-2011	E-Class	212	CDI - Motor electronics 'CDID2' for combustion engine 'OM651' (N3/9)	X	X	X	X	
All	2009-2011	E-Class	212	VGSNAG2 (722.9) - Fully integrated transmission control unit (Y3/8n4)	X	X	X	X	
All	2009-2011	E-Class	212	EGS53 - Electronic transmission control (N15/3)	X	X	X	X	
All	2009-2011	E-Class	212	ME - Motor electronic 'SIM271KECNG' for combustion engine 'M271CNG'	X	X	X	X	
All	2009-2011	E-Class	212	ME - Motor electronics 'ME97 AMG' for combustion engine 'M156' (N3/10)	X	X	X	X	Learning of the throttle valve stop
All	2009-2011	E-Class	212	ME - Motor electronics 'ME97' for combustion engine 'M272' (N3/10)	X	X	X	X	Learning of the throttle valve stop
All	2009-2011	E-Class	212	ME - Motor electronics 'ME97' for combustion engine 'M273' (N3/10)	X	X	X	X	Learning of the throttle valve stop
All	2009-2011	E-Class	212	ME - Motor electronics 'MED97' for combustion engine 'M272' (N3/10)	X	X	X	X	Learning of the throttle valve stop
All	2009-2011	E-Class	212	EZS - Electronic ignition lock (N73)	X	X	X		
All	2009-2011	E-Class	212	AAC - Air conditioning (N22/7)	X	X	X		
All	2009-2011	E-Class	212	IC- Instrument cluster (A1)	X	X	X	X	Transfer of manufacturer default setting Reinitialization of ASSYST data
All	2009-2011	E-Class	212	SRS - Supplemental restraint system (N2/10)	X	X	X		
All	2009-2011	E-Class	212	DCU-LF - Left front door (N69/1)LIN: SSE-LF-Switch group 'Left front seat adjustment'(S22)	X	X	X	X	
All	2009-2011	E-Class	212	DCU-RF - Right front door (N69/2)LIN: SSE-LF-Switch group 'Right front seat adjustment'(S23)	X	X	X	X	
All	2009-2011	E-Class	212	DCU-LR - Left rear door (N69/3)	X	X	X	X	
All	2009-2011	E-Class	212	DCU-RR - Right rear door (N69/4)	X	X	X	X	
All	2009-2011	E-Class	212	ZBE - Audio/CQMAND operating unit (A40/9)	X	X	X	X	
All	2009-2011	E-Class	212	ZAN - Audio/COMAND display (A40/8)	X	X	X	X	

All	2009-2011	E-Class	212	TV - TV tuner (A90/1)	X	X	X	X	
All	2009-2011	E-Class	212	UMI - Navigation 20 (N125/2)	X	X	X		
All	2009-2011	E-Class	212	ME - Motor electronics 'MED 177' for combustion engine 'M276' (N3/10)	X	X	X	X	
All	2009-2011	E-Class	212	ME - Motor electronics 'MED177' for combustion engine 'M157' (N3/10)	X	X	X	X	
All	2009-2011	E-Class	212	ME - Motor electronics 'MED177' for combustion engine 'M276' (N3/10)	X	X	X	X	
All	2009-2011	E-Class	212	ME - Motor electronics 'MED177' for combustion engine 'M278' (N3/10)	X	X	X	X	
All	2009-2011	E-Class	212	ME - Motor electronic 'SIM271DE20' for combustion engine 'M271EVO' (N3/10)	X	X	X	X	
All	2009-2011	E-Class	212	FSCU - Control unit Fuel pump (N 118)	X	X	X	X	Display of coding data. Read coding and change if necessary.
All	2009-2011	E-Class	212	FSCU_EC - Control unit Fuel pump (N118)	*	*	*	*	
All	2009-2011	E-Class	212	RFK - Backup camera(N66/2)	*	*	*		
All	2009-2011	E-Class	212	SDAR - Satellite digital audio radio (N87/5)	*	*	*		
All	2009-2011	E-Class	212	Driver-side SAM - Front signal acquisition and actuation module (N10/1)	*	*	*	*	
All	2009-2011	E-Class	212	SRS - Supplemental restraint system (N2/10)	*	*	*		
All	2009-2011	E-Class	207	CGW [ZGW] - Central gateway (CGW [ZGW])	X	X	X	X	
All	2009-2011	E-Class	207	ME - Motor electronic 'SIM271DE20' for combustion engine 'M271EVO' (N3/10)	X	X	X	X	
All	2009-2011	E-Class	207	FSCU - Control unit Fuel pump (N 118)	X	X	X	X	Display of coding data. Read coding and change if necessary.
All	2009-2011	E-Class	207	EZS - Electronic ignition lock(N73)	X	X	X	X	Initial startup:EZS Initial startup:ESL[ELV]. Disabling of key or key track with workshop key. Disabling of key or key track. Re-enabling of key or key track. Writing of vehicle identification number. Teach in of a spare key. Activation of control unit 'N73(Electronic ignition lock control unit)'
All	2009-2011	E-Class	207	DCU-LF - Left front door (N69/1)LIN: SSE-LF-Switch group 'Left front seat adjustment'(S22)	X	X	X		
All	2009-2011	E-Class	207	DCU-RF - Right front door (N69/2)LIN: SSE-LF-Switch group 'Right front seat adjustment'(S23)	X	X	X		
All	2009-2011	E-Class	207	AAC - Air conditioning (N22/7)	X	X	X		
All	2009-2011	E-Class	207	IC- Instrument cluster (A1)	X	X	X	X	General servicing

All	2009-2011	E-Class	207	SRS - Supplemental restraint system (N2/10)	X	X	X	X	
All	2009-2011	E-Class	207	ZBE - Audio/CQMAND operating unit (A40/9)	X	X	X	X	
All	2009-2011	E-Class	207	ZAN - Audio/COMAND display (A40/8)	X	X	X	X	
All	2009-2011	E-Class	207	TV - TV tuner(A90/1)	X	X			
All	2009-2011	E-Class	207	FSCU_EC - Control unit Fuel pump (N118)	*	*	*	*	
All	2009-2011	E-Class	207	RFK - Backup camera(N66/2)	*	*	*		
All	2009-2011	E-Class	207	SDAR - Satellite digital audio radio (N87/5)	*	*	*		
All	2009-2011	E-Class	207	Driver-side SAM - Front signal acquisition and actuation module (N10/1)	*	*	*	*	
All	2009-2011	SLK	172	CGW [ZGW] - Central gateway (CGW [ZGW])	X	X	X		
All	2009-2011	SLK	172	CDI - Motor electronics 'CDID3' for combustion engine 'OM651' (N3/9)	X	X	X	X	
All	2009-2011	SLK	172	FSCU - Control unit Fuel pump (N 118)	X	X	X	X	Display of coding data. Read coding and change if necessary.
All	2009-2011	SLK	172	VGSNAG2 (722.9) - Fully integrated transmission control unit (Y3/8n4)	X	X	X	X	
All	2009-2011	SLK	172	EZS - Electronic ignition lock(N73)	X	X	X	X	Initial startup:EZS Initial startup:ESL[ELV]. Disabling of key or key track with workshop key. Disabling of key or key track. Re-enabling of key or key track. Writing of vehicle identification number. Teach in of a spare key. Activation of control unit 'N73(Electronic ignition lock control unit)'
All	2009-2011	SLK	172	DCU-LF - Left front door (N69/1)LIN: SSE-LF-Switch group 'Left front seat adjustment'(S22)	X	X	X		
All	2009-2011	SLK	172	DCU-RF - Right front door (N69/2)LIN: SSE-LF-Switch group 'Right front seat adjustment'(S23)	X	X	X		
All	2009-2011	SLK	172	IC- Instrument cluster (A1)	X	X	X	X	General servicing
All	2009-2011	SLK	172	ZBE - Audio/CQMAND operating unit (A40/9)	X	X	X	X	
All	2009-2011	SLK	172	ZAN - Audio/COMAND display (A40/8)	X	X	X	X	
All	2009-2011	SLK	172	ME - Motor electronics 'MED177' for combustion engine 'M276' (N3/10)	X	X	X	X	
All	2009-2011	SLK	172	ME - Motor electronic 'SIM271DE20' for combustion engine 'M271EVO' (N3/10)	X	X	X	X	
All	2009-2011	SLK	172	FSCU_EC - Control unit Fuel pump (N 118)	X	X	X	X	Display of coding data. Read coding and change if necessary.

All	2009-2011	SLK	172	EGS53 - Electronic transmission control (N15/3)	X	X	X	X	
All	2009-2011	SLK	172	SDAR - Satellite digital audio radio (N87/5)	*	*	*		
All	2009-2011	CLS	218	CGW [ZGW] - Central gateway (CGW [ZGW])	X	X	X		
All	2009-2011	CLS	218	ESP - Electronic stability program	X	X		X	
All	2009-2011	CLS	218	FSCU - Control unit Fuel pump (N 118)	X	X	X	X	Display of coding data. Read coding and change if necessary.
All	2009-2011	CLS	218	VGSNAG2 (722.9) - Fully integrated transmission control unit (Y3/8n4)	X	X	X	X	
All	2009-2011	CLS	218	EZS - Electronic ignition lock(N73)	X	X	X	X	Initial startup:EZS Initial startup:ESL[ELV]. Disabling of key or key track with workshop key. Disabling of key or key track. Re-enabling of key or key track. Writing of vehicle identification number. Teach in of a spare key. Activation of control unit 'N73(Electronic ignition lock control unit)'
All	2009-2011	CLS	218	DCU-LF - Left front door (N69/1)LIN: SSE-LF-Switch group 'Left front seat adjustment'(S22)	X	X	X		
All	2009-2011	CLS	218	DCU-RF - Right front door (N69/2)LIN: SSE-LF-Switch group 'Right front seat adjustment'(S23)	X	X	X		
All	2009-2011	CLS	218	DCU-LR - Left rear door (N69/3)	X	X	X	X	
All	2009-2011	CLS	218	DCU-RR - Right rear door (N69/4)	X	X	X	X	
All	2009-2011	CLS	218	AAC - Air conditioning (N22/7)	X	X	X		
All	2009-2011	CLS	218	IC- Instrument cluster (A1)	X	X	X	X	General servicing
All	2009-2011	CLS	218	SRS - Supplemental restraint system (N2/10)	X	X	X	X	
All	2009-2011	CLS	218	ZBE - Audio/CQMAND operating unit (A40/9)	X	X	X	X	
All	2009-2011	CLS	218	ZAN - Audio/COMAND display (A40/8)	X	X	X	X	
All	2009-2011	CLS	218	TV - TV tuner(A90/1)	X	X			

All	2009-2011	CLS	218	CDI - Motor electronics 'CDI60LS' for combustion engine 'OM642' (N3/9)	X	X	X	X	Replace component Y74 (Pressure control valve) Replace component B28/8 (Pressure differential sensor (DPF)) Reset quantity mean value adaptation data Reset values for HFM drift compensation Resetting air filter learned values after air filter replacement Teaching in the diesel particulate filter after replacing the engine control unit Activate fuel pump Rapid teach-in of zero quantity calibration values
All	2009-2011	CLS	218	FSCU_EC - Control unit Fuel pump (N 118)	X	X	X	X	Display of coding data. Read coding and change if necessary.
All	2009-2011	CLS	218	ME - Motor electronics 'MED177' for combustion engine 'M276' (N3/10)	X	X	X	X	
All	2009-2011	CLS	218	ME - Motor electronics 'MED177' for combustion engine 'M278' (N3/10)	X	X	X	X	
All	2009-2011	CLS	218	ME - Motor electronics 'MED177' for combustion engine 'M157' (N3/10)	X	X	X	X	
All	2009-2011	CLS	218	RFK - Backup camera(N66/2)	*	*	*		
All	2009-2011	CLS	218	SDAR - Satellite digital audio radio (N87/5)	*	*	*		
All	2009-2011	SLS	197	CGW [ZGW] - Central gateway (CGW [ZGW])	X	X	X		
All	2009-2011	SLS	197	ME - Motor electronics 'ME97 AMG' for combustion engine 'M159' (N3/10)	X	X	X	X	Learning of the throttle valve stop
All	2009-2011	SLS	197	IC- Instrument cluster (A1)	X	X	X	X	General servicing
All	2009-2011	SLS	197	SRS - Supplemental restraint system (N2/10)	X	X	X	X	
All	2009-2011	SLS	197	EZS - Electronic ignition lock(N73)	X	X	X	X	Initial startup:EZS Initial startup:ESL[ELV]. Disabling of key or key track with workshop key. Disabling of key or key track. Re-enabling of key or key track. Writing of vehicle identification number. Teach in of a spare key. Activation of control unit 'N73(Electronic ignition lock control unit)'
All	2009-2011	SLS	197	DCU-LF - Left front door (N69/1)LIN: SSE-LF-Switch group 'Left front seat adjustment'(S22)	X	X	X		
All	2009-2011	SLS	197	DCU-RF - Right front door (N69/2)LIN: SSE-LF-Switch group 'Right front seat adjustment'(S23)	X	X	X		

All	2009-2011	SLS	197	ZBE - Audio/CQMAND operating unit (A40/9)	X	X	X	X	
All	2009-2011	SLS	197	ZAN - Audio/COMAND display (A40/8)	X	X	X	X	
All	2009-2011	SLS	197	SDAR - Satellite digital audio radio (N87/5)	*	*	*		