

Note X: Covered *: New update

Peugeot V10.0								
Model Information				Diagnostic Function				
Market	Model	Class	System	ECU Info.	DTC	Data List	Active Test	Special Func.
All	1007 VAN	KFU MM6LP I	Petrol Engine	X	X	X	X	Initialising the autoadaptives
All	1007 VAN	KFU MM6LP II	Petrol Engine	X	X	X	X	Initialising the autoadaptives
All	1007 VAN	N6A BOSCH ME7.4.5	Petrol Engine	X	X	X	X	Initialising the autoadaptives
All	1007 VAN	N6B BOSCH ME7.4.5	Petrol Engine	X	X	X	X	Initialising the autoadaptives
All	1007 VAN	NFU BOSCH ME7.4.5	Petrol Engine	X	X	X	X	Initialising the autoadaptives
All	1007 VAN	NFU ME7.4.4	Petrol Engine	X	X	X	X	
All	1007 VAN	KFV S2000PM2	Petrol Engine	X	X	X		
All	1007 VAN	KFV J34P	Petrol Engine	X	X	X	X	
All	1007 VAN	8HX SIEMENS SID 804	Diesel Engine	X	X	X		
All	1007 VAN	8HZ SIEMENS SID 804	Diesel Engine	X	X	X		
All	1007 VAN		ABS	X	X	X	X	Bleeding
All	1007 VAN	Controlled manual gearbox(BVMP)	Auto gearbox	X	X		X	
All	1007 VAN		Alarm ALARME	X	X	X	X	
All	1007 VAN		Radio RD3	X	X	X	X	
All	1007 VAN		Built-in system interface(BSI)	X	X	X		
All	1007 VAN		Instrument panel	X	X	X		
All	1007 VAN		Steering wheel switching module	X	X	X		
All	1007 VAN		Airbags	X	X	X		
All	1007 VAN		Air Conditioning	X	X	X		
All	1007 VAN	Multi-function display EMF	Display/Telematics	X	X	X	X	
All	1007 VAN		Parking assistance	X	X	X		
All	1007 VAN		CD player	X	X	X		
All	1007 VAN		Rain/brightness sensor	X	X			
All	1007 VAN		Sliding side doors module	X	X	X		
All	106R	CDY BOSCH MA3.1	Petrol Engine	X	X	X	X	
All	106R	CDZ BOSCH MA3.1	Petrol Engine	X	X	X	X	
All	106R	HDY BOSCH MA3.1	Petrol Engine	X	X	X	X	
All	106R	HDZ BOSCH MA3.1	Petrol Engine	X	X	X	X	
All	106R	HFX BOSCH M7.4.4	Petrol Engine	X	X	X	X	
All	106R	KFX BOSCH MP7.3	Petrol Engine	X	X	X		
All	106R	KFX MM1AP	Petrol Engine	X	X	X	X	
All	106R	NFX MM1AP	Petrol Engine	X	X	X	X	
All	106R	KFW SAGEM S2000	Petrol Engine	X	X	X	X	Initialising the autoadaptives
All	206	NFU BOSCH ME7.4.4	Petrol Engine	X	X	X	X	Initialising the autoadaptives
All	206	RFR MM4.8P	Petrol Engine	X	X	X	X	Initialising the autoadaptives

All	206	N6A BOSCH ME7.4.4	Petrol Engine	X	*	X	X	Initialising the autoadaptives
All	206	RFN MM4.8P	Petrol Engine	X	X	X	X	Initialising the autoadaptives
All	206	KFX BOSCH MP7.3	Petrol Engine	X	X	X		
All	206	KFX MM1AP	Petrol Engine	X	X	X	X	
All	206	KFU MM6LP	Petrol Engine	X	X	X	X	
All	206	RFN MM6LP	Petrol Engine	X	X	X	X	
All	206	HFY MM1AP	Petrol Engine	X	X	X	X	
All	206	HFZ MM1AP	Petrol Engine	X	X	X	X	
All	206	RFK MM6LP	Petrol Engine	X	X	X	X	
All	206	N6A BOSCH ME7.4.5	Petrol Engine	X	X	X	X	Initialising the autoadaptives
All	206	NFU BOSCH ME7.4.5	Petrol Engine	X	X	X	X	Initialising the autoadaptives
All	206	KFW SAGEM S2000	Petrol Engine	X	X	X	X	Initialising the autoadaptives
All	206	K6D SAGEM S2000	Petrol Engine	X	X	X	X	Initialising the autoadaptives
All	206	KFW BOSCH ME7.4.4	Petrol Engine	X	X	X	X	Initialising the autoadaptives
All	206	7LZ MM5NP	Petrol Engine	X	X	X	X	Initialising the autoadaptives
All	206	N6A BOSCH ME7.4.4 FLEX FUEL	Petrol Engine	X	X	X	X	
All	206	NFU BOSCH ME7.4.4 FLEX FUEL	Petrol Engine	X	X	X	X	Initialising the autoadaptives
All	206	KFW BOSCH ME7.4.4 FLEX FUEL	Petrol Engine	X	X	X	X	Initialising the autoadaptives
All	206	KFW J34P	Petrol Engine	X	X	X	X	Initialising the autoadaptives
All	206	K6D J34P	Petrol Engine	X	X	X	X	
All	206	NFU or N6A or N6B ME7.4.9 FLEX FUEL	Petrol Engine	X	X	X	X	
All	206	NFU J35	Petrol Engine	X	X	X	X	Initialising the autoadaptives
All	206	K6C MM1AP	Petrol Engine	X	X	X	X	
All	206	HFX MM4.8P	Petrol Engine	X	X	X	X	Initialising the autoadaptives
All	206	WJY LUCAS DCN2	Diesel Engine	X	X	X		
All	206	WJZ LUCAS DCN2	Diesel Engine	X	X	X		
All	206	RHY BOSCH EDC15C2	Diesel Engine	X	X	X	X	Particle filter regeneration
All	206	9HZ BOSCH EDC16C3	Diesel Engine	X	X	X	X	Particle filter regeneration
All	206	8HX/8HZ BOSCH EDC16C3 EURO3	Diesel Engine	X	X	X	X	
All	206	8HZ BOSCH EDC16C3 EURO4	Diesel Engine	X	X	X	X	
All	206	9HY BOSCH EDC16C3 EURO4	Diesel Engine	X	X	X	X	
All	206	ABS BOSCH 5.3	ABS	X	X	X	X	Bleeding
All	206	ABS MK70	ABS	X	X	X	X	Bleeding
All	206	ABS TEVES	ABS	X	X	X	X	
All	206	ESP MK60	ABS	X	X	X		Bleeding
All	206	Auto Gearbox AL4	AT	X	X	X	X	Initialising the autoadaptives
All	206	Auto Gearbox AL4 AT8	AT	X	X	X	X	Initialising the autoadaptives
All	206	BVA AL4	AT	X	X	X	X	Initialising the autoadaptives
All	206	Airbag and seatbelts	Airbag	X	X			
All	206	Left side airbag	Airbag	X	X			
All	206	Right side airbag	Airbag	X	X			
All	206	SAC-CENT-AUTOLIV-2	Airbag	X	X			

All	206	BSI	Built-In System	X	X	X	X	1.Forcing of the customer mode 2.Resetting to zero of the service mileage 3.Configuration
All	206	BIS_SIEMENS	Built-In System	X	X	X	X	
All	206	AMF	Multi-function display	X	X	X	X	
All	206	AUTORADIO	Radio	X	X	X	X	
All	206	COMBINE_MM	Instrument panel	X	X	X	X	
All	206	COM2000	Steering wheel switching module	X	X	X		
All	206	ALARME_TEXTON	Alarm	X	X			
All	206		On-board navigation system	X	X	X	X	
All	206	CLIM_T12001	Air Conditioning	X	X	X	X	
All	206		Driving school	X		X	X	
All	206	CPT_PLUIE_LUM	Rain/brightness sensor	X	X			
All	206		Diesel fuel additive control unit	X	X	X	X	
All	206	TOUV_TEXTON	Sun roof	X	X	X	X	
All	206 MUX	NFU BOSCH ME7.4.4	Petrol Engine	X	X	X	X	Initialising the autoadaptives
All	206 MUX	RFR MM4.8P	Petrol Engine	X	X	X	X	Initialising the autoadaptives
All	206 MUX	N6A BOSCH ME7.4.4	Petrol Engine	X	X	X	X	Initialising the autoadaptives
All	206 MUX	RFN MM4.8P	Petrol Engine	X	X	X	X	Initialising the autoadaptives
All	206 MUX	KFX BOSCH MP7.3	Petrol Engine	X	X	X		
All	206 MUX	KFX MM1AP	Petrol Engine	X	X	X	X	
All	206 MUX	KFU MM6LP	Petrol Engine	X	X	X	X	
All	206 MUX	RFN MM6LP	Petrol Engine	X	X	X	X	
All	206 MUX	HFY MM1AP	Petrol Engine	X	X	X	X	
All	206 MUX	HFZ MM1AP	Petrol Engine	X	X	X	X	
All	206 MUX	RFK MM6LP	Petrol Engine	X	X	X	X	
All	206 MUX	N6A BOSCH ME7.4.5	Petrol Engine	X	X	X	X	Initialising the autoadaptives
All	206 MUX	NFU BOSCH ME7.4.5	Petrol Engine	X	X	X	X	Initialising the autoadaptives
All	206 MUX	KFW SAGEM S2000	Petrol Engine	X	X	X	X	Initialising the autoadaptives
All	206 MUX	K6D SAGEM S2000	Petrol Engine	X	X	X	X	Initialising the autoadaptives
All	206 MUX	KFW BOSCH ME7.4.4	Petrol Engine	X	X	X	X	Initialising the autoadaptives
All	206 MUX	7LZ MM5NP	Petrol Engine	X	X	X	X	
All	206 MUX	N6A BOSCH ME7.4.4 FLEX FUEL	Petrol Engine	X	X	X	X	Initialising the autoadaptives
All	206 MUX	NFU BOSCH ME7.4.4 FLEX FUEL	Petrol Engine	X	X	X	X	Initialising the autoadaptives
All	206 MUX	KFW BOSCH ME7.4.4 FLEX FUEL	Petrol Engine	X	X	X	X	Initialising the autoadaptives
All	206 MUX	KFW J34P	Petrol Engine	X	X	X	X	
All	206 MUX	K6D J34P	Petrol Engine	X	X	X	X	
All	206 MUX	NFU or N6A or N6B ME7.4.9 FLEX FUEL	Petrol Engine	X	X	X	X	Initialising the autoadaptives
All	206 MUX	NFU J35	Petrol Engine	X	X	X	X	
All	206 MUX	K6C MM1AP	Petrol Engine	X	X	X	X	
All	206 MUX	HFX MM4.8P	Petrol Engine	X	X	X	X	Initialising the autoadaptives
All	206 MUX	WJY LUCAS DCN2	Diesel Engine	X	X	X		
All	206 MUX	WJZ LUCAS DCN2	Diesel Engine	X	X	X		

All	206 MUX	RHY BOSCH EDC15C2	Diesel Engine	X	X	X	X	Particle filter regeneration
All	206 MUX	9HZ BOSCH EDC16C3	Diesel Engine	X	X	X	X	Particle filter regeneration
All	206 MUX	8HX/8HZ BOSCH EDC16C3 EURO3	Diesel Engine	X	X	X	X	
All	206 MUX	8HZ BOSCH EDC16C3 EURO4	Diesel Engine	X	X	X	X	
All	206 MUX	9HY BOSCH EDC16C3 EURO4	Diesel Engine	X	X	X	X	
All	206 MUX	ABS BOSCH 5.3	ABS	X	X	X	X	Bleeding
All	206 MUX	ABS MK70	ABS	X	X	X	X	Bleeding
All	206 MUX	ABS TEVES	ABS	X	X	X		
All	206 MUX	ESP MK60	ABS	X	X	X	X	Bleeding
All	206 MUX	TEVES_MK20E	ABS	X	X	X	X	Bleeding
All	206 MUX	Auto Gearbox AL4	AT	X	X	X	X	Initialising the autoadaptives
All	206 MUX	Auto Gearbox AL4 AT8	AT	X	X	X	X	Initialising the autoadaptives
All	206 MUX	BVA AL4	AT	X	X	X	X	Initialising the autoadaptives
All	206 MUX	Airbag and seatbelts	Airbag	X	X			
All	206 MUX	Left side airbag	Airbag	X	X			
All	206 MUX	Right side airbag	Airbag	X	X			
All	206 MUX	SAC-CENT-AUTOLIV-2	Airbag	X	X			
All	206 MUX	BSI	Built-In System	X	X	X	X	1.Forcing of the customer mode 2.Resetting to zero of the service mileage 3.Configuration
All	206 MUX	BIS_SIEMENS	Built-In System	X	X	X	X	
All	206 MUX	AMF	Multi-function display	X	X	X	X	
All	206 MUX	AUTORADIO	Radio	X	X	X	X	
All	206 MUX	COMBINE_MM	Instrument panel	X	X	X	X	
All	206 MUX	COM2000	Steering wheel switching module	X	X	X		
All	206 MUX	ALARME_TEXTON	Alarm	X	X			
All	206 MUX		On-board navigation system	X	X	X		
All	206 MUX	CLIM_T12001	Air Conditioning	X	X	X	X	
All	206 MUX		Driving school	X		X	X	
All	206 MUX	CPT_PLUIE_LUM	Rain/brightness sensor	X	X			
All	206 MUX		Diesel fuel additive control unit	X	X	X	X	
All	206 MUX	TOUV_TEXTON	Sun roof	X	X	X	X	
All	207 VAN	NFU BOSCH ME7.4.4	Petrol Engine	X	X	X	X	Initialising the autoadaptives
All	207 VAN	RFR MM4.8P	Petrol Engine	X	X	X	X	Initialising the autoadaptives
All	207 VAN	N6A BOSCH ME7.4.4	Petrol Engine	X	X	X	X	Initialising the autoadaptives
All	207 VAN	RFN MM4.8P	Petrol Engine	X	X	X	X	Initialising the autoadaptives
All	207 VAN	KFX BOSCH MP7.3	Petrol Engine	X	X	X		
All	207 VAN	KFX MM1AP	Petrol Engine	X	X	X	X	
All	207 VAN	KFU MM6LP	Petrol Engine	X	X	X	X	
All	207 VAN	RFN MM6LP	Petrol Engine	X	X	X	X	
All	207 VAN	HFY MM1AP	Petrol Engine	X	X	X	X	
All	207 VAN	HFZ MM1AP	Petrol Engine	X	X	X	X	
All	207 VAN	RFK MM6LP	Petrol Engine	X	X	X	X	
All	207 VAN	N6A BOSCH ME7.4.5	Petrol Engine	X	X	X	X	Initialising the autoadaptives

All	207 VAN	NFU BOSCH ME7.4.5	Petrol Engine	X	X	X	X	Initialising the autoadaptives
All	207 VAN	KFW SAGEM S2000	Petrol Engine	X	X	X	X	Initialising the autoadaptives
All	207 VAN	K6D SAGEM S2000	Petrol Engine	X	X	X	X	Initialising the autoadaptives
All	207 VAN	KFW BOSCH ME7.4.4	Petrol Engine	X	X	X	X	Initialising the autoadaptives
All	207 VAN	7LZ MM5NP	Petrol Engine	X	X	X	X	Initialising the autoadaptives
All	207 VAN	N6A BOSCH ME7.4.4 FLEX FUEL	Petrol Engine	X	X	X	X	
All	207 VAN	NFU BOSCH ME7.4.4 FLEX FUEL	Petrol Engine	X	X	X	X	Initialising the autoadaptives
All	207 VAN	KFW BOSCH ME7.4.4 FLEX FUEL	Petrol Engine	X	X	X	X	Initialising the autoadaptives
All	207 VAN	KFW J34P	Petrol Engine	X	X	X	X	Initialising the autoadaptives
All	207 VAN	K6D J34P	Petrol Engine	X	X	X	X	
All	207 VAN	NFU or N6A or N6B ME7.4.9 FLEX FUEL	Petrol Engine	X	X	X	X	
All	207 VAN	NFU J35	Petrol Engine	X	X	X	X	Initialising the autoadaptives
All	207 VAN	K6C MM1AP	Petrol Engine	X	X	X	X	
All	207 VAN	HFX MM4.8P	Petrol Engine	X	X	X	X	Initialising the autoadaptives
All	207 VAN	WJY LUCAS DCN2	Diesel Engine	X	X	X		
All	207 VAN	WJZ LUCAS DCN2	Diesel Engine	X	X	X		
All	207 VAN	RHY BOSCH EDC15C2	Diesel Engine	X	X	X	X	Particle filter regeneration
All	207 VAN	9HZ BOSCH EDC16C3	Diesel Engine	X	X	X	X	Particle filter regeneration
All	207 VAN	8HX/8HZ BOSCH EDC16C3 EURO3	Diesel Engine	X	X	X	X	
All	207 VAN	8HZ BOSCH EDC16C3 EURO4	Diesel Engine	X	X	X	X	
All	207 VAN	9HY BOSCH EDC16C3 EURO4	Diesel Engine	X	X	X	X	
All	207 VAN	ABS BOSCH 5.3	ABS	X	X	X	X	Bleeding
All	207 VAN	ABS MK70	ABS	X	X	X	X	Bleeding
All	207 VAN	ABS TEVES	ABS	X	X	X	X	
All	207 VAN	ESP MK60	ABS	X	X	X		Bleeding
All	207 VAN	Auto Gearbox AL4	AT	X	X	X	X	Initialising the autoadaptives
All	207 VAN	Auto Gearbox AL4 AT8	AT	X	X	X	X	Initialising the autoadaptives
All	207 VAN	BVA AL4	AT	X	X	X	X	Initialising the autoadaptives
All	207 VAN	Airbag and seatbelts	Airbag	X	X			
All	207 VAN	Left side airbag	Airbag	X	X			
All	207 VAN	Right side airbag	Airbag	X	X			
All	207 VAN	SAC-CENT-AUTOLIV-2	Airbag	X	X			
All	207 VAN	BSI	Built-In System	X	X	X	X	*1.Programming of the build-in systems interface (Engine Immobilizer code and keys)
All	207 VAN	BIS_SIEMENS	Built-In System	X	X	X	X	
All	207 VAN	AMF	Multi-function display	X	X	X	X	
All	207 VAN	AUTORADIO	Radio	X	X	X	X	
All	207 VAN	COMBINE_MM	Instrument panel	X	X	X	X	
All	207 VAN	COM2000	Steering wheel switching module	X	X	X		
All	207 VAN	ALARME_TEXTON	Alarm	X	X			
All	207 VAN		On-board navigation system	X	X	X	X	
All	207 VAN	CLIM_T12001	Air Conditioning	X	X	X	X	
All	207 VAN		Driving school	X		X	X	

All	207 VAN	CPT_PLUIE_LUM	Rain/brightness sensor	X	X			
All	207 VAN		Diesel fuel additive control unit	X	X	X	X	
All	207 VAN	TOUV_TEXTON	Sun roof	X	X	X	X	
All	207	5FW MEV17.4	Petrol Engine	X	X	X	X	
All	207	8FS MEV17.4	Petrol Engine	X	X	X	X	
All	207	MM6LPB	Petrol Engine	X	X	X	X	
All	207	NFS BOSCH ME7.4.5	Petrol Engine		X	X	X	
All	207	NFU BOSCH ME7.4.5	Petrol Engine		X	X	X	
All	207	MK70.1	ABS	X	X	X	X	
All	207 Diesel	9HX BOSCH EDC 16C3 Common Rail	Engine		X	X	X	1.EGR throttle learning
All	207 Diesel	9HZ BOSCH EDC 16C34 Common Rail	Engine		X	X	X	1.EGR throttle learning
All	207 Diesel	8HZ BOSCH EDC 16C3 Common Rail	Engine		X	X	X	
All	207 Diesel	9HX BOSCH EDC 16C34 (K-LINE)	Engine		X	X	X	1.EGR SV learning 2.EGR throttle learning 3.Initialization turbo limit 4.Particle filter replacement 5.Initializ. FAP filter additive quantity 6.Replace or fill additive tank 7.Replace metering pump 8.Tank filling 9.Particle filter regeneration
All	207 Diesel	9HZ BOSCH EDC 16C34 (K-LINE)	Engine		X	X	X	1.EGR SV learning 2.EGR throttle learning 3.Initialization turbo limit 4.Particle filter replacement 5.Initializ. FAP filter additive quantity 6.Replace or fill additive tank 7.Replace metering pump 8.Tank filling 9.Particle filter regeneration
All	207	A/T AM6	AT		X	X	X	
All	207		ABS		X	X	X	
All	207		Airbag		X	X		
All	207		Steering column module		X	X	X	
All	207		SERVICE LIGHT RESET					1.Service Reset
All	207		Parking brake		X	X		
All	306	HDY BOSCH MA3.1	Petrol Engine	X	X	X	X	
All	306	HDZ BOSCH MA3.1	Petrol Engine	X	X	X	X	
All	306	KFX MM1AP	Petrol Engine	X	X	X	X	
All	306	RFS MM1AP	Petrol Engine	X	X	X	X	
All	306R	KFX BOSCH MP7.3	Petrol Engine	X	X	X		

All	306R	KFX MM1AP	Petrol Engine	X	X	X	X	
All	306R	KFX SAGEM SL96	Petrol Engine	X	X	X		
All	306R	LFY BOSCH MP7.3	Petrol Engine	X	X	X		
All	306R	LFY SAGEM SL96	Petrol Engine	X	X	X		
All	306R	NFT BOSCH M7.4.4	Petrol Engine	X	X	X	X	
All	306R	NFV BOSCH M7.4.4	Petrol Engine	X	X	X	X	
All	306R	RFS MM1AP	Petrol Engine	X	X	X	X	
All	306R	KFW SAGEM S2000	Petrol Engine	X	X	X	X	Initialising the autoadaptives
All	306R	K6D SAGEM S2000	Petrol Engine	X	X	X	X	Initialising the autoadaptives
All	306R	WJY LUCAS DCN2	Diesel Engine	X	X	X		
All	306R	WJZ LUCAS DCN2	Diesel Engine	X	X	X		
All	306R	RHY BOSCH EDC15C2	Diesel Engine	X	X	X	X	
All	306R		ABS	X	X	X	X	Bleeding
All	306R		Auto Gearbox	X	X	X	X	Initialising the autoadaptives
All	306R	Airbag and seatbelts	Airbag	X	X			
All	306R	Left side airbag	Airbag	X	X			
All	306R	Right side airbag	Airbag	X	X			
All	306R	CPH_TEXTON	Built-In System	X	X	X		
All	307 VAN	NFU BOSCH ME7.4.4	Petrol Engine	X	X	X	X	Initialising the autoadaptives
All	307 VAN	N6A BOSCH ME7.4.4	Petrol Engine	X	X	X	X	Initialising the autoadaptives
All	307 VAN	KFU MM6LP	Petrol Engine	X	X	X	X	
All	307 VAN	RFN MM6LP	Petrol Engine	X	X	X	X	
All	307 VAN	RFK MM6LP	Petrol Engine	X	X	X	X	
All	307 VAN	N6A BOSCH ME7.4.5	Petrol Engine	X	X	*	*	*Initialising the autoadaptives
All	307 VAN	NFU BOSCH ME7.4.5	Petrol Engine	X	X	X	X	Initialising the autoadaptives
All	307 VAN	KFW SAGEM S2000	Petrol Engine	X	X	X	X	Initialising the autoadaptives
All	307 VAN	RFN MM48P(Mechanical throttle housing)	Petrol Engine	X	X	X	X	Initialising the autoadaptives
All	307 VAN		Petrol Engine	X	X	X	X	Initialising the autoadaptives
All	307 VAN	K6D SAGEM S2000	Petrol Engine	X	X	X	X	
All	307 VAN	RHZ BOSCH EDC15C2	Diesel Engine	X	X	X	X	
All	307 VAN	RHS BOSCH EDC15C2	Diesel Engine	X	X	X	X	Particle filter regeneration
All	307 VAN	RHY BOSCH EDC15C2	Diesel Engine	X	X	X	X	Particle filter regeneration
All	307 VAN	8HZ BOSCH EDC16C3	Diesel Engine	X	X	X	X	
All	307 VAN	9HX BOSCH EDC16C3	Diesel Engine	X	X	X	X	
All	307 VAN	9HZ BOSCH EDC16C3	Diesel Engine	X	X	X	X	1.Particle filter regeneration(stationary) 2.Particle filter regeneration(moving)
All	307 VAN	RHY SIEMENS SID 801	Diesel Engine	X	X	X	X	
All	307 VAN	9HY BOSCH EDC16C3 EURO4	Diesel Engine	X	X	X	X	
All	307 VAN	RHL SIEMENS SID 803	Diesel Engine	X	X	X	X	1.Particle filter regeneration(stationary) 2.Particle filter regeneration(moving)
All	307 VAN	RHR SIEMENS SID 803	Diesel Engine	X	X	X	X	1.Particle filter regeneration(stationary) 2.Particle filter regeneration(moving)
All	307 VAN	ABS8_BOSCH	ABS	X	X	X	X	Bleeding

AII	307 VAN	ESP BOSCH 8	ABS	X	X	X	X	Bleeding
AII	307 VAN	ESP BOSCH 5.7	ABS	X	X	X	X	Bleeding
AII	307 VAN	TEVES_MK60_ABS	ABS	X	X	X		
AII	307 VAN	ABS BOSCH 5.3	ABS	X	X	X	X	Bleeding
AII	307 VAN	ABS BOSCH 8 (K-Line)	ABS	X	X	X		
AII	307 VAN	ABS BOSCH 8 (CAN)		X	X	X		
AII	307 VAN	Auto Gearbox 4PH20	AT	X	X	X	X	Initialising the autoadaptives
AII	307 VAN	BVA AL4	AT	X	X	X	X	Initialising the autoadaptives
AII	307 VAN	SAC Central	Airbag	X	X	X		
AII	307 VAN	SAC_CENT_SIEMENS	Airbag	X	X			
AII	307 VAN	CLIM T5	Air Conditioning	X	X	X	X	
AII	307 VAN	BSI	Built-In System	X	X	X	X	1.Forcing of the customer mode 2.Resetting to zero of the service mileage
AII	307 VAN	AMF	Multi-function display	X	X	X	X	
AII	307 VAN	AUTORADIO	Radio	X	X	X	X	
AII	307 VAN	CHANGEUR_CD	CD Player	X	X	X	X	
AII	307 VAN	COMBINE_SAGEM	Instrument Panel	X	X	*	X	
AII	307 VAN	GEP	Power Steering	X	X	X		
AII	307 VAN	COM2000	Steering wheel switching module	X	X	X		
AII	307 VAN	ALARME_TEXTON	Alarm	X	X			
AII	307 VAN	TO_WEBASTO	Sun roof	X	X	X	X	
AII	307 VAN	TOUV_TEXTON	Sun roof	X	X	X	X	
AII	307 VAN	MDP_CONDUCT	Driver's door module	X	X	X		
AII	307 VAN	MDP_PASSAG	Passenger door module	X	X	X		
AII	307 VAN	BRET	Roll-over ECU	X	X	X		
AII	307 VAN		Diesel fuel additive control unit	X	X	X	X	
AII	307 VAN		Driving school	X		X	X	
AII	307 CAN	RFJ MM6LPB	Petrol Engine	X	X	X	X	
AII	307 CAN	KFU MM6LP	Petrol Engine	X	X	X	X	
AII	307 CAN	RFK MM6LP	Petrol Engine	X	X	X	X	
AII	307 CAN	RFN MM6LP	Petrol Engine	X	X	X	X	
AII	307 CAN	N6A BOSCH ME7.4.5	Petrol Engine		X	X	X	
AII	307 CAN	NFU BOSCH ME7.4.5	Petrol Engine		X	X	X	
AII	307 CAN	9HZ BOSCH EDC 16C34 Common Rail	Desel Engine		X	X	X	1.EGR throttle learning 2.Particle filter regeneration

All	307 CAN	9HW BOSCH EDC 16C34	Desel Engine		X	X	X	1.EGR SV learning 2.EGR throttle learning 3.Initialization turbo limit 4.Particle filter replacement 5.Initializ. FAP filter additive quantity 6.Replace or fill additive tank 7.Replace metering pump 8.Tank filling 9.Particle filter regeneration
All	307 CAN	9HX BOSCH EDC 16C34	Desel Engine		X	X	X	1.EGR SV learning 2.EGR throttle learning 3.Initialization turbo limit 4.Particle filter regeneration 5.Particle filter replacement 6.Initializ. FAP filter additive quantity 7.Replace or fill additive tank 8.Replace metering pump 9.Tank filling
All	307 CAN	9HY BOSCH EDC 16C34	Desel Engine		X	X	X	1.EGR SV learning 2.EGR throttle learning 3.Initialization turbo limit 4.Particle filter replacement 5.Initializ. FAP filter additive quantity 6.Replace or fill additive tank 7.Replace metering pump 8.Tank filling 9.Particle filter regeneration
All	307 CAN	2.0 SIMENS HDI SID803A[RHR]	Desel Engine		X	X	X	1.Particle filter regeneration 2.Replace or fill additive tank 3.Replace metering pump
All	307 CAN		ABS/ESP	X	X	X	X	
All	307 CAN		Automatic transmission control unit	X	X	X	X	
All	307 CAN		Air bag	X	X	X		
All	307 CAN		Air Conditioning	X	X	X	X	
All	307 CAN		Built-In System	X	X	X	X	Resetting_zero_service
All	307 CAN		Multi-function display	X	X	X	X	
All	307 CAN		Instrument Panel	X	X	X	X	
All	307 CAN		Steering wheel switching module	X	X	X	X	
All	307 CAN		Alarm	X	X	X	X	
All	307 CAN		Driver's door module	X	X	X	X	
All	307 CAN		Passenger door module	X	X	X	X	
All	307 CAN		Rain/brightness sensor	X	X			
All	307 CAN		Parking assistance	X	X	X	X	

All	307 CAN		CD Player	X	X		X	
All	307 CAN		Power Steering	X	X	X		
All	307 CAN		Hand Free Kit	X	X	X	X	
All	308	BOSCH EDC 16C34	Engine		X	X	X	1.EGR SV learning 2.EGR throttle learning 3.Initialization turbo limit 4.Particle filter replacement 5.Initializ. FAP filter additive quantity 6.Replace or fill additive tank 7.Replace metering pump 8.Tank filling 9.Particle filter regeneration
All	308	BOSCH ABS 8.0	ABS		X	X	X	1.Steering angle calibration 2.Brake air bleed
All	308	TRW Autoliv AirBag	Airbag		X	X	X	
All	308		ICM		X	X	X	
All	308		Steering column module		X	X	X	
All	308		SERVICE LIGHT RESET					1.Service Reset
All	405	LFZ SAGEM S2000	Petrol Engine	X	X	X		
All	405	1600RD SAGEM S2000	Petrol Engine	X	X	X		
All	405	N6A ME7.4.4	Petrol Engine	X	X	X	X	Initialising the autoadaptives
All	405	N6B ME7.4.4	Petrol Engine	X	X	X	X	Initialising the autoadaptives
All	405	NFU ME7.4.4	Petrol Engine	X	X	X	X	Initialising the autoadaptives
All	405	LFY BOSCH MP7.3	Petrol Engine	X	X	X		
All	406	KFX SAGEM SL96	Petrol Engine	X	X	X		
All	406	XFX BOSCH ME7.4.6	Petrol Engine	X	X	X	X	
All	406	3FZ MM4MP2	Petrol Engine	X	X	X		Initialising the autoadaptives
All	406	RFR MM4.8P	Petrol Engine	X	X	X	X	
All	406	RLZ SIEMENS SIRIUS 81	Petrol Engine	X	X	X	X	Initialising the autoadaptives
All	406	LFY BOSCH MP7.3	Petrol Engine	X	X	X		Initialising the autoadaptives
All	406	LFY SAGEM SL96	Petrol Engine	X	X	X		
All	406	LFX MM1AP	Petrol Engine	X	X	X	X	
All	406	RHZ BOSCH EDC15C2	Diesel Engine	X	X	X	X	
All	406	RHY BOSCH EDC15C2	Diesel Engine	X	X	X	X	
All	406		ABS	X	X	X	X	Bleeding
All	406		Auto Gearbox	X	X	X	X	Initialising the autoadaptives
All	406	Airbag and seatbelts	Airbag	X	X			
All	406	Left side airbag	Airbag	X	X			
All	406	Right side airbag	Airbag	X	X			
All	406R	KFX SAGEM SL96	Petrol Engine	X	X	X		
All	406R	XFX BOSCH ME7.4.6	Petrol Engine	X	X	X	X	Initialising the autoadaptives
All	406R	3FZ MM4MP2	Petrol Engine	X	X	X		
All	406R	RFR MM4.8P	Petrol Engine	X	X	X	X	Initialising the autoadaptives
All	406R	RLZ SIEMENS SIRIUS 81	Petrol Engine	X	X	X	X	Initialising the autoadaptives

All	406R	LFY BOSCH MP7.3	Petrol Engine	X	X	X		
All	406R	R6F MM4.8P	Petrol Engine	X	X	X	X	Initialising the autoadaptives
All	406R	LFY SAGEM SL96	Petrol Engine	X	X	X		
All	406R	LFX MM1AP	Petrol Engine	X	X	X	X	
All	406R	RLZ IDE SIRIUS 81	Petrol Engine	X	X	X	X	Initialising the autoadaptives
All	406R	6FZ SAGEM S2000	Petrol Engine	X	X	X	X	Initialising the autoadaptives
All	406R	RFN MM4.8P	Petrol Engine	X	X	X	X	Initialising the autoadaptives
All	406R	RHZ BOSCH EDC15C2	Diesel Engine	X	X	X	X	
All	406R	RHY BOSCH EDC15C2	Diesel Engine	X	X	X	X	
All	406R	RHS BOSCH EDC15C2	Diesel Engine	X	X	X	X	
All	406R	RHY SIEMENS SID 801	Diesel Engine	X	X	X	X	
All	406R	4HX BOSCH EDC15C2	Diesel Engine	X	X	X	X	
All	406R	ABR5.3	ABS	X	X	X	X	Bleeding
All	406R	BVA_AL4	Auto Gearbox	X	X	X	X	Initialising the autoadaptives
All	406R	BVA_AL41	Auto Gearbox	X	X	X	X	Initialising the autoadaptives
All	406R	Auto Gearbox 4HP20	Auto Gearbox	X	X	X	X	Initialising the autoadaptives
All	406R	Auto Gearbox AL4	Auto Gearbox	X	X	X	X	Initialising the autoadaptives
All	406R	Auto Gearbox AL4 AT8	AT	X	X	X	X	Initialising the autoadaptives
All	406R	BVA_ZF	Auto Gearbox	X	X	X	X	
All	406R	SAC_ACK	Airbag	X	X	X		
All	406R	SAC_CENT_AUTOLIV_2	Airbag	X	X			
All	406R	BSI	Built-in system interface	X	X	X	X	
All	406R	BSI SIEMENS	Built-in system interface	X	X	X	X	
All	406R	CLIM_D92001	Air Conditioning	X	X	X	X	
All	406R	CLIM_D9	Air Conditioning	X	X	X	X	
All	406R	AMF	Multi-function display	X	X	X	X	
All	406R	AUTORADIO	Radio	X	X	X	X	
All	406R	COMBINE_VDO	Instrument panel	X	X	X	X	
All	406R	SIEGE_BITRON	Seat and mirrors with memory	X	X	X		
All	406R		Alarm	X	X			
All	406R	DVA_ZF	Power Steering	X	X			
All	406R	CD player	CD player	X	X	X	X	
All	406R		On-board navigation system	X	X	X		
All	406R		Diesel fuel additive control unit	X	X	X		
All	406R		Rain/brightness sensor	X	X			
All	406R Coupe	KFX SAGEM SL96	Petrol Engine	X	X	X		
All	406R Coupe	XFX BOSCH ME7.4.6	Petrol Engine	X	X	X	X	Initialising the autoadaptives
All	406R Coupe	3FZ MM4MP2	Petrol Engine	X	X	X		
All	406R Coupe	RFR MM4.8P	Petrol Engine	X	X	X	X	Initialising the autoadaptives
All	406R Coupe	RLZ SIEMENS SIRIUS 81	Petrol Engine	X	X	X	X	Initialising the autoadaptives
All	406R Coupe	LFY BOSCH MP7.3	Petrol Engine	X	X	X		
All	406R Coupe	R6F MM4.8P	Petrol Engine	X	X	X	X	Initialising the autoadaptives
All	406R Coupe	LFY SAGEM SL96	Petrol Engine	X	X	X		
All	406R Coupe	LFX MM1AP	Petrol Engine	X	X	X	X	
All	406R Coupe	RLZ IDE SIRIUS 81	Petrol Engine	X	X	X	X	Initialising the autoadaptives

All	406R Coupe	6FZ SAGEM S2000	Petrol Engine	X	X	X	X	Initialising the autoadaptives
All	406R Coupe	RFN MM4.8P	Petrol Engine	X	X	X	X	Initialising the autoadaptives
All	406R Coupe	RHZ BOSCH EDC15C2	Diesel Engine	X	X	X	X	
All	406R Coupe	RHY BOSCH EDC15C2	Diesel Engine	X	X	X	X	
All	406R Coupe	RHS BOSCH EDC15C2	Diesel Engine	X	X	X	X	
All	406R Coupe	RHY SIEMENS SID 801	Diesel Engine	X	X	X	X	
All	406R Coupe	4HX BOSCH EDC15C2	Diesel Engine	X	X	X	X	
All	406R Coupe	ABS ABR5.3	ABS	X	X	X	X	Bleeding
All	406R Coupe	BVA_AL4	Auto Gearbox	X	X	X	X	Initialising the autoadaptives
All	406R Coupe	BVA_AL41	Auto Gearbox	X	X	X	X	Initialising the autoadaptives
All	406R Coupe	Auto Gearbox 4HP20	Auto Gearbox	X	X	X	X	Initialising the autoadaptives
All	406R Coupe	Auto Gearbox AL4	Auto Gearbox	X	X	X	X	Initialising the autoadaptives
All	406R Coupe	Auto Gearbox AL4 AT8	AT	X	X	X	X	Initialising the autoadaptives
All	406R Coupe	Auto Gearbox	Auto Gearbox	X	X	X	X	
All	406R Coupe	BVA_ZF	Auto Gearbox	X	X	X	X	
All	406R Coupe	SAC_ACK	Airbag	X	X	X		
All	406R Coupe	SAC_CENT_AUTOLIV_2	Airbag	X	X			
All	406R Coupe	BSI	Built-in system interface	X	X	X	X	
All	406R Coupe	BSI_SIEMENS	Built-in system interface	X	X	X	X	
All	406R Coupe	CLIM_D92001	Air Conditioning	X	X	X	X	
All	406R Coupe	CLIM_D9	Air Conditioning	X	X	X	X	
All	406R Coupe	AMF	Multi-function display	X	X	X	X	
All	406R Coupe	AMF1	Multi-function display	X	X	X	X	
All	406R Coupe	AUTORADIO	Radio	X	X	X	X	
All	406R Coupe	COMBINE_VDO	Instrument panel	X	X	X	X	
All	406R Coupe	COMBINE_VDO1	Instrument panel	X	X	X	X	
All	406R Coupe	SIEGE_BITRON	Seat and mirrors with memory	X	X	X		
All	406R Coupe		Alarm	X	X			
All	406R Coupe	DVA_Z	Power Steering	X	X			
All	406R Coupe		CD player On-board	X	X	X	X	
All	406R Coupe		navigation system	X	X	X		
All	406R Coupe		Diesel fuel additive control unit	X	X	X		
All	406R Coupe		Rain/brightness sensor	X	X			
All	407	9HY BOSCH EDC 16C34 (CANBUS)	Engine		X	X	X	1.EGR SV learning 2.EGR throttle learning 3.Initialization turbo limit 4.Particle filter replacement 5.Initializ. FAP filter additive quantity 6.Replace or fill additive tank 7.Replace metering pump 8.Tank filling 9.Particle filter regeneration

All	407	9HY BOSCH EDC 16C34 (K-LINE)	Engine		X	X	X	1.EGR SV learning 2.EGR throttle learning 3.Initialization turbo limit 4.Particle filter replacement 5.Initializ. FAP filter additive quantity 6.Replace or fill additive tank 7.Replace metering pump 8.Tank filling 9.Particle filter regeneration
All	407	RHL DCM3.4	Engine	X	X	X		
All	407	RHR DCM3.4	Engine	X	X	X		
All	407	RHF DCM3.4	Engine	X	X	X		
All	407	UHZ SIEMENS SID201	Engine	X	X	X		
All	407	TRW Autoliv AirBag	AIRBAG		X	X		
All	407	TEVES ABS MK60 (CANBUS)	ABS + TRACT. CONTROL		X	X	X	
All	407	TEVES ABS MK60 (K-LINE)	ABS + TRACT. CONTROL		X	X	X	
All	407		Steering column module		X	X	X	
All	407	A/T AM6	AT		X	X	X	
All	407		ICM		X	X	X	
All	407	Clima	Air Condition		X	X		
All	407		Parking brake		X	X		
All	407	K-LINE	Diesel addition		X	X	X	
All	407	CANBUS	Diesel addition		X	X	X	
All	407		SERVICE LIGHT RESET					1.Service Reset
All	407	TEVES ABS MK60 (CANBUS)	ABS + TRACT. CONTROL		X	X	X	
All	407	TEVES ABS MK60 (K-LINE)	ABS + TRACT. CONTROL		X	X	X	
All	407	BOSCH EDC 16C34 [9HZ]	ENGINE		X	X	X	1.EGR SV learning 2.EGR throttle initial. and intake air heat.
All	407	9HY BOSCH EDC 16C34 (K-LINE)	Engine		X	X	X	1.EGR SV learning 2.EGR throttle learning 3.Initialization turbo limit 4.Particle filter replacement 5.Initializ. FAP filter additive quantity 6.Replace or fill additive tank 7.Replace metering pump 8.Tank filling 9.Particle filter regeneration
All	407	RHL DCM3.4	Engine	X	X	X		
All	407	RHR DCM3.4	Engine	X	X	X		
All	407	RHF DCM3.4	Engine	X	X	X		
All	407	UHZ SIEMENS SID201	Engine	X	X	X		
All	407		Steering column module		X	X	X	
All	407	A/T AM6	AT		X	X	X	
All	407	TRW Autoliv AirBag	AIRBAG		X	X		

All	407		ICM		X	X	X	
All	407	Clima	Air Condition		X	X		
All	407		Parking brake		X	X		
All	407	K-LINE	Diesel addition		X	X	X	
All	407	CANBUS	Diesel addition		X	X	X	
All	407		SERVICE LIGHT RESET					*1.Service Reset
All	407	TEVES ABS MK60 (CANBUS)	ABS + TRACT. CONTROL		X	X	X	
All	407	TEVES ABS MK60 (K-LINE)	ABS + TRACT. CONTROL		X	X	X	
All	407	MARELLI MPI MM6LPB [6FY]	ENGINE MANAGEMENT		X	X	X	
All	407	RHL DCM3.4	ENGINE MANAGEMENT	X	X	X		
All	407	RHR DCM3.4	ENGINE MANAGEMENT	X	X	X		
All	407	RHF DCM3.4	ENGINE MANAGEMENT	X	X	X		
All	407	UHZ SIEMENS SID201	ENGINE MANAGEMENT	X	X	X		
All	407	TRW Autoliv AirBag	AIRBAG		X	X		
All	407		Steering column module		X	X	X	
All	407	A/T AM6	AT		X	X	X	
All	407		ICM		X	X	X	
All	407	Clima	Air Condition		X	X		
All	407		Parking brake		X	X		
All	407		SERVICE LIGHT RESET					1.Service Reset
All	407	TRW Autoliv AirBag	AIRBAG		X	X		
All	407	TEVES ABS MK60 (CANBUS)	ABS + TRACT. CONTROL		X	X	X	
All	407	TEVES ABS MK60 (K-LINE)	ABS + TRACT. CONTROL		X	X	X	
All	407	MARELLI MPI MM6LPB [RFJ]	ENGINE MANAGEMENT		X	X	X	
All	407	RFN MM6LP(K-Line)	ENGINE MANAGEMENT	X	X	X		
All	407	RHL DCM3.4	ENGINE MANAGEMENT	X	X	X		
All	407	RHR DCM3.4	ENGINE MANAGEMENT	X	X	X		
All	407	RHF DCM3.4	ENGINE MANAGEMENT	X	X	X		
All	407	UHZ SIEMENS SID201	ENGINE MANAGEMENT	X	X	X		
All	407		Steering column module		X	X	X	
All	407	A/T AM6	AT		X	X	X	
All	407		ICM		X	X	X	
All	407	Clima	Air Condition		X	X		
All	407		Parking brake		X	X		
All	407		SERVICE LIGHT RESET					1.Service Reset
All	407	RHL DCM3.4	Diesel Engine	X	X	X		
All	407	RHR DCM3.4	Diesel Engine	X	X	X		
All	407	RHF DCM3.4	Diesel Engine	X	X	X		
All	407	UHZ SIEMENS SID201	Diesel Engine	X	X	X		
All	407	TEVES ABS MK60 (CANBUS)	ABS + TRACT. CONTROL		X	X	X	
All	407	TEVES ABS MK60 (K-LINE)	ABS + TRACT. CONTROL		X	X	X	
All	407	TRW Autoliv AirBag	AIRBAG		X	X		
All	407		Steering column module		X	X	X	
All	407	A/T AM6	AT		X	X	X	
All	407		ICM		X	X	X	

All	407	Clima	Air Condition		X	X		
All	407		Parking brake		X	X		
All	407	K-LINE	Diesel addition		X	X	X	
All	407	CANBUS	Diesel addition		X	X	X	
All	407		SERVICE LIGHT RESET					1.Service Reset
All	407	SIMENS HDI SID803A[RHR](K-LINE)	Engine		X	X	X	1.Particle filter regeneration 2.Replace or fill additive tank 3.Replace metering pump
All	407	SIMENS HDI SID803A[RHR](CANBUS)	Engine		X	X	X	1.Particle filter regeneration 2.Replace or fill additive tank 3.Replace metering pump
All	407	SIMENS HDI SID803A[RHL](K-LINE)	Engine		X	X	X	1.Particle filter regeneration 2.Replace or fill additive tank 3.Replace metering pump
All	407	SIMENS HDI SID803A[RHL](CANBUS)	Engine		X	X	X	1.Particle filter regeneration 2.Replace or fill additive tank 3.Replace metering pump
All	407	RHL DCM3.4	Engine	X	X	X		
All	407	RHR DCM3.4	Engine	X	X	X		
All	407	RHF DCM3.4	Engine	X	X	X		
All	407	UHZ SIEMENS SID201	Engine	X	X	X		
All	407	TEVES ABS MK60 (CANBUS)	ABS + TRACT. CONTROL		X	X	X	
All	407	TEVES ABS MK60 (K-LINE)	ABS + TRACT. CONTROL		X	X	X	
All	407	TRW Autoliv AirBag	AIRBAG		X	X		
All	407		Steering column module		X	X	X	
All	407	A/T AM6	AT		X	X	X	
All	407		ICM		X	X	X	
All	407	Clima	Air Condition		X	X		
All	407		Parking brake		X	X		
All	407	K-LINE	Diesel addition		X	X	X	
All	407	CANBUS	Diesel addition		X	X	X	
All	407		SERVICE LIGHT RESET					1.Service Reset
All	407	4HP BOSCH EDC16CP39	Diesel Engine	X	X	X		
All	407	4HR BOSCH EDC16CP39	Diesel Engine	X	X	X		
All	407	4HS BOSCH EDC16CP39	Diesel Engine	X	X	X		
All	407	4HT BOSCH EDC16CP39	Diesel Engine	X	X	X		
All	407	RHL DCM3.4	Diesel Engine	X	X	X		
All	407	RHR DCM3.4	Diesel Engine	X	X	X		
All	407	RHF DCM3.4	Diesel Engine	X	X	X		
All	407	UHZ SIEMENS SID201	Diesel Engine	X	X	X		
All	407	TEVES ABS MK60 (CANBUS)	ABS + TRACT. CONTROL		X	X	X	
All	407	TEVES ABS MK60 (K-LINE)	ABS + TRACT. CONTROL		X	X	X	
All	407	TRW Autoliv AirBag	AIRBAG		X	X		
All	407		Steering column module		X	X	X	

All	407	A/T AM6	AT		X	X	X	
All	407		ICM		X	X	X	
All	407	Clima	Air Condition		X	X		
All	407		Parking brake		X	X		
All	407	K-LINE	Diesel addition		X	X	X	
All	407	CANBUS	Diesel addition		X	X	X	
All	407		SERVICE LIGHT RESET					1.Service Reset
All	407	4HP BOSCH EDC16CP39	Diesel Engine	X	X	X		
All	407	4HR BOSCH EDC16CP39	Diesel Engine	X	X	X		
All	407	4HS BOSCH EDC16CP39	Diesel Engine	X	X	X		
All	407	4HT BOSCH EDC16CP39	Diesel Engine	X	X	X		
All	407	RHL DCM3.4	Diesel Engine	X	X	X		
All	407	RHR DCM3.4	Diesel Engine	X	X	X		
All	407	RHF DCM3.4	Diesel Engine	X	X	X		
All	407	UHZ SIEMENS SID201	Diesel Engine	X	X	X		
All	407	TEVES ABS MK60 (CANBUS)	ABS + TRACT. CONTROL		X	X	X	
All	407	TEVES ABS MK60 (K-LINE)	ABS + TRACT. CONTROL		X	X	X	
All	407	TRW Autoliv AirBag	AIRBAG		X	X		
All	407		Steering column module		X	X	X	
All	407	A/T AM6	AT		X	X	X	
All	407		ICM		X	X	X	
All	407	Clima	Air Condition		X	X		
All	407		Parking brake		X	X		
All	407	K-LINE	Diesel addition		X	X	X	
All	407	CANBUS	Diesel addition		X	X	X	
All	407		SERVICE LIGHT RESET					1.Service Reset
All	407	EDC17CP11	Diesel Engine	X	X	X		
All	407	RHL DCM3.4	Diesel Engine	X	X	X		
All	407	RHR DCM3.4	Diesel Engine	X	X	X		
All	407	RHF DCM3.4	Diesel Engine	X	X	X		
All	407	UHZ SIEMENS SID201	Diesel Engine	X	X	X		
All	407	TEVES ABS MK60 (CANBUS)	ABS + TRACT. CONTROL		X	X	X	
All	407	TEVES ABS MK60 (K-LINE)	ABS + TRACT. CONTROL		X	X	X	
All	407	TRW Autoliv AirBag	AIRBAG		X	X		
All	407		Steering column module		X	X	X	
All	407	A/T AM6	AT		X	X	X	
All	407		ICM		X	X	X	
All	407	Clima	Air Condition		X	X		
All	407		Parking brake		X	X		
All	407		SERVICE LIGHT RESET					1.Service Reset
All	408	NFU ME749 Bio Flex	Engine	X	X	X		
All	408	RFJ MM6LPB	Engine	X	X	X		
All	408	TU5JP4 ME745	Engine	X	X	X		
All	408	Instrument Panel	Instrument Panel	X	X	X		
All	408	ABS 8.1	ABS/ESP	X	X	X		

All	408	ESP8.1	ABS/ESP	X	X	X		
All	408	Airbag(China)	Airbag	X	X	X		
All	408	Airbag(Mercosur)	Airbag	X	X	X		
All	408	BSI	BSI	X	X	X		
All	408	AT AL4AT8	Gearbox	X	X	X		
All	607	3FZ MM4MP2	Petrol Engine	X	X	X		
All	607	R6F MM4.8P	Petrol Engine	X	X	X	X	Initialising the autoadaptives
All	607	RFN MM48P(Mechanical throttle housing)	Petrol Engine	X	X	X	X	Initialising the autoadaptives
All	607		Petrol Engine	X	X	X	X	Initialising the autoadaptives
All	607	AFX BOSCH ME7.4.6	Petrol Engine	X	X	X	X	
All	607	RHZ BOSCH EDC15C2	Diesel Engine	X	X	X	X	
All	607	RHS BOSCH EDC15C2	Diesel Engine	X	X	X	X	
All	607	4HX BOSCH EDC15C2	Diesel Engine	X	X	X	X	
All	607		ABS	X	X	X	X	Bleeding
All	607		Auto Gearbox	X	X	X	X	Initialising the autoadaptives
All	607		Airbag	X	X			
All	607		Air Conditioning	X	X	X		
All	806	R6F MM4.8P	Petrol Engine	X	X	X	X	Initialising the autoadaptives
All	806	RFN MM4.8P	Petrol Engine	X	X	X	X	Initialising the autoadaptives
All	806	RHZ BOSCH EDC15C2	Diesel Engine	X	X	X	X	
All	806	RHW BOSCH EDC15C2	Diesel Engine	X	X	X	X	
All	806	Airbag and seatbelts	Airbag	X	X	X	X	
All	806	BOSCH ABS 5.3	ABS	X	X			Bleeding
All	807 VAN	3FZ MM4MP2	Petrol Engine	X	X	X		
All	807 VAN	3FZ MM6LP	Petrol Engine	X	X	X	X	
All	807 VAN	RFN MM6LP	Petrol Engine	X	X	X	X	
All	807 VAN	XFW BOSCH ME746	Petrol Engine	X	X	X		
All	807 VAN	R6F MM4.8P	Petrol Engine	X	X	X	X	Initialising the autoadaptives
All	807 VAN	RFN MM48P(Mechanical throttle housing)	Petrol Engine	X	X	X	X	Initialising the autoadaptives
All	807 VAN	RHW BOSCH EDC15C2	Diesel Engine	X	X	X	X	
All	807 VAN	RHT BOSCH EDC15C2	Diesel Engine	X	X	X	X	
All	807 VAN	RHM BOSCH EDC15C2	Diesel Engine	X	X	X	X	
All	807 VAN	4HW BOSCH EDC15C2	Diesel Engine	X	X	X	X	
All	807 VAN	ESP BOSCH 5.7	ABS	X	X	X	X	Bleeding
All	807 VAN	BVA_AL4	Auto Gearbox	X	X	X	X	Initialising the autoadaptives
All	807 VAN	4PH20 automatic gearbox	Auto Gearbox	X	X	X	X	Initialising the autoadaptives
All	807 VAN		Airbag	X	X			
All	807 VAN	Climate control	Air Conditioning	X	X	X	X	
All	807 VAN		Multi-function display	X	X	X	X	
All	807 VAN		Instrument panel	X	X	X	X	
All	807 VAN		Steering wheel switching module	X	X	X		
All	807 VAN		Alarm	X	X			

AII	807 VAN	AUTORADIO	Radio	X	X	X	X	
AII	807 VAN		Driver's door module	X	X	X		
AII	807 VAN		Passenger door module	X	X	X		
AII	807 VAN		CD player	X	X	X	X	
AII	807 VAN		Diesel fuel additive control unit	X	X	X	X	
AII	BOXER	MM48P 2L essence plombee	Petrol Engine	X	X	X	X	Initialising the autoadaptives
AII	BOXER	ABS/ESP	ABS	X	X	X	X	Bleeding
AII	BOXER 3	4HU PUMA DCU102	Engine	X	X	X	X	
AII	BOXER 3	4HV PUMA DCU102	Engine	X	X	X	X	
AII	BOXER 3	Sofim 3.0 145cv	Engine	X	X		X	
AII	BOXER 3	Sofim 3.0 145cv FAP	Engine	X	X		X	
AII	EXPERT	R6F MM4.8P	Petrol Engine	X	X	X	X	Initialising the autoadaptives
AII	EXPERT	RFN MM4.8P	Petrol Engine	X	X	X	X	Initialising the autoadaptives
AII	EXPERT	RHZ BOSCH EDC15C2	Diesel Engine	X	X	X	X	
AII	EXPERT	WJY LUCAS DCN2	Diesel Engine	X	X	X		
AII	EXPERT	RHW BOSCH EDC15C2	Diesel Engine	X	X	X	X	
AII	EXPERT	RHX BOSCH EDC15C2	Diesel Engine	X	X	X	X	
AII	EXPERT	BOSCH ABS5.3	ABS	X	X	X	X	Bleeding
AII	EXPERT	BOSCH ABS5.3	Airbag	X	X			
AII	PARTNER	HDY BOSCH MA3.1	Petrol Engine	X	X	X	X	
AII	PARTNER	HDZ BOSCH MA3.1	Petrol Engine	X	X	X	X	
AII	PARTNER	HFX BOSCH M7.4.4	Petrol Engine	X	X	X	X	
AII	PARTNER	KFX BOSCH MP7.3	Petrol Engine	X	X	X		
AII	PARTNER	KFX MM1AP	Petrol Engine	X	X	X	X	
AII	PARTNER	KFX SGEAM SL96	Petrol Engine	X	X	X		
AII	PARTNER	LFX MM1AP	Petrol Engine	X	X	X	X	
AII	PARTNER	N6A BOSCH ME7.4.4	Petrol Engine	X	X	X	X	Initialising the autoadaptives
AII	PARTNER	NFU BOSCH ME7.4.4	Petrol Engine	X	X	X	X	Initialising the autoadaptives
AII	PARTNER	K6D SAGEM S2000	Petrol Engine	X	X	X	X	Initialising the autoadaptives
AII	PARTNER	KFW SAGEM S2000	Petrol Engine	X	X	X	X	Initialising the autoadaptives
AII	PARTNER	N6A BOSCH ME7.4.5	Petrol Engine	X	X	X	X	Initialising the autoadaptives
AII	PARTNER	NFU BOSCH ME7.4.5	Petrol Engine	X	X	X	X	Initialising the autoadaptives
AII	PARTNER	N6B BOSCH ME7.4.5	Petrol Engine	X	X	X	X	Initialising the autoadaptives
AII	PARTNER	KFW J34P	Petrol Engine	X	X	X	X	
AII	PARTNER	KFW SAGEM S2000PM1	Petrol Engine	X	X	X	X	
AII	PARTNER	HFX MM4.8P	Petrol Engine	X	X	X	X	Initialising the autoadaptives
AII	PARTNER	WJY LUCAS DCN2	Diesel Engine	X	X	X		
AII	PARTNER	WJZ LUCAS DCN2	Diesel Engine	X	X	X		
AII	PARTNER	RHY BOSCH EDC15C2	Diesel Engine	X	X	X	X	
AII	PARTNER	RHY SIEMENS SID 801	Diesel Engine	X	X	X	X	
AII	PARTNER	9HX BOSCH EDC16C3	Diesel Engine	X	X	X	X	
AII	PARTNER	9HW BOSCH EDC16C3	Diesel Engine	X	X	X	X	
AII	PARTNER	ALARME_TEXTON	Alarm	X	X			
AII	PARTNER	COM2000	Steering wheel switching module	X	X	X		
AII	PARTNER	AUTORADIO	Radio	X	X	X	X	

All	PARTNER	COMBINE_MM	Instrument panel	X	X	X	X	
All	PARTNER	BSI	Built-in system interface(BSI)	X	X	X	X	
All	PARTNER	BSI1	Built-in system interface(BSI)	X	X	X	X	1.Forcing of the customer mode 2.Resetting to zero of the service mileage
All	PARTNER	ESP BOSCH 5.7	ABS	X	X	X	X	Bleeding
All	PARTNER	ABS BOSCH 8	ABS	X	X	X	X	Bleeding
All	PARTNER	ESP BOSCH 8	ABS	X	X	X	X	Bleeding
All	PARTNER	ABS 8.1	ABS	X	X	X	X	Bleeding
All	PARTNER	Airbag and seatbelts	Airbag	X	X	X		
All	PARTNER	SAC_CENT_AUTOLIV	Airbag	X	X			
All	PARTNER		Display/Telematics	X	X	X	X	
All	PARTNER		CD player	X	X	X	X	
All	PARTNER		Rain/brightness sensor	X	X			
All	PARTNER 2	BOSCH ME 7.4.5	Engine		X	X	X	
All	PARTNER 2	9HW BOSCH EDC 16C34	Engine		X	X	X	1.EGR SV learning 2.EGR throttle learning 3.Initialization turbo limit 4.Particle filter replacement 5.Initializ. FAP filter additive quantity 6.Replace or fill additive tank 7.Replace metering pump 8.Tank filling 9.Particle filter regeneration
All	PARTNER 2	BOSCH ABS 8.1	ABS		X	X	X	
All	PARTNER 2		Airbag		X	X	X	
All	PARTNER 2		SERVICE LIGHT RESET					1.Service Reset