

Digiprog3-Adapter

ST01/02 8 Pin SOIC Clip

ST04 8 Pin Dill Chip Clip

ST06 BMW OBD Diagnostic Plug

ST07 BMW Compact SW7

ST08 Mercedes Benz C Class VDO 1993/1995

ST08 ST09 ST15 ST18

ST09 VW Golf 3 MM Cluster Diagnostic

ST10 Mercedes Benz OBD Diagnostic Plug

ST11 Mercedes Benz S Class Cluster Diagnostic

ST12 Mercedes Sprinter Kienzle Diagnostic plug

ST13 Digiprog Power Lead

ST14 Audi A6 Diag 1994/1996 & ST17 Audi A6 Diag 1994/1996

ST15 ST17 VW Golf Mk3 VDO Cluster Diagnostic

ST16 OBD II Diagnostic

ST19 Mercedes Sprinter VDO Cluster diagnostic

ST20 BMW 5/7 Series Cluster Diagnostic

ST21 Toyota Avensis Cluster Diagnostic

ST22 Peugeot 306 VDO Cluster Diagnostic

ST23 Jaguar XJ6 11DU 90/91/93/95

ST24 Data lead for ST16

ST25 Ford Scorpio Cluster Diagnostic

ST26 BMW 3 Series Compact SW9/10

ST27 Ford Focus

ST28 Peugeot 206 Jeager

ST29 Ford Fiesta Mk 3 & 4 up to year 2000

ST30 Smart car BSI

ST31 Peugeot 406 VDO Cluster Diagnostic

ST32 Fiat Multipla

ST33 Alfa 156 HC11

ST34 Alfa 145/146 ST
ST35 HC11 lead this is used on several applications
ST36 Alfa
ST37 Jaguar XK8
ST38 Ford Cougar
ST39 Peugeot 806 Citroen Synergy, Fiat ScudoCable Title
ST41 Audi MM Dash cluster lead
ST42 This lead has several applications
ST45 Chrysler Grand Cherokee 1999/2000 Cluster Diagnostic
ST46 Peugeot 406 Jeager
ST47 This lead has several applications
ST49 Mercedes W203 Diagnostic
ST50 Mercedes A Class HC 12 & Vaneo
ST51 HC12 Micro lead
ST55 Jaguar X Type
ST60 W211 & W203 Cluster Diagnostic
POWER 12V DC
ST-BMW
Back-up Adapter