

1. Install VOLVO VIDA



To install VOLVO VIDA, Driver C: must be NTFS format, with at least 10G free space. IE 6.0 needed.

- Put the VIDA installation DVD into DVDRROM, setup will run automatically.



If the installation program does not run automatically, please manually run:

[Install\DVD\Vida_dvdheader\Main\setup.exe](#)

