

VEHICLE COVERAGE

Vehicle Coverage

Diagnostic Tools

Other Tools

Product Model

MaxiAP200

Vehicle Make

Sprinter

Vehicle Model

SprinterIII

Year

ALL

Function/Sub-function

SEARCH

| Vehicle Model | Year | Engine | Chassis | Series | Vehicle Type | System | Sub-system | Function | Sub-function | Version | Note |
|---------------|------|--------|---------|--------|--------------|----------------------------|------------|-----------------|-----------------------------|----------------------|------|
| SprinterIII | / | / | 906 | | | Instrument Cluster | / | ECU Information | / | Above Sprinter_V1.00 | / |
| SprinterIII | / | / | 906 | | | Instrument Cluster | / | Erase Codes | / | Above Sprinter_V1.00 | / |
| SprinterIII | / | / | 906 | | | Instrument Cluster | / | Live Data | / | Above Sprinter_V1.00 | / |
| SprinterIII | / | / | 906 | | | Instrument Cluster | / | Read Codes | / | Above Sprinter_V1.00 | / |
| SprinterIII | / | / | 906 | | | Instrument Cluster | / | Oil reset | *ASSYST*Service information | Above Sprinter_V1.00 | / |
| SprinterIII | / | / | 906 | | | Navigation module | / | ECU Information | / | Above Sprinter_V1.00 | / |
| SprinterIII | / | / | 906 | | | Navigation module | / | Erase Codes | / | Above Sprinter_V1.00 | / |
| SprinterIII | / | / | 906 | | | Navigation module | / | Live Data | / | Above Sprinter_V1.00 | / |
| SprinterIII | / | / | 906 | | | Navigation module | / | Read Codes | / | Above Sprinter_V1.00 | / |
| SprinterIII | / | / | 906 | | | Air Conditioning | / | ECU Information | / | Above Sprinter_V1.00 | / |
| SprinterIII | / | / | 906 | | | Air Conditioning | / | Erase Codes | / | Above Sprinter_V1.00 | / |
| SprinterIII | / | / | 906 | | | Air Conditioning | / | Live Data | / | Above Sprinter_V1.00 | / |
| SprinterIII | / | / | 906 | | | Air Conditioning | / | Read Codes | / | Above Sprinter_V1.00 | / |
| SprinterIII | / | / | 906 | | | Electronic Selector Module | / | ECU Information | / | Above Sprinter_V1.00 | / |
| SprinterIII | / | / | 906 | | | Electronic Selector Module | / | Erase Codes | / | Above Sprinter_V1.00 | / |
| SprinterIII | / | / | 906 | | | Electronic Selector Module | / | Live Data | / | Above Sprinter_V1.00 | / |
| SprinterIII | / | / | 906 | | | Electronic Selector Module | / | Read Codes | / | Above Sprinter_V1.00 | / |

| Vehicle Model | Year | Engine | Chassis | Series | Vehicle Type | System | Sub-system | Function | Sub-function | Version | Note |
|---------------|------|--------|---------|--------|--------------|------------------------------------------|------------|-----------------|--------------|----------------------|------|
| SprinterIII | / | / | 906 | | | Electronic ignition lock | / | ECU Information | / | Above Sprinter_V1.00 | / |
| SprinterIII | / | / | 906 | | | Electronic ignition lock | / | Erase Codes | / | Above Sprinter_V1.00 | / |
| SprinterIII | / | / | 906 | | | Electronic ignition lock | / | Live Data | / | Above Sprinter_V1.00 | / |
| SprinterIII | / | / | 906 | | | Electronic ignition lock | / | Read Codes | / | Above Sprinter_V1.00 | / |
| SprinterIII | / | / | 906 | | | Transfer case | / | ECU Information | / | Above Sprinter_V1.00 | / |
| SprinterIII | / | / | 906 | | | Transfer case | / | Erase Codes | / | Above Sprinter_V1.00 | / |
| SprinterIII | / | / | 906 | | | Transfer case | / | Live Data | / | Above Sprinter_V1.00 | / |
| SprinterIII | / | / | 906 | | | Transfer case | / | Read Codes | / | Above Sprinter_V1.00 | / |
| SprinterIII | / | / | 906 | | | Compressed Natural Gas | / | ECU Information | / | Above Sprinter_V1.00 | / |
| SprinterIII | / | / | 906 | | | Compressed Natural Gas | / | Erase Codes | / | Above Sprinter_V1.00 | / |
| SprinterIII | / | / | 906 | | | Compressed Natural Gas | / | Live Data | / | Above Sprinter_V1.00 | / |
| SprinterIII | / | / | 906 | | | Compressed Natural Gas | / | Read Codes | / | Above Sprinter_V1.00 | / |
| SprinterIII | / | / | 906 | | | Control Module for Parktronic(PTS) | / | ECU Information | / | Above Sprinter_V1.00 | / |
| SprinterIII | / | / | 906 | | | Control Module for Parktronic(PTS) | / | Erase Codes | / | Above Sprinter_V1.00 | / |
| SprinterIII | / | / | 906 | | | Control Module for Parktronic(PTS) | / | Live Data | / | Above Sprinter_V1.00 | / |
| SprinterIII | / | / | 906 | | | Control Module for Parktronic(PTS) | / | Read Codes | / | Above Sprinter_V1.00 | / |
| SprinterIII | / | / | 906 | | | Driver door | / | ECU Information | / | Above Sprinter_V1.00 | / |
| SprinterIII | / | / | 906 | | | Driver door | / | Erase Codes | / | Above Sprinter_V1.00 | / |
| SprinterIII | / | / | 906 | | | Driver door | / | Live Data | / | Above Sprinter_V1.00 | / |
| SprinterIII | / | / | 906 | | | Driver door | / | Read Codes | / | Above Sprinter_V1.00 | / |
| SprinterIII | / | / | 906 | | | Electronic Stability Program(ESP) | / | ECU Information | / | Above Sprinter_V1.00 | / |
| SprinterIII | / | / | 906 | | | Electronic Stability Program(ESP) | / | Erase Codes | / | Above Sprinter_V1.00 | / |
| SprinterIII | / | / | 906 | | | Electronic Stability Program(ESP) | / | Live Data | / | Above Sprinter_V1.00 | / |
| SprinterIII | / | / | 906 | | | Electronic Stability Program(ESP) | / | Read Codes | / | Above Sprinter_V1.00 | / |
| SprinterIII | / | / | 906 | | | Electronic Transmission Control(ETC/EGS) | / | ECU Information | / | Above Sprinter_V1.00 | / |
| SprinterIII | / | / | 906 | | | Electronic Transmission Control(ETC/EGS) | / | Erase Codes | / | Above Sprinter_V1.00 | / |
| SprinterIII | / | / | 906 | | | Electronic Transmission Control(ETC/EGS) | / | Live Data | / | Above Sprinter_V1.00 | / |
| SprinterIII | / | / | 906 | | | Electronic Transmission Control(ETC/EGS) | / | Read Codes | / | Above Sprinter_V1.00 | / |
| SprinterIII | / | / | 906 | | | Electronic Ignition lock(NAFTA version) | / | ECU Information | / | Above Sprinter_V1.00 | / |
| SprinterIII | / | / | 906 | | | Electronic Ignition lock(NAFTA version) | / | Erase Codes | / | Above Sprinter_V1.00 | / |
| SprinterIII | / | / | 906 | | | Electronic Ignition lock(NAFTA version) | / | Live Data | / | Above Sprinter_V1.00 | / |
| SprinterIII | / | / | 906 | | | Electronic Ignition lock(NAFTA version) | / | Read Codes | / | Above Sprinter_V1.00 | / |

| Vehicle Model | Year | Engine | Chassis | Series | Vehicle Type | System | Sub-system | Function | Sub-function | Version | Note |
|---------------|------|--------|---------|--------|--------------|-----------------------------------------------------------|------------|-----------------|--------------|----------------------|------|
| SprinterIII | / | / | 906 | | | Fuel pump(FSCU1) | / | ECU Information | / | Above Sprinter_V1.00 | / |
| SprinterIII | / | / | 906 | | | Fuel pump(FSCU1) | / | Erase Codes | / | Above Sprinter_V1.00 | / |
| SprinterIII | / | / | 906 | | | Fuel pump(FSCU1) | / | Live Data | / | Above Sprinter_V1.00 | / |
| SprinterIII | / | / | 906 | | | Fuel pump(FSCU1) | / | Read Codes | / | Above Sprinter_V1.00 | / |
| SprinterIII | / | / | 906 | | | Fuel pump(FSCU2) | / | ECU Information | / | Above Sprinter_V1.00 | / |
| SprinterIII | / | / | 906 | | | Fuel pump(FSCU2) | / | Erase Codes | / | Above Sprinter_V1.00 | / |
| SprinterIII | / | / | 906 | | | Fuel pump(FSCU2) | / | Live Data | / | Above Sprinter_V1.00 | / |
| SprinterIII | / | / | 906 | | | Fuel pump(FSCU2) | / | Read Codes | / | Above Sprinter_V1.00 | / |
| SprinterIII | / | / | 906 | | | Full integrated transmission control(NAG2) | / | ECU Information | / | Above Sprinter_V1.00 | / |
| SprinterIII | / | / | 906 | | | Full integrated transmission control(NAG2) | / | Erase Codes | / | Above Sprinter_V1.00 | / |
| SprinterIII | / | / | 906 | | | Full integrated transmission control(NAG2) | / | Live Data | / | Above Sprinter_V1.00 | / |
| SprinterIII | / | / | 906 | | | Full integrated transmission control(NAG2) | / | Read Codes | / | Above Sprinter_V1.00 | / |
| SprinterIII | / | / | 906 | | | Heater Booster(HB/ZH/ZUH) | / | ECU Information | / | Above Sprinter_V1.00 | / |
| SprinterIII | / | / | 906 | | | Heater Booster(HB/ZH/ZUH) | / | Erase Codes | / | Above Sprinter_V1.00 | / |
| SprinterIII | / | / | 906 | | | Heater Booster(HB/ZH/ZUH) | / | Live Data | / | Above Sprinter_V1.00 | / |
| SprinterIII | / | / | 906 | | | Heater Booster(HB/ZH/ZUH) | / | Read Codes | / | Above Sprinter_V1.00 | / |
| SprinterIII | / | / | 906 | | | Keyless entry&slide | / | ECU Information | / | Above Sprinter_V1.00 | / |
| SprinterIII | / | / | 906 | | | Keyless entry&slide | / | Erase Codes | / | Above Sprinter_V1.00 | / |
| SprinterIII | / | / | 906 | | | Keyless entry&slide | / | Live Data | / | Above Sprinter_V1.00 | / |
| SprinterIII | / | / | 906 | | | Keyless entry&slide | / | Read Codes | / | Above Sprinter_V1.00 | / |
| SprinterIII | / | / | 906 | | | Left electric sliding door | / | ECU Information | / | Above Sprinter_V1.00 | / |
| SprinterIII | / | / | 906 | | | Left electric sliding door | / | Erase Codes | / | Above Sprinter_V1.00 | / |
| SprinterIII | / | / | 906 | | | Left electric sliding door | / | Live Data | / | Above Sprinter_V1.00 | / |
| SprinterIII | / | / | 906 | | | Left electric sliding door | / | Read Codes | / | Above Sprinter_V1.00 | / |
| SprinterIII | / | / | 906 | | | Level control | / | ECU Information | / | Above Sprinter_V1.00 | / |
| SprinterIII | / | / | 906 | | | Level control | / | Erase Codes | / | Above Sprinter_V1.00 | / |
| SprinterIII | / | / | 906 | | | Level control | / | Live Data | / | Above Sprinter_V1.00 | / |
| SprinterIII | / | / | 906 | | | Level control | / | Read Codes | / | Above Sprinter_V1.00 | / |
| SprinterIII | / | / | 906 | | | Motor Electronics(ME)'CDI43'for combustion engine 'OM651' | / | ECU Information | / | Above Sprinter_V1.00 | / |
| SprinterIII | / | / | 906 | | | Motor Electronics(ME)'CDI43'for combustion engine 'OM651' | / | Erase Codes | / | Above Sprinter_V1.00 | / |
| SprinterIII | / | / | 906 | | | Motor Electronics(ME)'CDI43'for combustion engine 'OM651' | / | Live Data | / | Above Sprinter_V1.00 | / |
| SprinterIII | / | / | 906 | | | Motor Electronics(ME)'CDI43'for combustion engine 'OM651' | / | Read Codes | / | Above Sprinter_V1.00 | / |

| Vehicle Model | Year | Engine | Chassis | Series | Vehicle Type | System | Sub-system | Function | Sub-function | Version | Note |
|---------------|------|--------|---------|--------|--------------|--------------------------------------------------------------------|------------|-----------------|---------------------------|----------------------|------|
| SprinterIII | / | / | 906 | | | Motor Electronics(ME)'CDI43'for combustion engine 'OM651' | / | DPF | Diesel Particulate Filter | Above Sprinter_V1.00 | / |
| SprinterIII | / | / | 906 | | | Motor Electronics(ME)'CDI6'for combustion engine 'OM642' | / | ECU Information | / | Above Sprinter_V1.00 | / |
| SprinterIII | / | / | 906 | | | Motor Electronics(ME)'CDI6'for combustion engine 'OM642' | / | Erase Codes | / | Above Sprinter_V1.00 | / |
| SprinterIII | / | / | 906 | | | Motor Electronics(ME)'CDI6'for combustion engine 'OM642' | / | Live Data | / | Above Sprinter_V1.00 | / |
| SprinterIII | / | / | 906 | | | Motor Electronics(ME)'CDI6'for combustion engine 'OM642' | / | Read Codes | / | Above Sprinter_V1.00 | / |
| SprinterIII | / | / | 906 | | | Motor Electronics(ME)'CDI6'for combustion engine 'OM642' | / | DPF | Diesel Particulate Filter | Above Sprinter_V1.00 | / |
| SprinterIII | / | / | 906 | | | Motor Electronics(ME)'CDI60'for combustion engine 'OM642' | / | ECU Information | / | Above Sprinter_V1.00 | / |
| SprinterIII | / | / | 906 | | | Motor Electronics(ME)'CDI60'for combustion engine 'OM642' | / | Erase Codes | / | Above Sprinter_V1.00 | / |
| SprinterIII | / | / | 906 | | | Motor Electronics(ME)'CDI60'for combustion engine 'OM642' | / | Live Data | / | Above Sprinter_V1.00 | / |
| SprinterIII | / | / | 906 | | | Motor Electronics(ME)'CDI60'for combustion engine 'OM642' | / | Read Codes | / | Above Sprinter_V1.00 | / |
| SprinterIII | / | / | 906 | | | Motor Electronics(ME)'CDI60'for combustion engine 'OM642' | / | DPF | Diesel Particulate Filter | Above Sprinter_V1.00 | / |
| SprinterIII | / | / | 906 | | | Motor Electronics(ME)'CDI60'for combustion engine 'OM642'(CDI) | / | ECU Information | / | Above Sprinter_V1.00 | / |
| SprinterIII | / | / | 906 | | | Motor Electronics(ME)'CDI60'for combustion engine 'OM642'(CDI) | / | Erase Codes | / | Above Sprinter_V1.00 | / |
| SprinterIII | / | / | 906 | | | Motor Electronics(ME)'CDI60'for combustion engine 'OM642'(CDI) | / | Live Data | / | Above Sprinter_V1.00 | / |
| SprinterIII | / | / | 906 | | | Motor Electronics(ME)'CDI60'for combustion engine 'OM642'(CDI) | / | Read Codes | / | Above Sprinter_V1.00 | / |
| SprinterIII | / | / | 906 | | | Motor Electronics(ME)'CDI60'for combustion engine 'OM642'(CDI) | / | DPF | Diesel Particulate Filter | Above Sprinter_V1.00 | / |
| SprinterIII | / | / | 906 | | | Motor Electronics(ME)'CDID2'for combustion engine 'OM651' | / | ECU Information | / | Above Sprinter_V1.00 | / |
| SprinterIII | / | / | 906 | | | Motor Electronics(ME)'CDID2'for combustion engine 'OM651' | / | Erase Codes | / | Above Sprinter_V1.00 | / |
| SprinterIII | / | / | 906 | | | Motor Electronics(ME)'CDID2'for combustion engine 'OM651' | / | Live Data | / | Above Sprinter_V1.00 | / |
| SprinterIII | / | / | 906 | | | Motor Electronics(ME)'CDID2'for combustion engine 'OM651' | / | Read Codes | / | Above Sprinter_V1.00 | / |
| SprinterIII | / | / | 906 | | | Motor Electronics(ME)'CDID2'for combustion engine 'OM651' | / | DPF | Diesel Particulate Filter | Above Sprinter_V1.00 | / |
| SprinterIII | / | / | 906 | | | Motor Electronics(ME)'CDID3'for combustion engine 'OM651' | / | ECU Information | / | Above Sprinter_V1.00 | / |
| SprinterIII | / | / | 906 | | | Motor Electronics(ME)'CDID3'for combustion engine 'OM651' | / | Erase Codes | / | Above Sprinter_V1.00 | / |
| SprinterIII | / | / | 906 | | | Motor Electronics(ME)'CDID3'for combustion engine 'OM651' | / | Live Data | / | Above Sprinter_V1.00 | / |
| SprinterIII | / | / | 906 | | | Motor Electronics(ME)'CDID3'for combustion engine 'OM651' | / | Read Codes | / | Above Sprinter_V1.00 | / |
| SprinterIII | / | / | 906 | | | Motor Electronics(ME)'CDID3'for combustion engine 'OM651' | / | DPF | Diesel Particulate Filter | Above Sprinter_V1.00 | / |
| SprinterIII | / | / | 906 | | | Motor Electronics(ME)'ME'for combustion engine 'M272' | / | ECU Information | / | Above Sprinter_V1.00 | / |
| SprinterIII | / | / | 906 | | | Motor Electronics(ME)'ME'for combustion engine 'M272' | / | Erase Codes | / | Above Sprinter_V1.00 | / |
| SprinterIII | / | / | 906 | | | Motor Electronics(ME)'ME'for combustion engine 'M272' | / | Live Data | / | Above Sprinter_V1.00 | / |
| SprinterIII | / | / | 906 | | | Motor Electronics(ME)'ME'for combustion engine 'M272' | / | Read Codes | / | Above Sprinter_V1.00 | / |
| SprinterIII | / | / | 906 | | | Motor Electronics(ME)'SIM271CNG906'for combustion engine 'M271CNG' | / | ECU Information | / | Above Sprinter_V1.00 | / |
| SprinterIII | / | / | 906 | | | Motor Electronics(ME)'SIM271CNG906'for combustion engine 'M271CNG' | / | Erase Codes | / | Above Sprinter_V1.00 | / |

| Vehicle Model | Year | Engine | Chassis | Series | Vehicle Type | System | Sub-system | Function | Sub-function | Version | Note |
|---------------|------|--------|---------|--------|--------------|--------------------------------------------------------------------|------------|-----------------|--------------|----------------------|------|
| SprinterIII | / | / | 906 | | | Motor Electronics(ME)'SIM271CNG906'for combustion engine 'M271CNG' | / | Live Data | / | Above Sprinter_V1.00 | / |
| SprinterIII | / | / | 906 | | | Motor Electronics(ME)'SIM271CNG906'for combustion engine 'M271CNG' | / | Read Codes | / | Above Sprinter_V1.00 | / |
| SprinterIII | / | / | 906 | | | N2/14-Supplemental Restraint System | / | ECU Information | / | Above Sprinter_V1.00 | / |
| SprinterIII | / | / | 906 | | | N2/14-Supplemental Restraint System | / | Erase Codes | / | Above Sprinter_V1.00 | / |
| SprinterIII | / | / | 906 | | | N2/14-Supplemental Restraint System | / | Live Data | / | Above Sprinter_V1.00 | / |
| SprinterIII | / | / | 906 | | | N2/14-Supplemental Restraint System | / | Read Codes | / | Above Sprinter_V1.00 | / |
| SprinterIII | / | / | 906 | | | N2/15-Supplemental Restraint System | / | ECU Information | / | Above Sprinter_V1.00 | / |
| SprinterIII | / | / | 906 | | | N2/15-Supplemental Restraint System | / | Erase Codes | / | Above Sprinter_V1.00 | / |
| SprinterIII | / | / | 906 | | | N2/15-Supplemental Restraint System | / | Live Data | / | Above Sprinter_V1.00 | / |
| SprinterIII | / | / | 906 | | | N2/15-Supplemental Restraint System | / | Read Codes | / | Above Sprinter_V1.00 | / |
| SprinterIII | / | / | 906 | | | Overhead Control Panel(OCP/DBE) | / | ECU Information | / | Above Sprinter_V1.00 | / |
| SprinterIII | / | / | 906 | | | Overhead Control Panel(OCP/DBE) | / | Erase Codes | / | Above Sprinter_V1.00 | / |
| SprinterIII | / | / | 906 | | | Overhead Control Panel(OCP/DBE) | / | Live Data | / | Above Sprinter_V1.00 | / |
| SprinterIII | / | / | 906 | | | Overhead Control Panel(OCP/DBE) | / | Read Codes | / | Above Sprinter_V1.00 | / |
| SprinterIII | / | / | 906 | | | Parameterizable Special Module(PSM) | / | ECU Information | / | Above Sprinter_V1.00 | / |
| SprinterIII | / | / | 906 | | | Parameterizable Special Module(PSM) | / | Erase Codes | / | Above Sprinter_V1.00 | / |
| SprinterIII | / | / | 906 | | | Parameterizable Special Module(PSM) | / | Live Data | / | Above Sprinter_V1.00 | / |
| SprinterIII | / | / | 906 | | | Parameterizable Special Module(PSM) | / | Read Codes | / | Above Sprinter_V1.00 | / |
| SprinterIII | / | / | 906 | | | Positive Temperature Coefficient(PTC) Heater Booster(HB/ZH/ZUH) | / | ECU Information | / | Above Sprinter_V1.00 | / |
| SprinterIII | / | / | 906 | | | Positive Temperature Coefficient(PTC) Heater Booster(HB/ZH/ZUH) | / | Erase Codes | / | Above Sprinter_V1.00 | / |
| SprinterIII | / | / | 906 | | | Positive Temperature Coefficient(PTC) Heater Booster(HB/ZH/ZUH) | / | Live Data | / | Above Sprinter_V1.00 | / |
| SprinterIII | / | / | 906 | | | Positive Temperature Coefficient(PTC) Heater Booster(HB/ZH/ZUH) | / | Read Codes | / | Above Sprinter_V1.00 | / |
| SprinterIII | / | / | 906 | | | Radio | AUDIO906 | ECU Information | / | Above Sprinter_V1.00 | / |
| SprinterIII | / | / | 906 | | | Radio | AUDIO906 | Erase Codes | / | Above Sprinter_V1.00 | / |
| SprinterIII | / | / | 906 | | | Radio | AUDIO906 | Live Data | / | Above Sprinter_V1.00 | / |
| SprinterIII | / | / | 906 | | | Radio | AUDIO906 | Read Codes | / | Above Sprinter_V1.00 | / |
| SprinterIII | / | / | 906 | | | Radio | CDRSA906 | ECU Information | / | Above Sprinter_V1.00 | / |
| SprinterIII | / | / | 906 | | | Radio | CDRSA906 | Erase Codes | / | Above Sprinter_V1.00 | / |
| SprinterIII | / | / | 906 | | | Radio | CDRSA906 | Live Data | / | Above Sprinter_V1.00 | / |
| SprinterIII | / | / | 906 | | | Radio | CDRSA906 | Read Codes | / | Above Sprinter_V1.00 | / |
| SprinterIII | / | / | 906 | | | Right electric sliding door | / | ECU Information | / | Above Sprinter_V1.00 | / |
| SprinterIII | / | / | 906 | | | Right electric sliding door | / | Erase Codes | / | Above Sprinter_V1.00 | / |

| Vehicle Model | Year | Engine | Chassis | Series | Vehicle Type | System | Sub-system | Function | Sub-function | Version | Note |
|---------------|------|--------|---------|--------|--------------|----------------------------------------------|------------|-----------------|--------------|----------------------|------|
| SprinterIII | / | / | 906 | | | Right electric sliding door | / | Live Data | / | Above Sprinter_V1.00 | / |
| SprinterIII | / | / | 906 | | | Right electric sliding door | / | Read Codes | / | Above Sprinter_V1.00 | / |
| SprinterIII | / | / | 906 | | | SAM(Signal Acquisition and Actuation Module) | / | ECU Information | / | Above Sprinter_V1.00 | / |
| SprinterIII | / | / | 906 | | | SAM(Signal Acquisition and Actuation Module) | / | Erase Codes | / | Above Sprinter_V1.00 | / |
| SprinterIII | / | / | 906 | | | SAM(Signal Acquisition and Actuation Module) | / | Live Data | / | Above Sprinter_V1.00 | / |
| SprinterIII | / | / | 906 | | | SAM(Signal Acquisition and Actuation Module) | / | Read Codes | / | Above Sprinter_V1.00 | / |
| SprinterIII | / | / | 906 | | | Selective Catalytic Reduction(SCR GEN1) | / | ECU Information | / | Above Sprinter_V1.00 | / |
| SprinterIII | / | / | 906 | | | Selective Catalytic Reduction(SCR GEN1) | / | Erase Codes | / | Above Sprinter_V1.00 | / |
| SprinterIII | / | / | 906 | | | Selective Catalytic Reduction(SCR GEN1) | / | Live Data | / | Above Sprinter_V1.00 | / |
| SprinterIII | / | / | 906 | | | Selective Catalytic Reduction(SCR GEN1) | / | Read Codes | / | Above Sprinter_V1.00 | / |
| SprinterIII | / | / | 906 | | | Selective Catalytic Reduction(SCR) | / | ECU Information | / | Above Sprinter_V1.00 | / |
| SprinterIII | / | / | 906 | | | Selective Catalytic Reduction(SCR) | / | Erase Codes | / | Above Sprinter_V1.00 | / |
| SprinterIII | / | / | 906 | | | Selective Catalytic Reduction(SCR) | / | Live Data | / | Above Sprinter_V1.00 | / |
| SprinterIII | / | / | 906 | | | Selective Catalytic Reduction(SCR) | / | Read Codes | / | Above Sprinter_V1.00 | / |
| SprinterIII | / | / | 906 | | | Speedometer(Digital Tachograph (DTCO)) | / | ECU Information | / | Above Sprinter_V1.00 | / |
| SprinterIII | / | / | 906 | | | Speedometer(Digital Tachograph (DTCO)) | / | Erase Codes | / | Above Sprinter_V1.00 | / |
| SprinterIII | / | / | 906 | | | Speedometer(Digital Tachograph (DTCO)) | / | Live Data | / | Above Sprinter_V1.00 | / |
| SprinterIII | / | / | 906 | | | Speedometer(Digital Tachograph (DTCO)) | / | Read Codes | / | Above Sprinter_V1.00 | / |
| SprinterIII | / | / | 906 | | | Stationary Heater(STH) | / | ECU Information | / | Above Sprinter_V1.00 | / |
| SprinterIII | / | / | 906 | | | Stationary Heater(STH) | / | Erase Codes | / | Above Sprinter_V1.00 | / |
| SprinterIII | / | / | 906 | | | Stationary Heater(STH) | / | Live Data | / | Above Sprinter_V1.00 | / |
| SprinterIII | / | / | 906 | | | Stationary Heater(STH) | / | Read Codes | / | Above Sprinter_V1.00 | / |
| SprinterIII | / | / | 906 | | | Steering Column Module(SCM/MRM) | / | ECU Information | / | Above Sprinter_V1.00 | / |
| SprinterIII | / | / | 906 | | | Steering Column Module(SCM/MRM) | / | Erase Codes | / | Above Sprinter_V1.00 | / |
| SprinterIII | / | / | 906 | | | Steering Column Module(SCM/MRM) | / | Live Data | / | Above Sprinter_V1.00 | / |
| SprinterIII | / | / | 906 | | | Steering Column Module(SCM/MRM) | / | Read Codes | / | Above Sprinter_V1.00 | / |
| SprinterIII | / | / | 906 | | | Tire Pressure Monitor(TPM/RDK) | / | ECU Information | / | Above Sprinter_V1.00 | / |
| SprinterIII | / | / | 906 | | | Tire Pressure Monitor(TPM/RDK) | / | Erase Codes | / | Above Sprinter_V1.00 | / |
| SprinterIII | / | / | 906 | | | Tire Pressure Monitor(TPM/RDK) | / | Live Data | / | Above Sprinter_V1.00 | / |
| SprinterIII | / | / | 906 | | | Tire Pressure Monitor(TPM/RDK) | / | Read Codes | / | Above Sprinter_V1.00 | / |
| SprinterIII | / | / | 906 | | | Trailer recognition(AHE1) | / | ECU Information | / | Above Sprinter_V1.00 | / |
| SprinterIII | / | / | 906 | | | Trailer recognition(AHE1) | / | Erase Codes | / | Above Sprinter_V1.00 | / |

| Vehicle Model | Year | Engine | Chassis | Series | Vehicle Type | System | Sub-system | Function | Sub-function | Version | Note |
|---------------|------|--------|---------|--------|--------------|----------------------------------------------|------------|-----------------|--------------|----------------------|------|
| SprinterIII | / | / | 906 | | | Trailer recognition(AHE1) | / | Live Data | / | Above Sprinter_V1.00 | / |
| SprinterIII | / | / | 906 | | | Trailer recognition(AHE1) | / | Read Codes | / | Above Sprinter_V1.00 | / |
| SprinterIII | / | / | 906 | | | Trailer recognition(AHE2) | / | ECU Information | / | Above Sprinter_V1.00 | / |
| SprinterIII | / | / | 906 | | | Trailer recognition(AHE2) | / | Erase Codes | / | Above Sprinter_V1.00 | / |
| SprinterIII | / | / | 906 | | | Trailer recognition(AHE2) | / | Live Data | / | Above Sprinter_V1.00 | / |
| SprinterIII | / | / | 906 | | | Trailer recognition(AHE2) | / | Read Codes | / | Above Sprinter_V1.00 | / |
| SprinterIII | / | / | 906 | | | Upper Control Panel | / | ECU Information | / | Above Sprinter_V1.00 | / |
| SprinterIII | / | / | 906 | | | Upper Control Panel | / | Erase Codes | / | Above Sprinter_V1.00 | / |
| SprinterIII | / | / | 906 | | | Upper Control Panel | / | Live Data | / | Above Sprinter_V1.00 | / |
| SprinterIII | / | / | 906 | | | Upper Control Panel | / | Read Codes | / | Above Sprinter_V1.00 | / |
| SprinterIII | / | / | 906 | | | eCall Russia | / | ECU Information | / | Above Sprinter_V1.00 | / |
| SprinterIII | / | / | 906 | | | eCall Russia | / | Erase Codes | / | Above Sprinter_V1.00 | / |
| SprinterIII | / | / | 906 | | | eCall Russia | / | Live Data | / | Above Sprinter_V1.00 | / |
| SprinterIII | / | / | 906 | | | eCall Russia | / | Read Codes | / | Above Sprinter_V1.00 | / |
| SprinterIII | / | / | 906 | | | Control module 'Collision Prevention Assist' | / | ECU Information | / | Above Sprinter_V1.00 | / |
| SprinterIII | / | / | 906 | | | Control module 'Collision Prevention Assist' | / | Erase Codes | / | Above Sprinter_V1.00 | / |
| SprinterIII | / | / | 906 | | | Control module 'Collision Prevention Assist' | / | Live Data | / | Above Sprinter_V1.00 | / |
| SprinterIII | / | / | 906 | | | Control module 'Collision Prevention Assist' | / | Read Codes | / | Above Sprinter_V1.00 | / |
| SprinterIII | / | / | 906 | | | Multifunction camera | / | ECU Information | / | Above Sprinter_V1.00 | / |
| SprinterIII | / | / | 906 | | | Multifunction camera | / | Erase Codes | / | Above Sprinter_V1.00 | / |
| SprinterIII | / | / | 906 | | | Multifunction camera | / | Live Data | / | Above Sprinter_V1.00 | / |
| SprinterIII | / | / | 906 | | | Multifunction camera | / | Read Codes | / | Above Sprinter_V1.00 | / |
| SprinterIII | / | / | 906 | | | Headlamp range adjustment | / | ECU Information | / | Above Sprinter_V1.00 | / |
| SprinterIII | / | / | 906 | | | Headlamp range adjustment | / | Erase Codes | / | Above Sprinter_V1.00 | / |
| SprinterIII | / | / | 906 | | | Headlamp range adjustment | / | Live Data | / | Above Sprinter_V1.00 | / |
| SprinterIII | / | / | 906 | | | Headlamp range adjustment | / | Read Codes | / | Above Sprinter_V1.00 | / |