

**Note** X: Covered \*: New update

Mini V10.0									
Model Information					Diagnostic Function				
Mark et	Year	Model	Type	System	ECU Info.	DTC	Data List	Active Test	Special Func.
All	2001-2006	MINI_R50/R52/R53	MINI_ONE,COOPER,COOPER_S	Quick test (Only for Drive systems)	X	X			
All	2001-2006	MINI_R50/R52/R53	MINI_ONE,COOPER,COOPER_S	DME Digital Engine/Gearbox Electronics 2	X	X	X	X	
All	2001-2006	MINI_R50/R52/R53	MINI_ONE,COOPER,COOPER_S	EWS Electronic immobilizer	X	X	X		
All	2001-2006	MINI_R50/R52/R53	MINI_ONE,COOPER,COOPER_S	Quick test (Only for Drive systems)	X	X			
All	2001-2006	MINI_R50/R52/R53	MINI_ONE,COOPER,COOPER_S	ABS/ASC/DSC Dynamic Stability control	X	X	X	X	
All	2001-2006	MINI_R50/R52/R53	MINI_ONE,COOPER,COOPER_S	EHPS Electro-hydraulic steering assistance	X	X	X	X	
All	2001-2006	MINI_R50/R52/R53	MINI_ONE,COOPER,COOPER_S	LEW Steering-angle sensor	X	X	X		
All	2001-2006	MINI_R50/R52/R53	MINI_ONE,COOPER,COOPER_S	Quick test (Only for Body systems)	X	X			
All	2001-2006	MINI_R50/R52/R53	MINI_ONE,COOPER,COOPER_S	RLS/AIC (Rain/Light Sensor/Automatic interval Control)	X	X			
All	2001-2006	MINI_R50/R52/R53	MINI_ONE,COOPER,COOPER_S	BM On-board monitor	X				
All	2001-2006	MINI_R50/R52/R53	MINI_ONE,COOPER,COOPER_S	KOM Instrument cluster	X	X	X	X	
All	2001-2006	MINI_R50/R52/R53	MINI_ONE,COOPER,COOPER_S	KOMBI2 additional Instruments	X				
All	2001-2006	MINI_R50/R52/R53	MINI_ONE,COOPER,COOPER_S	IHKA Heater/automatic A/C control	X	X	X	X	
All	2001-2006	MINI_R50/R52/R53	MINI_ONE,COOPER,COOPER_S	MFL Multifunction steering wheel I	X	X	X		
All	2001-2006	MINI_R50/R52/R53	MINI_ONE,COOPER,COOPER_S	MRS Multiple Restraint System IV	X	X			
All	2001-2006	MINI_R50/R52/R53	MINI_ONE,COOPER,COOPER_S	LRA Headlight vertical aim control	X	X	X	X	
All	2001-2006	MINI_R50/R52/R53	MINI_ONE,COOPER,COOPER_S	NAV Navigation computer, Europe	X	X	X		
All	2001-2006	MINI_R50/R52/R53	MINI_ONE,COOPER,COOPER_S	PDC Park Distance Control	X	X	X	X	
All	2001-2006	MINI_R50/R52/R53	MINI_ONE,COOPER,COOPER_S	RAD Radio	X	X	X	X	
All	2001-2006	MINI_R50/R52/R53	MINI_ONE,COOPER,COOPER_S	CVM Convertible top module	X	X	X	X	
All	2001-2006	MINI_R50/R52/R53	MINI_ONE,COOPER,COOPER_S	STH park heating	X				
All	2001-2006	MINI_R50/R52/R53	MINI_ONE,COOPER,COOPER_S	SHD Sliding/tilting sunroof module	X	X			
All	2001-2006	MINI_R50/R52/R53	MINI_ONE,COOPER,COOPER_S	ZKE Central body electronics BC 1	X	X	X	X	
All	2001-2006	MINI_R50/R52/R53	MINI_ONE,COOPER,COOPER_S	DriveDigital Motor Electronics					Clear adaptations X
All	2001-2006	MINI_R50/R52/R53	MINI_ONE,COOPER,COOPER_S	DriveEGS transmission control					Clear adaptations X
All	2001-2006	MINI_R50/R52/R53	MINI_ONE,COOPER,COOPER_S	DriveElectronic car immobilisation system					Disable/enable key X
All	2001-2006	MINI_R50/R52/R53	MINI_ONE,COOPER,COOPER_S	BodyInstrument cluster					Reset service interval indicator X
All	2007-2010	MINI_R55/R56/R57	MINI_ONE,COOPER,COOPER_S,C OOPER_D	Quick test	X	X			
All	2007-2010	MINI_R55/R56/R57	MINI_ONE,COOPER,COOPER_S,C OOPER_D	CAS Car Access System	X	X	X	X	
All	2007-2010	MINI_R55/R56/R57	MINI_ONE,COOPER,COOPER_S,C OOPER_D	EGS transmission control	X	X	X	X	

All	2007-2010	MINI_R55/R56/R57	MINI_ONE,COOPER,COOPER_S,C OOPER_D	DME Motor Electronics	X	X	X	X	
All	2007-2010	MINI_R55/R56/R57	MINI_ONE,COOPER,COOPER_S,C OOPER_D	DDE Diesel Electronics	X	X	X	X	
All	2007-2010	MINI_R55/R56/R57	MINI_ONE,COOPER,COOPER_S,C OOPER_D	EPS Electronic Power Steering	X	X	X	X	
All	2007-2010	MINI_R55/R56/R57	MINI_ONE,COOPER,COOPER_S,C OOPER_D	DSC Dynamic Stability Control	X	X	X	X	
All	2007-2010	MINI_R55/R56/R57	MINI_ONE,COOPER,COOPER_S,C OOPER_D	Quick test	X	X			
All	2007-2010	MINI_R55/R56/R57	MINI_ONE,COOPER,COOPER_S,C OOPER_D	RAD2-BO User interface	X	X	X	X	
All	2007-2010	MINI_R55/R56/R57	MINI_ONE,COOPER,COOPER_S,C OOPER_D	RAD2-GW Gateway	X	X	X	X	
All	2007-2010	MINI_R55/R56/R57	MINI_ONE,COOPER,COOPER_S,C OOPER_D	FRM/FRM2 Footwell module	X	X	X	X	
All	2007-2010	MINI_R55/R56/R57	MINI_ONE,COOPER,COOPER_S,C OOPER_D	IHKS Integrated heating/air-conditioning control	X	X	X	X	
All	2007-2010	MINI_R55/R56/R57	MINI_ONE,COOPER,COOPER_S,C OOPER_D	IHKA Integrated heating /air conditioning	X	X	X	X	
All	2007-2010	MINI_R55/R56/R57	MINI_ONE,COOPER,COOPER_S,C OOPER_D	IHS Heater control	X	X	X	X	
	2007-2010	MINI_R55/R56/R57	MINI_ONE,COOPER,COOPER_S,C OOPER_D	CA Comfort Access	X	X	X	X	
All	2007-2010	MINI_R55/R56/R57	MINI_ONE,COOPER,COOPER_S,C OOPER_D	JBE Junction-box electronics	X	X	X	X	
All	2007-2010	MINI_R55/R56/R57	MINI_ONE,COOPER,COOPER_S,C OOPER_D	INSTR Instrument cluster	X	X	X	X	
All	2007-2010	MINI_R55/R56/R57	MINI_ONE,COOPER,COOPER_S,C OOPER_D	MRS Multiple Restraint System	X	X	X		
All	2007-2010	MINI_R55/R56/R57	MINI_ONE,COOPER,COOPER_S,C OOPER_D	SZL Switch center,steering column	X	X	X		
All	2007-2010	MINI_R55/R56/R57	MINI_ONE,COOPER,COOPER_S,C OOPER_D	AMP Amplifier	X	X	X	X	
All	2007-2010	MINI_R55/R56/R57	MINI_ONE,COOPER,COOPER_S,C OOPER_D	SHD Sliding/tilting sunroof module	X	X	X	X	
All	2007-2010	MINI_R55/R56/R57	MINI_ONE,COOPER,COOPER_S,C OOPER_D	Maintenance\CBS reset					1 Engine oil X
All	2007-2010	MINI_R55/R56/R57	MINI_ONE,COOPER,COOPER_S,C OOPER_D	Maintenance\CBS reset					3 Front brake X
All	2007-2010	MINI_R55/R56/R57	MINI_ONE,COOPER,COOPER_S,C OOPER_D	Maintenance\CBS reset					4 Rear brake X
All	2007-2010	MINI_R55/R56/R57	MINI_ONE,COOPER,COOPER_S,C OOPER_D	Maintenance\CBS reset					8 Brake fluid X

All	2007-2010	MINI_R55/R56/R57	MINI_ONE,COOPER,COOPER_S,C OOPER_D	Maintenance\CBS reset					9 Vehicle check X
All	2007-2010	MINI_R55/R56/R57	MINI_ONE,COOPER,COOPER_S,C OOPER_D	Maintenance\CBS reset					10 Vehicle inspection: X
	2007-2010	MINI_R55/R56/R57	MINI_ONE,COOPER,COOPER_S,C OOPER_D	Maintenance\CBS reset					11 Exhaust emission inspection: X
All	2007-2010	MINI_R55/R56/R57	MINI_ONE,COOPER,COOPER_S,C OOPER_D	Maintenance\CBS reset					12 Vehicle check-linked X
All				Maintenance\					CBS correction, vehicle data
All				Body\JBE Junction-box electronics					Start windows initalisation
All				Chassis\DSC Dynamic Stability Control					DSC Sensor Calibration
All				Chassis\SZL Switch center, steeing column					Steering angle sensor adjustment
All		Coding/Program		ALIGNMENT EWS-DME					ALIGNMENT EWS-DME X