

Note X: Covered *: New update

| EurFord V10.0 | | | | | | | | |
|-------------------|----------|-------------------------------|---|---------------------|-----|-----------|-------------|---------------|
| Model Information | | | | Diagnostic Function | | | | |
| Market | Model | Class | System | ECU Info. | DTC | Data List | Active Test | Special Func. |
| AII | COUGAR | 3.8L | PCM - Powertrain Control Module | | X | X | X | |
| AII | COUGAR | 3.8L | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| AII | COUGAR | 3.8L | ARC - Automatic Ride Control | | X | X | X | |
| AII | COUGAR | 4.6L | PCM - Powertrain Control Module | | X | X | X | |
| AII | COUGAR | 4.6L | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| AII | COUGAR | 4.6L | ARC - Automatic Ride Control | | X | X | X | |
| AII | COUGAR | 3.8L(DURATEC-VE) | PCM - Powertrain Control Module | | X | X | | |
| AII | COUGAR | 4.6L(DURATEC-VE) | PCM - Powertrain Control Module | | X | X | | |
| AII | ECONOVAN | 1.4L (2BL OHC) | PCM - Powertrain Control Module | | X | X | X | |
| AII | ECONOVAN | 1.4L (2BL OHC) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| AII | ECONOVAN | 2.0L (DIESEL) | PCM - Powertrain Control Module | | X | X | X | |
| AII | ECONOVAN | 2.0L (DIESEL) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| AII | ESCORT | 1.3L (CFI/HCS/SFI) | PCM - Powertrain Control Module | | X | X | X | |
| AII | ESCORT | 1.3L (CFI/HCS/SFI) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| AII | ESCORT | 1.3L (CFI/HCS/SFI) | CSM - Security module | | X | X | X | |
| AII | ESCORT | 1.3L (CFI/HCS/SFI) | HEC - Hybrid Electronic Cluster | | X | X | X | |
| AII | ESCORT | 1.3L (CFI/HCS/SFI) | PATS - Passive Anti-Theft System | | X | X | X | |
| AII | ESCORT | 1.4L (HCS/CVH/EFI/SFI) | PCM - Powertrain Control Module | | X | X | X | |
| AII | ESCORT | 1.4L (HCS/CVH/EFI/SFI) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| AII | ESCORT | 1.4L (HCS/CVH/EFI/SFI) | CSM - Security module | | X | X | X | |
| AII | ESCORT | 1.4L (HCS/CVH/EFI/SFI) | HEC - Hybrid Electronic Cluster | | X | X | X | |
| AII | ESCORT | 1.4L (HCS/CVH/EFI/SFI) | PATS - Passive Anti-Theft System | | X | X | X | |
| AII | ESCORT | 1.6L (SFI) | PCM - Powertrain Control Module | | X | X | X | |
| AII | ESCORT | 1.6L (SFI) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| AII | ESCORT | 1.6L (SFI) | CSM - Security module | | X | X | X | |
| AII | ESCORT | 1.6L (SFI) | HEC - Hybrid Electronic Cluster | | X | X | X | |
| AII | ESCORT | 1.6L (SFI) | PATS - Passive Anti-Theft System | | X | X | X | |
| AII | ESCORT | 1.8L (DIESEL/SFI/T-DIESEL) | PCM - Powertrain Control Module | | X | X | X | |
| AII | ESCORT | 1.8L (DIESEL/SFI/T-DIESEL) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| AII | ESCORT | 1.8L (DIESEL/SFI/T-DIESEL) | CSM - Security module | | X | X | X | |
| AII | ESCORT | 1.8L (DIESEL/SFI/T-DIESEL) | HEC - Hybrid Electronic Cluster | | X | X | X | |
| AII | ESCORT | 1.8L (DIESEL/SFI/T-DIESEL) | PATS - Passive Anti-Theft System | | X | X | X | |
| AII | ESCORT | 1.8L (DIESEL/SFI/T-DIESEL) | IABM - Integrated Air Bag Module | | X | X | X | |
| AII | ESCORT | 2.0L (MPI 16V/COSWORTH TURBO) | PCM - Powertrain Control Module | | X | X | X | |
| AII | ESCORT | 2.0L (MPI 16V/COSWORTH TURBO) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |

| | | | | | | | | |
|-----|----------|-------------------------------|---|--|---|---|---|--|
| AII | ESCORT | 2.0L (MPI 16V/COSWORTH TURBO) | CSM - Security module | | X | X | X | |
| AII | ESCORT | 2.0L (MPI 16V/COSWORTH TURBO) | HEC - Hybrid Electronic Cluster | | X | X | X | |
| AII | ESCORT | 2.0L (MPI 16V/COSWORTH TURBO) | PATS - Passive Anti-Theft System | | X | X | X | |
| AII | ESCORT | 2.0L (MPI 16V/COSWORTH TURBO) | IABM - Integrated Air Bag Module | | X | X | X | |
| AII | ESCORT | 1.8L(Endura-DE) | PCM - Powertrain Control Module | | X | X | | |
| AII | ESCORT | 1.3L(Endura-E) | PCM - Powertrain Control Module | | X | X | | |
| AII | ESCORT | 1.6L(Zetec) | PCM - Powertrain Control Module | | X | X | | |
| AII | ESCORT | 1.8L(Zetec) | PCM - Powertrain Control Module | | X | X | | |
| AII | ESCORT | 1.9L(Other) | PCM - Powertrain Control Module | | X | X | | |
| AII | ESCORT | 1.8L(Other) | PCM - Powertrain Control Module | | X | X | | |
| AII | ESCORT | 1.8L(Other) | PCM - Powertrain Control Module | | X | X | | |
| AII | EXPLORER | 4.0L (SOHC SFI) | PCM - Powertrain Control Module | | X | X | X | |
| AII | EXPLORER | 4.0L (SOHC SFI) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| AII | EXPLORER | 4.0L (SOHC SFI) | ARC - Automatic Ride Control | | X | X | X | |
| AII | EXPLORER | 4.0L (SOHC SFI) | EATC - Electronic Automatic Temperature Control | | X | X | X | |
| AII | EXPLORER | 4.0L (SOHC SFI) | GEM - Generic electric module(CTM) | | X | X | X | |
| AII | EXPLORER | 4.0L (SOHC SFI) | IABM - Integrated Air Bag Module | | X | X | X | |
| AII | EXPLORER | 4.0L (SOHC SFI) | RAP - Remote Anti-Theft / Personality Module | | X | X | X | |
| AII | EXPLORER | 5.0L | PCM - Powertrain Control Module | | X | X | X | |
| AII | EXPLORER | 5.0L | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| AII | EXPLORER | 5.0L | ARC - Automatic Ride Control | | X | X | X | |
| AII | EXPLORER | 5.0L | EATC - Electronic Automatic Temperature Control | | X | X | X | |
| AII | EXPLORER | 5.0L | GEM - Generic electric module(CTM) | | X | X | X | |
| AII | EXPLORER | 5.0L | IABM - Integrated Air Bag Module | | X | X | X | |
| AII | EXPLORER | 5.0L | RAP - Remote Anti-Theft / Personality Module | | X | X | X | |
| AII | EXPLORER | 4.0L(V6-OHV) | PCM - Powertrain Control Module | | X | X | | |
| AII | EXPLORER | 4.0L(V6-OHV) | GEM - Generic electric module(CTM) | | X | X | | |
| AII | EXPLORER | 4.0L(Other) | PCM - Powertrain Control Module | | X | X | | |
| AII | EXPLORER | 4.0L(Other) | GEM - Generic electric module(CTM) | | X | X | | |
| AII | EXPLORER | 5.0L(Other) | PCM - Powertrain Control Module | | X | X | | |
| AII | EXPLORER | 5.0L(Other) | GEM - Generic electric module(CTM) | | X | X | | |
| AII | FIESTA | 1.1L (CFI) | PCM - Powertrain Control Module | | X | X | X | |
| AII | FIESTA | 1.1L (CFI) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| AII | FIESTA | 1.1L (CFI) | IABM - Integrated Air Bag Module | | X | X | X | |
| AII | FIESTA | 1.25L (SFI) | PCM - Powertrain Control Module | | X | X | X | |
| AII | FIESTA | 1.25L (SFI) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| AII | FIESTA | 1.25L (SFI) | IABM - Integrated Air Bag Module | | X | X | X | |
| AII | FIESTA | 1.3L (CFI/SFI) | PCM - Powertrain Control Module | | X | X | X | |
| AII | FIESTA | 1.3L (CFI/SFI) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| AII | FIESTA | 1.3L (CFI/SFI) | IABM - Integrated Air Bag Module | | X | X | X | |
| AII | FIESTA | 1.4L (SFI) | PCM - Powertrain Control Module | | X | X | X | |
| AII | FIESTA | 1.4L (SFI) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| AII | FIESTA | 1.4L (SFI) | IABM - Integrated Air Bag Module | | X | X | X | |
| AII | FIESTA | 1.6L (SFI) | PCM - Powertrain Control Module | | X | X | X | |
| AII | FIESTA | 1.6L (SFI) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |

| | | | | | | | | |
|-----|--------|-------------------------------|---|--|---|---|---|---|
| AII | FIESTA | 1.6L (SFI) | IABM - Integrated Air Bag Module | | X | X | X | |
| AII | FIESTA | 1.8L (DIESEL/SFI 105/SFI 130) | PCM - Powertrain Control Module | | X | X | X | 1.Fuel Injector Coding. 2.Key Programming. |
| AII | FIESTA | 1.8L (DIESEL/SFI 105/SFI 130) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| AII | FIESTA | 1.8L (DIESEL/SFI 105/SFI 130) | IABM - Integrated Air Bag Module | | X | X | X | |
| AII | GALAXY | 1.9L (DIESEL) | PCM - Powertrain Control Module | | X | | | |
| AII | GALAXY | 1.9L (DIESEL) | TCM - Transmission Control Module | | X | | | |
| AII | GALAXY | 1.9L (DIESEL) | ABS - Anti-Lock Brake / Traction Control Module | | X | | | |
| AII | GALAXY | 1.9L (DIESEL) | RCM - Restraint Control Module | | X | | | |
| AII | GALAXY | 1.9L (DIESEL) | ICM - Instrument Cluster | | X | | | |
| AII | GALAXY | 1.9L (DIESEL) | NAV - Navigation System | | X | | | |
| AII | GALAXY | 2.0L (SFI DOHC) | PCM - Powertrain Control Module | | X | | | |
| AII | GALAXY | 2.0L (SFI DOHC) | TCM - Transmission Control Module | | X | | | |
| AII | GALAXY | 2.0L (SFI DOHC) | ABS - Anti-Lock Brake / Traction Control Module | | X | | | |
| AII | GALAXY | 2.0L (SFI DOHC) | RCM - Restraint Control Module | | X | | | |
| AII | GALAXY | 2.0L (SFI DOHC) | ICM - Instrument Cluster | | X | | | |
| AII | GALAXY | 2.0L (SFI DOHC) | NAV - Navigation System | | X | | | |
| AII | GALAXY | 2.3L (DOHC 16V) | PCM - Powertrain Control Module | | X | | | |
| AII | GALAXY | 2.3L (DOHC 16V) | TCM - Transmission Control Module | | X | | | |
| AII | GALAXY | 2.3L (DOHC 16V) | ABS - Anti-Lock Brake / Traction Control Module | | X | | | |
| AII | GALAXY | 2.3L (DOHC 16V) | RCM - Restraint Control Module | | X | | | |
| AII | GALAXY | 2.3L (DOHC 16V) | ICM - Instrument Cluster | | X | | | |
| AII | GALAXY | 2.3L (DOHC 16V) | NAV - Navigation System | | X | | | |
| AII | GALAXY | 2.8L (V6 SFI) | PCM - Powertrain Control Module | | X | | | |
| AII | GALAXY | 2.8L (V6 SFI) | TCM - Transmission Control Module | | X | | | |
| AII | GALAXY | 2.8L (V6 SFI) | ABS - Anti-Lock Brake / Traction Control Module | | X | | | |
| AII | GALAXY | 2.8L (V6 SFI) | RCM - Restraint Control Module | | X | | | |
| AII | GALAXY | 2.8L (V6 SFI) | ICM - Instrument Cluster | | X | | | |
| AII | GALAXY | 2.8L (V6 SFI) | NAV - Navigation System | | X | | | |
| AII | RANGER | 2.2L (F2) | PCM - Powertrain Control Module | | X | X | | |
| AII | RANGER | 2.2L (F2) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | | |
| AII | RANGER | 2.6L (G6) | PCM - Powertrain Control Module | | X | X | | |
| AII | RANGER | 2.6L (G6) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | | |
| AII | KA | 1.3L (SFI) | PCM - Powertrain Control Module | | X | X | | |
| AII | KA | 1.3L (SFI) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | | |
| AII | KA | 1.3L (SFI) | ECS - Electronic Crash Sensor(or IABM) | | X | X | | |
| AII | KA | 1.3L (SFI) | EPS - Electronic Controlled Power Steering | | X | X | | |
| AII | KA | 1.3L (SFI) | GEM - Generic electric module(CTM) | | X | X | | |
| AII | KA | 1.3L (SFI) | PATS - Passive Anti-Theft System | | X | X | | |
| AII | KA | 1.6L | PCM - Powertrain Control Module | | X | X | | |
| AII | KA | 1.6L | ABS - Anti-Lock Brake / Traction Control Module | | X | X | | |
| AII | KA | 1.6L | ECS - Electronic Crash Sensor(or IABM) | | X | X | | |
| AII | KA | 1.6L | EPS - Electronic Controlled Power Steering | | X | X | | |
| AII | KA | 1.6L | GEM - Generic electric module(CTM) | | X | X | | |

| | | | | | | | | |
|-----|------------------------|----------------|---|--|---|---|--|--|
| All | KA | 1.6L | PATS - Passive Anti-Theft System | | X | X | | |
| All | MAVERICK | 2.4L (SFI) | PCM - Powertrain Control Module | | X | X | | |
| All | MAVERICK | 2.4L (SFI) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | | |
| All | MAVERICK | 2.4L (SFI) | RCM - Restraint Control Module | | X | X | | |
| All | MAVERICK | 2.4L (SFI) | GEM - Generic electric module(CTM) | | X | X | | |
| All | MAVERICK | 2.4L (SFI) | PAM - Parking Aid Module | | X | X | | |
| All | MAVERICK | 2.4L (SFI) | 4X4M - 4X4 Control Module | | X | X | | |
| All | MAVERICK | 2.7L(T-DIESEL) | PCM - Powertrain Control Module | | X | X | | |
| All | MAVERICK | 2.7L(T-DIESEL) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | | |
| All | MAVERICK | 2.7L(T-DIESEL) | RCM - Restraint Control Module | | X | X | | |
| All | MAVERICK | 2.7L(T-DIESEL) | GEM - Generic electric module(CTM) | | X | X | | |
| All | MAVERICK | 2.7L(T-DIESEL) | PAM - Parking Aid Module | | X | X | | |
| All | MAVERICK | 2.7L(T-DIESEL) | 4X4M - 4X4 Control Module | | X | X | | |
| All | F-SERIES SUPER DUTY | 5.4L | PCM - Powertrain Control Module | | X | | | |
| All | F-SERIES SUPER DUTY | 5.4L | ABS - Anti-Lock Brake / Traction Control Module | | X | X | | |
| All | F-SERIES SUPER DUTY | 5.4L | RCM - Restraint Control Module | | X | X | | |
| All | F-SERIES SUPER DUTY | 5.4L | TCM - Transmission Control Module | | X | X | | |
| All | F-SERIES SUPER DUTY | 5.4L | ICM - Instrument Cluster | | X | X | | |
| All | F-SERIES SUPER DUTY | 5.4L | GEM - Generic electric module(CTM) | | X | X | | |
| All | F-SERIES SUPER DUTY | 5.4L | PATS - Passive Anti-Theft System | | X | X | | |
| All | F-SERIES SUPER DUTY | 6.0L | PCM - Powertrain Control Module | | X | | | |
| All | F-SERIES SUPER DUTY | 6.0L | ABS - Anti-Lock Brake / Traction Control Module | | X | X | | |
| All | F-SERIES SUPER DUTY | 6.0L | RCM - Restraint Control Module | | X | X | | |
| All | F-SERIES SUPER DUTY | 6.0L | TCM - Transmission Control Module | | X | X | | |
| All | F-SERIES SUPER DUTY | 6.0L | ICM - Instrument Cluster | | X | X | | |
| All | F-SERIES SUPER DUTY | 6.0L | GEM - Generic electric module(CTM) | | X | X | | |
| All | F-SERIES SUPER DUTY | 6.0L | PATS - Passive Anti-Theft System | | X | X | | |
| All | F-SERIES SUPER DUTY | 6.8L | PCM - Powertrain Control Module | | X | | | |

| | | | | | | | | |
|-----|------------------------|---------------------|---|--|---|---|---|--------------------|
| All | F-SERIES SUPER DUTY | 6.8L | ABS - Anti-Lock Brake / Traction Control Module | | X | X | | |
| All | F-SERIES SUPER DUTY | 6.8L | RCM - Restraint Control Module | | X | X | | |
| All | F-SERIES SUPER DUTY | 6.8L | TCM - Transmission Control Module | | X | X | | |
| All | F-SERIES SUPER DUTY | 6.8L | ICM - Instrument Cluster | | X | X | | |
| All | F-SERIES SUPER DUTY | 6.8L | GEM - Generic electric module(CTM) | | X | X | | |
| All | F-SERIES SUPER DUTY | 6.8L | PATS - Passive Anti-Theft System | | X | X | | |
| All | F-SERIES SUPER DUTY | 7.3L | PCM - Powertrain Control Module | | X | | | |
| All | F-SERIES SUPER DUTY | 7.3L | ABS - Anti-Lock Brake / Traction Control Module | | X | X | | |
| All | F-SERIES SUPER DUTY | 7.3L | RCM - Restraint Control Module | | X | X | | |
| All | F-SERIES SUPER DUTY | 7.3L | TCM - Transmission Control Module | | X | X | | |
| All | F-SERIES SUPER DUTY | 7.3L | ICM - Instrument Cluster | | X | X | | |
| All | F-SERIES SUPER DUTY | 7.3L | GEM - Generic electric module(CTM) | | X | X | | |
| All | F-SERIES SUPER DUTY | 7.3L | PATS - Passive Anti-Theft System | | X | X | | |
| All | MONDEO | 1.6L (SFI) | PCM - Powertrain Control Module | | X | X | X | |
| All | MONDEO | 1.6L (SFI) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| All | MONDEO | 1.6L (SFI) | PATS - Passive Anti-Theft System | | X | | | 1.Key Programming. |
| All | MONDEO | 1.6L (SFI) | RIM - Remote Anti-Theft / Personality Module | | X | X | X | |
| All | MONDEO | 1.8L (SFI/T-DIESEL) | PATS - Passive Anti-Theft System | | X | | | 1.Key Programming. |
| All | MONDEO | 1.8L (SFI/T-DIESEL) | RIM - Remote Anti-Theft / Personality Module | | X | X | X | |
| All | MONDEO | 2.0L (SFI) | PCM - Powertrain Control Module | | X | X | X | |
| All | MONDEO | 2.0L (SFI) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| All | MONDEO | 2.0L (SFI) | PATS - Passive Anti-Theft System | | X | | | 1.Key Programming. |
| All | MONDEO | 2.0L (SFI) | RIM - Remote Anti-Theft / Personality Module | | X | X | X | |
| All | MONDEO | 2.5L (SFI) | PCM - Powertrain Control Module | | X | X | X | |
| All | MONDEO | 2.5L (SFI) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| All | MONDEO | 2.5L (SFI) | PATS - Passive Anti-Theft System | | X | | | 1.Key Programming. |
| All | MONDEO | 2.5L (SFI) | RIM - Remote Anti-Theft / Personality Module | | X | X | X | |
| All | PROBE | 2.0L (MPI) | PCM - Powertrain Control Module | | X | X | X | |
| All | PROBE | 2.0L (MPI) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| All | PROBE | 2.2L (MPI) | PCM - Powertrain Control Module | | X | X | X | |
| All | PROBE | 2.2L (MPI) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |

| | | | | | | | | |
|-----|-------------------|-------------------------|---|--|---|---|---|---|
| AII | PROBE | 2.5L (MPI) | PCM - Powertrain Control Module | | X | X | X | |
| AII | PROBE | 2.5L (MPI) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| AII | SCORPIO | 2.0L (16V DOHC/8V DOHC) | PCM - Powertrain Control Module | | X | X | X | |
| AII | SCORPIO | 2.0L (16V DOHC/8V DOHC) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| AII | SCORPIO | 2.3L (16V DOHC) | PCM - Powertrain Control Module | | X | X | X | |
| AII | SCORPIO | 2.3L (16V DOHC) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| AII | SCORPIO | 2.5L (DIESEL) | PCM - Powertrain Control Module | | X | X | X | |
| AII | SCORPIO | 2.5L (DIESEL) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| AII | SCORPIO | 2.9L (12V V6/24V V6) | PCM - Powertrain Control Module | | X | X | X | |
| AII | SCORPIO | 2.9L (12V V6/24V V6) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| AII | TRANSIT | 2.0L (MPI/SFI 8V) | PCM - Powertrain Control Module | | X | X | X | |
| AII | TRANSIT | 2.0L (MPI/SFI 8V) | PATS - Passive Anti-Theft System | | X | | X | 1.Key Programming. |
| AII | TRANSIT | 2.5L (DIESEL/T-DIESEL) | PCM - Powertrain Control Module | | X | X | X | 1.Fuel Injector Coding. 2.Key Programming. |
| AII | TRANSIT | 2.5L (DIESEL/T-DIESEL) | PATS - Passive Anti-Theft System | | X | | | 1.Key Programming. |
| AII | WINDSTAR | 3.0L (V6 SFI) | PCM - Powertrain Control Module | | X | X | X | |
| AII | WINDSTAR | 3.0(V6-OHV) | PCM - Powertrain Control Module | | X | X | | |
| AII | WINDSTAR | 3.0(V6-OHV) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | | |
| AII | WINDSTAR | 3.0(V6-OHV) | GEM - Generic electric module(CTM) | | X | X | | |
| AII | WINDSTAR | 3.8(V6-OHV) | PCM - Powertrain Control Module | | X | X | | |
| AII | WINDSTAR | 3.8(V6-OHV) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | | |
| AII | WINDSTAR | 3.8(V6-OHV) | GEM - Generic electric module(CTM) | | X | X | | |
| AII | CROWN VICTORIA | 4.6L(2V) | PCM - Powertrain Control Module | | X | X | | |
| AII | CROWN VICTORIA | 4.6L(2V) | PCM - Powertrain Control Module | | X | X | | |
| AII | AEROSTAR | 3.0L(Other) | PCM - Powertrain Control Module | | X | X | | |
| AII | AEROSTAR | 4.0L(Other) | PCM - Powertrain Control Module | | X | X | | |
| AII | CONTOUR | 2.0L | PCM - Powertrain Control Module | | X | X | X | |
| AII | CONTOUR | 2.0L | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| AII | CONTOUR | 2.0L | IABM - Integrated Air Bag Module | | X | X | X | |
| AII | CONTOUR | 2.5L | PCM - Powertrain Control Module | | X | X | X | |
| AII | CONTOUR | 2.5L | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| AII | CONTOUR | 2.5L | IABM - Integrated Air Bag Module | | X | X | X | |
| AII | COUGAR | 3.8L | PCM - Powertrain Control Module | | X | X | X | |
| AII | COUGAR | 3.8L | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| AII | COUGAR | 3.8L | ARC - Automatic Ride Control | | X | X | X | |
| AII | COUGAR | 4.6L | PCM - Powertrain Control Module | | X | X | X | |
| AII | COUGAR | 4.6L | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| AII | COUGAR | 4.6L | ARC - Automatic Ride Control | | X | X | X | |
| AII | COUGAR | 3.8L(2V) | PCM - Powertrain Control Module | | X | X | | |
| AII | COUGAR | 4.6L(2V) | PCM - Powertrain Control Module | | X | X | | |
| AII | ECONOVAN | 1.4L (2BL OHC) | PCM - Powertrain Control Module | | X | X | X | |
| AII | ECONOVAN | 1.4L (2BL OHC) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |

| | | | | | | | | |
|-----|----------|----------------------------|---|--|---|---|---|--|
| AII | ECONOVAN | 2.0L (DIESEL) | PCM - Powertrain Control Module | | X | X | X | |
| AII | ECONOVAN | 2.0L (DIESEL) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| AII | ESCORT | 1.3L (CFI/HCS/SFI) | PCM - Powertrain Control Module | | X | X | X | |
| AII | ESCORT | 1.3L (CFI/HCS/SFI) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| AII | ESCORT | 1.3L (CFI/HCS/SFI) | PATS - Passive Anti-Theft System | | X | X | X | |
| AII | ESCORT | 1.4L (HCS/CVH/EFI/SFI) | PCM - Powertrain Control Module | | X | X | X | |
| AII | ESCORT | 1.4L (HCS/CVH/EFI/SFI) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| AII | ESCORT | 1.4L (HCS/CVH/EFI/SFI) | PATS - Passive Anti-Theft System | | X | X | X | |
| AII | ESCORT | 1.6L (SFI) | PCM - Powertrain Control Module | | X | X | X | |
| AII | ESCORT | 1.6L (SFI) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| AII | ESCORT | 1.6L (SFI) | PATS - Passive Anti-Theft System | | X | X | X | |
| AII | ESCORT | 1.8L (DIESEL/SFI/T-DIESEL) | PCM - Powertrain Control Module | | X | X | X | |
| AII | ESCORT | 1.8L (DIESEL/SFI/T-DIESEL) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| AII | ESCORT | 1.8L (DIESEL/SFI/T-DIESEL) | PATS - Passive Anti-Theft System | | X | X | X | |
| AII | ESCORT | 2.0L (MPI 16V) | PCM - Powertrain Control Module | | X | X | X | |
| AII | ESCORT | 2.0L (MPI 16V) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| AII | ESCORT | 2.0L (MPI 16V) | RAP - Remote Anti-Theft / Personality Module | | X | X | X | |
| AII | ESCORT | 2.0L (MPI 16V) | CSM - Security module | | X | X | X | |
| AII | ESCORT | 2.0L (MPI 16V) | PATS - Passive Anti-Theft System | | X | X | X | |
| AII | ESCORT | 2.0L (MPI 16V) | IABM - Integrated Air Bag Module | | X | X | X | |
| AII | ESCORT | 1.6L(Zetec) | PCM - Powertrain Control Module | | X | X | | |
| AII | ESCORT | 2.0L(SPI) | PCM - Powertrain Control Module | | X | X | | |
| AII | ESCORT | 2.0L(SPI) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | | |
| AII | EXPLORER | 4.0L (SOHC SFI) | PCM - Powertrain Control Module | | X | X | X | |
| AII | EXPLORER | 4.0L (SOHC SFI) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| AII | EXPLORER | 4.0L (SOHC SFI) | ARC - Automatic Ride Control | | X | X | X | |
| AII | EXPLORER | 4.0L (SOHC SFI) | EATC - Electronic Automatic Temperature Control | | X | X | X | |
| AII | EXPLORER | 4.0L (SOHC SFI) | GEM - Generic electric module(CTM) | | X | X | X | |
| AII | EXPLORER | 4.0L (SOHC SFI) | IABM - Integrated Air Bag Module | | X | X | X | |
| AII | EXPLORER | 4.0L (SOHC SFI) | RAP - Remote Anti-Theft / Personality Module | | X | X | X | |
| AII | EXPLORER | 5.0L | PCM - Powertrain Control Module | | X | X | X | |
| AII | EXPLORER | 5.0L | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| AII | EXPLORER | 5.0L | ARC - Automatic Ride Control | | X | X | X | |
| AII | EXPLORER | 5.0L | EATC - Electronic Automatic Temperature Control | | X | X | X | |
| AII | EXPLORER | 5.0L | GEM - Generic electric module(CTM) | | X | X | X | |
| AII | EXPLORER | 5.0L | IABM - Integrated Air Bag Module | | X | X | X | |
| AII | EXPLORER | 5.0L | RAP - Remote Anti-Theft / Personality Module | | X | X | X | |
| AII | EXPLORER | 4.0L(V6-SOHC) | PCM - Powertrain Control Module | | X | X | | |
| AII | EXPLORER | 4.0L(V6-SOHC) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | | |
| AII | EXPLORER | 4.0L(V6-SOHC) | GEM - Generic electric module(CTM) | | X | X | | |
| AII | EXPLORER | 4.0L(V6-OHV) | PCM - Powertrain Control Module | | X | X | | |
| AII | EXPLORER | 4.0L(V6-OHV) | GEM - Generic electric module(CTM) | | X | X | | |
| AII | EXPLORER | 4.0L(Other) | PCM - Powertrain Control Module | | X | X | | |
| AII | EXPLORER | 4.0L(Other) | GEM - Generic electric module(CTM) | | X | X | | |
| AII | EXPLORER | 5.0L(Other) | PCM - Powertrain Control Module | | X | X | | |

| | | | | | | | | |
|-----|----------|--------------------------|---|--|---|---|---|---|
| All | EXPLORER | 5.0L(Other) | GEM - Generic electric module(CTM) | | X | X | | |
| All | FIESTA | 1.25L(SFI) | PCM - Powertrain Control Module | | X | X | X | |
| All | FIESTA | 1.25L(SFI) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| All | FIESTA | 1.3L (SFI) | PCM - Powertrain Control Module | | X | X | X | |
| All | FIESTA | 1.3L (SFI) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| All | FIESTA | 1.4L (SFI) | PCM - Powertrain Control Module | | X | X | X | |
| All | FIESTA | 1.4L (SFI) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| All | FIESTA | 1.6L (SFI) | PCM - Powertrain Control Module | | X | X | X | |
| All | FIESTA | 1.6L (SFI) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| All | FIESTA | 1.8L (DIESEL) | PCM - Powertrain Control Module | | X | X | X | 1.Fuel Injector Coding. 2.Key Programming. |
| All | FIESTA | 1.8L (DIESEL) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| All | GALAXY | 1.9L (DIESEL) | PCM - Powertrain Control Module | | X | | | |
| All | GALAXY | 1.9L (DIESEL) | TCM - Transmission Control Module | | X | | | |
| All | GALAXY | 1.9L (DIESEL) | ABS - Anti-Lock Brake / Traction Control Module | | X | | | |
| All | GALAXY | 1.9L (DIESEL) | RCM - Restraint Control Module | | X | | | |
| All | GALAXY | 1.9L (DIESEL) | ICM - Instrument Cluster | | X | | | |
| All | GALAXY | 1.9L (DIESEL) | NAV - Navigation System | | X | | | |
| All | GALAXY | 2.0L (SFI DOHC/DOHC 16V) | PCM - Powertrain Control Module | | X | | | |
| All | GALAXY | 2.0L (SFI DOHC/DOHC 16V) | TCM - Transmission Control Module | | X | | | |
| All | GALAXY | 2.0L (SFI DOHC/DOHC 16V) | ABS - Anti-Lock Brake / Traction Control Module | | X | | | |
| All | GALAXY | 2.0L (SFI DOHC/DOHC 16V) | RCM - Restraint Control Module | | X | | | |
| All | GALAXY | 2.0L (SFI DOHC/DOHC 16V) | ICM - Instrument Cluster | | X | | | |
| All | GALAXY | 2.0L (SFI DOHC/DOHC 16V) | NAV - Navigation System | | X | | | |
| All | GALAXY | 2.3L | PCM - Powertrain Control Module | | X | | | |
| All | GALAXY | 2.3L | TCM - Transmission Control Module | | X | | | |
| All | GALAXY | 2.3L | ABS - Anti-Lock Brake / Traction Control Module | | X | | | |
| All | GALAXY | 2.3L | RCM - Restraint Control Module | | X | | | |
| All | GALAXY | 2.3L | ICM - Instrument Cluster | | X | | | |
| All | GALAXY | 2.3L | NAV - Navigation System | | X | | | |
| All | GALAXY | 2.8L (V6 SFI) | PCM - Powertrain Control Module | | X | | | |
| All | GALAXY | 2.8L (V6 SFI) | TCM - Transmission Control Module | | X | | | |
| All | GALAXY | 2.8L (V6 SFI) | ABS - Anti-Lock Brake / Traction Control Module | | X | | | |
| All | GALAXY | 2.8L (V6 SFI) | RCM - Restraint Control Module | | X | | | |
| All | GALAXY | 2.8L (V6 SFI) | ICM - Instrument Cluster | | X | | | |
| All | GALAXY | 2.8L (V6 SFI) | NAV - Navigation System | | X | | | |
| All | KA | 1.3L (SFI) | PCM - Powertrain Control Module | | X | | | |
| All | KA | 1.3L (SFI) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | | |
| All | KA | 1.3L (SFI) | ECS - Electronic Crash Sensor(or IABM) | | X | X | | |
| All | KA | 1.3L (SFI) | EPS - Electronic Controlled Power Steering | | X | X | | |
| All | KA | 1.3L (SFI) | GEM - Generic electric module(CTM) | | X | X | | |
| All | KA | 1.3L (SFI) | PATS - Passive Anti-Theft System | | X | X | | |
| All | KA | 1.6L | PCM - Powertrain Control Module | | X | X | | |
| All | KA | 1.6L | ABS - Anti-Lock Brake / Traction Control Module | | X | X | | |

| | | | | | | | | |
|-----|------------------------|----------------|---|--|---|---|--|--|
| AII | KA | 1.6L | ECS - Electronic Crash Sensor(or IABM) | | X | X | | |
| AII | KA | 1.6L | EPS - Electronic Controlled Power Steering | | X | X | | |
| AII | KA | 1.6L | GEM - Generic electric module(CTM) | | X | X | | |
| AII | KA | 1.6L | PATS - Passive Anti-Theft System | | X | X | | |
| AII | MAVERICK | 2.4L (SFI) | PCM - Powertrain Control Module | | X | X | | |
| AII | MAVERICK | 2.4L (SFI) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | | |
| AII | MAVERICK | 2.4L (SFI) | RCM - Restraint Control Module | | X | X | | |
| AII | MAVERICK | 2.4L (SFI) | GEM - Generic electric module(CTM) | | X | X | | |
| AII | MAVERICK | 2.4L (SFI) | PAM - Parking Aid Module | | X | X | | |
| AII | MAVERICK | 2.4L (SFI) | 4X4M - 4X4 Control Module | | X | X | | |
| AII | MAVERICK | 2.7L(T-DIESEL) | PCM - Powertrain Control Module | | X | X | | |
| AII | MAVERICK | 2.7L(T-DIESEL) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | | |
| AII | MAVERICK | 2.7L(T-DIESEL) | RCM - Restraint Control Module | | X | X | | |
| AII | MAVERICK | 2.7L(T-DIESEL) | GEM - Generic electric module(CTM) | | X | X | | |
| AII | MAVERICK | 2.7L(T-DIESEL) | PAM - Parking Aid Module | | X | X | | |
| AII | MAVERICK | 2.7L(T-DIESEL) | 4X4M - 4X4 Control Module | | X | X | | |
| AII | F-SERIES SUPER DUTY | 5.4L | PCM - Powertrain Control Module | | X | | | |
| AII | F-SERIES SUPER DUTY | 5.4L | ABS - Anti-Lock Brake / Traction Control Module | | X | X | | |
| AII | F-SERIES SUPER DUTY | 5.4L | RCM - Restraint Control Module | | X | X | | |
| AII | F-SERIES SUPER DUTY | 5.4L | TCM - Transmission Control Module | | X | X | | |
| AII | F-SERIES SUPER DUTY | 5.4L | ICM - Instrument Cluster | | X | X | | |
| AII | F-SERIES SUPER DUTY | 5.4L | GEM - Generic electric module(CTM) | | X | X | | |
| AII | F-SERIES SUPER DUTY | 5.4L | PATS - Passive Anti-Theft System | | X | X | | |
| AII | F-SERIES SUPER DUTY | 6.0L | PCM - Powertrain Control Module | | X | | | |
| AII | F-SERIES SUPER DUTY | 6.0L | ABS - Anti-Lock Brake / Traction Control Module | | X | X | | |
| AII | F-SERIES SUPER DUTY | 6.0L | RCM - Restraint Control Module | | X | X | | |
| AII | F-SERIES SUPER DUTY | 6.0L | TCM - Transmission Control Module | | X | X | | |
| AII | F-SERIES SUPER DUTY | 6.0L | ICM - Instrument Cluster | | X | X | | |
| AII | F-SERIES SUPER DUTY | 6.0L | GEM - Generic electric module(CTM) | | X | X | | |
| AII | F-SERIES SUPER DUTY | 6.0L | PATS - Passive Anti-Theft System | | X | X | | |

| | | | | | | | | |
|-----|------------------------|--------------------------|---|--|---|---|---|---|
| All | F-SERIES SUPER DUTY | 6.8L | PCM - Powertrain Control Module | | X | | | |
| All | F-SERIES SUPER DUTY | 6.8L | ABS - Anti-Lock Brake / Traction Control Module | | X | X | | |
| All | F-SERIES SUPER DUTY | 6.8L | RCM - Restraint Control Module | | X | X | | |
| All | F-SERIES SUPER DUTY | 6.8L | TCM - Transmission Control Module | | X | X | | |
| All | F-SERIES SUPER DUTY | 6.8L | ICM - Instrument Cluster | | X | X | | |
| All | F-SERIES SUPER DUTY | 6.8L | GEM - Generic electric module(CTM) | | X | X | | |
| All | F-SERIES SUPER DUTY | 6.8L | PATS - Passive Anti-Theft System | | X | X | | |
| All | F-SERIES SUPER DUTY | 7.3L | PCM - Powertrain Control Module | | X | | | |
| All | F-SERIES SUPER DUTY | 7.3L | ABS - Anti-Lock Brake / Traction Control Module | | X | X | | |
| All | F-SERIES SUPER DUTY | 7.3L | RCM - Restraint Control Module | | X | X | | |
| All | F-SERIES SUPER DUTY | 7.3L | TCM - Transmission Control Module | | X | X | | |
| All | F-SERIES SUPER DUTY | 7.3L | ICM - Instrument Cluster | | X | X | | |
| All | F-SERIES SUPER DUTY | 7.3L | GEM - Generic electric module(CTM) | | X | X | | |
| All | F-SERIES SUPER DUTY | 7.3L | PATS - Passive Anti-Theft System | | X | X | | |
| All | MONDEO | 1.6L (SFI) | PCM - Powertrain Control Module | | X | X | X | |
| All | MONDEO | 1.6L (SFI) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| All | MONDEO | 1.6L (SFI) | PATS - Passive Anti-Theft System | | X | X | X | |
| All | MONDEO | 1.8L (HC/SFI/T-DIESEL) | PCM - Powertrain Control Module | | X | X | X | 1.Fuel Injector Coding. 2.Key Programming. |
| All | MONDEO | 1.8L (HC/SFI/T-DIESEL) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| All | MONDEO | 1.8L (HC/SFI/T-DIESEL) | PATS - Passive Anti-Theft System | | X | | | 1.Key Programming. |
| All | MONDEO | 1.8L (HC/SFI/T-DIESEL) | RIM - Remote Anti-Theft / Personality Module | | X | X | X | |
| All | MONDEO | 2.0L (HC ATX/HC MTX/SFI) | PCM - Powertrain Control Module | | X | X | X | |
| All | MONDEO | 2.0L (HC ATX/HC MTX/SFI) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| All | MONDEO | 2.0L (HC ATX/HC MTX/SFI) | PATS - Passive Anti-Theft System | | X | | | 1.Key Programming. |
| All | MONDEO | 2.5L (HC/SFI) | PCM - Powertrain Control Module | | X | X | X | |
| All | MONDEO | 2.5L (HC/SFI) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| All | MONDEO | 2.5L (HC/SFI) | PATS - Passive Anti-Theft System | | X | | | 1.Key Programming. |
| All | PROBE | 2.0L (MPI) | PCM - Powertrain Control Module | | X | X | X | |
| All | PROBE | 2.0L (MPI) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |

| | | | | | | | | |
|-----|------------------|-------------------------|---|--|---|---|---|---|
| AII | PROBE | 2.2L (MPI) | PCM - Powertrain Control Module | | X | X | X | |
| AII | PROBE | 2.2L (MPI) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| AII | PROBE | 2.5L (MPI) | PCM - Powertrain Control Module | | X | X | X | |
| AII | PROBE | 2.5L (MPI) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| AII | PUMA | 1.4L (SFI) | PCM - Powertrain Control Module | | X | X | X | |
| AII | PUMA | 1.4L (SFI) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| AII | PUMA | 1.7L (SFI) | PCM - Powertrain Control Module | | X | X | X | |
| AII | PUMA | 1.7L (SFI) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| AII | SCORPIO | 2.0L (16V DOHC/8V DOHC) | PCM - Powertrain Control Module | | X | X | X | |
| AII | SCORPIO | 2.0L (16V DOHC/8V DOHC) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| AII | SCORPIO | 2.3L (16V DOHC) | PCM - Powertrain Control Module | | X | X | X | |
| AII | SCORPIO | 2.3L (16V DOHC) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| AII | SCORPIO | 2.5L (DIESEL) | PCM - Powertrain Control Module | | X | X | X | |
| AII | SCORPIO | 2.5L (DIESEL) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| AII | SCORPIO | 2.9L (12V V6/24V V6) | PCM - Powertrain Control Module | | X | X | X | |
| AII | SCORPIO | 2.9L (12V V6/24V V6) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| AII | TRANSIT | 2.0L (MPI/SFI 8V) | PCM - Powertrain Control Module | | X | X | X | |
| AII | TRANSIT | 2.0L (MPI/SFI 8V) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| AII | TRANSIT | 2.0L (MPI/SFI 8V) | PATS - Passive Anti-Theft System | | X | | | 1.Key Programming. |
| AII | TRANSIT | 2.5L (DIESEL/T-DIESEL) | PCM - Powertrain Control Module | | X | X | X | 1.Fuel Injector Coding. 2.Key Programming. |
| AII | TRANSIT | 2.5L (DIESEL/T-DIESEL) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| AII | TRANSIT | 2.5L (DIESEL/T-DIESEL) | PATS - Passive Anti-Theft System | | X | X | X | |
| AII | TRANSIT | 2.5L (DIESEL/T-DIESEL) | RIM - Remote Anti-Theft / Personality Module | | X | X | X | |
| AII | WINDSTAR | 3.0L (V6 SFI) | PCM - Powertrain Control Module | | X | X | X | |
| AII | WINDSTAR | 3.0L (V6 SFI) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| AII | WINDSTAR | 3.0(V6-OHV) | PCM - Powertrain Control Module | | X | X | | |
| AII | WINDSTAR | 3.0(V6-OHV) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | | |
| AII | WINDSTAR | 3.0(V6-OHV) | GEM - Generic electric module(CTM) | | X | X | | |
| AII | WINDSTAR | 3.8(V6-OHV) | PCM - Powertrain Control Module | | X | X | | |
| AII | WINDSTAR | 3.8(V6-OHV) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | | |
| AII | WINDSTAR | 3.8(V6-OHV) | GEM - Generic electric module(CTM) | | X | X | | |
| AII | CROWN-VICTORIA | 4.6L(2V) | PCM - Powertrain Control Module | | X | X | | |
| AII | CROWN-VICTORIA | 4.6L(2V) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | | |
| AII | CROWN-VICTORIA | 4.6L(2V-NGV) | PCM - Powertrain Control Module | | X | X | | |
| AII | CROWN-VICTORIA | 4.6L(2V-NGV) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | | |
| AII | F-250 LIGHT DUTY | 4.6L(Other) | PCM - Powertrain Control Module | | X | X | | |
| AII | F-250 LIGHT DUTY | 4.6L(Other) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | | |

| | | | | | | | | |
|-----|------------------|------------------|---|--|---|---|---|--|
| AII | F-250 LIGHT DUTY | 4.6L(Other) | GEM - Generic electric module(CTM) | | X | X | | |
| AII | F-250 LIGHT DUTY | 5.4L(Other) | PCM - Powertrain Control Module | | X | X | | |
| AII | F-250 LIGHT DUTY | 5.4L(Other) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | | |
| AII | F-250 LIGHT DUTY | 5.4L(Other) | GEM - Generic electric module(CTM) | | X | X | | |
| AII | EXPEDITION | 4.6L(Other) | PCM - Powertrain Control Module | | X | X | | |
| AII | EXPEDITION | 4.6L(Other) | GEM - Generic electric module(CTM) | | X | X | | |
| AII | EXPEDITION | 4.6L(Other) | PATS - Passive Anti-Theft System | | X | X | | |
| AII | EXPEDITION | 5.4L(Other) | PCM - Powertrain Control Module | | X | X | | |
| AII | EXPEDITION | 5.4L(Other) | GEM - Generic electric module(CTM) | | X | X | | |
| AII | EXPEDITION | 5.4L(Other) | PATS - Passive Anti-Theft System | | X | X | | |
| AII | AEROSTAR | 3.0L(Other) | PCM - Powertrain Control Module | | X | X | | |
| AII | AEROSTAR | 4.0L(Other) | PCM - Powertrain Control Module | | X | X | | |
| AII | CONTOUR | 2.0L | PCM - Powertrain Control Module | | X | X | X | |
| AII | CONTOUR | 2.0L | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| AII | CONTOUR | 2.0L | CSM - Security module | | X | X | X | |
| AII | CONTOUR | 2.0L | PATS - Passive Anti-Theft System | | X | X | X | |
| AII | CONTOUR | 2.0L | ECS - Electronic Crash Sensor | | X | X | X | |
| AII | CONTOUR | 2.5L | PCM - Powertrain Control Module | | X | X | X | |
| AII | CONTOUR | 2.5L | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| AII | CONTOUR | 2.5L | CSM - Security module | | X | X | X | |
| AII | CONTOUR | 2.5L | PATS - Passive Anti-Theft System | | X | X | X | |
| AII | CONTOUR | 2.5L | ECS - Electronic Crash Sensor | | X | X | X | |
| AII | COGUAR | 2.0L (SFI) | PCM - Powertrain Control Module | | X | X | X | |
| AII | COGUAR | 2.0L (SFI) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| AII | COGUAR | 2.0L (SFI) | ARC - Automatic Ride Control | | X | X | X | |
| AII | COGUAR | 2.5L (SFI) | PCM - Powertrain Control Module | | X | X | X | |
| AII | COGUAR | 2.5L (SFI) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| AII | COGUAR | 2.5L (SFI) | ARC - Automatic Ride Control | | X | X | X | |
| AII | COUGAR | 2.0L(2V) | PCM - Powertrain Control Module | | X | X | | |
| AII | COUGAR | 2.0L(2V) | ICM - Instrument Cluster | | X | X | | |
| AII | COUGAR | 2.0L(2V) | PATS - Passive Anti-Theft System | | X | X | | |
| AII | COUGAR | 2.5L(Zetec) | PCM - Powertrain Control Module | | X | X | | |
| AII | COUGAR | 2.5L(Zetec) | ICM - Instrument Cluster | | X | X | | |
| AII | COUGAR | 2.5L(Zetec) | PATS - Passive Anti-Theft System | | X | X | | |
| AII | COUGAR | 2.0L(Zetec) | PCM - Powertrain Control Module | | X | X | | |
| AII | COUGAR | 2.0L(Zetec) | ICM - Instrument Cluster | | X | X | | |
| AII | COUGAR | 2.5L(Duratec-VE) | PCM - Powertrain Control Module | | X | X | | |
| AII | ECONOVAN | 1.4L (2BL OHC) | PCM - Powertrain Control Module | | X | X | X | |
| AII | ECONOVAN | 1.4L (2BL OHC) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| AII | ECONOVAN | 2.0L (DIESEL) | PCM - Powertrain Control Module | | X | X | X | |

| | | | | | | | | |
|-----|----------|----------------------------|---|--|---|---|---|--|
| AII | ECONOVAN | 2.0L (DIESEL) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| AII | ESCORT | 1.3L (CFI/HCS/SFI) | PCM - Powertrain Control Module | | X | X | X | |
| AII | ESCORT | 1.3L (CFI/HCS/SFI) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| AII | ESCORT | 1.3L (CFI/HCS/SFI) | PATS - Passive Anti-Theft System | | X | X | X | |
| AII | ESCORT | 1.4L (HCS/CVH/EFI/SFI) | PCM - Powertrain Control Module | | X | X | X | |
| AII | ESCORT | 1.4L (HCS/CVH/EFI/SFI) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| AII | ESCORT | 1.4L (HCS/CVH/EFI/SFI) | PATS - Passive Anti-Theft System | | X | X | X | |
| AII | ESCORT | 1.6L (SFI) | PCM - Powertrain Control Module | | X | X | X | |
| AII | ESCORT | 1.6L (SFI) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| AII | ESCORT | 1.6L (SFI) | PATS - Passive Anti-Theft System | | X | X | X | |
| AII | ESCORT | 1.8L (DIESEL/SFI/T-DIESEL) | PCM - Powertrain Control Module | | X | X | X | |
| AII | ESCORT | 1.8L (DIESEL/SFI/T-DIESEL) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| AII | ESCORT | 1.8L (DIESEL/SFI/T-DIESEL) | PATS - Passive Anti-Theft System | | X | X | X | |
| AII | ESCORT | 1.8L (DIESEL/SFI/T-DIESEL) | RIM - Remote Anti-Theft / Personality Module | | X | X | X | |
| AII | ESCORT | 2.0L (MPI 16V) | PCM - Powertrain Control Module | | X | X | X | |
| AII | ESCORT | 2.0L (MPI 16V) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| AII | ESCORT | 2.0L (MPI 16V) | CSM - Security module | | X | X | X | |
| AII | ESCORT | 2.0L (MPI 16V) | ECS - Electronic Crash Sensor | | X | X | X | |
| AII | ESCORT | 2.0L (MPI 16V) | PATS - Passive Anti-Theft System | | X | X | X | |
| AII | ESCORT | 2.0L (MPI 16V) | RAP - Remote Anti-Theft / Personality Module | | X | X | X | |
| AII | ESCORT | 1.6L(Zetec) | PCM - Powertrain Control Module | | X | X | | |
| AII | ESCORT | 2.0L(Zetec) | PCM - Powertrain Control Module | | X | X | | |
| AII | ESCORT | 2.0L(Zetec) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | | |
| AII | ESCORT | 2.0L(Zetec) | RCM - Restraint Control Module | | X | X | | |
| AII | ESCORT | 2.0L(SPI) | PCM - Powertrain Control Module | | X | X | | |
| AII | ESCORT | 2.0L(SPI) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | | |
| AII | ESCORT | 2.0L(SPI) | RCM - Restraint Control Module | | X | X | | |
| AII | EXPLORER | 4.0L (SOHC SFI) | PCM - Powertrain Control Module | | X | X | X | |
| AII | EXPLORER | 4.0L (SOHC SFI) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| AII | EXPLORER | 4.0L (SOHC SFI) | ARC - Automatic Ride Control | | X | X | X | |
| AII | EXPLORER | 4.0L (SOHC SFI) | CTM - Central timer module | | X | X | X | |
| AII | EXPLORER | 4.0L (SOHC SFI) | DSM - Drivers Seat Module | | X | X | X | |
| AII | EXPLORER | 4.0L (SOHC SFI) | EATC - Electronic Automatic Temperature Control | | X | X | X | |
| AII | EXPLORER | 4.0L (SOHC SFI) | GEM - Generic electric module(CTM) | | X | X | X | |
| AII | EXPLORER | 4.0L (SOHC SFI) | IABM - Integrated Air Bag Module | | X | X | X | |
| AII | EXPLORER | 4.0L (SOHC SFI) | RAP - Remote Anti-Theft / Personality Module | | X | X | X | |
| AII | EXPLORER | 5.0L | PCM - Powertrain Control Module | | X | X | X | |
| AII | EXPLORER | 5.0L | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| AII | EXPLORER | 5.0L | ARC - Automatic Ride Control | | X | X | X | |
| AII | EXPLORER | 5.0L | CTM - Central timer module | | X | X | X | |
| AII | EXPLORER | 5.0L | DSM - Drivers Seat Module | | X | X | X | |
| AII | EXPLORER | 5.0L | EATC - Electronic Automatic Temperature Control | | X | X | X | |
| AII | EXPLORER | 5.0L | GEM - Generic electric module(CTM) | | X | X | X | |
| AII | EXPLORER | 5.0L | IABM - Integrated Air Bag Module | | X | X | X | |
| AII | EXPLORER | 5.0L | RAP - Remote Anti-Theft / Personality Module | | X | X | X | |

| | | | | | | | | |
|-----|----------|----------------------|---|--|---|---|---|---|
| All | EXPLORER | 4.0L(V6-SOHC) | PCM - Powertrain Control Module | | X | X | | |
| All | EXPLORER | 4.0L(V6-SOHC) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | | |
| All | EXPLORER | 4.0L(V6-SOHC) | GEM - Generic electric module(CTM) | | X | X | | |
| All | EXPLORER | 4.0L(V6-SOHC) | PATS - Passive Anti-Theft System | | X | X | | |
| All | EXPLORER | 4.0L(V6-OHV) | PCM - Powertrain Control Module | | X | X | | |
| All | EXPLORER | 4.0L(V6-OHV) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | | |
| All | EXPLORER | 4.0L(V6-OHV) | GEM - Generic electric module(CTM) | | X | X | | |
| All | EXPLORER | 4.0L(V6-OHV) | PATS - Passive Anti-Theft System | | X | X | | |
| All | EXPLORER | 4.0L(Other) | PCM - Powertrain Control Module | | X | X | | |
| All | EXPLORER | 4.0L(Other) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | | |
| All | EXPLORER | 4.0L(Other) | GEM - Generic electric module(CTM) | | X | X | | |
| All | EXPLORER | 4.0L(Other) | PATS - Passive Anti-Theft System | | X | X | | |
| All | EXPLORER | 5.0L(Other) | PCM - Powertrain Control Module | | X | X | | |
| All | EXPLORER | 5.0L(Other) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | | |
| All | EXPLORER | 5.0L(Other) | GEM - Generic electric module(CTM) | | X | X | | |
| All | EXPLORER | 5.0L(Other) | PATS - Passive Anti-Theft System | | X | X | | |
| All | FIESTA | 1.25L(SFI) | PCM - Powertrain Control Module | | X | X | X | |
| All | FIESTA | 1.25L(SFI) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| All | FIESTA | 1.25L(SFI) | RCM - Restraint Control Module | | X | X | X | |
| All | FIESTA | 1.3L (SFI) | PCM - Powertrain Control Module | | X | X | X | |
| All | FIESTA | 1.3L (SFI) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| All | FIESTA | 1.3L (SFI) | RCM - Restraint Control Module | | X | X | X | |
| All | FIESTA | 1.4L (SFI) | PCM - Powertrain Control Module | | X | X | X | |
| All | FIESTA | 1.4L (SFI) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| All | FIESTA | 1.4L (SFI) | RCM - Restraint Control Module | | X | X | X | |
| All | FIESTA | 1.6L (SFI) | PCM - Powertrain Control Module | | X | X | X | |
| All | FIESTA | 1.6L (SFI) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| All | FIESTA | 1.6L (SFI) | RCM - Restraint Control Module | | X | X | X | |
| All | FIESTA | 1.8L (DIESEL) | PCM - Powertrain Control Module | | X | X | X | 1.Fuel Injector Coding. 2.Key Programming. |
| All | FIESTA | 1.8L (DIESEL) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| All | FIESTA | 1.8L (DIESEL) | RCM - Restraint Control Module | | X | X | X | |
| All | FIESTA | 1.4L(Zetec-SE) | PCM - Powertrain Control Module | | X | X | | |
| All | FIESTA | 1.4L(ZETEC_CFI/PT-E) | PCM - Powertrain Control Module | | X | X | | |
| All | FOCUS | 1.4L (DOHC) | PCM - Powertrain Control Module | | X | X | X | |
| All | FOCUS | 1.4L (DOHC) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| All | FOCUS | 1.4L (DOHC) | RCM - Restraint Control Module | | X | X | X | |
| All | FOCUS | 1.6L (SFI) | PCM - Powertrain Control Module | | X | X | X | |
| All | FOCUS | 1.6L (SFI) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| All | FOCUS | 1.6L (SFI) | RCM - Restraint Control Module | | X | X | X | |
| All | FOCUS | 1.8L (SFI/DIESEL) | PCM - Powertrain Control Module | | X | X | X | 1.Fuel Injector Coding. 2.Key Programming. |
| All | FOCUS | 1.8L (SFI/DIESEL) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| All | FOCUS | 1.8L (SFI/DIESEL) | RCM - Restraint Control Module | | X | X | X | |

| | | | | | | | | |
|-----|----------|------------------------|---|--|---|---|---|--|
| AII | FOCUS | 2.0L (SFI/VVT) | PCM - Powertrain Control Module | | X | X | X | |
| AII | FOCUS | 2.0L (SFI/VVT) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| AII | FOCUS | 2.0L (SFI/VVT) | RCM - Restraint Control Module | | X | X | X | |
| AII | GALAXY | 1.9L (DIESEL/T-DIESEL) | PCM - Powertrain Control Module | | X | | | |
| AII | GALAXY | 1.9L (DIESEL/T-DIESEL) | TCM - Transmission Control Module | | X | | | |
| AII | GALAXY | 1.9L (DIESEL/T-DIESEL) | ABS - Anti-Lock Brake / Traction Control Module | | X | | | |
| AII | GALAXY | 1.9L (DIESEL/T-DIESEL) | RCM - Restraint Control Module | | X | | | |
| AII | GALAXY | 1.9L (DIESEL/T-DIESEL) | ICM - Instrument Cluster | | X | | | |
| AII | GALAXY | 1.9L (DIESEL/T-DIESEL) | NAV - Navigation System | | X | | | |
| AII | GALAXY | 2.0L (SFI DOHC) | PCM - Powertrain Control Module | | X | | | |
| AII | GALAXY | 2.0L (SFI DOHC) | TCM - Transmission Control Module | | X | | | |
| AII | GALAXY | 2.0L (SFI DOHC) | ABS - Anti-Lock Brake / Traction Control Module | | X | | | |
| AII | GALAXY | 2.0L (SFI DOHC) | RCM - Restraint Control Module | | X | | | |
| AII | GALAXY | 2.0L (SFI DOHC) | ICM - Instrument Cluster | | X | | | |
| AII | GALAXY | 2.0L (SFI DOHC) | NAV - Navigation System | | X | | | |
| AII | GALAXY | 2.3L (DOHC 16V) | PCM - Powertrain Control Module | | X | | | |
| AII | GALAXY | 2.3L (DOHC 16V) | TCM - Transmission Control Module | | X | | | |
| AII | GALAXY | 2.3L (DOHC 16V) | ABS - Anti-Lock Brake / Traction Control Module | | X | | | |
| AII | GALAXY | 2.3L (DOHC 16V) | RCM - Restraint Control Module | | X | | | |
| AII | GALAXY | 2.3L (DOHC 16V) | ICM - Instrument Cluster | | X | | | |
| AII | GALAXY | 2.3L (DOHC 16V) | NAV - Navigation System | | X | | | |
| AII | GALAXY | 2.8L (V6 SFI) | PCM - Powertrain Control Module | | X | | | |
| AII | GALAXY | 2.8L (V6 SFI) | TCM - Transmission Control Module | | X | | | |
| AII | GALAXY | 2.8L (V6 SFI) | ABS - Anti-Lock Brake / Traction Control Module | | X | | | |
| AII | GALAXY | 2.8L (V6 SFI) | RCM - Restraint Control Module | | X | | | |
| AII | GALAXY | 2.8L (V6 SFI) | ICM - Instrument Cluster | | X | | | |
| AII | GALAXY | 2.8L (V6 SFI) | NAV - Navigation System | | X | | | |
| AII | KA | 1.3L (SFI) | PCM - Powertrain Control Module | | X | | | |
| AII | KA | 1.3L (SFI) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | | |
| AII | KA | 1.3L (SFI) | ECS - Electronic Crash Sensor(or IABM) | | X | X | | |
| AII | KA | 1.3L (SFI) | EPS - Electronic Controlled Power Steering | | X | X | | |
| AII | KA | 1.3L (SFI) | GEM - Generic electric module(CTM) | | X | X | | |
| AII | KA | 1.3L (SFI) | PATS - Passive Anti-Theft System | | X | X | | |
| AII | KA | 1.6L | PCM - Powertrain Control Module | | X | X | | |
| AII | KA | 1.6L | ABS - Anti-Lock Brake / Traction Control Module | | X | X | | |
| AII | KA | 1.6L | ECS - Electronic Crash Sensor(or IABM) | | X | X | | |
| AII | KA | 1.6L | EPS - Electronic Controlled Power Steering | | X | X | | |
| AII | KA | 1.6L | GEM - Generic electric module(CTM) | | X | X | | |
| AII | KA | 1.6L | PATS - Passive Anti-Theft System | | X | X | | |
| AII | MAVERICK | 2.4L (SFI) | PCM - Powertrain Control Module | | X | X | | |
| AII | MAVERICK | 2.4L (SFI) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | | |
| AII | MAVERICK | 2.4L (SFI) | RCM - Restraint Control Module | | X | X | | |
| AII | MAVERICK | 2.4L (SFI) | GEM - Generic electric module(CTM) | | X | X | | |
| AII | MAVERICK | 2.4L (SFI) | PAM - Parking Aid Module | | X | X | | |
| AII | MAVERICK | 2.4L (SFI) | 4X4M - 4X4 Control Module | | X | X | | |

| | | | | | | | | |
|-----|------------------------|----------------|---|--|---|---|--|--|
| All | MAVERICK | 2.7L(T-DIESEL) | PCM - Powertrain Control Module | | X | X | | |
| All | MAVERICK | 2.7L(T-DIESEL) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | | |
| All | MAVERICK | 2.7L(T-DIESEL) | RCM - Restraint Control Module | | X | X | | |
| All | MAVERICK | 2.7L(T-DIESEL) | GEM - Generic electric module(CTM) | | X | X | | |
| All | MAVERICK | 2.7L(T-DIESEL) | PAM - Parking Aid Module | | X | X | | |
| All | MAVERICK | 2.7L(T-DIESEL) | 4X4M - 4X4 Control Module | | X | X | | |
| All | F-SERIES SUPER DUTY | 5.4L | PCM - Powertrain Control Module | | X | | | |
| All | F-SERIES SUPER DUTY | 5.4L | ABS - Anti-Lock Brake / Traction Control Module | | X | X | | |
| All | F-SERIES SUPER DUTY | 5.4L | RCM - Restraint Control Module | | X | X | | |
| All | F-SERIES SUPER DUTY | 5.4L | TCM - Transmission Control Module | | X | X | | |
| All | F-SERIES SUPER DUTY | 5.4L | ICM - Instrument Cluster | | X | X | | |
| All | F-SERIES SUPER DUTY | 5.4L | GEM - Generic electric module(CTM) | | X | X | | |
| All | F-SERIES SUPER DUTY | 5.4L | PATS - Passive Anti-Theft System | | X | X | | |
| All | F-SERIES SUPER DUTY | 6.8L | PCM - Powertrain Control Module | | X | | | |
| All | F-SERIES SUPER DUTY | 6.8L | ABS - Anti-Lock Brake / Traction Control Module | | X | X | | |
| All | F-SERIES SUPER DUTY | 6.8L | RCM - Restraint Control Module | | X | X | | |
| All | F-SERIES SUPER DUTY | 6.8L | TCM - Transmission Control Module | | X | X | | |
| All | F-SERIES SUPER DUTY | 6.8L | ICM - Instrument Cluster | | X | X | | |
| All | F-SERIES SUPER DUTY | 6.8L | GEM - Generic electric module(CTM) | | X | X | | |
| All | F-SERIES SUPER DUTY | 6.8L | PATS - Passive Anti-Theft System | | X | X | | |
| All | F-SERIES SUPER DUTY | 7.3L | PCM - Powertrain Control Module | | X | | | |
| All | F-SERIES SUPER DUTY | 7.3L | ABS - Anti-Lock Brake / Traction Control Module | | X | X | | |
| All | F-SERIES SUPER DUTY | 7.3L | RCM - Restraint Control Module | | X | X | | |
| All | F-SERIES SUPER DUTY | 7.3L | TCM - Transmission Control Module | | X | X | | |
| All | F-SERIES SUPER DUTY | 7.3L | ICM - Instrument Cluster | | X | X | | |

| | | | | | | | | |
|-----|------------------------|--------------------------|---|--|---|---|---|---|
| All | F-SERIES SUPER DUTY | 7.3L | GEM - Generic electric module(CTM) | | X | X | | |
| All | F-SERIES SUPER DUTY | 7.3L | PATS - Passive Anti-Theft System | | X | X | | |
| All | MONDEO | 1.6L (SFI) | PCM - Powertrain Control Module | | X | X | X | |
| All | MONDEO | 1.6L (SFI) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| All | MONDEO | 1.6L (SFI) | CSM - Security module | | X | X | X | |
| All | MONDEO | 1.6L (SFI) | PATS - Passive Anti-Theft System | | X | X | X | |
| All | MONDEO | 1.8L (HC/SFI/T-DIESEL) | PCM - Powertrain Control Module | | X | X | X | 1.Fuel Injector Coding. 2.Key Programming. |
| All | MONDEO | 1.8L (HC/SFI/T-DIESEL) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| All | MONDEO | 1.8L (HC/SFI/T-DIESEL) | CSM - Security module | | X | X | X | |
| All | MONDEO | 1.8L (HC/SFI/T-DIESEL) | PATS - Passive Anti-Theft System | | X | X | X | |
| All | MONDEO | 1.8L (HC/SFI/T-DIESEL) | RIM - Remote Anti-Theft / Personality Module | | X | X | X | |
| All | MONDEO | 2.0L (HC ATX/HC MTX/SFI) | PCM - Powertrain Control Module | | X | X | X | |
| All | MONDEO | 2.0L (HC ATX/HC MTX/SFI) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| All | MONDEO | 2.0L (HC ATX/HC MTX/SFI) | CSM - Security module | | X | X | X | |
| All | MONDEO | 2.0L (HC ATX/HC MTX/SFI) | PATS - Passive Anti-Theft System | | X | X | X | 1.Key Programming. |
| All | MONDEO | 2.5L (HC/SFI) | PCM - Powertrain Control Module | | X | X | X | |
| All | MONDEO | 2.5L (HC/SFI) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| All | MONDEO | 2.5L (HC/SFI) | CSM - Security module | | X | X | X | |
| All | MONDEO | 2.5L (HC/SFI) | PATS - Passive Anti-Theft System | | X | X | X | 1.Key Programming. |
| All | PROBE | 2.0L (MPI) | PCM - Powertrain Control Module | | X | X | X | |
| All | PROBE | 2.0L (MPI) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| All | PROBE | 2.2L (MPI) | PCM - Powertrain Control Module | | X | X | X | |
| All | PROBE | 2.2L (MPI) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| All | PROBE | 2.5L (MPI) | PCM - Powertrain Control Module | | X | X | X | |
| All | PROBE | 2.5L (MPI) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| All | PUMA | 1.4L (SFI) | PCM - Powertrain Control Module | | X | X | X | |
| All | PUMA | 1.4L (SFI) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| All | PUMA | 1.7L (SFI) | PCM - Powertrain Control Module | | X | X | X | |
| All | PUMA | 1.7L (SFI) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| All | SCORPIO | 2.0L (16V DOHC/8V DOHC) | PCM - Powertrain Control Module | | X | X | X | |
| All | SCORPIO | 2.0L (16V DOHC/8V DOHC) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| All | SCORPIO | 2.3L (16V DOHC) | PCM - Powertrain Control Module | | X | X | X | |
| All | SCORPIO | 2.3L (16V DOHC) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| All | SCORPIO | 2.5L (DIESEL) | PCM - Powertrain Control Module | | X | X | X | |
| All | SCORPIO | 2.5L (DIESEL) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| All | SCORPIO | 2.9L (12V V6/24V V6) | PCM - Powertrain Control Module | | X | X | X | |
| All | SCORPIO | 2.9L (12V V6/24V V6) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| All | TRANSIT | 2.0L (MPI/SFI 8V) | PCM - Powertrain Control Module | | X | X | X | |
| All | TRANSIT | 2.0L (MPI/SFI 8V) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| All | TRANSIT | 2.0L (MPI/SFI 8V) | PATS - Passive Anti-Theft System | | X | | | 1.Key Programming. |

| | | | | | | | | |
|-----|------------------|------------------------|---|--|---|---|---|---|
| All | TRANSIT | 2.5L (DIESEL/T-DIESEL) | PCM - Powertrain Control Module | | X | X | X | 1.Fuel Injector Coding. 2.Key Programming. |
| All | TRANSIT | 2.5L (DIESEL/T-DIESEL) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| All | TRANSIT | 2.5L (DIESEL/T-DIESEL) | PATS - Passive Anti-Theft System | | X | | | 1.Key Programming. |
| All | TRANSIT | 2.5L (DIESEL/T-DIESEL) | RIM - Remote Anti-Theft / Personality Module | | X | X | X | |
| All | WINDSTAR | 3.0L (V6 SFI) | PCM - Powertrain Control Module | | X | X | X | |
| All | WINDSTAR | 3.0L (V6 SFI) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| All | WINDSTAR | 3.0(V6-OHV) | PCM - Powertrain Control Module | | X | X | | |
| All | WINDSTAR | 3.0(V6-OHV) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | | |
| All | WINDSTAR | 3.0(V6-OHV) | GEM - Generic electric module(CTM) | | X | X | | |
| All | WINDSTAR | 3.8(V6-OHV) | PCM - Powertrain Control Module | | X | X | | |
| All | WINDSTAR | 3.8(V6-OHV) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | | |
| All | WINDSTAR | 3.8(V6-OHV) | GEM - Generic electric module(CTM) | | X | X | | |
| All | F-250 LIGHT DUTY | 4.6L(NGV) | PCM - Powertrain Control Module | | X | X | | |
| All | F-250 LIGHT DUTY | 4.6L(NGV) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | | |
| All | F-250 LIGHT DUTY | 4.6L(NGV) | GEM - Generic electric module(CTM) | | X | X | | |
| All | F-250 LIGHT DUTY | 5.4L(NGV) | PCM - Powertrain Control Module | | X | X | | |
| All | F-250 LIGHT DUTY | 5.4L(NGV) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | | |
| All | EXPEDITION | 4.6L(Other) | PCM - Powertrain Control Module | | X | X | | |
| All | EXPEDITION | 4.6L(Other) | GEM - Generic electric module(CTM) | | X | X | | |
| All | EXPEDITION | 4.6L(Other) | PATS - Passive Anti-Theft System | | X | X | | |
| All | EXPEDITION | 5.4L(Other) | PCM - Powertrain Control Module | | X | X | | |
| All | EXPEDITION | 5.4L(Other) | GEM - Generic electric module(CTM) | | X | X | | |
| All | EXPEDITION | 5.4L(Other) | PATS - Passive Anti-Theft System | | X | X | | |
| All | GRANADA/SC ORPIO | 2.3L(2.9-V6-24V) | PATS - Passive Anti-Theft System | | X | X | | |
| All | GRANADA/SC ORPIO | 2.3L(DOHC-SFI-16V) | PATS - Passive Anti-Theft System | | X | X | | |
| All | GRANADA/SC ORPIO | 2.9L(DOHC-SFI-16V) | PATS - Passive Anti-Theft System | | X | X | | |
| All | CONTOUR | 2.0L | PCM - Powertrain Control Module | | X | X | X | |
| All | CONTOUR | 2.0L | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| All | CONTOUR | 2.0L | CSM - Security module | | X | X | X | |
| All | CONTOUR | 2.0L | RCM - Restraint Control Module | | X | X | X | |
| All | CONTOUR | 2.5L | PCM - Powertrain Control Module | | X | X | X | |
| All | CONTOUR | 2.5L | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| All | CONTOUR | 2.5L | CSM - Security module | | X | X | X | |
| All | CONTOUR | 2.5L | RCM - Restraint Control Module | | X | X | X | |
| All | COGUAR | 2.0L (SFI) | PCM - Powertrain Control Module | | X | X | X | |

| | | | | | | | | |
|-----|----------|----------------------------|---|--|---|---|---|--|
| AII | COGUAR | 2.0L (SFI) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| AII | COGUAR | 2.0L (SFI) | CSM - Security module | | X | X | X | |
| AII | COGUAR | 2.0L (SFI) | ECS - Electronic Crash Sensor | | X | X | X | |
| AII | COGUAR | 2.5L (SFI) | PCM - Powertrain Control Module | | X | X | X | |
| AII | COGUAR | 2.5L (SFI) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| AII | COGUAR | 2.5L (SFI) | CSM - Security module | | X | X | X | |
| AII | COGUAR | 2.5L (SFI) | ECS - Electronic Crash Sensor | | X | X | X | |
| AII | COUGAR | 2.5L(2V) | PCM - Powertrain Control Module | | X | X | | |
| AII | COUGAR | 2.5L(2V) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | | |
| AII | COUGAR | 2.5L(2V) | RCM - Restraint Control Module | | X | X | | |
| AII | COUGAR | 2.5L(2V) | ICM - Instrument Cluster | | X | X | | |
| AII | COUGAR | 2.5L(Zetec) | PCM - Powertrain Control Module | | X | X | | |
| AII | COUGAR | 2.5L(Zetec) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | | |
| AII | COUGAR | 2.5L(Zetec) | RCM - Restraint Control Module | | X | X | | |
| AII | COUGAR | 2.5L(Zetec) | ICM - Instrument Cluster | | X | X | | |
| AII | COUGAR | 2.5L(Duratec-VE) | PCM - Powertrain Control Module | | X | X | | |
| AII | COUGAR | 2.5L(Duratec-VE) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | | |
| AII | COUGAR | 2.5L(Duratec-VE) | RCM - Restraint Control Module | | X | X | | |
| AII | COUGAR | 2.5L(Duratec-VE) | ICM - Instrument Cluster | | X | X | | |
| AII | COUGAR | 2.0L(Zetec) | ICM - Instrument Cluster | | X | X | | |
| AII | ECONOVAN | 1.4L (2BL OHC) | PCM - Powertrain Control Module | | X | X | X | |
| AII | ECONOVAN | 1.4L (2BL OHC) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| AII | ECONOVAN | 1.4L (2BL OHC) | RCM - Restraint Control Module | | X | X | X | |
| AII | ECONOVAN | 2.0L (DIESEL) | PCM - Powertrain Control Module | | X | X | X | |
| AII | ECONOVAN | 2.0L (DIESEL) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| AII | ECONOVAN | 2.0L (DIESEL) | RCM - Restraint Control Module | | X | X | X | |
| AII | ESCORT | 1.3L (CFI/HCS/SFI) | PCM - Powertrain Control Module | | X | X | X | |
| AII | ESCORT | 1.3L (CFI/HCS/SFI) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| AII | ESCORT | 1.3L (CFI/HCS/SFI) | PATS - Passive Anti-Theft System | | X | X | X | |
| AII | ESCORT | 1.4L (HCS/CVH/EFI/SFI) | PCM - Powertrain Control Module | | X | X | X | |
| AII | ESCORT | 1.4L (HCS/CVH/EFI/SFI) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| AII | ESCORT | 1.4L (HCS/CVH/EFI/SFI) | PATS - Passive Anti-Theft System | | X | X | X | |
| AII | ESCORT | 1.6L (CFI) | PCM - Powertrain Control Module | | X | X | X | |
| AII | ESCORT | 1.6L (CFI) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| AII | ESCORT | 1.6L (CFI) | PATS - Passive Anti-Theft System | | X | X | X | |
| AII | ESCORT | 1.8L (SFI/DIESEL/T-DIESEL) | PCM - Powertrain Control Module | | X | X | X | |
| AII | ESCORT | 1.8L (SFI/DIESEL/T-DIESEL) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| AII | ESCORT | 1.8L (SFI/DIESEL/T-DIESEL) | PATS - Passive Anti-Theft System | | X | X | X | |
| AII | ESCORT | 1.8L (SFI/DIESEL/T-DIESEL) | RIM - Remote Anti-Theft / Personality Module | | X | X | X | |
| AII | ESCORT | 2.0L (MPI 16V) | PCM - Powertrain Control Module | | X | X | X | |
| AII | ESCORT | 2.0L (MPI 16V) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| AII | ESCORT | 2.0L (MPI 16V) | ECS - Electronic Crash Sensor | | X | X | X | |
| AII | ESCORT | 2.0L (MPI 16V) | RAP - Remote Anti-Theft / Personality Module | | X | X | X | |
| AII | ESCORT | 2.0L (MPI 16V) | CSM - Security module | | X | X | X | |
| AII | ESCORT | 2.0L (MPI 16V) | PATS - Passive Anti-Theft System | | X | X | X | |

| | | | | | | | | |
|-----|----------|-----------------|---|--|---|---|---|--|
| AII | ESCORT | 2.0L(SPI) | PCM - Powertrain Control Module | | X | X | | |
| AII | ESCORT | 2.0L(SPI) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | | |
| AII | ESCORT | 2.0L(SPI) | RCM - Restraint Control Module | | X | X | | |
| AII | ESCORT | 2.0L(Zetec) | PCM - Powertrain Control Module | | X | X | | |
| AII | EXPLORER | 4.0L (SOHC SFI) | PCM - Powertrain Control Module | | X | X | X | |
| AII | EXPLORER | 4.0L (SOHC SFI) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| AII | EXPLORER | 4.0L (SOHC SFI) | ARC - Automatic Ride Control | | X | X | X | |
| AII | EXPLORER | 4.0L (SOHC SFI) | CTM - Central timer module | | X | X | X | |
| AII | EXPLORER | 4.0L (SOHC SFI) | DSM - Drivers Seat Module | | X | X | X | |
| AII | EXPLORER | 4.0L (SOHC SFI) | EATC - Electronic Automatic Temperature Control | | X | X | X | |
| AII | EXPLORER | 4.0L (SOHC SFI) | GEM - Generic electric module(CTM) | | X | X | X | |
| AII | EXPLORER | 4.0L (SOHC SFI) | PAM - Parking Aid Module | | X | X | X | |
| AII | EXPLORER | 4.0L (SOHC SFI) | RAP - Remote Anti-Theft / Personality Module | | X | X | X | |
| AII | EXPLORER | 4.0L (SOHC SFI) | RCM - Restraint Control Module | | X | X | X | |
| AII | EXPLORER | 5.0L | PCM - Powertrain Control Module | | X | X | X | |
| AII | EXPLORER | 5.0L | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| AII | EXPLORER | 5.0L | ARC - Automatic Ride Control | | X | X | X | |
| AII | EXPLORER | 5.0L | CTM - Central timer module | | X | X | X | |
| AII | EXPLORER | 5.0L | DSM - Drivers Seat Module | | X | X | X | |
| AII | EXPLORER | 5.0L | EATC - Electronic Automatic Temperature Control | | X | X | X | |
| AII | EXPLORER | 5.0L | GEM - Generic electric module(CTM) | | X | X | X | |
| AII | EXPLORER | 5.0L | PAM - Parking Aid Module | | X | X | X | |
| AII | EXPLORER | 5.0L | RAP - Remote Anti-Theft / Personality Module | | X | X | X | |
| AII | EXPLORER | 5.0L | RCM - Restraint Control Module | | X | X | X | |
| AII | EXPLORER | 4.0L(V6-SOHC) | PCM - Powertrain Control Module | | X | X | | |
| AII | EXPLORER | 4.0L(V6-SOHC) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | | |
| AII | EXPLORER | 4.0L(V6-SOHC) | RCM - Restraint Control Module | | X | X | | |
| AII | EXPLORER | 4.0L(V6-SOHC) | GEM - Generic electric module(CTM) | | X | X | | |
| AII | EXPLORER | 4.0L(V6-SOHC) | PATS - Passive Anti-Theft System | | X | X | | |
| AII | EXPLORER | 4.0L(Other) | PCM - Powertrain Control Module | | X | X | | |
| AII | EXPLORER | 4.0L(Other) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | | |
| AII | EXPLORER | 4.0L(Other) | RCM - Restraint Control Module | | X | X | | |
| AII | EXPLORER | 4.0L(Other) | GEM - Generic electric module(CTM) | | X | X | | |
| AII | EXPLORER | 4.0L(Other) | PATS - Passive Anti-Theft System | | X | X | | |
| AII | EXPLORER | 4.0L(V6-OHV) | PCM - Powertrain Control Module | | X | X | | |
| AII | EXPLORER | 4.0L(V6-OHV) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | | |
| AII | EXPLORER | 4.0L(V6-OHV) | RCM - Restraint Control Module | | X | X | | |
| AII | EXPLORER | 4.0L(V6-OHV) | GEM - Generic electric module(CTM) | | X | X | | |
| AII | EXPLORER | 4.0L(V6-OHV) | PATS - Passive Anti-Theft System | | X | X | | |
| AII | EXPLORER | 5.0L(Other) | PCM - Powertrain Control Module | | X | X | | |
| AII | EXPLORER | 5.0L(Other) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | | |
| AII | EXPLORER | 5.0L(Other) | RCM - Restraint Control Module | | X | X | | |
| AII | EXPLORER | 5.0L(Other) | GEM - Generic electric module(CTM) | | X | X | | |
| AII | EXPLORER | 5.0L(Other) | PATS - Passive Anti-Theft System | | X | X | | |
| AII | FIESTA | 1.25L(SFI) | PCM - Powertrain Control Module | | X | X | X | |

| | | | | | | | | |
|-----|--------|------------------------|---|--|---|---|---|---|
| AII | FIESTA | 1.25L(SFI) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| AII | FIESTA | 1.25L(SFI) | RCM - Restraint Control Module | | X | X | X | |
| AII | FIESTA | 1.25L(SFI) | PATS - Passive Anti-Theft System | | X | | | 1.Key Programming. |
| AII | FIESTA | 1.3L (SFI) | PCM - Powertrain Control Module | | X | X | X | |
| AII | FIESTA | 1.3L (SFI) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| AII | FIESTA | 1.3L (SFI) | RCM - Restraint Control Module | | X | X | X | |
| AII | FIESTA | 1.3L (SFI) | PATS - Passive Anti-Theft System | | X | | | 1.Key Programming. |
| AII | FIESTA | 1.4L (GHIA/SFI) | PCM - Powertrain Control Module | | X | X | X | |
| AII | FIESTA | 1.4L (GHIA/SFI) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| AII | FIESTA | 1.4L (GHIA/SFI) | RCM - Restraint Control Module | | X | X | X | |
| AII | FIESTA | 1.4L (GHIA/SFI) | ICM - Instrument Cluster | | X | X | X | |
| AII | FIESTA | 1.4L (GHIA/SFI) | PATS - Passive Anti-Theft System | | X | | | 1.Key Programming. |
| AII | FIESTA | 1.6L (SFI) | PCM - Powertrain Control Module | | X | X | X | |
| AII | FIESTA | 1.6L (SFI) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| AII | FIESTA | 1.6L (SFI) | RCM - Restraint Control Module | | X | X | X | |
| AII | FIESTA | 1.6L (SFI) | ICM - Instrument Cluster | | X | X | X | |
| AII | FIESTA | 1.6L (SFI) | PATS - Passive Anti-Theft System | | X | | | 1.Key Programming. |
| AII | | | | | | | | 1.Fuel Injector Coding. 2.Key Programming. |
| AII | FIESTA | 1.8L (DIESEL/T-DIESEL) | PCM - Powertrain Control Module | | X | X | X | |
| AII | FIESTA | 1.8L (DIESEL/T-DIESEL) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| AII | FIESTA | 1.8L (DIESEL/T-DIESEL) | RCM - Restraint Control Module | | X | X | X | |
| AII | FIESTA | 1.8L (DIESEL/T-DIESEL) | ICM - Instrument Cluster | | X | X | X | |
| AII | FIESTA | 1.8L (DIESEL/T-DIESEL) | PATS - Passive Anti-Theft System | | X | | | 1.Key Programming. |
| AII | FIESTA | 1.3L(Endura-E) | PCM - Powertrain Control Module | | X | X | | |
| AII | FIESTA | 1.3L(Endura-E) | GEM - Generic electric module(CTM) | | X | X | | |
| AII | FIESTA | 1.25L(Zetec-SE) | PCM - Powertrain Control Module | | X | X | | |
| AII | FIESTA | 1.25L(Zetec-SE) | GEM - Generic electric module(CTM) | | X | X | | |
| AII | FIESTA | 1.0L(HCS) | GEM - Generic electric module(CTM) | | X | X | | |
| AII | FIESTA | 1.6L(SOHC/Zetec-Rocam) | PCM - Powertrain Control Module | | X | X | | |
| AII | FIESTA | 1.6L(SOHC/Zetec-Rocam) | GEM - Generic electric module(CTM) | | X | X | | |
| AII | FIESTA | 1.8L(Zetec) | GEM - Generic electric module(CTM) | | X | X | | |
| AII | FIESTA | 1.0L(SOHC/Zetec-Rocam) | GEM - Generic electric module(CTM) | | X | X | | |
| AII | FIESTA | 1.4L(Zetec-SE) | PCM - Powertrain Control Module | | X | X | | |
| AII | FIESTA | 1.4L(Zetec-SE) | GEM - Generic electric module(CTM) | | X | X | | |
| AII | FIESTA | 1.4L(ZETEC_CFI/PT-E) | GEM - Generic electric module(CTM) | | X | X | | |
| AII | FIESTA | 1.25L(Zetec) | PCM - Powertrain Control Module | | X | X | | |
| AII | FIESTA | 1.25L(Zetec) | GEM - Generic electric module(CTM) | | X | X | | |
| AII | FOCUS | 1.4L (DOHC) | PCM - Powertrain Control Module | | X | X | X | |
| AII | FOCUS | 1.4L (DOHC) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| AII | FOCUS | 1.4L (DOHC) | RCM - Restraint Control Module | | X | X | X | |
| AII | FOCUS | 1.4L (DOHC) | PATS - Passive Anti-Theft System | | X | | | 1.Key Programming. |
| AII | FOCUS | 1.6L (SFI) | PCM - Powertrain Control Module | | X | X | X | |
| AII | FOCUS | 1.6L (SFI) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| AII | FOCUS | 1.6L (SFI) | RCM - Restraint Control Module | | X | X | X | |

| | | | | | | | | |
|-----|--------|--------------------------|---|--|---|---|---|---|
| AII | FOCUS | 1.6L (SFI) | PATS - Passive Anti-Theft System | | X | | | 1.Key Programming. |
| AII | FOCUS | 1.8L (SFI/DIESEL) | PCM - Powertrain Control Module | | X | X | X | 1.Fuel Injector Coding. 2.Key Programming. |
| AII | FOCUS | 1.8L (SFI/DIESEL) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| AII | FOCUS | 1.8L (SFI/DIESEL) | CSM - Security module | | X | X | X | |
| AII | FOCUS | 1.8L (SFI/DIESEL) | CTM - Central timer module | | X | X | X | |
| AII | FOCUS | 1.8L (SFI/DIESEL) | ECS - Electronic Crash Sensor | | X | X | X | |
| AII | FOCUS | 1.8L (SFI/DIESEL) | MCM - Information central module | | X | X | X | |
| AII | FOCUS | 1.8L (SFI/DIESEL) | PATS - Passive Anti-Theft System | | X | | | 1.Key Programming. |
| AII | FOCUS | 2.0L (SFI/VVT) | PCM - Powertrain Control Module | | X | X | X | |
| AII | FOCUS | 2.0L (SFI/VVT) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| AII | FOCUS | 2.0L (SFI/VVT) | CSM - Security module | | X | X | X | |
| AII | FOCUS | 2.0L (SFI/VVT) | CTM - Central timer module | | X | X | X | |
| AII | FOCUS | 2.0L (SFI/VVT) | ECS - Electronic Crash Sensor | | X | X | X | |
| AII | FOCUS | 2.0L (SFI/VVT) | MCM - Information central module | | X | X | X | |
| AII | FOCUS | 2.0L (SFI/VVT) | PATS - Passive Anti-Theft System | | X | | | 1.Key Programming. |
| AII | GALAXY | 1.9L (DIESEL/T-DIESEL) | PCM - Powertrain Control Module | | X | | | |
| AII | GALAXY | 1.9L (DIESEL/T-DIESEL) | TCM - Transmission Control Module | | X | | | |
| AII | GALAXY | 1.9L (DIESEL/T-DIESEL) | ABS - Anti-Lock Brake / Traction Control Module | | X | | | |
| AII | GALAXY | 1.9L (DIESEL/T-DIESEL) | RCM - Restraint Control Module | | X | | | |
| AII | GALAXY | 1.9L (DIESEL/T-DIESEL) | ICM - Instrument Cluster | | X | | | |
| AII | GALAXY | 1.9L (DIESEL/T-DIESEL) | NAV - Navigation System | | X | | | |
| AII | GALAXY | 2.0L (EFI DOHC/SFI DOHC) | PCM - Powertrain Control Module | | X | | | |
| AII | GALAXY | 2.0L (EFI DOHC/SFI DOHC) | TCM - Transmission Control Module | | X | | | |
| AII | GALAXY | 2.0L (EFI DOHC/SFI DOHC) | ABS - Anti-Lock Brake / Traction Control Module | | X | | | |
| AII | GALAXY | 2.0L (EFI DOHC/SFI DOHC) | RCM - Restraint Control Module | | X | | | |
| AII | GALAXY | 2.0L (EFI DOHC/SFI DOHC) | ICM - Instrument Cluster | | X | | | |
| AII | GALAXY | 2.0L (EFI DOHC/SFI DOHC) | NAV - Navigation System | | X | | | |
| AII | GALAXY | 2.3L (DOHC 16V) | PCM - Powertrain Control Module | | X | | | |
| AII | GALAXY | 2.3L (DOHC 16V) | TCM - Transmission Control Module | | X | | | |
| AII | GALAXY | 2.3L (DOHC 16V) | ABS - Anti-Lock Brake / Traction Control Module | | X | | | |
| AII | GALAXY | 2.3L (DOHC 16V) | RCM - Restraint Control Module | | X | | | |
| AII | GALAXY | 2.3L (DOHC 16V) | ICM - Instrument Cluster | | X | | | |
| AII | GALAXY | 2.3L (DOHC 16V) | NAV - Navigation System | | X | | | |
| AII | GALAXY | 2.8L (V6 SFI) | PCM - Powertrain Control Module | | X | | | |
| AII | GALAXY | 2.8L (V6 SFI) | TCM - Transmission Control Module | | X | | | |
| AII | GALAXY | 2.8L (V6 SFI) | ABS - Anti-Lock Brake / Traction Control Module | | X | | | |
| AII | GALAXY | 2.8L (V6 SFI) | RCM - Restraint Control Module | | X | | | |
| AII | GALAXY | 2.8L (V6 SFI) | ICM - Instrument Cluster | | X | | | |
| AII | GALAXY | 2.8L (V6 SFI) | NAV - Navigation System | | X | | | |
| AII | RANGER | 2.2L (F2) | PCM - Powertrain Control Module | | X | X | | |
| AII | RANGER | 2.2L (F2) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | | |
| AII | RANGER | 2.5L(DIESEL/T-DIESEL) | PCM - Powertrain Control Module | | X | X | | |
| AII | RANGER | 2.5L(DIESEL/T-DIESEL) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | | |

| | | | | | | | | |
|-----|------------------------|----------------|---|--|---|---|--|--------------------|
| AII | RANGER | 2.6L (G6) | PCM - Powertrain Control Module | | X | X | | |
| AII | RANGER | 2.6L (G6) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | | |
| AII | KA | 1.3L (SFI) | PCM - Powertrain Control Module | | X | X | | |
| AII | KA | 1.3L (SFI) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | | |
| AII | KA | 1.3L (SFI) | ECS - Electronic Crash Sensor(or IABM) | | X | X | | |
| AII | KA | 1.3L (SFI) | EPS - Electronic Controlled Power Steering | | X | X | | |
| AII | KA | 1.3L (SFI) | GEM - Generic electric module(CTM) | | X | X | | |
| AII | KA | 1.3L (SFI) | PATS - Passive Anti-Theft System | | X | X | | 1.Key Programming. |
| AII | KA | 1.6L | PCM - Powertrain Control Module | | X | X | | |
| AII | KA | 1.6L | ABS - Anti-Lock Brake / Traction Control Module | | X | X | | |
| AII | KA | 1.6L | ECS - Electronic Crash Sensor(or IABM) | | X | X | | |
| AII | KA | 1.6L | EPS - Electronic Controlled Power Steering | | X | X | | |
| AII | KA | 1.6L | GEM - Generic electric module(CTM) | | X | X | | |
| AII | KA | 1.6L | PATS - Passive Anti-Theft System | | X | X | | |
| AII | MAVERICK | 2.4L (SFI) | PCM - Powertrain Control Module | | X | X | | |
| AII | MAVERICK | 2.4L (SFI) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | | |
| AII | MAVERICK | 2.4L (SFI) | RCM - Restraint Control Module | | X | X | | |
| AII | MAVERICK | 2.4L (SFI) | GEM - Generic electric module(CTM) | | X | X | | |
| AII | MAVERICK | 2.4L (SFI) | PAM - Parking Aid Module | | X | X | | |
| AII | MAVERICK | 2.4L (SFI) | 4X4M - 4X4 Control Module | | X | X | | |
| AII | MAVERICK | 2.7L(T-DIESEL) | PCM - Powertrain Control Module | | X | X | | |
| AII | MAVERICK | 2.7L(T-DIESEL) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | | |
| AII | MAVERICK | 2.7L(T-DIESEL) | RCM - Restraint Control Module | | X | X | | |
| AII | MAVERICK | 2.7L(T-DIESEL) | GEM - Generic electric module(CTM) | | X | X | | |
| AII | MAVERICK | 2.7L(T-DIESEL) | PAM - Parking Aid Module | | X | X | | |
| AII | MAVERICK | 2.7L(T-DIESEL) | 4X4M - 4X4 Control Module | | X | X | | |
| AII | F-SERIES SUPER DUTY | 5.4L | PCM - Powertrain Control Module | | X | | | |
| AII | F-SERIES SUPER DUTY | 5.4L | ABS - Anti-Lock Brake / Traction Control Module | | X | X | | |
| AII | F-SERIES SUPER DUTY | 5.4L | RCM - Restraint Control Module | | X | X | | |
| AII | F-SERIES SUPER DUTY | 5.4L | TCM - Transmission Control Module | | X | X | | |
| AII | F-SERIES SUPER DUTY | 5.4L | ICM - Instrument Cluster | | X | X | | |
| AII | F-SERIES SUPER DUTY | 5.4L | GEM - Generic electric module(CTM) | | X | X | | |
| AII | F-SERIES SUPER DUTY | 5.4L | PATS - Passive Anti-Theft System | | X | X | | |
| AII | F-SERIES SUPER DUTY | 6.0L | PCM - Powertrain Control Module | | X | | | |
| AII | F-SERIES SUPER DUTY | 6.0L | ABS - Anti-Lock Brake / Traction Control Module | | X | X | | |

| | | | | | | | | |
|-----|------------------------|------------------------|---|--|---|---|---|---|
| All | F-SERIES SUPER DUTY | 6.0L | RCM - Restraint Control Module | | X | X | | |
| All | F-SERIES SUPER DUTY | 6.0L | TCM - Transmission Control Module | | X | X | | |
| All | F-SERIES SUPER DUTY | 6.0L | ICM - Instrument Cluster | | X | X | | |
| All | F-SERIES SUPER DUTY | 6.0L | GEM - Generic electric module(CTM) | | X | X | | |
| All | F-SERIES SUPER DUTY | 6.0L | PATS - Passive Anti-Theft System | | X | X | | |
| All | F-SERIES SUPER DUTY | 6.8L | PCM - Powertrain Control Module | | X | | | |
| All | F-SERIES SUPER DUTY | 6.8L | ABS - Anti-Lock Brake / Traction Control Module | | X | X | | |
| All | F-SERIES SUPER DUTY | 6.8L | RCM - Restraint Control Module | | X | X | | |
| All | F-SERIES SUPER DUTY | 6.8L | TCM - Transmission Control Module | | X | X | | |
| All | F-SERIES SUPER DUTY | 6.8L | ICM - Instrument Cluster | | X | X | | |
| All | F-SERIES SUPER DUTY | 6.8L | GEM - Generic electric module(CTM) | | X | X | | |
| All | F-SERIES SUPER DUTY | 6.8L | PATS - Passive Anti-Theft System | | X | X | | |
| All | F-SERIES SUPER DUTY | 7.3L | PCM - Powertrain Control Module | | X | | | |
| All | F-SERIES SUPER DUTY | 7.3L | ABS - Anti-Lock Brake / Traction Control Module | | X | X | | |
| All | F-SERIES SUPER DUTY | 7.3L | RCM - Restraint Control Module | | X | X | | |
| All | F-SERIES SUPER DUTY | 7.3L | TCM - Transmission Control Module | | X | X | | |
| All | F-SERIES SUPER DUTY | 7.3L | ICM - Instrument Cluster | | X | X | | |
| All | F-SERIES SUPER DUTY | 7.3L | GEM - Generic electric module(CTM) | | X | X | | |
| All | F-SERIES SUPER DUTY | 7.3L | PATS - Passive Anti-Theft System | | X | X | | |
| All | MONDEO | 1.6L (SFI) | PCM - Powertrain Control Module | | X | X | X | |
| All | MONDEO | 1.6L (SFI) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| All | MONDEO | 1.6L (SFI) | CSM - Security module | | X | X | X | |
| All | MONDEO | 1.6L (SFI) | PATS - Passive Anti-Theft System | | X | | | 1.Key Programming. |
| All | MONDEO | 1.8L (HC/SFI/T-DIESEL) | PCM - Powertrain Control Module | | X | X | X | 1.Fuel Injector Coding. 2.Key Programming. |

| | | | | | | | | |
|-----|----------|--------------------------|---|--|---|---|---|--------------------|
| AII | MONDEO | 1.8L (HC/SFI/T-DIESEL) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| AII | MONDEO | 1.8L (HC/SFI/T-DIESEL) | CSM - Security module | | X | X | X | |
| AII | MONDEO | 1.8L (HC/SFI/T-DIESEL) | PATS - Passive Anti-Theft System | | X | X | X | |
| AII | MONDEO | 1.8L (HC/SFI/T-DIESEL) | RIM - Remote Anti-Theft / Personality Module | | X | X | X | |
| AII | MONDEO | 2.0L (HC HTX/HC MTX/SFI) | PCM - Powertrain Control Module | | X | X | X | |
| AII | MONDEO | 2.0L (HC HTX/HC MTX/SFI) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| AII | MONDEO | 2.0L (HC HTX/HC MTX/SFI) | CSM - Security module | | X | X | X | |
| AII | MONDEO | 2.0L (HC HTX/HC MTX/SFI) | PATS - Passive Anti-Theft System | | X | | | 1.Key Programming. |
| AII | MONDEO | 2.5L (HC/SFI) | PCM - Powertrain Control Module | | X | X | X | |
| AII | MONDEO | 2.5L (HC/SFI) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| AII | MONDEO | 2.5L (HC/SFI) | CSM - Security module | | X | X | X | |
| AII | MONDEO | 2.5L (HC/SFI) | PATS - Passive Anti-Theft System | | X | | | 1.Key Programming. |
| AII | PROBE | 2.0L (MPI) | PCM - Powertrain Control Module | | X | X | X | |
| AII | PROBE | 2.0L (MPI) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| AII | PROBE | 2.2L (MPI) | PCM - Powertrain Control Module | | X | X | X | |
| AII | PROBE | 2.2L (MPI) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| AII | PROBE | 2.5L (MPI) | PCM - Powertrain Control Module | | X | X | X | |
| AII | PROBE | 2.5L (MPI) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| AII | PUMA | 1.4L (SFI) | PCM - Powertrain Control Module | | X | X | X | |
| AII | PUMA | 1.4L (SFI) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| AII | PUMA | 1.4L (SFI) | GEM - Generic electric module(CTM) | | X | X | X | |
| AII | PUMA | 1.7L (SFI) | PCM - Powertrain Control Module | | X | X | X | |
| AII | PUMA | 1.7L (SFI) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| AII | PUMA | 1.7L (SFI) | GEM - Generic electric module(CTM) | | X | X | X | |
| AII | RANGER | 2.5L (DIESEL/T-DIESEL) | PCM - Powertrain Control Module | | X | X | X | |
| AII | RANGER | 2.5L (DIESEL/T-DIESEL) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| AII | SCORPIO | 2.0L (16V DOHC/8V DOHC) | PCM - Powertrain Control Module | | X | X | X | |
| AII | SCORPIO | 2.0L (16V DOHC/8V DOHC) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| AII | SCORPIO | 2.3L (16V DOHC) | PCM - Powertrain Control Module | | X | X | X | |
| AII | SCORPIO | 2.3L (16V DOHC) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| AII | SCORPIO | 2.9L (12V V6/24V V6) | PCM - Powertrain Control Module | | X | X | X | |
| AII | SCORPIO | 2.9L (12V V6/24V V6) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| AII | TRANSIT | 2.0L (MPI/SFI 8V) | PCM - Powertrain Control Module | | X | X | X | |
| AII | TRANSIT | 2.0L (MPI/SFI 8V) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| AII | TRANSIT | 2.0L (MPI/SFI 8V) | PATS - Passive Anti-Theft System | | X | | | 1.Key Programming. |
| AII | TRANSIT | 2.5L (DIESEL/T-DIESEL) | PCM - Powertrain Control Module | | X | X | X | |
| AII | TRANSIT | 2.5L (DIESEL/T-DIESEL) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| AII | TRANSIT | 2.5L (DIESEL/T-DIESEL) | PATS - Passive Anti-Theft System | | X | | | 1.Key Programming. |
| AII | WINDSTAR | 3.0L (V6 SFI) | PCM - Powertrain Control Module | | X | X | X | |
| AII | WINDSTAR | 3.0L (V6 SFI) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| AII | WINDSTAR | 3.0(V6-OHV) | PCM - Powertrain Control Module | | X | X | | |
| AII | WINDSTAR | 3.0(V6-OHV) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | | |
| AII | WINDSTAR | 3.0(V6-OHV) | ICM - Instrument Cluster | | X | X | | |
| AII | WINDSTAR | 3.8(V6-OHV) | PCM - Powertrain Control Module | | X | X | | |
| AII | WINDSTAR | 3.8(V6-OHV) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | | |

| | | | | | | | | |
|-----|------------------|--------------|---|--|---|---|--|--|
| All | WINDSTAR | 3.8(V6-OHV) | ICM - Instrument Cluster | | X | X | | |
| All | CROWN-VICTORIA | 4.6L(2V) | PCM - Powertrain Control Module | | X | X | | |
| All | CROWN-VICTORIA | 4.6L(2V) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | | |
| All | CROWN-VICTORIA | 4.6L(2V) | PATS - Passive Anti-Theft System | | X | X | | |
| All | CROWN-VICTORIA | 4.6L(2V-NGV) | PCM - Powertrain Control Module | | X | X | | |
| All | CROWN-VICTORIA | 4.6L(2V-NGV) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | | |
| All | CROWN-VICTORIA | 4.6L(2V-NGV) | PATS - Passive Anti-Theft System | | X | X | | |
| All | F-250 LIGHT DUTY | 4.2L(NGV) | PCM - Powertrain Control Module | | X | X | | |
| All | F-250 LIGHT DUTY | 4.2L(NGV) | ICM - Instrument Cluster | | X | X | | |
| All | F-250 LIGHT DUTY | 4.2L(NGV) | GEM - Generic electric module(CTM) | | X | X | | |
| All | F-250 LIGHT DUTY | 4.6L(BIF) | PCM - Powertrain Control Module | | X | X | | |
| All | F-250 LIGHT DUTY | 4.6L(BIF) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | | |
| All | F-250 LIGHT DUTY | 4.6L(BIF) | RCM - Restraint Control Module | | X | X | | |
| All | F-250 LIGHT DUTY | 4.6L(BIF) | ICM - Instrument Cluster | | X | X | | |
| All | F-250 LIGHT DUTY | 4.6L(BIF) | GEM - Generic electric module(CTM) | | X | X | | |
| All | F-250 LIGHT DUTY | 5.4L(NGV) | PCM - Powertrain Control Module | | X | X | | |
| All | F-250 LIGHT DUTY | 5.4L(NGV) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | | |
| All | F-250 LIGHT DUTY | 5.4L(NGV) | RCM - Restraint Control Module | | X | X | | |
| All | F-250 LIGHT DUTY | 5.4L(NGV) | ICM - Instrument Cluster | | X | X | | |
| All | F-250 LIGHT DUTY | 5.4L(NGV) | GEM - Generic electric module(CTM) | | X | X | | |
| All | EXPEDITION | 4.6L(Other) | PCM - Powertrain Control Module | | X | X | | |
| All | EXPEDITION | 4.6L(Other) | RCM - Restraint Control Module | | X | X | | |
| All | EXPEDITION | 5.4L(4V) | PCM - Powertrain Control Module | | X | X | | |
| All | EXPEDITION | 5.4L(4V) | RCM - Restraint Control Module | | X | X | | |
| All | EXPEDITION | 5.4L(Other) | PCM - Powertrain Control Module | | X | X | | |

| | | | | | | | | |
|-----|------------|------------------------|---|--|---|---|---|--|
| AII | EXPEDITION | 5.4L(Other) | RCM - Restraint Control Module | | X | X | | |
| AII | CONTOUR | 2.0L | PCM - Powertrain Control Module | | X | X | X | |
| AII | CONTOUR | 2.0L | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| AII | CONTOUR | 2.0L | CSM - Security module | | X | X | X | |
| AII | CONTOUR | 2.0L | RCM - Restraint Control Module | | X | X | X | |
| AII | CONTOUR | 2.5L | PCM - Powertrain Control Module | | X | X | X | |
| AII | CONTOUR | 2.5L | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| AII | CONTOUR | 2.5L | CSM - Security module | | X | X | X | |
| AII | CONTOUR | 2.5L | RCM - Restraint Control Module | | X | X | X | |
| AII | COGUAR | 2.0L (SFI) | PCM - Powertrain Control Module | | X | X | X | |
| AII | COGUAR | 2.0L (SFI) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| AII | COGUAR | 2.0L (SFI) | CSM - Security module | | X | X | X | |
| AII | COGUAR | 2.0L (SFI) | ECS - Electronic Crash Sensor | | X | X | X | |
| AII | COGUAR | 2.5L (SFI) | PCM - Powertrain Control Module | | X | X | X | |
| AII | COGUAR | 2.5L (SFI) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| AII | COGUAR | 2.5L (SFI) | CSM - Security module | | X | X | X | |
| AII | COGUAR | 2.5L (SFI) | ECS - Electronic Crash Sensor | | X | X | X | |
| AII | COUGAR | 2.0L(2V) | PCM - Powertrain Control Module | | X | X | | |
| AII | COUGAR | 2.0L(2V) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | | |
| AII | COUGAR | 2.0L(2V) | RCM - Restraint Control Module | | X | X | | |
| AII | COUGAR | 2.0L(2V) | ICM - Instrument Cluster | | X | X | | |
| AII | COUGAR | 2.5L(2V) | PCM - Powertrain Control Module | | X | X | | |
| AII | COUGAR | 2.5L(2V) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | | |
| AII | COUGAR | 2.5L(2V) | RCM - Restraint Control Module | | X | X | | |
| AII | COUGAR | 2.5L(2V) | ICM - Instrument Cluster | | X | X | | |
| AII | COUGAR | 2.0L(ZETEC) | PCM - Powertrain Control Module | | X | X | | |
| AII | COUGAR | 2.5L(Duratec-VE) | PCM - Powertrain Control Module | | X | X | | |
| AII | ECONOVAN | 1.4L (2BL OHC) | PCM - Powertrain Control Module | | X | X | X | |
| AII | ECONOVAN | 1.4L (2BL OHC) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| AII | ECONOVAN | 1.4L (2BL OHC) | ECS - Electronic Crash Sensor | | X | X | X | |
| AII | ECONOVAN | 2.0L (DIESEL) | PCM - Powertrain Control Module | | X | X | X | |
| AII | ECONOVAN | 2.0L (DIESEL) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| AII | ECONOVAN | 2.0L (DIESEL) | ECS - Electronic Crash Sensor | | X | X | X | |
| AII | ESCORT | 1.3L (CFI/HCS/SFI) | PCM - Powertrain Control Module | | X | X | X | |
| AII | ESCORT | 1.3L (CFI/HCS/SFI) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| AII | ESCORT | 1.3L (CFI/HCS/SFI) | HEC - Hybrid Electronic Cluster | | X | X | X | |
| AII | ESCORT | 1.3L (CFI/HCS/SFI) | PATS - Passive Anti-Theft System | | X | X | X | |
| AII | ESCORT | 1.4L (HCS/CVH/EFI/SFI) | PCM - Powertrain Control Module | | X | X | X | |
| AII | ESCORT | 1.4L (HCS/CVH/EFI/SFI) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| AII | ESCORT | 1.4L (HCS/CVH/EFI/SFI) | HEC - Hybrid Electronic Cluster | | X | X | X | |
| AII | ESCORT | 1.4L (HCS/CVH/EFI/SFI) | PATS - Passive Anti-Theft System | | X | X | X | |
| AII | ESCORT | 1.6L (CFI/SFI) | PCM - Powertrain Control Module | | X | X | X | |
| AII | ESCORT | 1.6L (CFI/SFI) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| AII | ESCORT | 1.6L (CFI/SFI) | HEC - Hybrid Electronic Cluster | | X | X | X | |
| AII | ESCORT | 1.6L (CFI/SFI) | PATS - Passive Anti-Theft System | | X | X | X | |

| | | | | | | | | |
|-----|----------|----------------------------|---|--|---|---|---|--|
| AII | ESCORT | 1.8L (SFI/DIESEL/T-DIESEL) | PCM - Powertrain Control Module | | X | X | X | |
| AII | ESCORT | 1.8L (SFI/DIESEL/T-DIESEL) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| AII | ESCORT | 1.8L (SFI/DIESEL/T-DIESEL) | HEC - Hybrid Electronic Cluster | | X | X | X | |
| AII | ESCORT | 1.8L (SFI/DIESEL/T-DIESEL) | PATS - Passive Anti-Theft System | | X | X | X | |
| AII | ESCORT | 1.8L (SFI/DIESEL/T-DIESEL) | RIM - Remote Anti-Theft / Personality Module | | X | X | X | |
| AII | ESCORT | 2.0L (MPI 16V) | PCM - Powertrain Control Module | | X | X | X | |
| AII | ESCORT | 2.0L (MPI 16V) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| AII | ESCORT | 2.0L (MPI 16V) | CSM - Security module | | X | X | X | |
| AII | ESCORT | 2.0L (MPI 16V) | ECS - Electronic Crash Sensor | | X | X | X | |
| AII | ESCORT | 2.0L (MPI 16V) | PATS - Passive Anti-Theft System | | X | X | X | |
| AII | ESCORT | 2.0L (MPI 16V) | RAP - Remote Anti-Theft / Personality Module | | X | X | X | |
| AII | ESCORT | 2.0L (SPI) | PCM - Powertrain Control Module | | X | X | | |
| AII | ESCORT | 2.0L (SPI) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | | |
| AII | ESCORT | 2.0L (SPI) | RCM - Restraint Control Module | | X | X | | |
| AII | ESCORT | 2.0L (Zetec) | PCM - Powertrain Control Module | | X | X | | |
| AII | ESCORT | 1.6L (SOHC/Zetec-Rocam) | PCM - Powertrain Control Module | | X | X | | |
| AII | EXPLORER | 4.0L (SOHC SFI) | PCM - Powertrain Control Module | | X | X | X | |
| AII | EXPLORER | 4.0L (SOHC SFI) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| AII | EXPLORER | 4.0L (SOHC SFI) | ARC - Automatic Ride Control | | X | X | X | |
| AII | EXPLORER | 4.0L (SOHC SFI) | CTM - Central timer module | | X | X | X | |
| AII | EXPLORER | 4.0L (SOHC SFI) | DSM - Drivers Seat Module | | X | X | X | |
| AII | EXPLORER | 4.0L (SOHC SFI) | EATC - Electronic Automatic Temperature Control | | X | X | X | |
| AII | EXPLORER | 4.0L (SOHC SFI) | GEM - Generic electric module(CTM) | | X | X | X | |
| AII | EXPLORER | 4.0L (SOHC SFI) | PAM - Parking Aid Module | | X | X | X | |
| AII | EXPLORER | 4.0L (SOHC SFI) | RAP - Remote Anti-Theft / Personality Module | | X | X | X | |
| AII | EXPLORER | 4.0L (SOHC SFI) | RCM - Restraint Control Module | | X | X | X | |
| AII | EXPLORER | 5.0L | PCM - Powertrain Control Module | | X | X | X | |
| AII | EXPLORER | 5.0L | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| AII | EXPLORER | 5.0L | ARC - Automatic Ride Control | | X | X | X | |
| AII | EXPLORER | 5.0L | CTM - Central timer module | | X | X | X | |
| AII | EXPLORER | 5.0L | DSM - Drivers Seat Module | | X | X | X | |
| AII | EXPLORER | 5.0L | EATC - Electronic Automatic Temperature Control | | X | X | X | |
| AII | EXPLORER | 5.0L | GEM - Generic electric module(CTM) | | X | X | X | |
| AII | EXPLORER | 5.0L | PAM - Parking Aid Module | | X | X | X | |
| AII | EXPLORER | 5.0L | RAP - Remote Anti-Theft / Personality Module | | X | X | X | |
| AII | EXPLORER | 5.0L | RCM - Restraint Control Module | | X | X | X | |
| AII | EXPLORER | 4.0L(V6-SOHC) | PCM - Powertrain Control Module | | X | X | | |
| AII | EXPLORER | 4.0L(V6-SOHC) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | | |
| AII | EXPLORER | 4.0L(V6-SOHC) | RCM - Restraint Control Module | | X | X | | |
| AII | EXPLORER | 4.0L(V6-SOHC) | GEM - Generic electric module(CTM) | | X | X | | |
| AII | EXPLORER | 4.0L(V6-SOHC) | PATS - Passive Anti-Theft System | | X | X | | |
| AII | EXPLORER | 4.0L(Other) | PCM - Powertrain Control Module | | X | X | | |
| AII | EXPLORER | 4.0L(Other) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | | |
| AII | EXPLORER | 4.0L(Other) | RCM - Restraint Control Module | | X | X | | |
| AII | EXPLORER | 4.0L(Other) | GEM - Generic electric module(CTM) | | X | X | | |

| | | | | | | | | |
|-----|----------|------------------------|---|--|---|---|---|---|
| All | EXPLORER | 4.0L(Other) | PATS - Passive Anti-Theft System | | X | X | | |
| All | EXPLORER | 5.0L(Other) | PCM - Powertrain Control Module | | X | X | | |
| All | EXPLORER | 5.0L(Other) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | | |
| All | EXPLORER | 5.0L(Other) | RCM - Restraint Control Module | | X | X | | |
| All | EXPLORER | 5.0L(Other) | GEM - Generic electric module(CTM) | | X | X | | |
| All | EXPLORER | 5.0L(Other) | PATS - Passive Anti-Theft System | | X | X | | |
| All | FIESTA | 1.25L(SFI) | PCM - Powertrain Control Module | | X | X | X | |
| All | FIESTA | 1.25L(SFI) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| All | FIESTA | 1.25L(SFI) | ECS - Electronic Crash Sensor | | X | X | X | |
| All | FIESTA | 1.25L(SFI) | PATS - Passive Anti-Theft System | | X | | | 1.Key Programming. |
| All | FIESTA | 1.3L (SFI) | PCM - Powertrain Control Module | | X | X | X | |
| All | FIESTA | 1.3L (SFI) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| All | FIESTA | 1.3L (SFI) | ECS - Electronic Crash Sensor | | X | X | X | |
| All | FIESTA | 1.3L (SFI) | PATS - Passive Anti-Theft System | | X | | | 1.Key Programming. |
| All | FIESTA | 1.4L (GHIA/SFI) | PCM - Powertrain Control Module | | X | X | X | |
| All | FIESTA | 1.4L (GHIA/SFI) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| All | FIESTA | 1.4L (GHIA/SFI) | ECS - Electronic Crash Sensor | | X | X | X | |
| All | FIESTA | 1.4L (GHIA/SFI) | PATS - Passive Anti-Theft System | | X | | | 1.Key Programming. |
| All | FIESTA | 1.6L (SFI) | PCM - Powertrain Control Module | | X | X | X | |
| All | FIESTA | 1.6L (SFI) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| All | FIESTA | 1.6L (SFI) | ECS - Electronic Crash Sensor | | X | X | X | |
| All | FIESTA | 1.6L (SFI) | PATS - Passive Anti-Theft System | | X | | | 1.Key Programming. |
| All | FIESTA | 1.8L (DIESEL/T-DIESEL) | PCM - Powertrain Control Module | | X | X | X | 1.Fuel Injector Coding. 2.Key Programming. |
| All | FIESTA | 1.8L (DIESEL/T-DIESEL) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| All | FIESTA | 1.8L (DIESEL/T-DIESEL) | ECS - Electronic Crash Sensor | | X | X | X | |
| All | FIESTA | 1.8L (DIESEL/T-DIESEL) | PATS - Passive Anti-Theft System | | X | | | 1.Key Programming. |
| All | FIESA | 1.8L(Endura-DI) | PCM - Powertrain Control Module | | X | X | | |
| All | FIESA | 1.8L(Endura-DI) | GEM - Generic electric module(CTM) | | X | X | | |
| All | FIESA | 1.25L(Zetec-SE) | PCM - Powertrain Control Module | | X | X | | |
| All | FIESA | 1.25L(Zetec-SE) | GEM - Generic electric module(CTM) | | X | X | | |
| All | FIESA | 1.4L(ZETEC_CF/PT-E) | GEM - Generic electric module(CTM) | | X | X | | |
| All | FIESA | 1.6L(Zetec-SE) | PCM - Powertrain Control Module | | X | X | | |
| All | FIESA | 1.6L(Zetec-SE) | GEM - Generic electric module(CTM) | | X | X | | |
| All | FOCUS | 1.4L (DOHC) | PCM - Powertrain Control Module | | X | X | X | |
| All | FOCUS | 1.4L (DOHC) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| All | FOCUS | 1.4L (DOHC) | RCM - Restraint Control Module | | X | X | X | |
| All | FOCUS | 1.4L (DOHC) | PATS - Passive Anti-Theft System | | X | | | 1.Key Programming. |
| All | FOCUS | 1.6L (SFI) | PCM - Powertrain Control Module | | X | X | X | |
| All | FOCUS | 1.6L (SFI) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| All | FOCUS | 1.6L (SFI) | RCM - Restraint Control Module | | X | X | X | |
| All | FOCUS | 1.6L (SFI) | PATS - Passive Anti-Theft System | | X | | | 1.Key Programming. |
| All | FOCUS | 1.8L (SFI/DIESEL) | PCM - Powertrain Control Module | | X | X | X | 1.Fuel Injector Coding. 2.Key Programming. |

| | | | | | | | | |
|-----|--------|-------------------------------|---|--|---|---|---|--------------------|
| AII | FOCUS | 1.8L (SFI/DIESEL) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| AII | FOCUS | 1.8L (SFI/DIESEL) | CSM - Security module | | X | X | X | |
| AII | FOCUS | 1.8L (SFI/DIESEL) | CTM - Central timer module | | X | X | X | |
| AII | FOCUS | 1.8L (SFI/DIESEL) | ECS - Electronic Crash Sensor | | X | X | X | |
| AII | FOCUS | 1.8L (SFI/DIESEL) | MCM - Information central module | | X | X | X | |
| AII | FOCUS | 1.8L (SFI/DIESEL) | PATS - Passive Anti-Theft System | | X | | | 1.Key Programming. |
| AII | FOCUS | 2.0L (SFI/VVT) | PCM - Powertrain Control Module | | X | X | X | |
| AII | FOCUS | 2.0L (SFI/VVT) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| AII | FOCUS | 2.0L (SFI/VVT) | CSM - Security module | | X | X | X | |
| AII | FOCUS | 2.0L (SFI/VVT) | CTM - Central timer module | | X | X | X | |
| AII | FOCUS | 2.0L (SFI/VVT) | ECS - Electronic Crash Sensor | | X | X | X | |
| AII | FOCUS | 2.0L (SFI/VVT) | MCM - Information central module | | X | X | X | |
| AII | FOCUS | 2.0L (SFI/VVT) | PATS - Passive Anti-Theft System | | X | | | 1.Key Programming. |
| AII | GALAXY | 1.8L (DOHC) | PCM - Powertrain Control Module | | X | X | X | |
| AII | GALAXY | 1.8L (DOHC) | TCM - Transmission Control Module | | X | X | X | |
| AII | GALAXY | 1.8L (DOHC) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| AII | GALAXY | 1.8L (DOHC) | RCM - Restraint Control Module | | X | X | X | |
| AII | GALAXY | 1.8L (DOHC) | ICM - Instrument Cluster | | X | X | X | |
| AII | GALAXY | 1.8L (DOHC) | NAV - Navigation System | | X | X | X | |
| AII | GALAXY | 1.9L (DIESEL/T-DIESEL) | PCM - Powertrain Control Module | | X | | | |
| AII | GALAXY | 1.9L (DIESEL/T-DIESEL) | TCM - Transmission Control Module | | X | | | |
| AII | GALAXY | 1.9L (DIESEL/T-DIESEL) | ABS - Anti-Lock Brake / Traction Control Module | | X | | | |
| AII | GALAXY | 1.9L (DIESEL/T-DIESEL) | RCM - Restraint Control Module | | X | | | |
| AII | GALAXY | 1.9L (DIESEL/T-DIESEL) | ICM - Instrument Cluster | | X | | | |
| AII | GALAXY | 1.9L (DIESEL/T-DIESEL) | NAV - Navigation System | | X | | | |
| AII | GALAXY | 2.0L (DOHC/EFI DOHC/SFI DOHC) | PCM - Powertrain Control Module | | X | | | |
| AII | GALAXY | 2.0L (DOHC/EFI DOHC/SFI DOHC) | TCM - Transmission Control Module | | X | | | |
| AII | GALAXY | 2.0L (DOHC/EFI DOHC/SFI DOHC) | ABS - Anti-Lock Brake / Traction Control Module | | X | | | |
| AII | GALAXY | 2.0L (DOHC/EFI DOHC/SFI DOHC) | RCM - Restraint Control Module | | X | | | |
| AII | GALAXY | 2.0L (DOHC/EFI DOHC/SFI DOHC) | ICM - Instrument Cluster | | X | | | |
| AII | GALAXY | 2.0L (DOHC/EFI DOHC/SFI DOHC) | NAV - Navigation System | | X | | | |
| AII | GALAXY | 2.3L (DOHC/DOHC 16V) | PCM - Powertrain Control Module | | X | | | |
| AII | GALAXY | 2.3L (DOHC/DOHC 16V) | TCM - Transmission Control Module | | X | | | |
| AII | GALAXY | 2.3L (DOHC/DOHC 16V) | ABS - Anti-Lock Brake / Traction Control Module | | X | | | |
| AII | GALAXY | 2.3L (DOHC/DOHC 16V) | RCM - Restraint Control Module | | X | | | |
| AII | GALAXY | 2.3L (DOHC/DOHC 16V) | ICM - Instrument Cluster | | X | | | |
| AII | GALAXY | 2.3L (DOHC/DOHC 16V) | NAV - Navigation System | | X | | | |
| AII | GALAXY | 2.8L (V6 SFI) | PCM - Powertrain Control Module | | X | | | |
| AII | GALAXY | 2.8L (V6 SFI) | TCM - Transmission Control Module | | X | | | |
| AII | GALAXY | 2.8L (V6 SFI) | ABS - Anti-Lock Brake / Traction Control Module | | X | | | |
| AII | GALAXY | 2.8L (V6 SFI) | RCM - Restraint Control Module | | X | | | |
| AII | GALAXY | 2.8L (V6 SFI) | ICM - Instrument Cluster | | X | | | |
| AII | GALAXY | 2.8L (V6 SFI) | NAV - Navigation System | | X | | | |
| AII | GALAXY | 2.0L(2.0-DOHC-SFI-8V) | ICM - Instrument Cluster | | X | X | | |
| AII | GALAXY | 2.3L(DOHC-SFI-16V) | ICM - Instrument Cluster | | X | X | | |

| | | | | | | | | |
|-----|--------|------------------------|---|--|---|---|---|---|
| AII | KA | 1.3L (SFI) | PCM - Powertrain Control Module | | X | X | | |
| AII | KA | 1.3L (SFI) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | | |
| AII | KA | 1.3L (SFI) | ECS - Electronic Crash Sensor(or IABM) | | X | X | | |
| AII | KA | 1.3L (SFI) | EPS - Electronic Controlled Power Steering | | X | X | | |
| AII | KA | 1.3L (SFI) | GEM - Generic electric module(CTM) | | X | X | | |
| AII | KA | 1.3L (SFI) | PATS - Passive Anti-Theft System | | X | X | | 1.Key Programming. |
| AII | KA | 1.6L | PCM - Powertrain Control Module | | X | X | | |
| AII | KA | 1.6L | ABS - Anti-Lock Brake / Traction Control Module | | X | X | | |
| AII | KA | 1.6L | ECS - Electronic Crash Sensor(or IABM) | | X | X | | |
| AII | KA | 1.6L | EPS - Electronic Controlled Power Steering | | X | X | | |
| AII | KA | 1.6L | GEM - Generic electric module(CTM) | | X | X | | |
| AII | KA | 1.6L | PATS - Passive Anti-Theft System | | X | X | | |
| AII | MONDEO | 1.6L (SFI) | PCM - Powertrain Control Module | | X | X | X | |
| AII | MONDEO | 1.6L (SFI) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| AII | MONDEO | 1.6L (SFI) | CSM - Security module | | X | X | X | |
| AII | MONDEO | 1.6L (SFI) | PATS - Passive Anti-Theft System | | X | | | 1.Key Programming. |
| AII | MONDEO | 1.8L (SFI/T-DIESEL) | PCM - Powertrain Control Module | | X | X | X | 1.Fuel Injector Coding. 2.Key Programming. |
| AII | MONDEO | 1.8L (SFI/T-DIESEL) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| AII | MONDEO | 1.8L (SFI/T-DIESEL) | CSM - Security module | | X | X | X | |
| AII | MONDEO | 1.8L (SFI/T-DIESEL) | PATS - Passive Anti-Theft System | | X | X | X | |
| AII | MONDEO | 1.8L (SFI/T-DIESEL) | RIM - Remote Anti-Theft / Personality Module | | X | X | X | |
| AII | MONDEO | 2.0L (SFI) | PCM - Powertrain Control Module | | X | X | X | |
| AII | MONDEO | 2.0L (SFI) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| AII | MONDEO | 2.0L (SFI) | CSM - Security module | | X | X | X | |
| AII | MONDEO | 2.0L (SFI) | PATS - Passive Anti-Theft System | | X | | | 1.Key Programming. |
| AII | MONDEO | 2.5L (SFI) | PCM - Powertrain Control Module | | X | X | X | |
| AII | MONDEO | 2.5L (SFI) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| AII | MONDEO | 2.5L (SFI) | CSM - Security module | | X | X | X | |
| AII | MONDEO | 2.5L (SFI) | PATS - Passive Anti-Theft System | | X | | | 1.Key Programming. |
| AII | PUMA | 1.4L (SFI) | PCM - Powertrain Control Module | | X | X | X | |
| AII | PUMA | 1.4L (SFI) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| AII | PUMA | 1.4L (SFI) | ECS - Electronic Crash Sensor | | X | X | X | |
| AII | PUMA | 1.7L (SFI) | PCM - Powertrain Control Module | | X | X | X | |
| AII | PUMA | 1.7L (SFI) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| AII | PUMA | 1.7L (SFI) | ECS - Electronic Crash Sensor | | X | X | X | |
| AII | RANGER | 2.5L (DIESEL/T-DIESEL) | PCM - Powertrain Control Module | | X | X | | |
| AII | RANGER | 2.5L (DIESEL/T-DIESEL) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | | |
| AII | RANGER | 2.5L (DIESEL/T-DIESEL) | ECS - Electronic Crash Sensor | | X | X | X | |
| AII | KA | 1.3L (SFI) | PCM - Powertrain Control Module | | X | X | | |
| AII | KA | 1.3L (SFI) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | | |
| AII | KA | 1.3L (SFI) | ECS - Electronic Crash Sensor(or IABM) | | X | X | | |
| AII | KA | 1.3L (SFI) | EPS - Electronic Controlled Power Steering | | X | X | | |
| AII | KA | 1.3L (SFI) | GEM - Generic electric module(CTM) | | X | X | | |

| | | | | | | | | |
|-----|------------------------|------------|---|--|---|---|--|--|
| All | KA | 1.3L (SFI) | PATS - Passive Anti-Theft System | | X | X | | |
| All | KA | 1.6L | PCM - Powertrain Control Module | | X | X | | |
| All | KA | 1.6L | ABS - Anti-Lock Brake / Traction Control Module | | X | X | | |
| All | KA | 1.6L | ECS - Electronic Crash Sensor(or IABM) | | X | X | | |
| All | KA | 1.6L | EPS - Electronic Controlled Power Steering | | X | X | | |
| All | KA | 1.6L | GEM - Generic electric module(CTM) | | X | X | | |
| All | KA | 1.6L | PATS - Passive Anti-Theft System | | X | X | | |
| All | F-SERIES SUPER DUTY | 5.4L | PCM - Powertrain Control Module | | X | | | |
| All | F-SERIES SUPER DUTY | 5.4L | ABS - Anti-Lock Brake / Traction Control Module | | X | X | | |
| All | F-SERIES SUPER DUTY | 5.4L | RCM - Restraint Control Module | | X | X | | |
| All | F-SERIES SUPER DUTY | 5.4L | TCM - Transmission Control Module | | X | X | | |
| All | F-SERIES SUPER DUTY | 5.4L | ICM - Instrument Cluster | | X | X | | |
| All | F-SERIES SUPER DUTY | 5.4L | GEM - Generic electric module(CTM) | | X | X | | |
| All | F-SERIES SUPER DUTY | 5.4L | PATS - Passive Anti-Theft System | | X | X | | |
| All | F-SERIES SUPER DUTY | 6.0L | PCM - Powertrain Control Module | | X | | | |
| All | F-SERIES SUPER DUTY | 6.0L | ABS - Anti-Lock Brake / Traction Control Module | | X | X | | |
| All | F-SERIES SUPER DUTY | 6.0L | RCM - Restraint Control Module | | X | X | | |
| All | F-SERIES SUPER DUTY | 6.0L | TCM - Transmission Control Module | | X | X | | |
| All | F-SERIES SUPER DUTY | 6.0L | ICM - Instrument Cluster | | X | X | | |
| All | F-SERIES SUPER DUTY | 6.0L | GEM - Generic electric module(CTM) | | X | X | | |
| All | F-SERIES SUPER DUTY | 6.0L | PATS - Passive Anti-Theft System | | X | X | | |
| All | F-SERIES SUPER DUTY | 6.8L | PCM - Powertrain Control Module | | X | | | |
| All | F-SERIES SUPER DUTY | 6.8L | ABS - Anti-Lock Brake / Traction Control Module | | X | X | | |
| All | F-SERIES SUPER DUTY | 6.8L | RCM - Restraint Control Module | | X | X | | |
| All | F-SERIES SUPER DUTY | 6.8L | TCM - Transmission Control Module | | X | X | | |

| | | | | | | | | |
|-----|------------------------|--------------------------|---|--|---|---|---|---|
| AII | F-SERIES SUPER DUTY | 6.8L | ICM - Instrument Cluster | | X | X | | |
| AII | F-SERIES SUPER DUTY | 6.8L | GEM - Generic electric module(CTM) | | X | X | | |
| AII | F-SERIES SUPER DUTY | 6.8L | PATS - Passive Anti-Theft System | | X | X | | |
| AII | F-SERIES SUPER DUTY | 7.3L | PCM - Powertrain Control Module | | X | | | |
| AII | F-SERIES SUPER DUTY | 7.3L | ABS - Anti-Lock Brake / Traction Control Module | | X | X | | |
| AII | F-SERIES SUPER DUTY | 7.3L | RCM - Restraint Control Module | | X | X | | |
| AII | F-SERIES SUPER DUTY | 7.3L | TCM - Transmission Control Module | | X | X | | |
| AII | F-SERIES SUPER DUTY | 7.3L | ICM - Instrument Cluster | | X | X | | |
| AII | F-SERIES SUPER DUTY | 7.3L | GEM - Generic electric module(CTM) | | X | X | | |
| AII | F-SERIES SUPER DUTY | 7.3L | PATS - Passive Anti-Theft System | | X | X | | |
| AII | SCORPIO | 2.0L (16V DOHC/8V DOHC) | PCM - Powertrain Control Module | | X | X | X | |
| AII | SCORPIO | 2.0L (16V DOHC/8V DOHC) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| AII | SCORPIO | 2.0L (16V DOHC/8V DOHC) | ECS - Electronic Crash Sensor | | X | X | X | |
| AII | SCORPIO | 2.3L (16V DOHC) | PCM - Powertrain Control Module | | X | X | X | |
| AII | SCORPIO | 2.3L (16V DOHC) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| AII | SCORPIO | 2.3L (16V DOHC) | ECS - Electronic Crash Sensor | | X | X | X | |
| AII | SCORPIO | 2.9L (24V V6) | PCM - Powertrain Control Module | | X | X | X | |
| AII | SCORPIO | 2.9L (24V V6) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| AII | SCORPIO | 2.9L (24V V6) | ECS - Electronic Crash Sensor | | X | X | X | |
| AII | TRANSIT | 2.0L (MPI/SFI 8V/DIESEL) | PCM - Powertrain Control Module | | X | X | X | |
| AII | TRANSIT | 2.0L (MPI/SFI 8V/DIESEL) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| AII | TRANSIT | 2.0L (MPI/SFI 8V/DIESEL) | PATS - Passive Anti-Theft System | | X | | | 1.Key Programming. |
| AII | TRANSIT | 2.3L (ALT/DIESEL) | PCM - Powertrain Control Module | | X | X | X | |
| AII | TRANSIT | 2.3L (ALT/DIESEL) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| AII | TRANSIT | 2.3L (ALT/DIESEL) | PATS - Passive Anti-Theft System | | X | | | 1.Key Programming. |
| AII | TRANSIT | 2.4L (DIESEL) | PCM - Powertrain Control Module | | X | X | X | |
| AII | TRANSIT | 2.4L (DIESEL) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| AII | TRANSIT | 2.4L (DIESEL) | PATS - Passive Anti-Theft System | | X | | | 1.Key Programming. |
| AII | TRANSIT | 2.5L (DIESEL/T-DIESEL) | PCM - Powertrain Control Module | | X | X | X | 1.Fuel Injector Coding. 2.Key Programming. |
| AII | TRANSIT | 2.5L (DIESEL/T-DIESEL) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| AII | TRANSIT | 2.5L (DIESEL/T-DIESEL) | PATS - Passive Anti-Theft System | | X | | | 1.Key Programming. |
| AII | TRANSIT | 2.4L(OTOSAN/DURATORQ_DI) | PCM - Powertrain Control Module | | X | X | | |
| AII | TRANSIT | 2.4L(OTOSAN/DURATORQ_DI) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | | |

| | | | | | | | | |
|-----|------------------|--|---|--|---|---|---|--|
| All | TRANSIT | 2.4L(TDCi/Duratorq-Turbo-Diesel-Common-Rail-Injection) | PCM - Powertrain Control Module | | X | X | | |
| All | TRANSIT | 2.4L(TDCi/Duratorq-Turbo-Diesel-Common-Rail-Injection) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | | |
| All | TRANSIT | 2.0L(TDCi/Duratorq-Turbo-Diesel-Common-Rail-Injection) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | | |
| All | TRANSIT | 2.4L(DURATORQ_DI) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | | |
| All | TRANSIT | 2.4L(DURATORQ_DI) | TCM - Transmission Control Module | | X | X | | |
| All | WINDSTAR | 3.0L (V6 SFI) | PCM - Powertrain Control Module | | X | X | X | |
| All | WINDSTAR | 3.0L (V6 SFI) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| All | WINDSTAR | 3.8(V6-OHV) | PCM - Powertrain Control Module | | X | X | | |
| All | WINDSTAR | 3.8(V6-OHV) | abs - Anti-Lock Brake / Traction Control Module | | X | X | | |
| All | WINDSTAR | 3.8(V6-OHV) | ICM - Instrument Cluster | | X | X | | |
| All | CROWN-VICTORIA | 4.6L(2V) | PCM - Powertrain Control Module | | X | X | | |
| All | CROWN-VICTORIA | 4.6L(2V) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | | |
| All | CROWN-VICTORIA | 4.6L(2V) | ICM - Instrument Cluster | | X | X | | |
| All | CROWN-VICTORIA | 4.6L(2V) | PATS - Passive Anti-Theft System | | X | X | | |
| All | F-250 LIGHT DUTY | 4.2L(BIF) | PCM - Powertrain Control Module | | X | X | | |
| All | F-250 LIGHT DUTY | 4.2L(BIF) | ICM - Instrument Cluster | | X | X | | |
| All | F-250 LIGHT DUTY | 5.4L(BIF) | PCM - Powertrain Control Module | | X | X | | |
| All | F-250 LIGHT DUTY | 5.4L(BIF) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | | |
| All | F-250 LIGHT DUTY | 5.4L(BIF) | RCM - Restraint Control Module | | X | X | | |
| All | F-250 LIGHT DUTY | 5.4L(BIF) | ICM - Instrument Cluster | | X | X | | |
| All | F-250 LIGHT DUTY | 5.4L(BIF) | GEM - Generic electric module(CTM) | | X | X | | |
| All | F-250 LIGHT DUTY | 5.4L(NGV) | PCM - Powertrain Control Module | | X | X | | |
| All | F-250 LIGHT DUTY | 5.4L(NGV) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | | |
| All | F-250 LIGHT DUTY | 5.4L(NGV) | RCM - Restraint Control Module | | X | X | | |
| All | F-250 LIGHT DUTY | 5.4L(NGV) | ICM - Instrument Cluster | | X | X | | |

| | | | | | | | | |
|-----|------------------|------------------------------|---|--|---|---|---|--|
| All | F-250 LIGHT DUTY | 5.4L(NGV) | GEM - Generic electric module(CTM) | | X | X | | |
| All | EXCURSION | 7.3L(Direct-Injection-Turbo) | PCM - Powertrain Control Module | | X | X | | |
| All | EXCURSION | 7.3L(Direct-Injection-Turbo) | GEM - Generic electric module(CTM) | | X | X | | |
| All | EXCURSION | 6.8L(Other) | PCM - Powertrain Control Module | | X | X | | |
| All | EXCURSION | 6.8L(Other) | GEM - Generic electric module(CTM) | | X | X | | |
| All | EXCURSION | 5.4L(Other) | PCM - Powertrain Control Module | | X | X | | |
| All | EXCURSION | 5.4L(Other) | GEM - Generic electric module(CTM) | | X | X | | |
| All | EXCURSION | 4.6L(Other) | PCM - Powertrain Control Module | | X | X | | |
| All | EXCURSION | 4.6L(Other) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | | |
| All | EXCURSION | 4.6L(Other) | RCM - Restraint Control Module | | X | X | | |
| All | EXCURSION | 4.6L(Other) | GEM - Generic electric module(CTM) | | X | X | | |
| All | EXCURSION | 5.4L(4V) | PCM - Powertrain Control Module | | X | X | | |
| All | EXCURSION | 5.4L(4V) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | | |
| All | EXCURSION | 5.4L(4V) | RCM - Restraint Control Module | | X | X | | |
| All | EXCURSION | 5.4L(4V) | GEM - Generic electric module(CTM) | | X | X | | |
| All | EXCURSION | 5.4L(Other) | PCM - Powertrain Control Module | | X | X | | |
| All | EXCURSION | 5.4L(Other) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | | |
| All | EXCURSION | 5.4L(Other) | RCM - Restraint Control Module | | X | X | | |
| All | EXCURSION | 5.4L(Other) | GEM - Generic electric module(CTM) | | X | X | | |
| All | COGUAR | 2.0L (SFI) | PCM - Powertrain Control Module | | X | X | X | |
| All | COGUAR | 2.0L (SFI) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| All | COGUAR | 2.0L (SFI) | CSM - Security module | | X | X | X | |
| All | COGUAR | 2.0L (SFI) | ECS - Electronic Crash Sensor | | X | X | X | |
| All | COGUAR | 2.5L (SFI) | PCM - Powertrain Control Module | | X | X | X | |
| All | COGUAR | 2.5L (SFI) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| All | COGUAR | 2.5L (SFI) | CSM - Security module | | X | X | X | |
| All | COGUAR | 2.5L (SFI) | ECS - Electronic Crash Sensor | | X | X | X | |
| All | ECONOVAN | 1.4L (2BL OHC) | PCM - Powertrain Control Module | | X | X | X | |
| All | ECONOVAN | 1.4L (2BL OHC) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| All | ECONOVAN | 1.4L (2BL OHC) | ECS - Electronic Crash Sensor | | X | X | X | |
| All | ECONOVAN | 2.0L (DIESEL) | PCM - Powertrain Control Module | | X | X | X | |
| All | ECONOVAN | 2.0L (DIESEL) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| All | ECONOVAN | 2.0L (DIESEL) | ECS - Electronic Crash Sensor | | X | X | X | |
| All | ESCORT | 1.1L (HCS) | PCM - Powertrain Control Module | | X | X | X | |
| All | ESCORT | 1.1L (HCS) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| All | ESCORT | 1.1L (HCS) | IABM - Integrated Air Bag Module | | X | X | X | |
| All | ESCORT | 1.3L (CFI/HCS/SFI) | PCM - Powertrain Control Module | | X | X | X | |
| All | ESCORT | 1.3L (CFI/HCS/SFI) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| All | ESCORT | 1.3L (CFI/HCS/SFI) | IABM - Integrated Air Bag Module | | X | X | X | |
| All | ESCORT | 1.4L (CVH/EFI/SFI) | PCM - Powertrain Control Module | | X | X | X | |
| All | ESCORT | 1.4L (CVH/EFI/SFI) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| All | ESCORT | 1.4L (CVH/EFI/SFI) | IABM - Integrated Air Bag Module | | X | X | X | |
| All | ESCORT | 1.6L (CFI) | PCM - Powertrain Control Module | | X | X | X | |

| | | | | | | | | |
|-----|----------|----------------------------|---|--|---|---|---|--------------------|
| AII | ESCORT | 1.6L (CFI) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| AII | ESCORT | 1.6L (CFI) | IABM - Integrated Air Bag Module | | X | X | X | |
| AII | ESCORT | 1.8L (SFI/DIESEL/T-DIESEL) | PCM - Powertrain Control Module | | X | X | X | |
| AII | ESCORT | 1.8L (SFI/DIESEL/T-DIESEL) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| AII | ESCORT | 1.8L (SFI/DIESEL/T-DIESEL) | CSM - Security module | | X | X | X | |
| AII | ESCORT | 1.8L (SFI/DIESEL/T-DIESEL) | HEC - Hybrid Electronic Cluster | | X | X | X | |
| AII | ESCORT | 1.8L (SFI/DIESEL/T-DIESEL) | PATS - Passive Anti-Theft System | | X | X | X | |
| AII | ESCORT | 1.8L (SFI/DIESEL/T-DIESEL) | IABM - Integrated Air Bag Module | | X | X | X | |
| AII | ESCORT | 2.0L (MPI 16V) | PCM - Powertrain Control Module | | X | X | X | |
| AII | ESCORT | 2.0L (MPI 16V) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| AII | ESCORT | 2.0L (MPI 16V) | CSM - Security module | | X | X | X | |
| AII | ESCORT | 2.0L (MPI 16V) | HEC - Hybrid Electronic Cluster | | X | X | X | |
| AII | ESCORT | 2.0L (MPI 16V) | PATS - Passive Anti-Theft System | | X | X | X | |
| AII | ESCORT | 2.0L (MPI 16V) | IABM - Integrated Air Bag Module | | X | X | X | |
| AII | EXPLORER | 4.0L (SOHC SFI) | PCM - Powertrain Control Module | | X | X | X | |
| AII | EXPLORER | 4.0L (SOHC SFI) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| AII | EXPLORER | 4.0L (SOHC SFI) | DSM - Drivers Seat Module | | X | X | X | |
| AII | EXPLORER | 4.0L (SOHC SFI) | EATC - Electronic Automatic Temperature Control | | X | X | X | |
| AII | EXPLORER | 4.0L (SOHC SFI) | GEM - Generic electric module(CTM) | | X | X | X | |
| AII | EXPLORER | 4.0L (SOHC SFI) | ICM - Instrument Cluster | | X | X | X | |
| AII | EXPLORER | 4.0L (SOHC SFI) | PAM - Parking Aid Module | | X | X | X | |
| AII | EXPLORER | 4.0L (SOHC SFI) | RASM - Rear Air Suspension Module | | X | X | X | |
| AII | EXPLORER | 4.0L (SOHC SFI) | RCM - Restraint Control Module | | X | X | X | |
| AII | EXPLORER | 5.0L | PCM - Powertrain Control Module | | X | X | X | |
| AII | EXPLORER | 5.0L | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| AII | EXPLORER | 5.0L | DSM - Drivers Seat Module | | X | X | X | |
| AII | EXPLORER | 5.0L | EATC - Electronic Automatic Temperature Control | | X | X | X | |
| AII | EXPLORER | 5.0L | GEM - Generic electric module(CTM) | | X | X | X | |
| AII | EXPLORER | 5.0L | ICM - Instrument Cluster | | X | X | X | |
| AII | EXPLORER | 5.0L | PAM - Parking Aid Module | | X | X | X | |
| AII | EXPLORER | 5.0L | RASM - Rear Air Suspension Module | | X | X | X | |
| AII | EXPLORER | 5.0L | RCM - Restraint Control Module | | X | X | X | |
| AII | FIESTA | 1.25L(MTX/CTX/SFI) | PCM - Powertrain Control Module | | X | X | X | |
| AII | FIESTA | 1.25L(MTX/CTX/SFI) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| AII | FIESTA | 1.25L(MTX/CTX/SFI) | ECS - Electronic Crash Sensor | | X | X | X | |
| AII | FIESTA | 1.25L(MTX/CTX/SFI) | PATS - Passive Anti-Theft System | | X | | | 1.Key Programming. |
| AII | FIESTA | 1.3L (SFI) | PCM - Powertrain Control Module | | X | X | X | |
| AII | FIESTA | 1.3L (SFI) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| AII | FIESTA | 1.3L (SFI) | ECS - Electronic Crash Sensor | | X | X | X | |
| AII | FIESTA | 1.3L (SFI) | PATS - Passive Anti-Theft System | | X | | | 1.Key Programming. |
| AII | FIESTA | 1.4L (2V/4V/SFI) | PCM - Powertrain Control Module | | X | X | X | |
| AII | FIESTA | 1.4L (2V/4V/SFI) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| AII | FIESTA | 1.4L (2V/4V/SFI) | ECS - Electronic Crash Sensor | | X | X | X | |
| AII | FIESTA | 1.4L (2V/4V/SFI) | PATS - Passive Anti-Theft System | | X | | | 1.Key Programming. |
| AII | FIESTA | 1.6L (SFI) | PCM - Powertrain Control Module | | X | X | X | |

| | | | | | | | | |
|-----|--------|---------------------------------|---|--|---|---|---|---|
| AII | FIESTA | 1.6L (SFI) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| AII | FIESTA | 1.6L (SFI) | ECS - Electronic Crash Sensor | | X | X | X | |
| AII | FIESTA | 1.6L (SFI) | PATS - Passive Anti-Theft System | | X | | | 1.Key Programming. |
| AII | FIESTA | 1.8L (DIESEL/T-DIESEL) | PCM - Powertrain Control Module | | X | X | X | 1.Fuel Injector Coding. 2.Key Programming. |
| AII | FIESTA | 1.8L (DIESEL/T-DIESEL) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| AII | FIESTA | 1.8L (DIESEL/T-DIESEL) | ECS - Electronic Crash Sensor | | X | X | X | |
| AII | FIESTA | 1.8L (DIESEL/T-DIESEL) | PATS - Passive Anti-Theft System | | X | | | 1.Key Programming. |
| AII | FIESTA | 1.6L(Other) | GEM - Generic electric module(CTM) | | X | X | | |
| AII | FIESTA | 1.1L(I3) | PCM - Powertrain Control Module | | X | X | | |
| AII | FIESTA | 1.1L(I3) | GEM - Generic electric module(CTM) | | X | X | | |
| AII | FIESTA | 1.3L(SOHC/Zetec-Rocam) | GEM - Generic electric module(CTM) | | X | X | | |
| AII | FOCUS | 1.4L (DOHC) | PCM - Powertrain Control Module | | X | X | X | |
| AII | FOCUS | 1.4L (DOHC) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| AII | FOCUS | 1.4L (DOHC) | RCM - Restraint Control Module | | X | X | X | |
| AII | FOCUS | 1.4L (DOHC) | PATS - Passive Anti-Theft System | | X | | | 1.Key Programming. |
| AII | FOCUS | 1.6L (ALT FUEL/DOHC/SFI) | PCM - Powertrain Control Module | | X | X | X | |
| AII | FOCUS | 1.6L (ALT FUEL/DOHC/SFI) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| AII | FOCUS | 1.6L (ALT FUEL/DOHC/SFI) | RCM - Restraint Control Module | | X | X | X | |
| AII | FOCUS | 1.6L (ALT FUEL/DOHC/SFI) | PATS - Passive Anti-Theft System | | X | | | 1.Key Programming. |
| AII | FOCUS | 1.8L (ALT FUEL/DIESEL/DOHC/SFI) | PCM - Powertrain Control Module | | X | X | X | 1.Fuel Injector Coding. 2.Key Programming. |
| AII | FOCUS | 1.8L (ALT FUEL/DIESEL/DOHC/SFI) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| AII | FOCUS | 1.8L (ALT FUEL/DIESEL/DOHC/SFI) | CSM - Security module | | X | X | X | |
| AII | FOCUS | 1.8L (ALT FUEL/DIESEL/DOHC/SFI) | CTM - Central timer module | | X | X | X | |
| AII | FOCUS | 1.8L (ALT FUEL/DIESEL/DOHC/SFI) | ECS - Electronic Crash Sensor | | X | X | X | |
| AII | FOCUS | 1.8L (ALT FUEL/DIESEL/DOHC/SFI) | MCM - Information central module | | X | X | X | |
| AII | FOCUS | 1.8L (ALT FUEL/DIESEL/DOHC/SFI) | PATS - Passive Anti-Theft System | | X | | | 1.Key Programming. |
| AII | FOCUS | 2.0L (SFI/VVT) | PCM - Powertrain Control Module | | X | X | X | |
| AII | FOCUS | 2.0L (SFI/VVT) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| AII | FOCUS | 2.0L (SFI/VVT) | CSM - Security module | | X | X | X | |
| AII | FOCUS | 2.0L (SFI/VVT) | CTM - Central timer module | | X | X | X | |
| AII | FOCUS | 2.0L (SFI/VVT) | ECS - Electronic Crash Sensor | | X | X | X | |
| AII | FOCUS | 2.0L (SFI/VVT) | MCM - Information central module | | X | X | X | |
| AII | FOCUS | 2.0L (SFI/VVT) | PATS - Passive Anti-Theft System | | X | | | 1.Key Programming. |
| AII | GALAXY | 1.8L (DOHC) | PCM - Powertrain Control Module | | X | | | |
| AII | GALAXY | 1.8L (DOHC) | TCM - Transmission Control Module | | X | | | |
| AII | GALAXY | 1.8L (DOHC) | ABS - Anti-Lock Brake / Traction Control Module | | X | | | |
| AII | GALAXY | 1.8L (DOHC) | RCM - Restraint Control Module | | X | | | |
| AII | GALAXY | 1.8L (DOHC) | ICM - Instrument Cluster | | X | | | |
| AII | GALAXY | 1.8L (DOHC) | NAV - Navigation System | | X | | | |
| AII | GALAXY | 1.9L (DIESEL/T-DIESEL) | PCM - Powertrain Control Module | | X | | | |
| AII | GALAXY | 1.9L (DIESEL/T-DIESEL) | TCM - Transmission Control Module | | X | | | |
| AII | GALAXY | 1.9L (DIESEL/T-DIESEL) | ABS - Anti-Lock Brake / Traction Control Module | | X | | | |

| | | | | | | | | |
|-----|----------|-------------------------------|---|--|---|---|--|--|
| AII | GALAXY | 1.9L (DIESEL/T-DIESEL) | RCM - Restraint Control Module | | X | | | |
| AII | GALAXY | 1.9L (DIESEL/T-DIESEL) | ICM - Instrument Cluster | | X | | | |
| AII | GALAXY | 1.9L (DIESEL/T-DIESEL) | NAV - Navigation System | | X | | | |
| AII | GALAXY | 2.0L (DOHC/EFI DOHC/SFI DOHC) | PCM - Powertrain Control Module | | X | | | |
| AII | GALAXY | 2.0L (DOHC/EFI DOHC/SFI DOHC) | TCM - Transmission Control Module | | X | | | |
| AII | GALAXY | 2.0L (DOHC/EFI DOHC/SFI DOHC) | ABS - Anti-Lock Brake / Traction Control Module | | X | | | |
| AII | GALAXY | 2.0L (DOHC/EFI DOHC/SFI DOHC) | RCM - Restraint Control Module | | X | | | |
| AII | GALAXY | 2.0L (DOHC/EFI DOHC/SFI DOHC) | ICM - Instrument Cluster | | X | | | |
| AII | GALAXY | 2.0L (DOHC/EFI DOHC/SFI DOHC) | NAV - Navigation System | | X | | | |
| AII | GALAXY | 2.3L (DOHC/DOHC 16V) | PCM - Powertrain Control Module | | X | | | |
| AII | GALAXY | 2.3L (DOHC/DOHC 16V) | TCM - Transmission Control Module | | X | | | |
| AII | GALAXY | 2.3L (DOHC/DOHC 16V) | ABS - Anti-Lock Brake / Traction Control Module | | X | | | |
| AII | GALAXY | 2.3L (DOHC/DOHC 16V) | RCM - Restraint Control Module | | X | | | |
| AII | GALAXY | 2.3L (DOHC/DOHC 16V) | ICM - Instrument Cluster | | X | | | |
| AII | GALAXY | 2.3L (DOHC/DOHC 16V) | NAV - Navigation System | | X | | | |
| AII | GALAXY | 2.8L (V6 SFI) | PCM - Powertrain Control Module | | X | | | |
| AII | GALAXY | 2.8L (V6 SFI) | TCM - Transmission Control Module | | X | | | |
| AII | GALAXY | 2.8L (V6 SFI) | ABS - Anti-Lock Brake / Traction Control Module | | X | | | |
| AII | GALAXY | 2.8L (V6 SFI) | RCM - Restraint Control Module | | X | | | |
| AII | GALAXY | 2.8L (V6 SFI) | ICM - Instrument Cluster | | X | | | |
| AII | GALAXY | 2.8L (V6 SFI) | NAV - Navigation System | | X | | | |
| AII | GALAXY | 1.9L(VW_TDI/1.9-EDC) | PATS - Passive Anti-Theft System | | X | X | | |
| AII | GALAXY | 2.8L(2.8-CD-V6) | PATS - Passive Anti-Theft System | | X | X | | |
| AII | RANGER | 2.5L(DIESEL/T-DIESEL) | PCM - Powertrain Control Module | | X | X | | |
| AII | RANGER | 2.5L(DIESEL/T-DIESEL) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | | |
| AII | RANGER | 2.5L(DIESEL/T-DIESEL) | RCM - Restraint Control Module | | X | X | | |
| AII | KA | 1.3L (SFI) | PCM - Powertrain Control Module | | X | X | | |
| AII | KA | 1.3L (SFI) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | | |
| AII | KA | 1.3L (SFI) | ECS - Electronic Crash Sensor(or IABM) | | X | X | | |
| AII | KA | 1.3L (SFI) | EPS - Electronic Controlled Power Steering | | X | X | | |
| AII | KA | 1.3L (SFI) | GEM - Generic electric module(CTM) | | X | X | | |
| AII | KA | 1.3L (SFI) | PATS - Passive Anti-Theft System | | X | X | | |
| AII | KA | 1.6L | PCM - Powertrain Control Module | | X | X | | |
| AII | KA | 1.6L | ABS - Anti-Lock Brake / Traction Control Module | | X | X | | |
| AII | KA | 1.6L | ECS - Electronic Crash Sensor(or IABM) | | X | X | | |
| AII | KA | 1.6L | EPS - Electronic Controlled Power Steering | | X | X | | |
| AII | KA | 1.6L | GEM - Generic electric module(CTM) | | X | X | | |
| AII | KA | 1.6L | PATS - Passive Anti-Theft System | | X | X | | |
| AII | MAVERICK | 2.0L | PCM - Powertrain Control Module | | X | X | | |
| AII | MAVERICK | 2.0L | ABS - Anti-Lock Brake / Traction Control Module | | X | X | | |
| AII | MAVERICK | 2.0L | RCM - Restraint Control Module | | X | X | | |
| AII | MAVERICK | 2.0L | GEM - Generic electric module(CTM) | | X | X | | |
| AII | MAVERICK | 2.0L | PAM - Parking Aid Module | | X | X | | |
| AII | MAVERICK | 2.0L | 4X4M - 4X4 Control Module | | X | X | | |
| AII | MAVERICK | 2.3L | PCM - Powertrain Control Module | | X | X | | |

| | | | | | | | | |
|-----|------------------------|------|---|--|---|---|--|--|
| All | MAVERICK | 2.3L | ABS - Anti-Lock Brake / Traction Control Module | | X | X | | |
| All | MAVERICK | 2.3L | RCM - Restraint Control Module | | X | X | | |
| All | MAVERICK | 2.3L | GEM - Generic electric module(CTM) | | X | X | | |
| All | MAVERICK | 2.3L | PAM - Parking Aid Module | | X | X | | |
| All | MAVERICK | 2.3L | 4X4M - 4X4 Control Module | | X | X | | |
| All | MAVERICK | 3.0L | PCM - Powertrain Control Module | | X | X | | |
| All | MAVERICK | 3.0L | ABS - Anti-Lock Brake / Traction Control Module | | X | X | | |
| All | MAVERICK | 3.0L | RCM - Restraint Control Module | | X | X | | |
| All | MAVERICK | 3.0L | GEM - Generic electric module(CTM) | | X | X | | |
| All | MAVERICK | 3.0L | PAM - Parking Aid Module | | X | X | | |
| All | MAVERICK | 3.0L | 4X4M - 4X4 Control Module | | X | X | | |
| All | F-SERIES SUPER DUTY | 5.4L | PCM - Powertrain Control Module | | X | | | |
| All | F-SERIES SUPER DUTY | 5.4L | ABS - Anti-Lock Brake / Traction Control Module | | X | X | | |
| All | F-SERIES SUPER DUTY | 5.4L | RCM - Restraint Control Module | | X | X | | |
| All | F-SERIES SUPER DUTY | 5.4L | TCM - Transmission Control Module | | X | X | | |
| All | F-SERIES SUPER DUTY | 5.4L | ICM - Instrument Cluster | | X | X | | |
| All | F-SERIES SUPER DUTY | 5.4L | GEM - Generic electric module(CTM) | | X | X | | |
| All | F-SERIES SUPER DUTY | 5.4L | PATS - Passive Anti-Theft System | | X | X | | |
| All | F-SERIES SUPER DUTY | 6.0L | PCM - Powertrain Control Module | | X | | | |
| All | F-SERIES SUPER DUTY | 6.0L | ABS - Anti-Lock Brake / Traction Control Module | | X | X | | |
| All | F-SERIES SUPER DUTY | 6.0L | RCM - Restraint Control Module | | X | X | | |
| All | F-SERIES SUPER DUTY | 6.0L | TCM - Transmission Control Module | | X | X | | |
| All | F-SERIES SUPER DUTY | 6.0L | ICM - Instrument Cluster | | X | X | | |
| All | F-SERIES SUPER DUTY | 6.0L | GEM - Generic electric module(CTM) | | X | X | | |
| All | F-SERIES SUPER DUTY | 6.0L | PATS - Passive Anti-Theft System | | X | X | | |
| All | F-SERIES SUPER DUTY | 6.8L | PCM - Powertrain Control Module | | X | | | |
| All | F-SERIES SUPER DUTY | 6.8L | ABS - Anti-Lock Brake / Traction Control Module | | X | X | | |

| | | | | | | | | |
|-----|------------------------|------------------------------|---|--|---|---|---|---|
| All | F-SERIES SUPER DUTY | 6.8L | RCM - Restraint Control Module | | X | X | | |
| All | F-SERIES SUPER DUTY | 6.8L | TCM - Transmission Control Module | | X | X | | |
| All | F-SERIES SUPER DUTY | 6.8L | ICM - Instrument Cluster | | X | X | | |
| All | F-SERIES SUPER DUTY | 6.8L | GEM - Generic electric module(CTM) | | X | X | | |
| All | F-SERIES SUPER DUTY | 6.8L | PATS - Passive Anti-Theft System | | X | X | | |
| All | F-SERIES SUPER DUTY | 7.3L | PCM - Powertrain Control Module | | X | | | |
| All | F-SERIES SUPER DUTY | 7.3L | ABS - Anti-Lock Brake / Traction Control Module | | X | X | | |
| All | F-SERIES SUPER DUTY | 7.3L | RCM - Restraint Control Module | | X | X | | |
| All | F-SERIES SUPER DUTY | 7.3L | TCM - Transmission Control Module | | X | X | | |
| All | F-SERIES SUPER DUTY | 7.3L | ICM - Instrument Cluster | | X | X | | |
| All | F-SERIES SUPER DUTY | 7.3L | GEM - Generic electric module(CTM) | | X | X | | |
| All | F-SERIES SUPER DUTY | 7.3L | PATS - Passive Anti-Theft System | | X | X | | |
| All | MONDEO | 1.8L (SFI) | PCM - Powertrain Control Module | | X | X | X | |
| All | MONDEO | 1.8L (SFI) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| All | MONDEO | 1.8L (SFI) | RCM - Restraint Control Module | | X | X | X | |
| All | MONDEO | 1.8L (SFI) | PATS - Passive Anti-Theft System | | X | | | 1.Key Programming. |
| All | MONDEO | 1.8L (SFI) | GEM - Generic electric module(CTM) | | X | X | X | |
| All | MONDEO | 1.8L (SFI) | EATC - Electronic Automatic Temperature Control | | X | X | X | |
| All | MONDEO | 2.0L (DOHC SFI/SFI/T-DIESEL) | PCM - Powertrain Control Module | | X | X | X | 1.Fuel Injector Coding. 2.Key Programming. |
| All | MONDEO | 2.0L (DOHC SFI/SFI/T-DIESEL) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| All | MONDEO | 2.0L (DOHC SFI/SFI/T-DIESEL) | RCM - Restraint Control Module | | X | X | X | |
| All | MONDEO | 2.0L (DOHC SFI/SFI/T-DIESEL) | PATS - Passive Anti-Theft System | | X | | | 1.Key Programming. |
| All | MONDEO | 2.0L (DOHC SFI/SFI/T-DIESEL) | GEM - Generic electric module(CTM) | | X | X | X | |
| All | MONDEO | 2.0L (DOHC SFI/SFI/T-DIESEL) | EATC - Electronic Automatic Temperature Control | | X | X | X | |
| All | MONDEO | 2.0L (DOHC SFI/SFI/T-DIESEL) | TCM - Transmission Control Module | | X | X | X | |
| All | MONDEO | 2.5L (SFI) | PCM - Powertrain Control Module | | X | X | X | |
| All | MONDEO | 2.5L (SFI) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| All | MONDEO | 2.5L (SFI) | RCM - Restraint Control Module | | X | X | X | |
| All | MONDEO | 2.5L (SFI) | GEM - Generic electric module(CTM) | | X | X | X | |
| All | MONDEO | 2.5L (SFI) | EATC - Electronic Automatic Temperature Control | | X | X | X | |
| All | MONDEO | 2.5L (SFI) | TCM - Transmission Control Module | | X | X | X | |

| | | | | | | | | |
|-----|---------|------------------------------------|---|--|---|---|---|---|
| AII | MONDEO | 2.5L (SFI) | PATS - Passive Anti-Theft System | | X | | | 1.Key Programming. |
| AII | MONDEO | 3.0L (Duratec-ST/Duratec-SE) | PCM - Powertrain Control Module | | X | X | X | |
| AII | MONDEO | 3.0L (Duratec-ST/Duratec-SE) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| AII | MONDEO | 3.0L (Duratec-ST/Duratec-SE) | RCM - Restraint Control Module | | X | X | X | |
| AII | MONDEO | 3.0L (Duratec-ST/Duratec-SE) | GEM - Generic electric module(CTM) | | X | X | X | |
| AII | MONDEO | 3.0L (Duratec-ST/Duratec-SE) | EATC - Electronic Automatic Temperature Control | | X | X | X | |
| AII | MONDEO | 3.0L (Duratec-ST/Duratec-SE) | TCM - Transmission Control Module | | X | X | X | |
| AII | MONDEO | 3.0L (Duratec-ST/Duratec-SE) | PATS - Passive Anti-Theft System | | X | | | 1.Key Programming. |
| AII | PUMA | 1.4L (SFI) | PCM - Powertrain Control Module | | X | X | X | |
| AII | PUMA | 1.4L (SFI) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| AII | PUMA | 1.4L (SFI) | GEM - Generic electric module(CTM) | | X | X | X | |
| AII | PUMA | 1.7L (SFI) | PCM - Powertrain Control Module | | X | X | X | |
| AII | PUMA | 1.7L (SFI) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| AII | PUMA | 1.7L (SFI) | GEM - Generic electric module(CTM) | | X | X | X | |
| AII | SCORPIO | 2.0L (16V DOHC/8V DOHC) | PCM - Powertrain Control Module | | X | X | X | |
| AII | SCORPIO | 2.0L (16V DOHC/8V DOHC) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| AII | SCORPIO | 2.0L (16V DOHC/8V DOHC) | RCM - Restraint Control Module | | X | X | X | |
| AII | SCORPIO | 2.3L (16V DOHC) | PCM - Powertrain Control Module | | X | X | X | |
| AII | SCORPIO | 2.3L (16V DOHC) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| AII | SCORPIO | 2.3L (16V DOHC) | RCM - Restraint Control Module | | X | X | X | |
| AII | SCORPIO | 2.9L (24V V6) | PCM - Powertrain Control Module | | X | X | X | |
| AII | SCORPIO | 2.9L (24V V6) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| AII | SCORPIO | 2.9L (24V V6) | RCM - Restraint Control Module | | X | X | X | |
| AII | TRANSIT | 2.0L (DIESEL/DIESEL TDCI/ALT FUEL) | PCM - Powertrain Control Module | | X | X | X | 1.Fuel Injector Coding. 2.Key Programming. |
| AII | TRANSIT | 2.0L (DIESEL/DIESEL TDCI/ALT FUEL) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| AII | TRANSIT | 2.0L (DIESEL/DIESEL TDCI/ALT FUEL) | CSM - Security module | | X | X | X | |
| AII | TRANSIT | 2.0L (DIESEL/DIESEL TDCI/ALT FUEL) | FFH - Fuel Fired Coolant Heating Module | | X | X | X | |
| AII | TRANSIT | 2.0L (DIESEL/DIESEL TDCI/ALT FUEL) | PAM - Parking Aid Module | | X | X | X | |
| AII | TRANSIT | 2.0L (DIESEL/DIESEL TDCI/ALT FUEL) | RASM - Rear Air Suspension Module | | X | X | X | |
| AII | TRANSIT | 2.0L (DIESEL/DIESEL TDCI/ALT FUEL) | RCM - Restraint Control Module | | X | X | X | |
| AII | TRANSIT | 2.0L (DIESEL/DIESEL TDCI/ALT FUEL) | PATS - Passive Anti-Theft System | | X | | | 1.Key Programming. |
| AII | TRANSIT | 2.3L (DIESEL) | PCM - Powertrain Control Module | | X | X | X | 1.Fuel Injector Coding. 2.Key Programming. |
| AII | TRANSIT | 2.3L (DIESEL) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| AII | TRANSIT | 2.3L (DIESEL) | CSM - Security module | | X | X | X | |
| AII | TRANSIT | 2.3L (DIESEL) | FFH - Fuel Fired Coolant Heating Module | | X | X | X | |
| AII | TRANSIT | 2.3L (DIESEL) | PAM - Parking Aid Module | | X | X | X | |
| AII | TRANSIT | 2.3L (DIESEL) | RASM - Rear Air Suspension Module | | X | X | X | |
| AII | TRANSIT | 2.3L (DIESEL) | RCM - Restraint Control Module | | X | X | X | |
| AII | TRANSIT | 2.3L (DIESEL) | PATS - Passive Anti-Theft System | | X | | | 1.Key Programming. |
| AII | TRANSIT | 2.4L (DIESEL) | PCM - Powertrain Control Module | | X | X | X | 1.Fuel Injector Coding. 2.Key Programming. |
| AII | TRANSIT | 2.4L (DIESEL) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |

| | | | | | | | | |
|-----|----------|--|---|--|---|---|---|--------------------|
| AII | TRANSIT | 2.4L (DIESEL) | CSM - Security module | | X | X | X | |
| AII | TRANSIT | 2.4L (DIESEL) | FFH - Fuel Fired Coolant Heating Module | | X | X | X | |
| AII | TRANSIT | 2.4L (DIESEL) | PAM - Parking Aid Module | | X | X | X | |
| AII | TRANSIT | 2.4L (DIESEL) | RASM - Rear Air Suspension Module | | X | X | X | |
| AII | TRANSIT | 2.4L (DIESEL) | RCM - Restraint Control Module | | X | X | X | |
| AII | TRANSIT | 2.4L (DIESEL) | PATS - Passive Anti-Theft System | | X | | | 1.Key Programming. |
| AII | TRANSIT | 2.0L(DURATORQ_DI) | PCM - Powertrain Control Module | | X | X | | |
| AII | TRANSIT | 2.0L(DURATORQ_DI) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | | |
| AII | TRANSIT | 2.0L(DURATORQ_DI) | TCM - Transmission Control Module | | X | X | | |
| AII | TRANSIT | 2.3L(DOHC-SFI-16V) | PCM - Powertrain Control Module | | X | X | | |
| AII | TRANSIT | 2.0L(TDCi/Duratorq-Turbo-Diesel-Common Rail-Injection) | PCM - Powertrain Control Module | | X | X | | |
| AII | TRANSIT | 2.0L(TDCi/Duratorq-Turbo-Diesel-Common Rail-Injection) | TCM - Transmission Control Module | | X | X | | |
| AII | WINDSTAR | 3.0L (V6 SFI) | PCM - Powertrain Control Module | | X | X | X | |
| AII | WINDSTAR | 3.0L (V6 SFI) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| AII | WINDSTAR | 3.0L (V6 SFI) | RCM - Restraint Control Module | | X | X | X | |
| AII | COUGAR | 2.0L (SFI) | PCM - Powertrain Control Module | | X | X | X | |
| AII | COUGAR | 2.0L (SFI) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| AII | COUGAR | 2.0L (SFI) | CSM - Security module | | X | X | X | |
| AII | COUGAR | 2.0L (SFI) | ECS - Electronic Crash Sensor | | X | X | X | |
| AII | COUGAR | 2.5L (SFI) | PCM - Powertrain Control Module | | X | X | X | |
| AII | COUGAR | 2.5L (SFI) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| AII | COUGAR | 2.5L (SFI) | CSM - Security module | | X | X | X | |
| AII | COUGAR | 2.5L (SFI) | ECS - Electronic Crash Sensor | | X | X | X | |
| AII | COUGAR | 2.0L(Duratec-VE) | PCM - Powertrain Control Module | | X | X | | |
| AII | COUGAR | 2.0L(Duratec-VE) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | | |
| AII | COUGAR | 2.0L(Duratec-VE) | RCM - Restraint Control Module | | X | X | | |
| AII | COUGAR | 2.0L(Duratec-VE) | ICM - Instrument Cluster | | X | X | | |
| AII | COUGAR | 2.0L(ZETEC) | PCM - Powertrain Control Module | | X | X | | |
| AII | COUGAR | 2.5L(Duratec-VE) | PCM - Powertrain Control Module | | X | X | | |
| AII | ECONOVAN | 1.4L (2BL OHC) | PCM - Powertrain Control Module | | X | X | X | |
| AII | ECONOVAN | 1.4L (2BL OHC) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| AII | ECONOVAN | 1.4L (2BL OHC) | ECS - Electronic Crash Sensor | | X | X | X | |
| AII | ECONOVAN | 2.0L (DIESEL) | PCM - Powertrain Control Module | | X | X | X | |
| AII | ECONOVAN | 2.0L (DIESEL) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| AII | ECONOVAN | 2.0L (DIESEL) | ECS - Electronic Crash Sensor | | X | X | X | |
| AII | ESCORT | 1.1L (HCS) | PCM - Powertrain Control Module | | X | X | X | |
| AII | ESCORT | 1.1L (HCS) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| AII | ESCORT | 1.1L (HCS) | ECS - Electronic Crash Sensor | | X | X | X | |
| AII | ESCORT | 1.3L (CFI/HCS/SFI) | PCM - Powertrain Control Module | | X | X | X | |
| AII | ESCORT | 1.3L (CFI/HCS/SFI) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| AII | ESCORT | 1.3L (CFI/HCS/SFI) | ECS - Electronic Crash Sensor | | X | X | X | |
| AII | ESCORT | 1.4L (CVH/EFI/SFI) | PCM - Powertrain Control Module | | X | X | X | |

| | | | | | | | | |
|-----|----------|----------------------------|---|--|---|---|---|--|
| AII | ESCORT | 1.4L (CVH/EFI/SFI) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| AII | ESCORT | 1.4L (CVH/EFI/SFI) | ECS - Electronic Crash Sensor | | X | X | X | |
| AII | ESCORT | 1.6L (CFI/SFI) | PCM - Powertrain Control Module | | X | X | X | |
| AII | ESCORT | 1.6L (CFI/SFI) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| AII | ESCORT | 1.6L (CFI/SFI) | CSM - Security module | | X | X | X | |
| AII | ESCORT | 1.6L (CFI/SFI) | ECS - Electronic Crash Sensor | | X | X | X | |
| AII | ESCORT | 1.6L (CFI/SFI) | PATS - Passive Anti-Theft System | | X | X | X | |
| AII | ESCORT | 1.6L (CFI/SFI) | RAP - Remote Anti-Theft / Personality Module | | X | X | X | |
| AII | ESCORT | 1.8L (SFI/DIESEL/T-DIESEL) | PCM - Powertrain Control Module | | X | X | X | |
| AII | ESCORT | 1.8L (SFI/DIESEL/T-DIESEL) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| AII | ESCORT | 1.8L (SFI/DIESEL/T-DIESEL) | CSM - Security module | | X | X | X | |
| AII | ESCORT | 1.8L (SFI/DIESEL/T-DIESEL) | ECS - Electronic Crash Sensor | | X | X | X | |
| AII | ESCORT | 1.8L (SFI/DIESEL/T-DIESEL) | PATS - Passive Anti-Theft System | | X | X | X | |
| AII | ESCORT | 1.8L (SFI/DIESEL/T-DIESEL) | RAP - Remote Anti-Theft / Personality Module | | X | X | X | |
| AII | ESCORT | 2.0L (MPI 16V) | PCM - Powertrain Control Module | | X | X | X | |
| AII | ESCORT | 2.0L (MPI 16V) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| AII | ESCORT | 2.0L (MPI 16V) | CSM - Security module | | X | X | X | |
| AII | ESCORT | 2.0L (MPI 16V) | ECS - Electronic Crash Sensor | | X | X | X | |
| AII | ESCORT | 2.0L (MPI 16V) | PATS - Passive Anti-Theft System | | X | X | X | |
| AII | ESCORT | 2.0L (MPI 16V) | RAP - Remote Anti-Theft / Personality Module | | X | X | X | |
| AII | ESCORT | 2.0L(SPI) | PCM - Powertrain Control Module | | X | X | | |
| AII | ESCORT | 2.0L(SPI) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | | |
| AII | ESCORT | 2.0L(SPI) | RCM - Restraint Control Module | | X | X | | |
| AII | ESCORT | 2.0L(Zetec) | PCM - Powertrain Control Module | | X | X | | |
| AII | ESCORT | 2.0L(Zetec) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | | |
| AII | ESCORT | 2.0L(Zetec) | RCM - Restraint Control Module | | X | X | | |
| AII | EXPLORER | 4.0L (SOHC SFI) | PCM - Powertrain Control Module | | X | X | X | |
| AII | EXPLORER | 4.0L (SOHC SFI) | 4X4M - 4X4 Control Module | | X | X | X | |
| AII | EXPLORER | 4.0L (SOHC SFI) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| AII | EXPLORER | 4.0L (SOHC SFI) | CSM - Security module | | X | X | X | |
| AII | EXPLORER | 4.0L (SOHC SFI) | DSM - Drivers Seat Module | | X | X | X | |
| AII | EXPLORER | 4.0L (SOHC SFI) | GEM - Generic electric module(CTM) | | X | X | X | |
| AII | EXPLORER | 4.0L (SOHC SFI) | ICM - Instrument Cluster | | X | X | X | |
| AII | EXPLORER | 4.0L (SOHC SFI) | PAM - Parking Aid Module | | X | X | X | |
| AII | EXPLORER | 4.0L (SOHC SFI) | RCM - Restraint Control Module | | X | X | X | |
| AII | EXPLORER | 4.6L | PCM - Powertrain Control Module | | X | X | X | |
| AII | EXPLORER | 4.6L | 4X4M - 4X4 Control Module | | X | X | X | |
| AII | EXPLORER | 4.6L | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| AII | EXPLORER | 4.6L | CSM - Security module | | X | X | X | |
| AII | EXPLORER | 4.6L | DSM - Drivers Seat Module | | X | X | X | |
| AII | EXPLORER | 4.6L | GEM - Generic electric module(CTM) | | X | X | X | |
| AII | EXPLORER | 4.6L | ICM - Instrument Cluster | | X | X | X | |
| AII | EXPLORER | 4.6L | PAM - Parking Aid Module | | X | X | X | |
| AII | EXPLORER | 4.6L | RCM - Restraint Control Module | | X | X | X | |
| AII | EXPLORER | 4.0L(V6-SOHC) | PCM - Powertrain Control Module | | X | X | | |

| | | | | | | | | |
|-----|----------|------------------------------|---|--|---|---|---|---|
| AII | EXPLORER | 4.0L(V6-SOHC) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | | |
| AII | EXPLORER | 4.0L(V6-SOHC) | RCM - Restraint Control Module | | X | X | | |
| AII | EXPLORER | 4.0L(V6-SOHC) | ICM - Instrument Cluster | | X | X | | |
| AII | EXPLORER | 4.0L(2V) | PCM - Powertrain Control Module | | X | X | | |
| AII | EXPLORER | 4.0L(2V) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | | |
| AII | EXPLORER | 4.0L(2V) | RCM - Restraint Control Module | | X | X | | |
| AII | EXPLORER | 4.0L(2V) | ICM - Instrument Cluster | | X | X | | |
| AII | EXPLORER | 4.6L(FFV) | PCM - Powertrain Control Module | | X | X | | |
| AII | EXPLORER | 4.6L(FFV) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | | |
| AII | EXPLORER | 4.6L(FFV) | RCM - Restraint Control Module | | X | X | | |
| AII | EXPLORER | 4.6L(FFV) | ICM - Instrument Cluster | | X | X | | |
| AII | EXPLORER | 4.6L(2V) | PCM - Powertrain Control Module | | X | X | | |
| AII | EXPLORER | 4.6L(2V) | ICM - Instrument Cluster | | X | X | | |
| AII | FIESTA | 1.25L(16V/DOHC/SFI) | PCM - Powertrain Control Module | | X | X | X | |
| AII | FIESTA | 1.25L(16V/DOHC/SFI) | RCM - Restraint Control Module | | X | X | X | |
| AII | FIESTA | 1.25L(16V/DOHC/SFI) | GEM - Generic electric module(CTM) | | X | X | X | |
| AII | FIESTA | 1.25L(16V/DOHC/SFI) | ICM - Instrument Cluster | | X | X | X | |
| AII | FIESTA | 1.25L(16V/DOHC/SFI) | PATS - Passive Anti-Theft System | | X | | | 1.Key Programming. |
| AII | FIESTA | 1.3L (DOHC/SFI/SOHC) | PCM - Powertrain Control Module | | X | X | X | |
| AII | FIESTA | 1.3L (DOHC/SFI/SOHC) | RCM - Restraint Control Module | | X | X | X | |
| AII | FIESTA | 1.3L (DOHC/SFI/SOHC) | GEM - Generic electric module(CTM) | | X | X | X | |
| AII | FIESTA | 1.3L (DOHC/SFI/SOHC) | ICM - Instrument Cluster | | X | X | X | |
| AII | FIESTA | 1.3L (DOHC/SFI/SOHC) | PATS - Passive Anti-Theft System | | X | | | 1.Key Programming. |
| AII | FIESTA | 1.4L (16V/DOHC/SFI/T-DIESEL) | PCM - Powertrain Control Module | | X | X | X | |
| AII | FIESTA | 1.4L (16V/DOHC/SFI/T-DIESEL) | RCM - Restraint Control Module | | X | X | X | |
| AII | FIESTA | 1.4L (16V/DOHC/SFI/T-DIESEL) | GEM - Generic electric module(CTM) | | X | X | X | |
| AII | FIESTA | 1.4L (16V/DOHC/SFI/T-DIESEL) | ICM - Instrument Cluster | | X | X | X | |
| AII | FIESTA | 1.4L (16V/DOHC/SFI/T-DIESEL) | PATS - Passive Anti-Theft System | | X | | | 1.Key Programming. |
| AII | FIESTA | 1.5L (DOHC) | PCM - Powertrain Control Module | | X | X | X | |
| AII | FIESTA | 1.5L (DOHC) | RCM - Restraint Control Module | | X | X | X | |
| AII | FIESTA | 1.5L (DOHC) | GEM - Generic electric module(CTM) | | X | X | X | |
| AII | FIESTA | 1.5L (DOHC) | ICM - Instrument Cluster | | X | X | X | |
| AII | FIESTA | 1.5L (DOHC) | PATS - Passive Anti-Theft System | | X | | | 1.Key Programming. |
| AII | FIESTA | 1.6L (DOHC/SFI) | PCM - Powertrain Control Module | | X | X | X | |
| AII | FIESTA | 1.6L (DOHC/SFI) | RCM - Restraint Control Module | | X | X | X | |
| AII | FIESTA | 1.6L (DOHC/SFI) | GEM - Generic electric module(CTM) | | X | X | X | |
| AII | FIESTA | 1.6L (DOHC/SFI) | ICM - Instrument Cluster | | X | X | X | |
| AII | FIESTA | 1.6L (DOHC/SFI) | PATS - Passive Anti-Theft System | | X | | | 1.Key Programming. |
| AII | FIESTA | 1.8L (DIESEL/T-DIESEL) | PCM - Powertrain Control Module | | X | X | X | 1.Fuel Injector Coding. 2.Key Programming. |
| AII | FIESTA | 1.8L (DIESEL/T-DIESEL) | RCM - Restraint Control Module | | X | X | X | |
| AII | FIESTA | 1.8L (DIESEL/T-DIESEL) | GEM - Generic electric module(CTM) | | X | X | X | |
| AII | FIESTA | 1.8L (DIESEL/T-DIESEL) | ICM - Instrument Cluster | | X | X | X | |
| AII | FIESTA | 1.8L (DIESEL/T-DIESEL) | PATS - Passive Anti-Theft System | | X | | | 1.Key Programming. |

| | | | | | | | | |
|-----|--------|--|---|--|---|---|--|--|
| All | FIESTA | 1.4L(DURATEC-16V) | PCM - Powertrain Control Module | | X | X | | |
| All | FIESTA | 1.4L(DURATEC-16V) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | | |
| All | FIESTA | 1.4L(DURATEC-16V) | RCM - Restraint Control Module | | X | X | | |
| All | FIESTA | 1.4L(DURATEC-16V) | TCM - Transmission Control Module | | X | X | | |
| All | FIESTA | 1.4L(DURATEC-16V) | ICM - Instrument Cluster | | X | X | | |
| All | FIESTA | 1.4L(DURATEC-16V) | GEM - Generic electric module(CTM) | | X | X | | |
| All | FIESTA | 1.6L(DURATEC-16V) | PCM - Powertrain Control Module | | X | X | | |
| All | FIESTA | 1.6L(DURATEC-16V) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | | |
| All | FIESTA | 1.6L(DURATEC-16V) | RCM - Restraint Control Module | | X | X | | |
| All | FIESTA | 1.6L(DURATEC-16V) | TCM - Transmission Control Module | | X | X | | |
| All | FIESTA | 1.6L(DURATEC-16V) | ICM - Instrument Cluster | | X | X | | |
| All | FIESTA | 1.6L(DURATEC-16V) | GEM - Generic electric module(CTM) | | X | X | | |
| All | FIESTA | 1.4L(TDCi/Duratorq-Turbo-Diesel-Common-Rail-Injection) | PCM - Powertrain Control Module | | X | X | | |
| All | FIESTA | 1.4L(TDCi/Duratorq-Turbo-Diesel-Common-Rail-Injection) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | | |
| All | FIESTA | 1.4L(TDCi/Duratorq-Turbo-Diesel-Common-Rail-Injection) | RCM - Restraint Control Module | | X | X | | |
| All | FIESTA | 1.4L(TDCi/Duratorq-Turbo-Diesel-Common-Rail-Injection) | TCM - Transmission Control Module | | X | X | | |
| All | FIESTA | 1.4L(TDCi/Duratorq-Turbo-Diesel-Common-Rail-Injection) | ICM - Instrument Cluster | | X | X | | |
| All | FIESTA | 1.4L(TDCi/Duratorq-Turbo-Diesel-Common-Rail-Injection) | GEM - Generic electric module(CTM) | | X | X | | |
| All | FIESTA | 1.3L(DURATEC-8V) | PCM - Powertrain Control Module | | X | X | | |
| All | FIESTA | 1.3L(DURATEC-8V) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | | |
| All | FIESTA | 1.3L(DURATEC-8V) | RCM - Restraint Control Module | | X | X | | |
| All | FIESTA | 1.3L(DURATEC-8V) | ICM - Instrument Cluster | | X | X | | |
| All | FIESTA | 1.3L(DURATEC-8V) | GEM - Generic electric module(CTM) | | X | X | | |
| All | FIESTA | 1.25L(DURATEC-16V) | PCM - Powertrain Control Module | | X | X | | |
| All | FIESTA | 1.25L(DURATEC-16V) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | | |
| All | FIESTA | 1.25L(DURATEC-16V) | RCM - Restraint Control Module | | X | X | | |
| All | FIESTA | 1.25L(DURATEC-16V) | ICM - Instrument Cluster | | X | X | | |
| All | FIESTA | 1.25L(DURATEC-16V) | GEM - Generic electric module(CTM) | | X | X | | |
| All | FIESTA | 1.6L(TDCi/Duratorq-Turbo-Diesel-Common-Rail-Injection) | PCM - Powertrain Control Module | | X | X | | |
| All | FIESTA | 1.6L(TDCi/Duratorq-Turbo-Diesel-Common-Rail-Injection) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | | |
| All | FIESTA | 1.6L(TDCi/Duratorq-Turbo-Diesel-Common-Rail-Injection) | RCM - Restraint Control Module | | X | X | | |
| All | FIESTA | 1.6L(TDCi/Duratorq-Turbo-Diesel-Common-Rail-Injection) | ICM - Instrument Cluster | | X | X | | |
| All | FIESTA | 1.6L(TDCi/Duratorq-Turbo-Diesel-Common-Rail-Injection) | GEM - Generic electric module(CTM) | | X | X | | |

| | | | | | | | | |
|-----|----------|--|---|--|---|---|---|---|
| All | FIESTA | 1.6L(TDCi/Duratorq-Turbo-Diesel-Common-Rail-Injection) | EPS - Electronic Controlled Power Steering | | X | X | | |
| All | FIESTA | 1.4L(DURATEC-8V) | PCM - Powertrain Control Module | | X | X | | |
| All | FIESTA | 1.4L(DURATEC-8V) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | | |
| All | FIESTA | 1.4L(DURATEC-8V) | RCM - Restraint Control Module | | X | X | | |
| All | FIESTA | 1.4L(DURATEC-8V) | ICM - Instrument Cluster | | X | X | | |
| All | FIESTA | 1.4L(DURATEC-8V) | GEM - Generic electric module(CTM) | | X | X | | |
| All | FIESTA | 1.3L(SOHC/Zetec-Rocam) | PCM - Powertrain Control Module | | X | X | | |
| All | FIESTA | 1.3L(SOHC/Zetec-Rocam) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | | |
| All | FIESTA | 1.3L(SOHC/Zetec-Rocam) | RCM - Restraint Control Module | | X | X | | |
| All | FIESTA | 1.3L(SOHC/Zetec-Rocam) | ICM - Instrument Cluster | | X | X | | |
| All | FIESTA | 1.3L(SOHC/Zetec-Rocam) | GEM - Generic electric module(CTM) | | X | X | | |
| All | FOCUS | 1.4L (ZETEC-SE) | PCM - Powertrain Control Module | | X | X | X | |
| All | FOCUS | 1.4L (ZETEC-SE) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| All | FOCUS | 1.4L (ZETEC-SE) | GEM - Generic electric module(CTM) | | X | X | X | |
| All | FOCUS | 1.4L (ZETEC-SE) | RCM - Restraint Control Module | | X | X | X | |
| All | FOCUS | 1.4L (ZETEC-SE) | PATS - Passive Anti-Theft System | | X | | | 1.Key Programming. |
| All | FOCUS | 1.6L (ALT FUEL/ZETEC/DURATEC) | PCM - Powertrain Control Module | | X | X | X | |
| All | FOCUS | 1.6L (ALT FUEL/ZETEC/DURATEC) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| All | FOCUS | 1.6L (ALT FUEL/ZETEC/DURATEC) | GEM - Generic electric module(CTM) | | X | X | X | |
| All | FOCUS | 1.6L (ALT FUEL/ZETEC/DURATEC) | RCM - Restraint Control Module | | X | X | X | |
| All | FOCUS | 1.6L (ALT FUEL/ZETEC/DURATEC) | PATS - Passive Anti-Theft System | | X | | | 1.Key Programming. |
| All | FOCUS | 1.8L (LPG/ZETEC/TDDI/TDCI) | PCM - Powertrain Control Module | | X | X | X | 1.Fuel Injector Coding. 2.Key Programming. |
| All | FOCUS | 1.8L (LPG/ZETEC/TDDI/TDCI) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| All | FOCUS | 1.8L (LPG/ZETEC/TDDI/TDCI) | GEM - Generic electric module(CTM) | | X | X | X | |
| All | FOCUS | 1.8L (LPG/ZETEC/TDDI/TDCI) | RCM - Restraint Control Module | | X | X | X | |
| All | FOCUS | 1.8L (LPG/ZETEC/TDDI/TDCI) | PATS - Passive Anti-Theft System | | X | | | 1.Key Programming. |
| All | FOCUS | 2.0L (ZETEC/DURATEC) | PCM - Powertrain Control Module | | X | X | X | |
| All | FOCUS | 2.0L (ZETEC/DURATEC) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| All | FOCUS | 2.0L (ZETEC/DURATEC) | GEM - Generic electric module(CTM) | | X | X | X | |
| All | FOCUS | 2.0L (ZETEC/DURATEC) | RCM - Restraint Control Module | | X | X | X | |
| All | FOCUS | 2.0L (ZETEC/DURATEC) | PATS - Passive Anti-Theft System | | X | | | 1.Key Programming. |
| All | FOCUS RS | 1.4L (ZTTEC-SE) | PCM - Powertrain Control Module | | X | X | X | |
| All | FOCUS RS | 1.4L (ZTTEC-SE) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| All | FOCUS RS | 1.4L (ZTTEC-SE) | GEM - Generic electric module(CTM) | | X | X | X | |
| All | FOCUS RS | 1.4L (ZTTEC-SE) | RCM - Restraint Control Module | | X | X | X | |
| All | FOCUS RS | 1.4L (ZTTEC-SE) | PATS - Passive Anti-Theft System | | X | | | 1.Key Programming. |
| All | FOCUS RS | 1.6L (ALT FUEL/ZETEC/DURATEC) | PCM - Powertrain Control Module | | X | X | X | |
| All | FOCUS RS | 1.6L (ALT FUEL/ZETEC/DURATEC) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| All | FOCUS RS | 1.6L (ALT FUEL/ZETEC/DURATEC) | GEM - Generic electric module(CTM) | | X | X | X | |
| All | FOCUS RS | 1.6L (ALT FUEL/ZETEC/DURATEC) | RCM - Restraint Control Module | | X | X | X | |
| All | FOCUS RS | 1.6L (ALT FUEL/ZETEC/DURATEC) | PATS - Passive Anti-Theft System | | X | | | 1.Key Programming. |

| | | | | | | | | |
|-----|----------|--|---|--|---|---|---|---|
| All | FOCUS RS | 1.8L (LPG/ZETEC/TDDI/TDCI) | PCM - Powertrain Control Module | | X | X | X | 1.Fuel Injector Coding. 2.Key Programming. |
| All | FOCUS RS | 1.8L (LPG/ZETEC/TDDI/TDCI) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| All | FOCUS RS | 1.8L (LPG/ZETEC/TDDI/TDCI) | GEM - Generic electric module(CTM) | | X | X | X | |
| All | FOCUS RS | 1.8L (LPG/ZETEC/TDDI/TDCI) | RCM - Restraint Control Module | | X | X | X | |
| All | FOCUS RS | 1.8L (LPG/ZETEC/TDDI/TDCI) | PATS - Passive Anti-Theft System | | X | | | 1.Key Programming. |
| All | FOCUS RS | 2.0L (ZETEC/DURATEC) | PCM - Powertrain Control Module | | X | X | X | |
| All | FOCUS RS | 2.0L (ZETEC/DURATEC) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| All | FOCUS RS | 2.0L (ZETEC/DURATEC) | GEM - Generic electric module(CTM) | | X | X | X | |
| All | FOCUS RS | 2.0L (ZETEC/DURATEC) | RCM - Restraint Control Module | | X | X | X | |
| All | FOCUS RS | 2.0L (ZETEC/DURATEC) | PATS - Passive Anti-Theft System | | X | | | 1.Key Programming. |
| All | FUSION | 1.25L(16V/DOHC) | PCM - Powertrain Control Module | | X | X | X | |
| All | FUSION | 1.25L(16V/DOHC) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| All | FUSION | 1.25L(16V/DOHC) | RCM - Restraint Control Module | | X | X | X | |
| All | FUSION | 1.3L (DOHC/SOHC) | PCM - Powertrain Control Module | | X | X | X | |
| All | FUSION | 1.3L (DOHC/SOHC) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| All | FUSION | 1.3L (DOHC/SOHC) | RCM - Restraint Control Module | | X | X | X | |
| All | FUSION | 1.4L (16V/DOHC/T-DIESEL) | PCM - Powertrain Control Module | | X | X | X | |
| All | FUSION | 1.4L (16V/DOHC/T-DIESEL) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| All | FUSION | 1.4L (16V/DOHC/T-DIESEL) | RCM - Restraint Control Module | | X | X | X | |
| All | FUSION | 1.5L (DOHC) | PCM - Powertrain Control Module | | X | X | X | |
| All | FUSION | 1.5L (DOHC) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| All | FUSION | 1.5L (DOHC) | RCM - Restraint Control Module | | X | X | X | |
| All | FUSION | 1.6L (SFI) | PCM - Powertrain Control Module | | X | X | X | |
| All | FUSION | 1.6L (SFI) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| All | FUSION | 1.6L (SFI) | RCM - Restraint Control Module | | X | X | X | |
| All | FUSION | 1.4L(DURATEC-16V) | PCM - Powertrain Control Module | | X | X | | |
| All | FUSION | 1.4L(DURATEC-16V) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | | |
| All | FUSION | 1.4L(DURATEC-16V) | RCM - Restraint Control Module | | X | X | | |
| All | FUSION | 1.4L(DURATEC-16V) | ICM - Instrument Cluster | | X | X | | |
| All | FUSION | 1.4L(DURATEC-16V) | GEM - Generic electric module(CTM) | | X | X | | |
| All | FUSION | 1.6L(DURATEC-16V) | PCM - Powertrain Control Module | | X | X | | |
| All | FUSION | 1.6L(DURATEC-16V) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | | |
| All | FUSION | 1.6L(DURATEC-16V) | RCM - Restraint Control Module | | X | X | | |
| All | FUSION | 1.6L(DURATEC-16V) | ICM - Instrument Cluster | | X | X | | |
| All | FUSION | 1.6L(DURATEC-16V) | GEM - Generic electric module(CTM) | | X | X | | |
| All | FUSION | 1.4L(TDCi/Duratorq-Turbo-Diesel-Common Rail-Injection) | PCM - Powertrain Control Module | | X | X | | |
| All | FUSION | 1.4L(TDCi/Duratorq-Turbo-Diesel-Common Rail-Injection) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | | |
| All | FUSION | 1.4L(TDCi/Duratorq-Turbo-Diesel-Common Rail-Injection) | RCM - Restraint Control Module | | X | X | | |
| All | FUSION | 1.4L(TDCi/Duratorq-Turbo-Diesel-Common Rail-Injection) | ICM - Instrument Cluster | | X | X | | |

| | | | | | | | | |
|-----|--------|--|---|--|---|---|--|--|
| All | FUSION | 1.4L(TDCi/Duratorq-Turbo-Diesel-Common-Rail-Injection) | GEM - Generic electric module(CTM) | | X | X | | |
| All | FUSION | 1.6L(TDCi/Duratorq-Turbo-Diesel-Common-Rail-Injection) | PCM - Powertrain Control Module | | X | X | | |
| All | FUSION | 1.6L(TDCi/Duratorq-Turbo-Diesel-Common-Rail-Injection) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | | |
| All | FUSION | 1.6L(TDCi/Duratorq-Turbo-Diesel-Common-Rail-Injection) | RCM - Restraint Control Module | | X | X | | |
| All | FUSION | 1.6L(TDCi/Duratorq-Turbo-Diesel-Common-Rail-Injection) | ICM - Instrument Cluster | | X | X | | |
| All | FUSION | 1.6L(TDCi/Duratorq-Turbo-Diesel-Common-Rail-Injection) | GEM - Generic electric module(CTM) | | X | X | | |
| All | FUSION | 1.6L(TDCi/Duratorq-Turbo-Diesel-Common-Rail-Injection) | EPS - Electronic Controlled Power Steering | | X | X | | |
| All | FUSION | 1.4L(DURATEC-8V) | PCM - Powertrain Control Module | | X | X | | |
| All | FUSION | 1.4L(DURATEC-8V) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | | |
| All | FUSION | 1.4L(DURATEC-8V) | RCM - Restraint Control Module | | X | X | | |
| All | FUSION | 1.4L(DURATEC-8V) | ICM - Instrument Cluster | | X | X | | |
| All | FUSION | 1.4L(DURATEC-8V) | GEM - Generic electric module(CTM) | | X | X | | |
| All | FUSION | 1.25L(DURATEC-16V) | PCM - Powertrain Control Module | | X | X | | |
| All | FUSION | 1.25L(DURATEC-16V) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | | |
| All | FUSION | 1.25L(DURATEC-16V) | RCM - Restraint Control Module | | X | X | | |
| All | FUSION | 1.25L(DURATEC-16V) | ICM - Instrument Cluster | | X | X | | |
| All | FUSION | 1.25L(DURATEC-16V) | GEM - Generic electric module(CTM) | | X | X | | |
| All | FUSION | 1.3L(DURATEC-8V) | PCM - Powertrain Control Module | | X | X | | |
| All | FUSION | 1.3L(DURATEC-8V) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | | |
| All | FUSION | 1.3L(DURATEC-8V) | RCM - Restraint Control Module | | X | X | | |
| All | FUSION | 1.3L(DURATEC-8V) | ICM - Instrument Cluster | | X | X | | |
| All | FUSION | 1.3L(DURATEC-8V) | GEM - Generic electric module(CTM) | | X | X | | |
| All | GALAXY | 1.8L (DOHC) | PCM - Powertrain Control Module | | X | | | |
| All | GALAXY | 1.8L (DOHC) | TCM - Transmission Control Module | | X | | | |
| All | GALAXY | 1.8L (DOHC) | ABS - Anti-Lock Brake / Traction Control Module | | X | | | |
| All | GALAXY | 1.8L (DOHC) | RCM - Restraint Control Module | | X | | | |
| All | GALAXY | 1.8L (DOHC) | ICM - Instrument Cluster | | X | | | |
| All | GALAXY | 1.8L (DOHC) | NAV - Navigation System | | X | | | |
| All | GALAXY | 1.9L (T-DIESEL) | PCM - Powertrain Control Module | | X | | | |
| All | GALAXY | 1.9L (T-DIESEL) | TCM - Transmission Control Module | | X | | | |
| All | GALAXY | 1.9L (T-DIESEL) | ABS - Anti-Lock Brake / Traction Control Module | | X | | | |
| All | GALAXY | 1.9L (T-DIESEL) | RCM - Restraint Control Module | | X | | | |
| All | GALAXY | 1.9L (T-DIESEL) | ICM - Instrument Cluster | | X | | | |
| All | GALAXY | 1.9L (T-DIESEL) | NAV - Navigation System | | X | | | |
| All | GALAXY | 2.0L (DOHC) | PCM - Powertrain Control Module | | X | | | |
| All | GALAXY | 2.0L (DOHC) | TCM - Transmission Control Module | | X | | | |
| All | GALAXY | 2.0L (DOHC) | ABS - Anti-Lock Brake / Traction Control Module | | X | | | |

| | | | | | | | | |
|-----|----------|-----------------------|---|--|---|---|--|--------------------|
| AII | GALAXY | 2.0L (DOHC) | RCM - Restraint Control Module | | X | | | |
| AII | GALAXY | 2.0L (DOHC) | ICM - Instrument Cluster | | X | | | |
| AII | GALAXY | 2.0L (DOHC) | NAV - Navigation System | | X | | | |
| AII | GALAXY | 2.3L (DOHC) | PCM - Powertrain Control Module | | X | | | |
| AII | GALAXY | 2.3L (DOHC) | TCM - Transmission Control Module | | X | | | |
| AII | GALAXY | 2.3L (DOHC) | ABS - Anti-Lock Brake / Traction Control Module | | X | | | |
| AII | GALAXY | 2.3L (DOHC) | RCM - Restraint Control Module | | X | | | |
| AII | GALAXY | 2.3L (DOHC) | ICM - Instrument Cluster | | X | | | |
| AII | GALAXY | 2.3L (DOHC) | NAV - Navigation System | | X | | | |
| AII | GALAXY | 2.8L (CD-24V-V6) | PCM - Powertrain Control Module | | X | | | |
| AII | GALAXY | 2.8L (CD-24V-V6) | TCM - Transmission Control Module | | X | | | |
| AII | GALAXY | 2.8L (CD-24V-V6) | ABS - Anti-Lock Brake / Traction Control Module | | X | | | |
| AII | GALAXY | 2.8L (CD-24V-V6) | RCM - Restraint Control Module | | X | | | |
| AII | GALAXY | 2.8L (CD-24V-V6) | ICM - Instrument Cluster | | X | | | |
| AII | GALAXY | 2.8L (CD-24V-V6) | NAV - Navigation System | | X | | | |
| AII | RANGER | 2.2L(F2) | PCM - Powertrain Control Module | | X | X | | |
| AII | RANGER | 2.2L(F2) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | | |
| AII | RANGER | 2.2L(F2) | RCM - Restraint Control Module | | X | X | | |
| AII | RANGER | 2.5L(DIESEL/T-DIESEL) | PCM - Powertrain Control Module | | X | X | | |
| AII | RANGER | 2.5L(DIESEL/T-DIESEL) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | | |
| AII | RANGER | 2.5L(DIESEL/T-DIESEL) | RCM - Restraint Control Module | | X | X | | |
| AII | KA | 1.3L | PCM - Powertrain Control Module | | X | X | | |
| AII | KA | 1.3L | ABS - Anti-Lock Brake / Traction Control Module | | X | X | | |
| AII | KA | 1.3L | ECS - Electronic Crash Sensor(or IABM) | | X | X | | |
| AII | KA | 1.3L | EPS - Electronic Controlled Power Steering | | X | X | | |
| AII | KA | 1.3L | GEM - Generic electric module(CTM) | | X | X | | |
| AII | KA | 1.3L | PATS - Passive Anti-Theft System | | X | X | | 1.Key Programming. |
| AII | KA | 1.6L | PCM - Powertrain Control Module | | X | X | | |
| AII | KA | 1.6L | ABS - Anti-Lock Brake / Traction Control Module | | X | X | | |
| AII | KA | 1.6L | ECS - Electronic Crash Sensor(or IABM) | | X | X | | |
| AII | KA | 1.6L | EPS - Electronic Controlled Power Steering | | X | X | | |
| AII | KA | 1.6L | GEM - Generic electric module(CTM) | | X | X | | |
| AII | KA | 1.6L | PATS - Passive Anti-Theft System | | X | X | | |
| AII | MAVERICK | 2.0L | PCM - Powertrain Control Module | | X | X | | |
| AII | MAVERICK | 2.0L | ABS - Anti-Lock Brake / Traction Control Module | | X | X | | |
| AII | MAVERICK | 2.0L | RCM - Restraint Control Module | | X | X | | |
| AII | MAVERICK | 2.0L | GEM - Generic electric module(CTM) | | X | X | | |
| AII | MAVERICK | 2.0L | PAM - Parking Aid Module | | X | X | | |
| AII | MAVERICK | 2.0L | 4X4M - 4X4 Control Module | | X | X | | |
| AII | MAVERICK | 2.3L | PCM - Powertrain Control Module | | X | X | | |
| AII | MAVERICK | 2.3L | ABS - Anti-Lock Brake / Traction Control Module | | X | X | | |
| AII | MAVERICK | 2.3L | RCM - Restraint Control Module | | X | X | | |
| AII | MAVERICK | 2.3L | GEM - Generic electric module(CTM) | | X | X | | |
| AII | MAVERICK | 2.3L | PAM - Parking Aid Module | | X | X | | |
| AII | MAVERICK | 2.3L | 4X4M - 4X4 Control Module | | X | X | | |

| | | | | | | | | |
|-----|------------------------|------|---|--|---|---|--|--|
| All | MAVERICK | 3.0L | PCM - Powertrain Control Module | | X | X | | |
| All | MAVERICK | 3.0L | ABS - Anti-Lock Brake / Traction Control Module | | X | X | | |
| All | MAVERICK | 3.0L | RCM - Restraint Control Module | | X | X | | |
| All | MAVERICK | 3.0L | GEM - Generic electric module(CTM) | | X | X | | |
| All | MAVERICK | 3.0L | PAM - Parking Aid Module | | X | X | | |
| All | MAVERICK | 3.0L | 4X4M - 4X4 Control Module | | X | X | | |
| All | F-SERIES SUPER DUTY | 5.4L | PCM - Powertrain Control Module | | X | | | |
| All | F-SERIES SUPER DUTY | 5.4L | ABS - Anti-Lock Brake / Traction Control Module | | X | X | | |
| All | F-SERIES SUPER DUTY | 5.4L | RCM - Restraint Control Module | | X | X | | |
| All | F-SERIES SUPER DUTY | 5.4L | TCM - Transmission Control Module | | X | X | | |
| All | F-SERIES SUPER DUTY | 5.4L | ICM - Instrument Cluster | | X | X | | |
| All | F-SERIES SUPER DUTY | 5.4L | GEM - Generic electric module(CTM) | | X | X | | |
| All | F-SERIES SUPER DUTY | 5.4L | PATS - Passive Anti-Theft System | | X | X | | |
| All | F-SERIES SUPER DUTY | 6.0L | PCM - Powertrain Control Module | | X | | | |
| All | F-SERIES SUPER DUTY | 6.0L | ABS - Anti-Lock Brake / Traction Control Module | | X | X | | |
| All | F-SERIES SUPER DUTY | 6.0L | RCM - Restraint Control Module | | X | X | | |
| All | F-SERIES SUPER DUTY | 6.0L | TCM - Transmission Control Module | | X | X | | |
| All | F-SERIES SUPER DUTY | 6.0L | ICM - Instrument Cluster | | X | X | | |
| All | F-SERIES SUPER DUTY | 6.0L | GEM - Generic electric module(CTM) | | X | X | | |
| All | F-SERIES SUPER DUTY | 6.0L | PATS - Passive Anti-Theft System | | X | X | | |
| All | F-SERIES SUPER DUTY | 6.8L | PCM - Powertrain Control Module | | X | | | |
| All | F-SERIES SUPER DUTY | 6.8L | ABS - Anti-Lock Brake / Traction Control Module | | X | X | | |
| All | F-SERIES SUPER DUTY | 6.8L | RCM - Restraint Control Module | | X | X | | |
| All | F-SERIES SUPER DUTY | 6.8L | TCM - Transmission Control Module | | X | X | | |
| All | F-SERIES SUPER DUTY | 6.8L | ICM - Instrument Cluster | | X | X | | |

| | | | | | | | | |
|-----|------------------------|--------------------------|---|--|---|---|---|---|
| AII | F-SERIES SUPER DUTY | 6.8L | GEM - Generic electric module(CTM) | | X | X | | |
| AII | F-SERIES SUPER DUTY | 6.8L | PATS - Passive Anti-Theft System | | X | X | | |
| AII | F-SERIES SUPER DUTY | 7.3L | PCM - Powertrain Control Module | | X | | | |
| AII | F-SERIES SUPER DUTY | 7.3L | ABS - Anti-Lock Brake / Traction Control Module | | X | X | | |
| AII | F-SERIES SUPER DUTY | 7.3L | RCM - Restraint Control Module | | X | X | | |
| AII | F-SERIES SUPER DUTY | 7.3L | TCM - Transmission Control Module | | X | X | | |
| AII | F-SERIES SUPER DUTY | 7.3L | ICM - Instrument Cluster | | X | X | | |
| AII | F-SERIES SUPER DUTY | 7.3L | GEM - Generic electric module(CTM) | | X | X | | |
| AII | F-SERIES SUPER DUTY | 7.3L | PATS - Passive Anti-Theft System | | X | X | | |
| AII | STREETKA | 1.6L (DURATEC) | PCM - Powertrain Control Module | | X | X | X | |
| AII | STREETKA | 1.6L (DURATEC) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| AII | STREETKA | 1.6L (DURATEC) | RCM - Restraint Control Module | | X | X | X | |
| AII | MONDEO | 1.8L (DURATEC-SC/HE) | PCM - Powertrain Control Module | | X | X | X | 1.Fuel Injector Coding. 2.Key Programming. |
| AII | MONDEO | 1.8L (DURATEC-SC/HE) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| AII | MONDEO | 1.8L (DURATEC-SC/HE) | RCM - Restraint Control Module | | X | X | X | |
| AII | MONDEO | 1.8L (DURATEC-SC/HE) | PATS - Passive Anti-Theft System | | X | | | 1.Key Programming. |
| AII | MONDEO | 2.0L (DURATEC/TDDI/TDCI) | PCM - Powertrain Control Module | | X | X | X | |
| AII | MONDEO | 2.0L (DURATEC/TDDI/TDCI) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| AII | MONDEO | 2.0L (DURATEC/TDDI/TDCI) | RCM - Restraint Control Module | | X | X | X | |
| AII | MONDEO | 2.0L (DURATEC/TDDI/TDCI) | PATS - Passive Anti-Theft System | | X | | | 1.Key Programming. |
| AII | MONDEO | 2.5L (DURATEC-VE) | PCM - Powertrain Control Module | | X | X | X | |
| AII | MONDEO | 2.5L (DURATEC-VE) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| AII | MONDEO | 2.5L (DURATEC-VE) | RCM - Restraint Control Module | | X | X | X | |
| AII | MONDEO | 2.5L (DURATEC-VE) | PATS - Passive Anti-Theft System | | X | | | 1.Key Programming. |
| AII | MONDEO | 3.0L (DURATEC-ST) | PCM - Powertrain Control Module | | X | X | X | |
| AII | MONDEO | 3.0L (DURATEC-ST) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| AII | MONDEO | 3.0L (DURATEC-ST) | RCM - Restraint Control Module | | X | X | X | |
| AII | MONDEO | 3.0L (DURATEC-ST) | PATS - Passive Anti-Theft System | | X | | | 1.Key Programming. |
| AII | PUMA | 1.4L (ZETEC-S) | PCM - Powertrain Control Module | | X | X | X | |
| AII | PUMA | 1.4L (ZETEC-S) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| AII | PUMA | 1.4L (ZETEC-S) | RCM - Restraint Control Module | | X | X | X | |
| AII | PUMA | 1.7L (ZETEC-S VCT) | PCM - Powertrain Control Module | | X | X | X | |
| AII | PUMA | 1.7L (ZETEC-S VCT) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| AII | PUMA | 1.7L (ZETEC-S VCT) | RCM - Restraint Control Module | | X | X | X | |

| | | | | | | | | |
|-----|--------------------|-----------------------------|---|--|---|---|---|---|
| All | SCORPIO | 2.0L (16V DOHC/8V DOHC) | PCM - Powertrain Control Module | | X | X | X | |
| All | SCORPIO | 2.0L (16V DOHC/8V DOHC) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| All | SCORPIO | 2.0L (16V DOHC/8V DOHC) | RCM - Restraint Control Module | | X | X | X | |
| All | SCORPIO | 2.3L (16V DOHC) | PCM - Powertrain Control Module | | X | X | X | |
| All | SCORPIO | 2.3L (16V DOHC) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| All | SCORPIO | 2.3L (16V DOHC) | RCM - Restraint Control Module | | X | X | X | |
| All | SCORPIO | 2.5L (DIESEL) | PCM - Powertrain Control Module | | X | X | X | |
| All | SCORPIO | 2.5L (DIESEL) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| All | SCORPIO | 2.5L (DIESEL) | RCM - Restraint Control Module | | X | X | X | |
| All | SCORPIO | 2.9L (12V V6/24V V6) | PCM - Powertrain Control Module | | X | X | X | |
| All | SCORPIO | 2.9L (12V V6/24V V6) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| All | SCORPIO | 2.9L (12V V6/24V V6) | RCM - Restraint Control Module | | X | X | X | |
| All | TRANSIT | 2.0L (DIESEL/ALT FUEL/TDCI) | PCM - Powertrain Control Module | | X | X | X | 1.Fuel Injector Coding. 2.Key Programming. |
| All | TRANSIT | 2.0L (DIESEL/ALT FUEL/TDCI) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| All | TRANSIT | 2.0L (DIESEL/ALT FUEL/TDCI) | CSM - Security module | | X | X | X | |
| All | TRANSIT | 2.0L (DIESEL/ALT FUEL/TDCI) | FFH - Fuel Fired Coolant Heating Module | | X | X | X | |
| All | TRANSIT | 2.0L (DIESEL/ALT FUEL/TDCI) | PAM - Parking Aid Module | | X | X | X | |
| All | TRANSIT | 2.0L (DIESEL/ALT FUEL/TDCI) | RASM - Rear Air Suspension Module | | X | X | X | |
| All | TRANSIT | 2.0L (DIESEL/ALT FUEL/TDCI) | RCM - Restraint Control Module | | X | X | X | |
| All | TRANSIT | 2.0L (DIESEL/ALT FUEL/TDCI) | PATS - Passive Anti-Theft System | | X | | | 1.Key Programming. |
| All | TRANSIT | 2.3L (DIESEL) | PCM - Powertrain Control Module | | X | X | X | 1.Fuel Injector Coding. 2.Key Programming. |
| All | TRANSIT | 2.3L (DIESEL) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| All | TRANSIT | 2.3L (DIESEL) | CSM - Security module | | X | X | X | |
| All | TRANSIT | 2.3L (DIESEL) | FFH - Fuel Fired Coolant Heating Module | | X | X | X | |
| All | TRANSIT | 2.3L (DIESEL) | PAM - Parking Aid Module | | X | X | X | |
| All | TRANSIT | 2.3L (DIESEL) | RASM - Rear Air Suspension Module | | X | X | X | |
| All | TRANSIT | 2.3L (DIESEL) | RCM - Restraint Control Module | | X | X | X | |
| All | TRANSIT | 2.3L (DIESEL) | PATS - Passive Anti-Theft System | | X | | | 1.Key Programming. |
| All | TRANSIT | 2.4L (DIESEL/TDCI) | PCM - Powertrain Control Module | | X | X | X | 1.Fuel Injector Coding. 2.Key Programming. |
| All | TRANSIT | 2.4L (DIESEL/TDCI) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| All | TRANSIT | 2.4L (DIESEL/TDCI) | CSM - Security module | | X | X | X | |
| All | TRANSIT | 2.4L (DIESEL/TDCI) | FFH - Fuel Fired Coolant Heating Module | | X | X | X | |
| All | TRANSIT | 2.4L (DIESEL/TDCI) | PAM - Parking Aid Module | | X | X | X | |
| All | TRANSIT | 2.4L (DIESEL/TDCI) | RASM - Rear Air Suspension Module | | X | X | X | |
| All | TRANSIT | 2.4L (DIESEL/TDCI) | RCM - Restraint Control Module | | X | X | X | |
| All | TRANSIT | 2.4L (DIESEL/TDCI) | PATS - Passive Anti-Theft System | | X | | | 1.Key Programming. |
| All | TRANSIT CONNECT | 1.8L (ZETEC/DURATORQ/TDCI) | PCM - Powertrain Control Module | | X | X | X | 1.Fuel Injector Coding. 2.Key Programming. |
| All | TRANSIT CONNECT | 1.8L (ZETEC/DURATORQ/TDCI) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |

| | | | | | | | | |
|-----|---|--|---|--|---|---|---|--|
| All | TRANSIT CONNECT | 1.8L (ZETEC/DURATORQ/TDCI) | CSM - Security module | | X | X | X | |
| All | TRANSIT CONNECT | 1.8L (ZETEC/DURATORQ/TDCI) | FFH - Fuel Fired Coolant Heating Module | | X | X | X | |
| All | TRANSIT CONNECT | 1.8L (ZETEC/DURATORQ/TDCI) | PAM - Parking Aid Module | | X | X | X | |
| All | TRANSIT CONNECT | 1.8L (ZETEC/DURATORQ/TDCI) | RASM - Rear Air Suspension Module | | X | X | X | |
| All | TRANSIT CONNECT | 1.8L (ZETEC/DURATORQ/TDCI) | RCM - Restraint Control Module | | X | X | X | |
| All | TRANSIT CONNECT | 1.8L (ZETEC/DURATORQ/TDCI) | PATS - Passive Anti-Theft System | | X | X | | |
| All | TRANSIT- CONNECT/TO URNEO- CONNECT | 1.8L(DURATEC-HE/I4) | PCM - Powertrain Control Module | | X | X | | |
| All | TRANSIT- CONNECT/TO URNEO- CONNECT | 1.8L(DURATEC-HE/I4) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | | |
| All | TRANSIT- CONNECT/TO URNEO- CONNECT | 1.8L(DURATEC-HE/I4) | RCM - Restraint Control Module | | X | X | | |
| All | TRANSIT- CONNECT/TO URNEO- CONNECT | 1.8L(Endura-DI) | PCM - Powertrain Control Module | | X | X | | |
| All | TRANSIT- CONNECT/TO URNEO- CONNECT | 1.8L(Endura-DI) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | | |
| All | TRANSIT- CONNECT/TO URNEO- CONNECT | 1.8L(Endura-DI) | RCM - Restraint Control Module | | X | X | | |
| All | TRANSIT- CONNECT/TO URNEO- CONNECT | 1.8L(TDCi/Duratorq-Turbo-Diesel-Common- Rail-Injection) | PCM - Powertrain Control Module | | X | X | | |
| All | TRANSIT- CONNECT/TO URNEO- CONNECT | 1.8L(TDCi/Duratorq-Turbo-Diesel-Common- Rail-Injection) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | | |

| | | | | | | | | |
|-----|----------------------------------|--|---|--|---|---|---|--|
| All | TRANSIT-CONNECT/TO URNEO-CONNECT | 1.8L(TDCi/Duratorq-Turbo-Diesel-Common-Rail-Injection) | RCM - Restraint Control Module | | X | X | | |
| All | TRANSIT-CONNECT/TO URNEO-CONNECT | 1.8L(Zetec) | PCM - Powertrain Control Module | | X | X | | |
| All | TRANSIT-CONNECT/TO URNEO-CONNECT | 1.8L(Zetec) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | | |
| All | TRANSIT-CONNECT/TO URNEO-CONNECT | 1.8L(Zetec) | RCM - Restraint Control Module | | X | X | | |
| All | WINDSTAR | 3.0L (V6 SFI) | PCM - Powertrain Control Module | | X | X | X | |
| All | WINDSTAR | 3.0L (V6 SFI) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| All | WINDSTAR | 3.0L (V6 SFI) | RCM - Restraint Control Module | | X | X | X | |
| All | WINDSTAR | 3.8(V6-OHV) | PCM - Powertrain Control Module | | X | X | | |
| All | WINDSTAR | 3.8(V6-OHV) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | | |
| All | WINDSTAR | 3.8(V6-OHV) | RCM - Restraint Control Module | | X | X | | |
| All | WINDSTAR | 3.8(V6-OHV) | ICM - Instrument Cluster | | X | X | | |
| All | CROWN-VICTORIA | 4.6L(2V-NGV) | PCM - Powertrain Control Module | | X | X | | |
| All | CROWN-VICTORIA | 4.6L(2V-NGV) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | | |
| All | CROWN-VICTORIA | 4.6L(2V-NGV) | RCM - Restraint Control Module | | X | X | | |
| All | CROWN-VICTORIA | 4.6L(2V-NGV) | PATS - Passive Anti-Theft System | | X | X | | |
| All | CROWN-VICTORIA | 4.6L(2V) | PCM - Powertrain Control Module | | X | X | | |
| All | CROWN-VICTORIA | 4.6L(2V) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | | |
| All | CROWN-VICTORIA | 4.6L(2V) | PATS - Passive Anti-Theft System | | X | X | | |
| All | EXCURSION | 5.4L(Other) | PCM - Powertrain Control Module | | X | X | | |
| All | EXCURSION | 5.4L(Other) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | | |
| All | EXCURSION | 5.4L(Other) | GEM - Generic electric module(CTM) | | X | X | | |
| All | EXCURSION | 6.8L(Other) | PCM - Powertrain Control Module | | X | X | | |
| All | EXCURSION | 6.8L(Other) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | | |
| All | EXCURSION | 6.8L(Other) | GEM - Generic electric module(CTM) | | X | X | | |
| All | EXCURSION | 7.3L(Direct-Injection-Turbo) | PCM - Powertrain Control Module | | X | X | | |

| | | | | | | | | |
|-----|-------------|--|---|--|---|---|--|--|
| All | EXCURSION | 7.3L(Direct-Injection-Turbo) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | | |
| All | EXCURSION | 7.3L(Direct-Injection-Turbo) | GEM - Generic electric module(CTM) | | X | X | | |
| All | FOCUS-C-MAX | 1.4L(DURATEC-16V) | PCM - Powertrain Control Module | | X | X | | |
| All | FOCUS-C-MAX | 1.4L(DURATEC-HE/I4) | PCM - Powertrain Control Module | | X | X | | |
| All | FOCUS-C-MAX | 1.4L(DURATEC-HE/I4) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | | |
| All | FOCUS-C-MAX | 1.4L(DURATEC-HE/I4) | RCM - Restraint Control Module | | X | X | | |
| All | FOCUS-C-MAX | 1.4L(DURATEC-HE/I4) | ICM - Instrument Cluster | | X | X | | |
| All | FOCUS-C-MAX | 1.4L(DURATEC-HE/I4) | GEM - Generic electric module(CTM) | | X | X | | |
| All | FOCUS-C-MAX | 1.4L(DURATEC-HE/I4) | EPS - Electronic Controlled Power Steering | | X | X | | |
| All | FOCUS-C-MAX | 1.6L(DURATEC-16V) | PCM - Powertrain Control Module | | X | X | | |
| All | FOCUS-C-MAX | 1.6L(DURATEC-VCT) | PCM - Powertrain Control Module | | X | X | | |
| All | FOCUS-C-MAX | 1.4L(DURATEC-16V) | PCM - Powertrain Control Module | | X | X | | |
| All | FOCUS-C-MAX | 1.6L(DURATEC-HE/I4) | PCM - Powertrain Control Module | | X | X | | |
| All | FOCUS-C-MAX | 1.6L(DURATEC-HE/I4) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | | |
| All | FOCUS-C-MAX | 1.6L(DURATEC-HE/I4) | RCM - Restraint Control Module | | X | X | | |
| All | FOCUS-C-MAX | 1.6L(DURATEC-HE/I4) | ICM - Instrument Cluster | | X | X | | |
| All | FOCUS-C-MAX | 1.6L(DURATEC-HE/I4) | GEM - Generic electric module(CTM) | | X | X | | |
| All | FOCUS-C-MAX | 1.6L(DURATEC-HE/I4) | EPS - Electronic Controlled Power Steering | | X | X | | |
| All | FOCUS-C-MAX | 1.6L(TDCi/Duratorq-Turbo-Diesel-Common-Rail-Injection) | PCM - Powertrain Control Module | | X | X | | |
| All | FOCUS-C-MAX | 1.6L(TDCi/Duratorq-Turbo-Diesel-Common-Rail-Injection) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | | |
| All | FOCUS-C-MAX | 1.6L(TDCi/Duratorq-Turbo-Diesel-Common-Rail-Injection) | RCM - Restraint Control Module | | X | X | | |
| All | FOCUS-C-MAX | 1.6L(TDCi/Duratorq-Turbo-Diesel-Common-Rail-Injection) | TCM - Transmission Control Module | | X | X | | |
| All | FOCUS-C-MAX | 1.6L(TDCi/Duratorq-Turbo-Diesel-Common-Rail-Injection) | ICM - Instrument Cluster | | X | X | | |

| | | | | | | | | |
|-----|-------------|--|---|--|---|---|---|--|
| All | FOCUS-C-MAX | 1.6L(TDCi/Duratorq-Turbo-Diesel-Common Rail-Injection) | GEM - Generic electric module(CTM) | | X | X | | |
| All | FOCUS-C-MAX | 1.6L(TDCi/Duratorq-Turbo-Diesel-Common Rail-Injection) | EPS - Electronic Controlled Power Steering | | X | X | | |
| All | FOCUS-C-MAX | 1.8L(DURATEC-HE/I4) | PCM - Powertrain Control Module | | X | X | | |
| All | FOCUS-C-MAX | 1.8L(DURATEC-HE/I4) | TCM - Transmission Control Module | | X | X | | |
| All | FOCUS-C-MAX | 1.8L(TDCi/Duratorq-Turbo-Diesel-Common Rail-Injection) | PCM - Powertrain Control Module | | X | X | | |
| All | FOCUS-C-MAX | 1.8L(TDCi/Duratorq-Turbo-Diesel-Common Rail-Injection) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | | |
| All | FOCUS-C-MAX | 1.8L(TDCi/Duratorq-Turbo-Diesel-Common Rail-Injection) | RCM - Restraint Control Module | | X | X | | |
| All | FOCUS-C-MAX | 1.8L(TDCi/Duratorq-Turbo-Diesel-Common Rail-Injection) | ICM - Instrument Cluster | | X | X | | |
| All | FOCUS-C-MAX | 1.8L(TDCi/Duratorq-Turbo-Diesel-Common Rail-Injection) | GEM - Generic electric module(CTM) | | X | X | | |
| All | FOCUS-C-MAX | 1.8L(TDCi/Duratorq-Turbo-Diesel-Common Rail-Injection) | EPS - Electronic Controlled Power Steering | | X | X | | |
| All | FOCUS-C-MAX | 2.0L(DURATEC-HE/I4) | PCM - Powertrain Control Module | | X | X | | |
| All | FOCUS-C-MAX | 2.0L(DURATEC-HE/I4) | TCM - Transmission Control Module | | X | X | | |
| All | FOCUS-C-MAX | 2.0L(TDCi/Duratorq-Turbo-Diesel-Common Rail-Injection) | PCM - Powertrain Control Module | | X | X | | |
| All | FOCUS-C-MAX | 2.0L(TDCi/Duratorq-Turbo-Diesel-Common Rail-Injection) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | | |
| All | FOCUS-C-MAX | 2.0L(TDCi/Duratorq-Turbo-Diesel-Common Rail-Injection) | RCM - Restraint Control Module | | X | X | | |
| All | FOCUS-C-MAX | 2.0L(TDCi/Duratorq-Turbo-Diesel-Common Rail-Injection) | ICM - Instrument Cluster | | X | X | | |
| All | FOCUS-C-MAX | 2.0L(TDCi/Duratorq-Turbo-Diesel-Common Rail-Injection) | GEM - Generic electric module(CTM) | | X | X | | |
| All | FOCUS-C-MAX | 2.0L(TDCi/Duratorq-Turbo-Diesel-Common Rail-Injection) | EPS - Electronic Controlled Power Steering | | X | X | | |
| All | COUGAR | 2.0L (SFI) | PCM - Powertrain Control Module | | X | X | X | |
| All | COUGAR | 2.0L (SFI) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| All | COUGAR | 2.0L (SFI) | RCM - Restraint Control Module | | X | X | X | |
| All | COUGAR | 2.5L (SFI) | PCM - Powertrain Control Module | | X | X | X | |
| All | COUGAR | 2.5L (SFI) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| All | COUGAR | 2.5L (SFI) | RCM - Restraint Control Module | | X | X | X | |
| All | EXPLORER | 4.0L (SOHC SFI) | PCM - Powertrain Control Module | | X | X | X | |
| All | EXPLORER | 4.0L (SOHC SFI) | 4X4M - 4X4 Control Module | | X | X | X | |

| | | | | | | | | |
|-----|----------|--------------------------|---|--|---|---|---|--|
| AII | EXPLORER | 4.0L (SOHC SFI) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| AII | EXPLORER | 4.0L (SOHC SFI) | CSM - Security module | | X | X | X | |
| AII | EXPLORER | 4.0L (SOHC SFI) | DSM - Drivers Seat Module | | X | X | X | |
| AII | EXPLORER | 4.0L (SOHC SFI) | ICM - Instrument Cluster | | X | X | X | |
| AII | EXPLORER | 4.0L (SOHC SFI) | PAM - Parking Aid Module | | X | X | X | |
| AII | EXPLORER | 4.0L (SOHC SFI) | RCM - Restraint Control Module | | X | X | X | |
| AII | EXPLORER | 4.0L (SOHC SFI) | TPM - 4Tire Pressure Monitor | | X | X | X | |
| AII | EXPLORER | 4.6L | PCM - Powertrain Control Module | | X | X | X | |
| AII | EXPLORER | 4.6L | 4X4M - 4X4 Control Module | | X | X | X | |
| AII | EXPLORER | 4.6L | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| AII | EXPLORER | 4.6L | CSM - Security module | | X | X | X | |
| AII | EXPLORER | 4.6L | DSM - Drivers Seat Module | | X | X | X | |
| AII | EXPLORER | 4.6L | ICM - Instrument Cluster | | X | X | X | |
| AII | EXPLORER | 4.6L | PAM - Parking Aid Module | | X | X | X | |
| AII | EXPLORER | 4.6L | RCM - Restraint Control Module | | X | X | X | |
| AII | EXPLORER | 4.6L | TPM - 4Tire Pressure Monitor | | X | X | X | |
| AII | EXPLORER | 4.0L(V6-SOHC) | PCM - Powertrain Control Module | | X | X | | |
| AII | EXPLORER | 4.0L(V6-SOHC) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | | |
| AII | EXPLORER | 4.0L(V6-SOHC) | RCM - Restraint Control Module | | X | X | | |
| AII | EXPLORER | 4.6L(2V) | PCM - Powertrain Control Module | | X | X | | |
| AII | EXPLORER | 4.6L(2V) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | | |
| AII | EXPLORER | 4.6L(2V) | RCM - Restraint Control Module | | X | X | | |
| AII | FIESTA | 1.25L(16V/DOHC) | PCM - Powertrain Control Module | | X | X | X | |
| AII | FIESTA | 1.25L(16V/DOHC) | RCM - Restraint Control Module | | X | X | X | |
| AII | FIESTA | 1.25L(16V/DOHC) | GEM - Generic electric module(CTM) | | X | X | X | |
| AII | FIESTA | 1.25L(16V/DOHC) | ICM - Instrument Cluster | | X | X | X | |
| AII | FIESTA | 1.3L (DOHC/SOHC) | PCM - Powertrain Control Module | | X | X | X | |
| AII | FIESTA | 1.3L (DOHC/SOHC) | RCM - Restraint Control Module | | X | X | X | |
| AII | FIESTA | 1.3L (DOHC/SOHC) | GEM - Generic electric module(CTM) | | X | X | X | |
| AII | FIESTA | 1.3L (DOHC/SOHC) | ICM - Instrument Cluster | | X | X | X | |
| AII | FIESTA | 1.4L (16V/DOHC/T-DIESEL) | PCM - Powertrain Control Module | | X | X | X | |
| AII | FIESTA | 1.4L (16V/DOHC/T-DIESEL) | RCM - Restraint Control Module | | X | X | X | |
| AII | FIESTA | 1.4L (16V/DOHC/T-DIESEL) | GEM - Generic electric module(CTM) | | X | X | X | |
| AII | FIESTA | 1.4L (16V/DOHC/T-DIESEL) | ICM - Instrument Cluster | | X | X | X | |
| AII | FIESTA | 1.5L (DOHC) | PCM - Powertrain Control Module | | X | X | X | |
| AII | FIESTA | 1.5L (DOHC) | RCM - Restraint Control Module | | X | X | X | |
| AII | FIESTA | 1.5L (DOHC) | GEM - Generic electric module(CTM) | | X | X | X | |
| AII | FIESTA | 1.5L (DOHC) | ICM - Instrument Cluster | | X | X | X | |
| AII | FIESTA | 1.6L (SFI) | PCM - Powertrain Control Module | | X | X | X | |
| AII | FIESTA | 1.6L (SFI) | RCM - Restraint Control Module | | X | X | X | |
| AII | FIESTA | 1.6L (SFI) | GEM - Generic electric module(CTM) | | X | X | X | |
| AII | FIESTA | 1.6L (SFI) | ICM - Instrument Cluster | | X | X | X | |
| AII | FOCUS | 1.4L (ZETEC-SE) | PCM - Powertrain Control Module | | X | X | X | |
| AII | FOCUS | 1.4L (ZETEC-SE) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| AII | FOCUS | 1.4L (ZETEC-SE) | GEM - Generic electric module(CTM) | | X | X | X | |

| | | | | | | | | |
|-----|-------|-------------------------------|---|--|---|---|---|---|
| AII | FOCUS | 1.4L (ZETEC-SE) | RCM - Restraint Control Module | | X | X | X | |
| AII | FOCUS | 1.4L (ZETEC-SE) | MCM - Information central module | | X | X | X | |
| AII | FOCUS | 1.4L (ZETEC-SE) | PATS - Passive Anti-Theft System | | X | | | 1.Key Programming. |
| AII | FOCUS | 1.4L (ZETEC-SE) | ICM - Instrument Cluster | | X | X | X | |
| AII | FOCUS | 1.4L (ZETEC-SE) | EPS - Electronic Controlled Power Steering | | X | X | X | |
| AII | FOCUS | 1.4L (ZETEC-SE) | EATC - Electronic Automatic Temperature Control | | X | X | X | |
| AII | FOCUS | 1.6L (ALT FUEL/ZETEC/DURATEC) | PCM - Powertrain Control Module | | X | X | X | |
| AII | FOCUS | 1.6L (ALT FUEL/ZETEC/DURATEC) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| AII | FOCUS | 1.6L (ALT FUEL/ZETEC/DURATEC) | GEM - Generic electric module(CTM) | | X | X | X | |
| AII | FOCUS | 1.6L (ALT FUEL/ZETEC/DURATEC) | RCM - Restraint Control Module | | X | X | X | |
| AII | FOCUS | 1.6L (ALT FUEL/ZETEC/DURATEC) | MCM - Information central module | | X | X | X | |
| AII | FOCUS | 1.6L (ALT FUEL/ZETEC/DURATEC) | PATS - Passive Anti-Theft System | | X | | | 1.Key Programming. |
| AII | FOCUS | 1.6L (ALT FUEL/ZETEC/DURATEC) | ICM - Instrument Cluster | | X | X | X | |
| AII | FOCUS | 1.6L (ALT FUEL/ZETEC/DURATEC) | EPS - Electronic Controlled Power Steering | | X | X | X | |
| AII | FOCUS | 1.6L (ALT FUEL/ZETEC/DURATEC) | EATC - Electronic Automatic Temperature Control | | X | X | X | |
| AII | FOCUS | 1.8L (LPG/ZETEC/TDDI/TDCI) | PCM - Powertrain Control Module | | X | X | X | 1.Fuel Injector Coding. 2.Key Programming. |
| AII | FOCUS | 1.8L (LPG/ZETEC/TDDI/TDCI) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| AII | FOCUS | 1.8L (LPG/ZETEC/TDDI/TDCI) | GEM - Generic electric module(CTM) | | X | X | X | |
| AII | FOCUS | 1.8L (LPG/ZETEC/TDDI/TDCI) | RCM - Restraint Control Module | | X | X | X | |
| AII | FOCUS | 1.8L (LPG/ZETEC/TDDI/TDCI) | MCM - Information central module | | X | X | X | |
| AII | FOCUS | 1.8L (LPG/ZETEC/TDDI/TDCI) | PATS - Passive Anti-Theft System | | X | | | 1.Key Programming. |
| AII | FOCUS | 1.8L (LPG/ZETEC/TDDI/TDCI) | ICM - Instrument Cluster | | X | X | X | |
| AII | FOCUS | 1.8L (LPG/ZETEC/TDDI/TDCI) | EPS - Electronic Controlled Power Steering | | X | X | X | |
| AII | FOCUS | 1.8L (LPG/ZETEC/TDDI/TDCI) | EATC - Electronic Automatic Temperature Control | | X | X | X | |
| AII | FOCUS | 2.0L (ZETEC/DURATEC) | PCM - Powertrain Control Module | | X | X | X | |
| AII | FOCUS | 2.0L (ZETEC/DURATEC) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| AII | FOCUS | 2.0L (ZETEC/DURATEC) | GEM - Generic electric module(CTM) | | X | X | X | |
| AII | FOCUS | 2.0L (ZETEC/DURATEC) | RCM - Restraint Control Module | | X | X | X | |
| AII | FOCUS | 2.0L (ZETEC/DURATEC) | MCM - Information central module | | X | X | X | |
| AII | FOCUS | 2.0L (ZETEC/DURATEC) | PATS - Passive Anti-Theft System | | X | | | 1.Key Programming. |
| AII | FOCUS | 2.0L (ZETEC/DURATEC) | ICM - Instrument Cluster | | X | X | X | |
| AII | FOCUS | 2.0L (ZETEC/DURATEC) | EPS - Electronic Controlled Power Steering | | X | X | X | |
| AII | FOCUS | 2.0L (ZETEC/DURATEC) | EATC - Electronic Automatic Temperature Control | | X | X | X | |
| AII | FOCUS | 2.3L (PZEV) | PCM - Powertrain Control Module | | X | X | X | |
| AII | FOCUS | 2.3L (PZEV) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| AII | FOCUS | 2.3L (PZEV) | GEM - Generic electric module(CTM) | | X | X | X | |
| AII | FOCUS | 2.3L (PZEV) | RCM - Restraint Control Module | | X | X | X | |
| AII | FOCUS | 2.3L (PZEV) | MCM - Information central module | | X | X | X | |
| AII | FOCUS | 2.3L (PZEV) | PATS - Passive Anti-Theft System | | X | | | 1.Key Programming. |
| AII | FOCUS | 2.3L (PZEV) | ICM - Instrument Cluster | | X | X | X | |
| AII | FOCUS | 2.3L (PZEV) | EPS - Electronic Controlled Power Steering | | X | X | X | |
| AII | FOCUS | 2.3L (PZEV) | EATC - Electronic Automatic Temperature Control | | X | X | X | |
| AII | FOCUS | 2.5L (I5) | PCM - Powertrain Control Module | | X | X | X | |

| | | | | | | | | |
|-----|-------------|-------------------------------|---|--|---|---|---|--------------------|
| AII | FOCUS | 2.5L (I5) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| AII | FOCUS | 2.5L (I5) | GEM - Generic electric module(CTM) | | X | X | X | |
| AII | FOCUS | 2.5L (I5) | RCM - Restraint Control Module | | X | X | X | |
| AII | FOCUS | 2.5L (I5) | MCM - Information central module | | X | X | X | |
| AII | FOCUS | 2.5L (I5) | PATS - Passive Anti-Theft System | | X | | | 1.Key Programming. |
| AII | FOCUS | 2.5L (I5) | ICM - Instrument Cluster | | X | X | X | |
| AII | FOCUS | 2.5L (I5) | EPS - Electronic Controlled Power Steering | | X | X | X | |
| AII | FOCUS | 2.5L (I5) | EATC - Electronic Automatic Temperature Control | | X | X | X | |
| AII | FOCUS RS | 1.4L (ZTTEC-SE) | PCM - Powertrain Control Module | | X | X | X | |
| AII | FOCUS RS | 1.4L (ZTTEC-SE) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| AII | FOCUS RS | 1.4L (ZTTEC-SE) | GEM - Generic electric module(CTM) | | X | X | X | |
| AII | FOCUS RS | 1.4L (ZTTEC-SE) | RCM - Restraint Control Module | | X | X | X | |
| AII | FOCUS RS | 1.4L (ZTTEC-SE) | MCM - Information central module | | X | X | X | |
| AII | FOCUS RS | 1.4L (ZTTEC-SE) | PATS - Passive Anti-Theft System | | X | | | 1.Key Programming. |
| AII | FOCUS RS | 1.6L (ALT FUEL/ZETEC/DURATEC) | PCM - Powertrain Control Module | | X | X | X | |
| AII | FOCUS RS | 1.6L (ALT FUEL/ZETEC/DURATEC) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| AII | FOCUS RS | 1.6L (ALT FUEL/ZETEC/DURATEC) | GEM - Generic electric module(CTM) | | X | X | X | |
| AII | FOCUS RS | 1.6L (ALT FUEL/ZETEC/DURATEC) | RCM - Restraint Control Module | | X | X | X | |
| AII | FOCUS RS | 1.6L (ALT FUEL/ZETEC/DURATEC) | MCM - Information central module | | X | X | X | |
| AII | FOCUS RS | 1.6L (ALT FUEL/ZETEC/DURATEC) | PATS - Passive Anti-Theft System | | X | | | 1.Key Programming. |
| AII | FOCUS RS | 1.8L (LPG/ZETEC/TDDI/TDCI) | PCM - Powertrain Control Module | | X | X | X | |
| AII | FOCUS RS | 1.8L (LPG/ZETEC/TDDI/TDCI) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| AII | FOCUS RS | 1.8L (LPG/ZETEC/TDDI/TDCI) | GEM - Generic electric module(CTM) | | X | X | X | |
| AII | FOCUS RS | 1.8L (LPG/ZETEC/TDDI/TDCI) | RCM - Restraint Control Module | | X | X | X | |
| AII | FOCUS RS | 1.8L (LPG/ZETEC/TDDI/TDCI) | MCM - Information central module | | X | X | X | |
| AII | FOCUS RS | 1.8L (LPG/ZETEC/TDDI/TDCI) | PATS - Passive Anti-Theft System | | X | | | 1.Key Programming. |
| AII | FOCUS RS | 2.0L (ZETEC/DURATEC) | PCM - Powertrain Control Module | | X | X | X | |
| AII | FOCUS RS | 2.0L (ZETEC/DURATEC) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| AII | FOCUS RS | 2.0L (ZETEC/DURATEC) | GEM - Generic electric module(CTM) | | X | X | X | |
| AII | FOCUS RS | 2.0L (ZETEC/DURATEC) | RCM - Restraint Control Module | | X | X | X | |
| AII | FOCUS RS | 2.0L (ZETEC/DURATEC) | MCM - Information central module | | X | X | X | |
| AII | FOCUS RS | 2.0L (ZETEC/DURATEC) | PATS - Passive Anti-Theft System | | X | | | 1.Key Programming. |
| AII | FOCUS C-MAX | | | | | | | |
| | | 1.4L (ZTTEC-SE) | PCM - Powertrain Control Module | | X | X | X | |
| AII | FOCUS C-MAX | | | | | | | |
| | | 1.4L (ZTTEC-SE) | ICM - Instrument Cluster | | X | X | X | |
| AII | FOCUS C-MAX | | | | | | | |
| | | 1.6L (ALT FUEL/ZETEC/DURATEC) | PCM - Powertrain Control Module | | X | X | X | |
| AII | FOCUS C-MAX | | | | | | | |
| | | 1.6L (ALT FUEL/ZETEC/DURATEC) | ICM - Instrument Cluster | | X | X | X | |
| AII | FOCUS C-MAX | | | | | | | |
| | | 1.8L (LPG/ZETEC/TDDI/TDCI) | PCM - Powertrain Control Module | | X | X | X | |
| AII | FOCUS C-MAX | | | | | | | |
| | | 1.8L (LPG/ZETEC/TDDI/TDCI) | ICM - Instrument Cluster | | X | X | X | |

| | | | | | | | | |
|-----|-------------|--------------------------|---|--|---|---|---|--|
| AII | FOCUS C-MAX | 2.0L (ZETEC/DURATEC) | PCM - Powertrain Control Module | | X | X | X | |
| AII | FOCUS C-MAX | 2.0L (ZETEC/DURATEC) | ICM - Instrument Cluster | | X | X | X | |
| AII | FUSION | 1.25L(16V/DOHC) | PCM - Powertrain Control Module | | X | X | X | |
| AII | FUSION | 1.25L(16V/DOHC) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| AII | FUSION | 1.25L(16V/DOHC) | GEM - Generic electric module(CTM) | | X | X | X | |
| AII | FUSION | 1.25L(16V/DOHC) | RCM - Restraint Control Module | | X | X | X | |
| AII | FUSION | 1.3L (DOHC/SOHC) | PCM - Powertrain Control Module | | X | X | X | |
| AII | FUSION | 1.3L (DOHC/SOHC) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| AII | FUSION | 1.3L (DOHC/SOHC) | GEM - Generic electric module(CTM) | | X | X | X | |
| AII | FUSION | 1.3L (DOHC/SOHC) | RCM - Restraint Control Module | | X | X | X | |
| AII | FUSION | 1.4L (16V/DOHC/T-DIESEL) | PCM - Powertrain Control Module | | X | X | X | |
| AII | FUSION | 1.4L (16V/DOHC/T-DIESEL) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| AII | FUSION | 1.4L (16V/DOHC/T-DIESEL) | GEM - Generic electric module(CTM) | | X | X | X | |
| AII | FUSION | 1.4L (16V/DOHC/T-DIESEL) | RCM - Restraint Control Module | | X | X | X | |
| AII | FUSION | 1.5L (DOHC) | PCM - Powertrain Control Module | | X | X | X | |
| AII | FUSION | 1.5L (DOHC) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| AII | FUSION | 1.5L (DOHC) | GEM - Generic electric module(CTM) | | X | X | X | |
| AII | FUSION | 1.5L (DOHC) | RCM - Restraint Control Module | | X | X | X | |
| AII | FUSION | 1.6L (SFI) | PCM - Powertrain Control Module | | X | X | X | |
| AII | FUSION | 1.6L (SFI) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| AII | FUSION | 1.6L (SFI) | GEM - Generic electric module(CTM) | | X | X | X | |
| AII | FUSION | 1.6L (SFI) | RCM - Restraint Control Module | | X | X | X | |
| AII | GALAXY | 1.9L (T-DIESEL) | PCM - Powertrain Control Module | | X | | | |
| AII | GALAXY | 1.9L (T-DIESEL) | TCM - Transmission Control Module | | X | | | |
| AII | GALAXY | 1.9L (T-DIESEL) | ABS - Anti-Lock Brake / Traction Control Module | | X | | | |
| AII | GALAXY | 1.9L (T-DIESEL) | RCM - Restraint Control Module | | X | | | |
| AII | GALAXY | 1.9L (T-DIESEL) | ICM - Instrument Cluster | | X | | | |
| AII | GALAXY | 1.9L (T-DIESEL) | NAV - Navigation System | | X | | | |
| AII | GALAXY | 2.0L (DOHC) | PCM - Powertrain Control Module | | X | | | |
| AII | GALAXY | 2.0L (DOHC) | TCM - Transmission Control Module | | X | | | |
| AII | GALAXY | 2.0L (DOHC) | ABS - Anti-Lock Brake / Traction Control Module | | X | | | |
| AII | GALAXY | 2.0L (DOHC) | RCM - Restraint Control Module | | X | | | |
| AII | GALAXY | 2.0L (DOHC) | ICM - Instrument Cluster | | X | | | |
| AII | GALAXY | 2.0L (DOHC) | NAV - Navigation System | | X | | | |
| AII | GALAXY | 2.3L (DOHC) | PCM - Powertrain Control Module | | X | | | |
| AII | GALAXY | 2.3L (DOHC) | TCM - Transmission Control Module | | X | | | |
| AII | GALAXY | 2.3L (DOHC) | ABS - Anti-Lock Brake / Traction Control Module | | X | | | |
| AII | GALAXY | 2.3L (DOHC) | RCM - Restraint Control Module | | X | | | |
| AII | GALAXY | 2.3L (DOHC) | ICM - Instrument Cluster | | X | | | |
| AII | GALAXY | 2.3L (DOHC) | NAV - Navigation System | | X | | | |
| AII | GALAXY | 2.8L (CD-24V-V6) | PCM - Powertrain Control Module | | X | | | |
| AII | GALAXY | 2.8L (CD-24V-V6) | TCM - Transmission Control Module | | X | | | |

| | | | | | | | | |
|-----|----------|-----------------------|---|--|---|---|--|--------------------|
| AII | GALAXY | 2.8L (CD-24V-V6) | ABS - Anti-Lock Brake / Traction Control Module | | X | | | |
| AII | GALAXY | 2.8L (CD-24V-V6) | RCM - Restraint Control Module | | X | | | |
| AII | GALAXY | 2.8L (CD-24V-V6) | ICM - Instrument Cluster | | X | | | |
| AII | GALAXY | 2.8L (CD-24V-V6) | NAV - Navigation System | | X | | | |
| AII | RANGER | 2.5L(DIESEL/T-DIESEL) | PCM - Powertrain Control Module | | X | X | | |
| AII | RANGER | 2.5L(DIESEL/T-DIESEL) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | | |
| AII | RANGER | 2.5L(DIESEL/T-DIESEL) | RCM - Restraint Control Module | | X | X | | |
| AII | RANGER | 2.5L(DIESEL/T-DIESEL) | GEM - Generic electric module(CTM) | | X | X | | |
| AII | RANGER | 2.5L(DIESEL/T-DIESEL) | EATC - Electronic Automatic Temperature Control | | X | X | | |
| AII | KA | 1.0L | PCM - Powertrain Control Module | | X | X | | |
| AII | KA | 1.0L | ABS - Anti-Lock Brake / Traction Control Module | | X | X | | |
| AII | KA | 1.0L | ECS - Electronic Crash Sensor(or IABM) | | X | X | | |
| AII | KA | 1.0L | EPS - Electronic Controlled Power Steering | | X | X | | |
| AII | KA | 1.0L | GEM - Generic electric module(CTM) | | X | X | | |
| AII | KA | 1.0L | PATS - Passive Anti-Theft System | | X | X | | 1.Key Programming. |
| AII | KA | 1.3L | PCM - Powertrain Control Module | | X | X | | |
| AII | KA | 1.3L | ABS - Anti-Lock Brake / Traction Control Module | | X | X | | |
| AII | KA | 1.3L | ECS - Electronic Crash Sensor(or IABM) | | X | X | | |
| AII | KA | 1.3L | EPS - Electronic Controlled Power Steering | | X | X | | |
| AII | KA | 1.3L | GEM - Generic electric module(CTM) | | X | X | | |
| AII | KA | 1.3L | PATS - Passive Anti-Theft System | | X | X | | 1.Key Programming. |
| AII | KA | 1.6L | PCM - Powertrain Control Module | | X | X | | |
| AII | KA | 1.6L | ABS - Anti-Lock Brake / Traction Control Module | | X | X | | |
| AII | KA | 1.6L | ECS - Electronic Crash Sensor(or IABM) | | X | X | | |
| AII | KA | 1.6L | EPS - Electronic Controlled Power Steering | | X | X | | |
| AII | KA | 1.6L | GEM - Generic electric module(CTM) | | X | X | | |
| AII | KA | 1.6L | PATS - Passive Anti-Theft System | | X | X | | 1.Key Programming. |
| AII | KA | 1.7L | PCM - Powertrain Control Module | | X | X | | |
| AII | KA | 1.7L | ABS - Anti-Lock Brake / Traction Control Module | | X | X | | |
| AII | KA | 1.7L | ECS - Electronic Crash Sensor(or IABM) | | X | X | | |
| AII | KA | 1.7L | EPS - Electronic Controlled Power Steering | | X | X | | |
| AII | KA | 1.7L | GEM - Generic electric module(CTM) | | X | X | | |
| AII | KA | 1.7L | PATS - Passive Anti-Theft System | | X | X | | 1.Key Programming. |
| AII | MAVERICK | 2.0L | PCM - Powertrain Control Module | | X | X | | |
| AII | MAVERICK | 2.0L | ABS - Anti-Lock Brake / Traction Control Module | | X | X | | |
| AII | MAVERICK | 2.0L | RCM - Restraint Control Module | | X | X | | |
| AII | MAVERICK | 2.0L | GEM - Generic electric module(CTM) | | X | X | | |
| AII | MAVERICK | 2.0L | PAM - Parking Aid Module | | X | X | | |
| AII | MAVERICK | 2.0L | 4X4M - 4X4 Control Module | | X | X | | |
| AII | MAVERICK | 2.3L | PCM - Powertrain Control Module | | X | X | | |
| AII | MAVERICK | 2.3L | ABS - Anti-Lock Brake / Traction Control Module | | X | X | | |
| AII | MAVERICK | 2.3L | RCM - Restraint Control Module | | X | X | | |
| AII | MAVERICK | 2.3L | GEM - Generic electric module(CTM) | | X | X | | |
| AII | MAVERICK | 2.3L | PAM - Parking Aid Module | | X | X | | |
| AII | MAVERICK | 2.3L | 4X4M - 4X4 Control Module | | X | X | | |

| | | | | | | | | |
|-----|------------------------|------|---|--|---|---|--|--|
| All | MAVERICK | 3.0L | PCM - Powertrain Control Module | | X | X | | |
| All | MAVERICK | 3.0L | ABS - Anti-Lock Brake / Traction Control Module | | X | X | | |
| All | MAVERICK | 3.0L | RCM - Restraint Control Module | | X | X | | |
| All | MAVERICK | 3.0L | GEM - Generic electric module(CTM) | | X | X | | |
| All | MAVERICK | 3.0L | PAM - Parking Aid Module | | X | X | | |
| All | MAVERICK | 3.0L | 4X4M - 4X4 Control Module | | X | X | | |
| All | F-SERIES SUPER DUTY | 5.4L | PCM - Powertrain Control Module | | X | | | |
| All | F-SERIES SUPER DUTY | 5.4L | ABS - Anti-Lock Brake / Traction Control Module | | X | X | | |
| All | F-SERIES SUPER DUTY | 5.4L | RCM - Restraint Control Module | | X | X | | |
| All | F-SERIES SUPER DUTY | 5.4L | TCM - Transmission Control Module | | X | X | | |
| All | F-SERIES SUPER DUTY | 5.4L | ICM - Instrument Cluster | | X | X | | |
| All | F-SERIES SUPER DUTY | 5.4L | GEM - Generic electric module(CTM) | | X | X | | |
| All | F-SERIES SUPER DUTY | 5.4L | PATS - Passive Anti-Theft System | | X | X | | |
| All | F-SERIES SUPER DUTY | 6.0L | PCM - Powertrain Control Module | | X | | | |
| All | F-SERIES SUPER DUTY | 6.0L | ABS - Anti-Lock Brake / Traction Control Module | | X | X | | |
| All | F-SERIES SUPER DUTY | 6.0L | RCM - Restraint Control Module | | X | X | | |
| All | F-SERIES SUPER DUTY | 6.0L | TCM - Transmission Control Module | | X | X | | |
| All | F-SERIES SUPER DUTY | 6.0L | ICM - Instrument Cluster | | X | X | | |
| All | F-SERIES SUPER DUTY | 6.0L | GEM - Generic electric module(CTM) | | X | X | | |
| All | F-SERIES SUPER DUTY | 6.0L | PATS - Passive Anti-Theft System | | X | X | | |
| All | F-SERIES SUPER DUTY | 6.8L | PCM - Powertrain Control Module | | X | | | |
| All | F-SERIES SUPER DUTY | 6.8L | ABS - Anti-Lock Brake / Traction Control Module | | X | X | | |
| All | F-SERIES SUPER DUTY | 6.8L | RCM - Restraint Control Module | | X | X | | |
| All | F-SERIES SUPER DUTY | 6.8L | TCM - Transmission Control Module | | X | X | | |
| All | F-SERIES SUPER DUTY | 6.8L | ICM - Instrument Cluster | | X | X | | |

| | | | | | | | | |
|-----|------------------------|------------------------------------|---|--|---|---|---|---|
| AII | F-SERIES SUPER DUTY | 6.8L | GEM - Generic electric module(CTM) | | X | X | | |
| AII | F-SERIES SUPER DUTY | 6.8L | PATS - Passive Anti-Theft System | | X | X | | |
| AII | F-SERIES SUPER DUTY | 7.3L | PCM - Powertrain Control Module | | X | | | |
| AII | F-SERIES SUPER DUTY | 7.3L | ABS - Anti-Lock Brake / Traction Control Module | | X | X | | |
| AII | F-SERIES SUPER DUTY | 7.3L | RCM - Restraint Control Module | | X | X | | |
| AII | F-SERIES SUPER DUTY | 7.3L | TCM - Transmission Control Module | | X | X | | |
| AII | F-SERIES SUPER DUTY | 7.3L | ICM - Instrument Cluster | | X | X | | |
| AII | F-SERIES SUPER DUTY | 7.3L | GEM - Generic electric module(CTM) | | X | X | | |
| AII | F-SERIES SUPER DUTY | 7.3L | PATS - Passive Anti-Theft System | | X | X | | |
| AII | STREETKA | 1.0L (SHOV/OHV) | PCM - Powertrain Control Module | | X | X | X | |
| AII | STREETKA | 1.0L (SHOV/OHV) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| AII | STREETKA | 1.0L (SHOV/OHV) | RCM - Restraint Control Module | | X | X | X | |
| AII | STREETKA | 1.3L (SHOC/OHV) | PCM - Powertrain Control Module | | X | X | X | |
| AII | STREETKA | 1.3L (SHOC/OHV) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| AII | STREETKA | 1.3L (SHOC/OHV) | RCM - Restraint Control Module | | X | X | X | |
| AII | STREETKA | 1.6L (SHOC/DHOC) | PCM - Powertrain Control Module | | X | X | X | |
| AII | STREETKA | 1.6L (SHOC/DHOC) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| AII | STREETKA | 1.6L (SHOC/DHOC) | RCM - Restraint Control Module | | X | X | X | |
| AII | STREETKA | 1.7L (DHOC) | PCM - Powertrain Control Module | | X | X | X | |
| AII | STREETKA | 1.7L (DHOC) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| AII | STREETKA | 1.7L (DHOC) | RCM - Restraint Control Module | | X | X | X | |
| AII | MONDEO | 1.8L (DURATEC-SC/DURATEC-HE) | PCM - Powertrain Control Module | | X | X | X | 1.Fuel Injector Coding. 2.Key Programming. |
| AII | MONDEO | 1.8L (DURATEC-SC/DURATEC-HE) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| AII | MONDEO | 1.8L (DURATEC-SC/DURATEC-HE) | RCM - Restraint Control Module | | X | X | X | |
| AII | MONDEO | 1.8L (DURATEC-SC/DURATEC-HE) | EATC - Electronic Automatic Temperature Control | | X | X | X | |
| AII | MONDEO | 1.8L (DURATEC-SC/DURATEC-HE) | GEM - Generic electric module(CTM) | | X | X | X | |
| AII | MONDEO | 1.8L (DURATEC-SC/DURATEC-HE) | HEC - Hybrid Electronic Cluster | | X | X | X | |
| AII | MONDEO | 1.8L (DURATEC-SC/DURATEC-HE) | PATS - Passive Anti-Theft System | | X | | | 1.Key Programming. |
| AII | MONDEO | 2.0L (DURATORQ TDDI/DURATORQ TDCI) | PCM - Powertrain Control Module | | X | X | X | |
| AII | MONDEO | 2.0L (DURATORQ TDDI/DURATORQ TDCI) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| AII | MONDEO | 2.0L (DURATORQ TDDI/DURATORQ TDCI) | RCM - Restraint Control Module | | X | X | X | |

| | | | | | | | | |
|-----|-------------|------------------------------------|---|--|---|---|---|--------------------|
| AII | MONDEO | 2.0L (DURATORQ TDDI/DURATORQ TDCI) | EATC - Electronic Automatic Temperature Control | | X | X | X | |
| AII | MONDEO | 2.0L (DURATORQ TDDI/DURATORQ TDCI) | GEM - Generic electric module(CTM) | | X | X | X | |
| AII | MONDEO | 2.0L (DURATORQ TDDI/DURATORQ TDCI) | HEC - Hybrid Electronic Cluster | | X | X | X | |
| AII | MONDEO | 2.0L (DURATORQ TDDI/DURATORQ TDCI) | PATS - Passive Anti-Theft System | | X | | | 1.Key Programming. |
| AII | MONDEO | 2.5L (DURATEC-VE) | PCM - Powertrain Control Module | | X | X | X | |
| AII | MONDEO | 2.5L (DURATEC-VE) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| AII | MONDEO | 2.5L (DURATEC-VE) | RCM - Restraint Control Module | | X | X | X | |
| AII | MONDEO | 2.5L (DURATEC-VE) | EATC - Electronic Automatic Temperature Control | | X | X | X | |
| AII | MONDEO | 2.5L (DURATEC-VE) | GEM - Generic electric module(CTM) | | X | X | X | |
| AII | MONDEO | 2.5L (DURATEC-VE) | HEC - Hybrid Electronic Cluster | | X | X | X | |
| AII | MONDEO | 2.5L (DURATEC-VE) | PATS - Passive Anti-Theft System | | X | | | 1.Key Programming. |
| AII | MONDEO | 3.0L (DURATEC-ST) | PCM - Powertrain Control Module | | X | X | X | |
| AII | MONDEO | 3.0L (DURATEC-ST) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| AII | MONDEO | 3.0L (DURATEC-ST) | RCM - Restraint Control Module | | X | X | X | |
| AII | MONDEO | 3.0L (DURATEC-ST) | EATC - Electronic Automatic Temperature Control | | X | X | X | |
| AII | MONDEO | 3.0L (DURATEC-ST) | GEM - Generic electric module(CTM) | | X | X | X | |
| AII | MONDEO | 3.0L (DURATEC-ST) | HEC - Hybrid Electronic Cluster | | X | X | X | |
| AII | MONDEO | 3.0L (DURATEC-ST) | PATS - Passive Anti-Theft System | | X | | | 1.Key Programming. |
| AII | PUMA | 1.4L (ZETEC-S) | PCM - Powertrain Control Module | | X | X | X | |
| AII | PUMA | 1.4L (ZETEC-S) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| AII | PUMA | 1.4L (ZETEC-S) | RCM - Restraint Control Module | | X | X | X | |
| AII | PUMA | 1.4L (ZETEC-S) | EATC - Electronic Automatic Temperature Control | | X | X | X | |
| AII | PUMA | 1.4L (ZETEC-S) | GEM - Generic electric module(CTM) | | X | X | X | |
| AII | PUMA | 1.7L (ZETEC-S VCT) | PCM - Powertrain Control Module | | X | X | X | |
| AII | PUMA | 1.7L (ZETEC-S VCT) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| AII | PUMA | 1.7L (ZETEC-S VCT) | RCM - Restraint Control Module | | X | X | X | |
| AII | PUMA | 1.7L (ZETEC-S VCT) | EATC - Electronic Automatic Temperature Control | | X | X | X | |
| AII | PUMA | 1.7L (ZETEC-S VCT) | GEM - Generic electric module(CTM) | | X | X | X | |
| AII | PUMA RACING | 1.4L (ZETEC-S) | PCM - Powertrain Control Module | | X | X | X | |
| AII | PUMA RACING | 1.4L (ZETEC-S) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| AII | PUMA RACING | 1.4L (ZETEC-S) | RCM - Restraint Control Module | | X | X | X | |
| AII | PUMA RACING | 1.4L (ZETEC-S) | EATC - Electronic Automatic Temperature Control | | X | X | X | |
| AII | PUMA RACING | 1.4L (ZETEC-S) | GEM - Generic electric module(CTM) | | X | X | X | |
| AII | PUMA RACING | 1.7L (ZETEC-S VCT) | PCM - Powertrain Control Module | | X | X | X | |

| | | | | | | | | |
|-----|-------------|-----------------------------|---|--|---|---|---|---|
| AII | PUMA RACING | 1.7L (ZETEC-S VCT) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| AII | PUMA RACING | 1.7L (ZETEC-S VCT) | RCM - Restraint Control Module | | X | X | X | |
| AII | PUMA RACING | 1.7L (ZETEC-S VCT) | EATC - Electronic Automatic Temperature Control | | X | X | X | |
| AII | PUMA RACING | 1.7L (ZETEC-S VCT) | GEM - Generic electric module(CTM) | | X | X | X | |
| AII | TRANSIT | 2.0L (DIESEL/ALT FUEL/TDCI) | PCM - Powertrain Control Module | | X | X | X | 1.Fuel Injector Coding. 2.Key Programming. |
| AII | TRANSIT | 2.0L (DIESEL/ALT FUEL/TDCI) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| AII | TRANSIT | 2.0L (DIESEL/ALT FUEL/TDCI) | CSM - Security module | | X | X | X | |
| AII | TRANSIT | 2.0L (DIESEL/ALT FUEL/TDCI) | FFH - Fuel Fired Coolant Heating Module | | X | X | X | |
| AII | TRANSIT | 2.0L (DIESEL/ALT FUEL/TDCI) | PAM - Parking Aid Module | | X | X | X | |
| AII | TRANSIT | 2.0L (DIESEL/ALT FUEL/TDCI) | RASM - Rear Air Suspension Module | | X | X | X | |
| AII | TRANSIT | 2.0L (DIESEL/ALT FUEL/TDCI) | RCM - Restraint Control Module | | X | X | X | |
| AII | TRANSIT | 2.0L (DIESEL/ALT FUEL/TDCI) | PATS - Passive Anti-Theft System | | X | | | 1.Key Programming. |
| AII | TRANSIT | 2.3L (DIESEL) | PCM - Powertrain Control Module | | X | X | X | 1.Fuel Injector Coding. 2.Key Programming. |
| AII | TRANSIT | 2.3L (DIESEL) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| AII | TRANSIT | 2.3L (DIESEL) | CSM - Security module | | X | X | X | |
| AII | TRANSIT | 2.3L (DIESEL) | FFH - Fuel Fired Coolant Heating Module | | X | X | X | |
| AII | TRANSIT | 2.3L (DIESEL) | PAM - Parking Aid Module | | X | X | X | |
| AII | TRANSIT | 2.3L (DIESEL) | RASM - Rear Air Suspension Module | | X | X | X | |
| AII | TRANSIT | 2.3L (DIESEL) | RCM - Restraint Control Module | | X | X | X | |
| AII | TRANSIT | 2.3L (DIESEL) | PATS - Passive Anti-Theft System | | X | | | 1.Key Programming. |
| AII | TRANSIT | 2.4L (DIESEL/TDCI) | PCM - Powertrain Control Module | | X | X | X | 1.Fuel Injector Coding. 2.Key Programming. |
| AII | TRANSIT | 2.4L (DIESEL/TDCI) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| AII | TRANSIT | 2.4L (DIESEL/TDCI) | CSM - Security module | | X | X | X | |
| AII | TRANSIT | 2.4L (DIESEL/TDCI) | FFH - Fuel Fired Coolant Heating Module | | X | X | X | |
| AII | TRANSIT | 2.4L (DIESEL/TDCI) | PAM - Parking Aid Module | | X | X | X | |
| AII | TRANSIT | 2.4L (DIESEL/TDCI) | RASM - Rear Air Suspension Module | | X | X | X | |
| AII | TRANSIT | 2.4L (DIESEL/TDCI) | RCM - Restraint Control Module | | X | X | X | |
| AII | TRANSIT | 2.4L (DIESEL/TDCI) | PATS - Passive Anti-Theft System | | X | | | 1.Key Programming. |
| AII | WINDSTAR | 3.0L (V6 SFI) | PCM - Powertrain Control Module | | X | X | X | 1.Fuel Injector Coding. 2.Key Programming. |
| AII | WINDSTAR | 3.0L (V6 SFI) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| AII | WINDSTAR | 3.0L (V6 SFI) | RCM - Restraint Control Module | | X | X | X | |
| AII | WINDSTAR | 3.0L (V6 SFI) | EATC - Electronic Automatic Temperature Control | | X | X | X | |
| AII | WINDSTAR | 3.0L (V6 SFI) | GEM - Generic electric module(CTM) | | X | X | X | |
| AII | WINDSTAR | 3.8L(V6-OHV) | PCM - Powertrain Control Module | | X | X | | |
| AII | WINDSTAR | 3.8L(V6-OHV) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | | |
| AII | WINDSTAR | 3.8(V6-OHV) | RCM - Restraint Control Module | | X | X | | |

| | | | | | | | | |
|-----|--------------------|------------------------------|---|--|---|---|---|---|
| AII | WINDSTAR | 3.8L(V6-OHV) | ICM - Instrument Cluster | | X | X | | |
| AII | WINDSTAR | 2.3L(DURATEC-HE/I4) | RCM - Restraint Control Module | | X | X | | |
| AII | TRANSIT CONNECT | 1.8L (ZETEC/DURATORQ/TDCI) | PCM - Powertrain Control Module | | X | X | X | 1.Fuel Injector Coding. 2.Key Programming. |
| AII | TRANSIT CONNECT | 1.8L (ZETEC/DURATORQ/TDCI) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| AII | TRANSIT CONNECT | 1.8L (ZETEC/DURATORQ/TDCI) | CSM - Security module | | X | X | X | |
| AII | TRANSIT CONNECT | 1.8L (ZETEC/DURATORQ/TDCI) | FFH - Fuel Fired Coolant Heating Module | | X | X | X | |
| AII | TRANSIT CONNECT | 1.8L (ZETEC/DURATORQ/TDCI) | PAM - Parking Aid Module | | X | X | X | |
| AII | TRANSIT CONNECT | 1.8L (ZETEC/DURATORQ/TDCI) | RASM - Rear Air Suspension Module | | X | X | X | |
| AII | TRANSIT CONNECT | 1.8L (ZETEC/DURATORQ/TDCI) | RCM - Restraint Control Module | | X | X | X | |
| AII | TRANSIT CONNECT | 1.8L (ZETEC/DURATORQ/TDCI) | PATS - Passive Anti-Theft System | | X | | | |
| AII | ESCORT | 2.0L(SPI) | PCM - Powertrain Control Module | | X | X | | |
| AII | ESCORT | 2.0L(SPI) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | | |
| AII | ESCORT | 2.0L(SPI) | RCM - Restraint Control Module | | X | X | | |
| AII | ESCORT | 2.0L(Zetec) | PCM - Powertrain Control Module | | X | X | | |
| AII | ESCORT | 2.0L(Zetec) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | | |
| AII | ESCORT | 2.0L(Zetec) | RCM - Restraint Control Module | | X | X | | |
| AII | EXCURSION | 6.0L(Direct-Injection-Turbo) | PCM - Powertrain Control Module | | X | X | | |
| AII | EXCURSION | 6.0L(Direct-Injection-Turbo) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | | |
| AII | EXCURSION | 6.0L(Direct-Injection-Turbo) | TCM - Transmission Control Module | | X | X | | |
| AII | EXCURSION | 6.0L(Direct-Injection-Turbo) | GEM - Generic electric module(CTM) | | X | X | | |
| AII | EXCURSION | 5.4L(Other) | PCM - Powertrain Control Module | | X | X | | |
| AII | EXCURSION | 5.4L(Other) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | | |
| AII | EXCURSION | 5.4L(Other) | GEM - Generic electric module(CTM) | | X | X | | |
| AII | EXCURSION | 7.3L(Direct-Injection-Turbo) | PCM - Powertrain Control Module | | X | X | | |
| AII | EXCURSION | 7.3L(Direct-Injection-Turbo) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | | |
| AII | EXCURSION | 7.3L(Direct-Injection-Turbo) | GEM - Generic electric module(CTM) | | X | X | | |
| AII | EXCURSION | 6.8L(Other) | PCM - Powertrain Control Module | | X | X | | |
| AII | EXCURSION | 6.8L(Other) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | | |
| AII | EXCURSION | 6.8L(Other) | GEM - Generic electric module(CTM) | | X | X | | |
| AII | EXPEDITION | 4.6L(2V) | PCM - Powertrain Control Module | | X | X | | |
| AII | EXPEDITION | 4.6L(2V) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | | |
| AII | EXPEDITION | 4.6L(2V) | RCM - Restraint Control Module | | X | X | | |
| AII | EXPEDITION | 5.4L(2V) | PCM - Powertrain Control Module | | X | X | | |
| AII | EXPEDITION | 5.4L(2V) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | | |
| AII | EXPEDITION | 5.4L(2V) | RCM - Restraint Control Module | | X | X | | |

| | | | | | | | | |
|-----|----------------|------------------|---|--|---|---|---|--|
| AII | CROWN-VICTORIA | 4.6L(2V) | PCM - Powertrain Control Module | | X | X | | |
| AII | CROWN-VICTORIA | 4.6L(2V) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | | |
| AII | CROWN-VICTORIA | 4.6L(2V) | RCM - Restraint Control Module | | X | X | | |
| AII | COUGAR | 2.0L (SFI) | PCM - Powertrain Control Module | | X | X | X | |
| AII | COUGAR | 2.0L (SFI) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| AII | COUGAR | 2.0L (SFI) | CSM - Security module | | X | X | X | |
| AII | COUGAR | 2.0L (SFI) | ECS - Electronic Crash Sensor | | X | X | X | |
| AII | COUGAR | 2.5L (SFI) | PCM - Powertrain Control Module | | X | X | X | |
| AII | COUGAR | 2.5L (SFI) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| AII | COUGAR | 2.5L (SFI) | CSM - Security module | | X | X | X | |
| AII | COUGAR | 2.5L (SFI) | ECS - Electronic Crash Sensor | | X | X | X | |
| AII | EXPLORER | 4.0L (SOHC SFI) | PCM - Powertrain Control Module | | X | X | X | |
| AII | EXPLORER | 4.0L (SOHC SFI) | 4X4M - 4X4 Control Module | | X | X | X | |
| AII | EXPLORER | 4.0L (SOHC SFI) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| AII | EXPLORER | 4.0L (SOHC SFI) | CSM - Security module | | X | X | X | |
| AII | EXPLORER | 4.0L (SOHC SFI) | DSM - Drivers Seat Module | | X | X | X | |
| AII | EXPLORER | 4.0L (SOHC SFI) | ICM - Instrument Cluster | | X | X | X | |
| AII | EXPLORER | 4.0L (SOHC SFI) | PAM - Parking Aid Module | | X | X | X | |
| AII | EXPLORER | 4.0L (SOHC SFI) | RCM - Restraint Control Module | | X | X | X | |
| AII | EXPLORER | 4.0L (SOHC SFI) | TPM - 4Tire Pressure Monitor | | X | X | X | |
| AII | EXPLORER | 4.6L | PCM - Powertrain Control Module | | X | X | X | |
| AII | EXPLORER | 4.6L | 4X4M - 4X4 Control Module | | X | X | X | |
| AII | EXPLORER | 4.6L | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| AII | EXPLORER | 4.6L | CSM - Security module | | X | X | X | |
| AII | EXPLORER | 4.6L | DSM - Drivers Seat Module | | X | X | X | |
| AII | EXPLORER | 4.6L | ICM - Instrument Cluster | | X | X | X | |
| AII | EXPLORER | 4.6L | PAM - Parking Aid Module | | X | X | X | |
| AII | EXPLORER | 4.6L | RCM - Restraint Control Module | | X | X | X | |
| AII | EXPLORER | 4.6L | TPM - 4Tire Pressure Monitor | | X | X | X | |
| AII | EXPLORER | 4.0L(V6-SOHC) | PCM - Powertrain Control Module | | X | X | | |
| AII | EXPLORER | 4.0L(V6-SOHC) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | | |
| AII | EXPLORER | 4.0L(V6-SOHC) | RCM - Restraint Control Module | | X | X | | |
| AII | EXPLORER | 4.0L(V6-SOHC) | ICM - Instrument Cluster | | X | X | | |
| AII | EXPLORER | 4.6L(2V) | PCM - Powertrain Control Module | | X | X | | |
| AII | EXPLORER | 4.6L(2V) | RCM - Restraint Control Module | | X | X | | |
| AII | EXPLORER | 4.6L(2V) | ICM - Instrument Cluster | | X | X | | |
| AII | FIESTA | 1.25L(16V/DOHC) | PCM - Powertrain Control Module | | X | X | X | |
| AII | FIESTA | 1.25L(16V/DOHC) | RCM - Restraint Control Module | | X | X | X | |
| AII | FIESTA | 1.25L(16V/DOHC) | GEM - Generic electric module(CTM) | | X | X | X | |
| AII | FIESTA | 1.25L(16V/DOHC) | ICM - Instrument Cluster | | X | X | X | |
| AII | FIESTA | 1.3L (DOHC/SOHC) | PCM - Powertrain Control Module | | X | X | X | |

| | | | | | | | | |
|-----|----------|-------------------------------|---|--|---|---|---|---|
| AII | FIESTA | 1.3L (DOHC/SOHC) | RCM - Restraint Control Module | | X | X | X | |
| AII | FIESTA | 1.3L (DOHC/SOHC) | GEM - Generic electric module(CTM) | | X | X | X | |
| AII | FIESTA | 1.3L (DOHC/SOHC) | ICM - Instrument Cluster | | X | X | X | |
| AII | FIESTA | 1.4L (16V/DOHC/T-DIESEL) | PCM - Powertrain Control Module | | X | X | X | |
| AII | FIESTA | 1.4L (16V/DOHC/T-DIESEL) | TCM - Transmission Control Module | | X | X | X | |
| AII | FIESTA | 1.4L (16V/DOHC/T-DIESEL) | RCM - Restraint Control Module | | X | X | X | |
| AII | FIESTA | 1.4L (16V/DOHC/T-DIESEL) | GEM - Generic electric module(CTM) | | X | X | X | |
| AII | FIESTA | 1.4L (16V/DOHC/T-DIESEL) | ICM - Instrument Cluster | | X | X | X | |
| AII | FIESTA | 1.5L (DOHC) | PCM - Powertrain Control Module | | X | X | X | |
| AII | FIESTA | 1.5L (DOHC) | RCM - Restraint Control Module | | X | X | X | |
| AII | FIESTA | 1.5L (DOHC) | GEM - Generic electric module(CTM) | | X | X | X | |
| AII | FIESTA | 1.5L (DOHC) | ICM - Instrument Cluster | | X | X | X | |
| AII | FIESTA | 1.6L (SFI) | PCM - Powertrain Control Module | | X | X | X | |
| AII | FIESTA | 1.6L (SFI) | RCM - Restraint Control Module | | X | X | X | |
| AII | FIESTA | 1.6L (SFI) | GEM - Generic electric module(CTM) | | X | X | X | |
| AII | FIESTA | 1.6L (SFI) | ICM - Instrument Cluster | | X | X | X | |
| AII | FOCUS | 1.4L (ZETEC-SE) | PCM - Powertrain Control Module | | X | X | X | |
| AII | FOCUS | 1.4L (ZETEC-SE) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| AII | FOCUS | 1.4L (ZETEC-SE) | GEM - Generic electric module(CTM) | | X | X | X | |
| AII | FOCUS | 1.4L (ZETEC-SE) | RCM - Restraint Control Module | | X | X | X | |
| AII | FOCUS | 1.6L (ALT FUEL/ZETEC/DURATEC) | PCM - Powertrain Control Module | | X | X | X | |
| AII | FOCUS | 1.6L (ALT FUEL/ZETEC/DURATEC) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| AII | FOCUS | 1.6L (ALT FUEL/ZETEC/DURATEC) | GEM - Generic electric module(CTM) | | X | X | X | |
| AII | FOCUS | 1.6L (ALT FUEL/ZETEC/DURATEC) | RCM - Restraint Control Module | | X | X | X | |
| AII | FOCUS | 1.6L (ALT FUEL/ZETEC/DURATEC) | PATS - Passive Anti-Theft System | | X | | | 1.Key Programming. |
| AII | FOCUS | 1.8L (LPG/ZETEC/TDDI/TDCI) | PCM - Powertrain Control Module | | X | X | X | 1.Fuel Injector Coding. 2.Key Programming. |
| AII | FOCUS | 1.8L (LPG/ZETEC/TDDI/TDCI) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| AII | FOCUS | 1.8L (LPG/ZETEC/TDDI/TDCI) | GEM - Generic electric module(CTM) | | X | X | X | |
| AII | FOCUS | 1.8L (LPG/ZETEC/TDDI/TDCI) | RCM - Restraint Control Module | | X | X | X | |
| AII | FOCUS | 1.8L (LPG/ZETEC/TDDI/TDCI) | PATS - Passive Anti-Theft System | | X | | | 1.Key Programming. |
| AII | FOCUS | 2.0L (ZETEC/DURATEC) | PCM - Powertrain Control Module | | X | X | X | |
| AII | FOCUS | 2.0L (ZETEC/DURATEC) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| AII | FOCUS | 2.0L (ZETEC/DURATEC) | GEM - Generic electric module(CTM) | | X | X | X | |
| AII | FOCUS | 2.0L (ZETEC/DURATEC) | RCM - Restraint Control Module | | X | X | X | |
| AII | FOCUS | 2.0L (ZETEC/DURATEC) | PATS - Passive Anti-Theft System | | X | | | 1.Key Programming. |
| AII | FOCUS | 2.3L (PZEV) | PCM - Powertrain Control Module | | X | X | X | |
| AII | FOCUS | 2.3L (PZEV) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| AII | FOCUS | 2.3L (PZEV) | GEM - Generic electric module(CTM) | | X | X | X | |
| AII | FOCUS | 2.3L (PZEV) | RCM - Restraint Control Module | | X | X | X | |
| AII | FOCUS | 2.3L (PZEV) | PATS - Passive Anti-Theft System | | X | | | 1.Key Programming. |
| AII | FOCUS RS | 1.4L (ZTTEC-SE) | PCM - Powertrain Control Module | | X | X | X | |
| AII | FOCUS RS | 1.4L (ZTTEC-SE) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| AII | FOCUS RS | 1.4L (ZTTEC-SE) | GEM - Generic electric module(CTM) | | X | X | X | |

| | | | | | | | | |
|-----|-------------|-------------------------------|---|--|---|---|---|--|
| AII | FOCUS RS | 1.4L (ZTTEC-SE) | RCM - Restraint Control Module | | X | X | X | |
| AII | FOCUS RS | 1.6L (ALT FUEL/ZETEC/DURATEC) | PCM - Powertrain Control Module | | X | X | X | |
| AII | FOCUS RS | 1.6L (ALT FUEL/ZETEC/DURATEC) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| AII | FOCUS RS | 1.6L (ALT FUEL/ZETEC/DURATEC) | GEM - Generic electric module(CTM) | | X | X | X | |
| AII | FOCUS RS | 1.6L (ALT FUEL/ZETEC/DURATEC) | RCM - Restraint Control Module | | X | X | X | |
| AII | FOCUS RS | 1.8L (LPG/ZETEC/TDDI/TDCI) | PCM - Powertrain Control Module | | X | X | X | |
| AII | FOCUS RS | 1.8L (LPG/ZETEC/TDDI/TDCI) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| AII | FOCUS RS | 1.8L (LPG/ZETEC/TDDI/TDCI) | GEM - Generic electric module(CTM) | | X | X | X | |
| AII | FOCUS RS | 1.8L (LPG/ZETEC/TDDI/TDCI) | RCM - Restraint Control Module | | X | X | X | |
| AII | FOCUS RS | 2.0L (ZETEC/DURATEC) | PCM - Powertrain Control Module | | X | X | X | |
| AII | FOCUS RS | 2.0L (ZETEC/DURATEC) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| AII | FOCUS RS | 2.0L (ZETEC/DURATEC) | GEM - Generic electric module(CTM) | | X | X | X | |
| AII | FOCUS RS | 2.0L (ZETEC/DURATEC) | RCM - Restraint Control Module | | X | X | X | |
| AII | FOCUS C-MAX | 1.4L (ZTTEC-SE) | PCM - Powertrain Control Module | | X | X | X | |
| AII | FOCUS C-MAX | 1.4L (ZTTEC-SE) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| AII | FOCUS C-MAX | 1.4L (ZTTEC-SE) | ICM - Instrument Cluster | | X | X | X | |
| AII | FOCUS C-MAX | 1.6L (ALT FUEL/ZETEC/DURATEC) | PCM - Powertrain Control Module | | X | X | X | |
| AII | FOCUS C-MAX | 1.6L (ALT FUEL/ZETEC/DURATEC) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| AII | FOCUS C-MAX | 1.6L (ALT FUEL/ZETEC/DURATEC) | ICM - Instrument Cluster | | X | X | X | |
| AII | FOCUS C-MAX | 1.8L (LPG/ZETEC/TDDI/TDCI) | PCM - Powertrain Control Module | | X | X | X | |
| AII | FOCUS C-MAX | 1.8L (LPG/ZETEC/TDDI/TDCI) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| AII | FOCUS C-MAX | 1.8L (LPG/ZETEC/TDDI/TDCI) | ICM - Instrument Cluster | | X | X | X | |
| AII | FOCUS C-MAX | 2.0L (ZETEC/DURATEC) | PCM - Powertrain Control Module | | X | X | X | |
| AII | FOCUS C-MAX | 2.0L (ZETEC/DURATEC) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| AII | FOCUS C-MAX | 2.0L (ZETEC/DURATEC) | ICM - Instrument Cluster | | X | X | X | |
| AII | FUSION | 1.25L(16V/DOHC) | PCM - Powertrain Control Module | | X | X | X | |
| AII | FUSION | 1.25L(16V/DOHC) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| AII | FUSION | 1.25L(16V/DOHC) | GEM - Generic electric module(CTM) | | X | X | X | |
| AII | FUSION | 1.25L(16V/DOHC) | RCM - Restraint Control Module | | X | X | X | |
| AII | FUSION | 1.3L (DOHC/SOHC) | PCM - Powertrain Control Module | | X | X | X | |
| AII | FUSION | 1.3L (DOHC/SOHC) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| AII | FUSION | 1.3L (DOHC/SOHC) | GEM - Generic electric module(CTM) | | X | X | X | |

| | | | | | | | | |
|-----|--------|--------------------------|---|--|---|---|---|--|
| AII | FUSION | 1.3L (DOHC/SOHC) | RCM - Restraint Control Module | | X | X | X | |
| AII | FUSION | 1.4L (16V/DOHC/T-DIESEL) | PCM - Powertrain Control Module | | X | X | X | |
| AII | FUSION | 1.4L (16V/DOHC/T-DIESEL) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| AII | FUSION | 1.4L (16V/DOHC/T-DIESEL) | GEM - Generic electric module(CTM) | | X | X | X | |
| AII | FUSION | 1.4L (16V/DOHC/T-DIESEL) | RCM - Restraint Control Module | | X | X | X | |
| AII | FUSION | 1.5L (DOHC) | PCM - Powertrain Control Module | | X | X | X | |
| AII | FUSION | 1.5L (DOHC) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| AII | FUSION | 1.5L (DOHC) | GEM - Generic electric module(CTM) | | X | X | X | |
| AII | FUSION | 1.5L (DOHC) | RCM - Restraint Control Module | | X | X | X | |
| AII | FUSION | 1.6L (SFI) | PCM - Powertrain Control Module | | X | X | X | |
| AII | FUSION | 1.6L (SFI) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| AII | FUSION | 1.6L (SFI) | GEM - Generic electric module(CTM) | | X | X | X | |
| AII | FUSION | 1.6L (SFI) | RCM - Restraint Control Module | | X | X | X | |
| AII | GALAXY | 1.9L (T-DIESEL) | PCM - Powertrain Control Module | | X | | | |
| AII | GALAXY | 1.9L (T-DIESEL) | TCM - Transmission Control Module | | X | | | |
| AII | GALAXY | 1.9L (T-DIESEL) | ABS - Anti-Lock Brake / Traction Control Module | | X | | | |
| AII | GALAXY | 1.9L (T-DIESEL) | RCM - Restraint Control Module | | X | | | |
| AII | GALAXY | 1.9L (T-DIESEL) | ICM - Instrument Cluster | | X | | | |
| AII | GALAXY | 1.9L (T-DIESEL) | NAV - Navigation System | | X | | | |
| AII | GALAXY | 2.0L (DOHC) | PCM - Powertrain Control Module | | X | | | |
| AII | GALAXY | 2.0L (DOHC) | TCM - Transmission Control Module | | X | | | |
| AII | GALAXY | 2.0L (DOHC) | ABS - Anti-Lock Brake / Traction Control Module | | X | | | |
| AII | GALAXY | 2.0L (DOHC) | RCM - Restraint Control Module | | X | | | |
| AII | GALAXY | 2.0L (DOHC) | ICM - Instrument Cluster | | X | | | |
| AII | GALAXY | 2.0L (DOHC) | NAV - Navigation System | | X | | | |
| AII | GALAXY | 2.3L (DOHC) | PCM - Powertrain Control Module | | X | | | |
| AII | GALAXY | 2.3L (DOHC) | TCM - Transmission Control Module | | X | | | |
| AII | GALAXY | 2.3L (DOHC) | ABS - Anti-Lock Brake / Traction Control Module | | X | | | |
| AII | GALAXY | 2.3L (DOHC) | RCM - Restraint Control Module | | X | | | |
| AII | GALAXY | 2.3L (DOHC) | ICM - Instrument Cluster | | X | | | |
| AII | GALAXY | 2.3L (DOHC) | NAV - Navigation System | | X | | | |
| AII | GALAXY | 2.8L (CD-24V-V6) | PCM - Powertrain Control Module | | X | | | |
| AII | GALAXY | 2.8L (CD-24V-V6) | TCM - Transmission Control Module | | X | | | |
| AII | GALAXY | 2.8L (CD-24V-V6) | ABS - Anti-Lock Brake / Traction Control Module | | X | | | |
| AII | GALAXY | 2.8L (CD-24V-V6) | RCM - Restraint Control Module | | X | | | |
| AII | GALAXY | 2.8L (CD-24V-V6) | ICM - Instrument Cluster | | X | | | |
| AII | GALAXY | 2.8L (CD-24V-V6) | NAV - Navigation System | | X | | | |
| AII | RANGER | 2.5L(DIESEL/T-DIESEL) | PCM - Powertrain Control Module | | X | X | | |
| AII | RANGER | 2.5L(DIESEL/T-DIESEL) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | | |
| AII | RANGER | 2.5L(DIESEL/T-DIESEL) | RCM - Restraint Control Module | | X | X | | |
| AII | RANGER | 2.5L(DIESEL/T-DIESEL) | GEM - Generic electric module(CTM) | | X | X | | |
| AII | KA | 1.0L | PCM - Powertrain Control Module | | X | X | | |
| AII | KA | 1.0L | ABS - Anti-Lock Brake / Traction Control Module | | X | X | | |
| AII | KA | 1.0L | ECS - Electronic Crash Sensor(or IABM) | | X | X | | |
| AII | KA | 1.0L | EPS - Electronic Controlled Power Steering | | X | X | | |

| | | | | | | | | |
|-----|------------------------|------|---|--|---|---|--|--------------------|
| AII | KA | 1.0L | GEM - Generic electric module(CTM) | | X | X | | |
| AII | KA | 1.0L | PATS - Passive Anti-Theft System | | X | X | | 1.Key Programming. |
| AII | KA | 1.3L | PCM - Powertrain Control Module | | X | X | | |
| AII | KA | 1.3L | ABS - Anti-Lock Brake / Traction Control Module | | X | X | | |
| AII | KA | 1.3L | ECS - Electronic Crash Sensor(or IABM) | | X | X | | |
| AII | KA | 1.3L | EPS - Electronic Controlled Power Steering | | X | X | | |
| AII | KA | 1.3L | GEM - Generic electric module(CTM) | | X | X | | |
| AII | KA | 1.3L | PATS - Passive Anti-Theft System | | X | X | | 1.Key Programming. |
| AII | KA | 1.6L | PCM - Powertrain Control Module | | X | X | | |
| AII | KA | 1.6L | ABS - Anti-Lock Brake / Traction Control Module | | X | X | | |
| AII | KA | 1.6L | ECS - Electronic Crash Sensor(or IABM) | | X | X | | |
| AII | KA | 1.6L | EPS - Electronic Controlled Power Steering | | X | X | | |
| AII | KA | 1.6L | GEM - Generic electric module(CTM) | | X | X | | |
| AII | KA | 1.6L | PATS - Passive Anti-Theft System | | X | X | | 1.Key Programming. |
| AII | KA | 1.7L | PCM - Powertrain Control Module | | X | X | | |
| AII | KA | 1.7L | ABS - Anti-Lock Brake / Traction Control Module | | X | X | | |
| AII | KA | 1.7L | ECS - Electronic Crash Sensor(or IABM) | | X | X | | |
| AII | KA | 1.7L | EPS - Electronic Controlled Power Steering | | X | X | | |
| AII | KA | 1.7L | GEM - Generic electric module(CTM) | | X | X | | |
| AII | KA | 1.7L | PATS - Passive Anti-Theft System | | X | X | | 1.Key Programming. |
| AII | MAVERICK | 2.0L | PCM - Powertrain Control Module | | X | X | | |
| AII | MAVERICK | 2.0L | ABS - Anti-Lock Brake / Traction Control Module | | X | X | | |
| AII | MAVERICK | 2.0L | RCM - Restraint Control Module | | X | X | | |
| AII | MAVERICK | 2.0L | GEM - Generic electric module(CTM) | | X | X | | |
| AII | MAVERICK | 2.0L | PAM - Parking Aid Module | | X | X | | |
| AII | MAVERICK | 2.0L | 4X4M - 4X4 Control Module | | X | X | | |
| AII | MAVERICK | 2.3L | PCM - Powertrain Control Module | | X | X | | |
| AII | MAVERICK | 2.3L | ABS - Anti-Lock Brake / Traction Control Module | | X | X | | |
| AII | MAVERICK | 2.3L | RCM - Restraint Control Module | | X | X | | |
| AII | MAVERICK | 2.3L | GEM - Generic electric module(CTM) | | X | X | | |
| AII | MAVERICK | 2.3L | PAM - Parking Aid Module | | X | X | | |
| AII | MAVERICK | 2.3L | 4X4M - 4X4 Control Module | | X | X | | |
| AII | MAVERICK | 3.0L | PCM - Powertrain Control Module | | X | X | | |
| AII | MAVERICK | 3.0L | ABS - Anti-Lock Brake / Traction Control Module | | X | X | | |
| AII | MAVERICK | 3.0L | RCM - Restraint Control Module | | X | X | | |
| AII | MAVERICK | 3.0L | GEM - Generic electric module(CTM) | | X | X | | |
| AII | MAVERICK | 3.0L | PAM - Parking Aid Module | | X | X | | |
| AII | MAVERICK | 3.0L | 4X4M - 4X4 Control Module | | X | X | | |
| AII | F-SERIES SUPER DUTY | 5.4L | PCM - Powertrain Control Module | | X | | | |
| AII | F-SERIES SUPER DUTY | 5.4L | ABS - Anti-Lock Brake / Traction Control Module | | X | X | | |
| AII | F-SERIES SUPER DUTY | 5.4L | RCM - Restraint Control Module | | X | X | | |

| | | | | | | | | |
|-----|------------------------|------|---|--|---|---|--|--|
| All | F-SERIES SUPER DUTY | 5.4L | TCM - Transmission Control Module | | X | X | | |
| All | F-SERIES SUPER DUTY | 5.4L | ICM - Instrument Cluster | | X | X | | |
| All | F-SERIES SUPER DUTY | 5.4L | GEM - Generic electric module(CTM) | | X | X | | |
| All | F-SERIES SUPER DUTY | 5.4L | PATS - Passive Anti-Theft System | | X | X | | |
| All | F-SERIES SUPER DUTY | 6.0L | PCM - Powertrain Control Module | | X | | | |
| All | F-SERIES SUPER DUTY | 6.0L | ABS - Anti-Lock Brake / Traction Control Module | | X | X | | |
| All | F-SERIES SUPER DUTY | 6.0L | RCM - Restraint Control Module | | X | X | | |
| All | F-SERIES SUPER DUTY | 6.0L | TCM - Transmission Control Module | | X | X | | |
| All | F-SERIES SUPER DUTY | 6.0L | ICM - Instrument Cluster | | X | X | | |
| All | F-SERIES SUPER DUTY | 6.0L | GEM - Generic electric module(CTM) | | X | X | | |
| All | F-SERIES SUPER DUTY | 6.0L | PATS - Passive Anti-Theft System | | X | X | | |
| All | F-SERIES SUPER DUTY | 6.8L | PCM - Powertrain Control Module | | X | | | |
| All | F-SERIES SUPER DUTY | 6.8L | ABS - Anti-Lock Brake / Traction Control Module | | X | X | | |
| All | F-SERIES SUPER DUTY | 6.8L | RCM - Restraint Control Module | | X | X | | |
| All | F-SERIES SUPER DUTY | 6.8L | TCM - Transmission Control Module | | X | X | | |
| All | F-SERIES SUPER DUTY | 6.8L | ICM - Instrument Cluster | | X | X | | |
| All | F-SERIES SUPER DUTY | 6.8L | GEM - Generic electric module(CTM) | | X | X | | |
| All | F-SERIES SUPER DUTY | 6.8L | PATS - Passive Anti-Theft System | | X | X | | |
| All | F-SERIES SUPER DUTY | 7.3L | PCM - Powertrain Control Module | | X | | | |
| All | F-SERIES SUPER DUTY | 7.3L | ABS - Anti-Lock Brake / Traction Control Module | | X | X | | |
| All | F-SERIES SUPER DUTY | 7.3L | RCM - Restraint Control Module | | X | X | | |
| All | F-SERIES SUPER DUTY | 7.3L | TCM - Transmission Control Module | | X | X | | |

| | | | | | | | | |
|-----|------------------------|------------------------------------|---|--|---|---|---|---|
| AII | F-SERIES SUPER DUTY | 7.3L | ICM - Instrument Cluster | | X | X | | |
| AII | F-SERIES SUPER DUTY | 7.3L | GEM - Generic electric module(CTM) | | X | X | | |
| AII | F-SERIES SUPER DUTY | 7.3L | PATS - Passive Anti-Theft System | | X | X | | |
| AII | STREETKA | 1.0L (SHOV/OHV) | PCM - Powertrain Control Module | | X | X | X | |
| AII | STREETKA | 1.0L (SHOV/OHV) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| AII | STREETKA | 1.0L (SHOV/OHV) | RCM - Restraint Control Module | | X | X | X | |
| AII | STREETKA | 1.3L (SHOC/OHV) | PCM - Powertrain Control Module | | X | X | X | |
| AII | STREETKA | 1.3L (SHOC/OHV) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| AII | STREETKA | 1.3L (SHOC/OHV) | RCM - Restraint Control Module | | X | X | X | |
| AII | STREETKA | 1.6L (SHOC) | PCM - Powertrain Control Module | | X | X | X | |
| AII | STREETKA | 1.6L (SHOC) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| AII | STREETKA | 1.6L (SHOC) | RCM - Restraint Control Module | | X | X | X | |
| AII | STREETKA | 1.7L (DHOC) | PCM - Powertrain Control Module | | X | X | X | |
| AII | STREETKA | 1.7L (DHOC) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| AII | STREETKA | 1.7L (DHOC) | RCM - Restraint Control Module | | X | X | X | |
| AII | MONDEO | 1.8L (DURATEC-SC/DURATEC-HE) | PCM - Powertrain Control Module | | X | X | X | 1.Fuel Injector Coding. 2.Key Programming. |
| AII | MONDEO | 1.8L (DURATEC-SC/DURATEC-HE) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| AII | MONDEO | 1.8L (DURATEC-SC/DURATEC-HE) | RCM - Restraint Control Module | | X | X | X | |
| AII | MONDEO | 1.8L (DURATEC-SC/DURATEC-HE) | GEM - Generic electric module(CTM) | | X | X | X | |
| AII | MONDEO | 1.8L (DURATEC-SC/DURATEC-HE) | HEC - Hybrid Electronic Cluster | | X | X | X | |
| AII | MONDEO | 1.8L (DURATEC-SC/DURATEC-HE) | ICM - Instrument Cluster | | X | X | X | |
| AII | MONDEO | 1.8L (DURATEC-SC/DURATEC-HE) | ACM - Audio Control Module | | X | X | X | |
| AII | MONDEO | 1.8L (DURATEC-SC/DURATEC-HE) | EATC - Electronic Automatic Temperature Control | | X | X | X | |
| AII | MONDEO | 1.8L (DURATEC-SC/DURATEC-HE) | PATS - Passive Anti-Theft System | | X | X | X | |
| AII | MONDEO | 2.0L (DURATORQ TDDI/DURATORQ TDCI) | PCM - Powertrain Control Module | | X | X | X | |
| AII | MONDEO | 2.0L (DURATORQ TDDI/DURATORQ TDCI) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| AII | MONDEO | 2.0L (DURATORQ TDDI/DURATORQ TDCI) | RCM - Restraint Control Module | | X | X | X | |
| AII | MONDEO | 2.0L (DURATORQ TDDI/DURATORQ TDCI) | GEM - Generic electric module(CTM) | | X | X | X | |
| AII | MONDEO | 2.0L (DURATORQ TDDI/DURATORQ TDCI) | HEC - Hybrid Electronic Cluster | | X | X | X | |
| AII | MONDEO | 2.0L (DURATORQ TDDI/DURATORQ TDCI) | ICM - Instrument Cluster | | X | X | X | |
| AII | MONDEO | 2.0L (DURATORQ TDDI/DURATORQ TDCI) | ACM - Audio Control Module | | X | X | X | |
| AII | MONDEO | 2.0L (DURATORQ TDDI/DURATORQ TDCI) | EATC - Electronic Automatic Temperature Control | | X | X | X | |

| | | | | | | | | |
|-----|-------------|------------------------------------|---|--|---|---|---|--------------------|
| AII | MONDEO | 2.0L (DURATORQ TDDI/DURATORQ TDCI) | PATS - Passive Anti-Theft System | | X | X | X | |
| AII | MONDEO | 2.5L (DURATEC-VE) | PCM - Powertrain Control Module | | X | X | X | |
| AII | MONDEO | 2.5L (DURATEC-VE) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| AII | MONDEO | 2.5L (DURATEC-VE) | RCM - Restraint Control Module | | X | X | X | |
| AII | MONDEO | 2.5L (DURATEC-VE) | GEM - Generic electric module(CTM) | | X | X | X | |
| AII | MONDEO | 2.5L (DURATEC-VE) | HEC - Hybrid Electronic Cluster | | X | X | X | |
| AII | MONDEO | 2.5L (DURATEC-VE) | ICM - Instrument Cluster | | X | X | X | |
| AII | MONDEO | 2.5L (DURATEC-VE) | ACM - Audio Control Module | | X | X | X | |
| AII | MONDEO | 2.5L (DURATEC-VE) | EATC - Electronic Automatic Temperature Control | | X | X | X | |
| AII | MONDEO | 2.5L (DURATEC-VE) | PATS - Passive Anti-Theft System | | X | X | X | |
| AII | MONDEO | 3.0L (DURATEC-ST) | PCM - Powertrain Control Module | | X | X | X | |
| AII | MONDEO | 3.0L (DURATEC-ST) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| AII | MONDEO | 3.0L (DURATEC-ST) | RCM - Restraint Control Module | | X | X | X | |
| AII | MONDEO | 3.0L (DURATEC-ST) | GEM - Generic electric module(CTM) | | X | X | X | |
| AII | MONDEO | 3.0L (DURATEC-ST) | HEC - Hybrid Electronic Cluster | | X | X | X | |
| AII | MONDEO | 3.0L (DURATEC-ST) | ICM - Instrument Cluster | | X | X | X | |
| AII | MONDEO | 3.0L (DURATEC-ST) | ACM - Audio Control Module | | X | X | X | |
| AII | MONDEO | 3.0L (DURATEC-ST) | EATC - Electronic Automatic Temperature Control | | X | X | X | |
| AII | MONDEO | 3.0L (DURATEC-ST) | PATS - Passive Anti-Theft System | | X | | | 1.Key Programming. |
| AII | PUMA | 1.4L (ZETEC-S) | PCM - Powertrain Control Module | | X | X | X | |
| AII | PUMA | 1.4L (ZETEC-S) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| AII | PUMA | 1.4L (ZETEC-S) | RCM - Restraint Control Module | | X | X | X | |
| AII | PUMA | 1.4L (ZETEC-S) | GEM - Generic electric module(CTM) | | X | X | X | |
| AII | PUMA | 1.7L (ZETEC-S VCT) | PCM - Powertrain Control Module | | X | X | X | |
| AII | PUMA | 1.7L (ZETEC-S VCT) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| AII | PUMA | 1.7L (ZETEC-S VCT) | RCM - Restraint Control Module | | X | X | X | |
| AII | PUMA | 1.7L (ZETEC-S VCT) | GEM - Generic electric module(CTM) | | X | X | X | |
| AII | PUMA RACING | 1.4L (ZETEC-S) | PCM - Powertrain Control Module | | X | X | X | |
| AII | PUMA RACING | 1.4L (ZETEC-S) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| AII | PUMA RACING | 1.4L (ZETEC-S) | RCM - Restraint Control Module | | X | X | X | |
| AII | PUMA RACING | 1.4L (ZETEC-S) | GEM - Generic electric module(CTM) | | X | X | X | |
| AII | PUMA RACING | 1.7L (ZETEC-S VCT) | PCM - Powertrain Control Module | | X | X | X | |
| AII | PUMA RACING | 1.7L (ZETEC-S VCT) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| AII | PUMA RACING | 1.7L (ZETEC-S VCT) | RCM - Restraint Control Module | | X | X | X | |
| AII | PUMA RACING | 1.7L (ZETEC-S VCT) | GEM - Generic electric module(CTM) | | X | X | X | |

| | | | | | | | | |
|-----|--------------------|-----------------------------|---|--|---|---|---|---|
| AII | TRANSIT | 2.0L (DIESEL/ALT FUEL/TDCI) | PCM - Powertrain Control Module | | X | X | X | 1.Fuel Injector Coding. 2.Key Programming. |
| AII | TRANSIT | 2.0L (DIESEL/ALT FUEL/TDCI) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| AII | TRANSIT | 2.0L (DIESEL/ALT FUEL/TDCI) | CSM - Security module | | X | X | X | |
| AII | TRANSIT | 2.0L (DIESEL/ALT FUEL/TDCI) | FFH - Fuel Fired Coolant Heating Module | | X | X | X | |
| AII | TRANSIT | 2.0L (DIESEL/ALT FUEL/TDCI) | PAM - Parking Aid Module | | X | X | X | |
| AII | TRANSIT | 2.0L (DIESEL/ALT FUEL/TDCI) | RASM - Rear Air Suspension Module | | X | X | X | |
| AII | TRANSIT | 2.0L (DIESEL/ALT FUEL/TDCI) | RCM - Restraint Control Module | | X | X | X | |
| AII | TRANSIT | 2.0L (DIESEL/ALT FUEL/TDCI) | PATS - Passive Anti-Theft System | | X | | | 1.Key Programming. |
| AII | TRANSIT | 2.3L (DIESEL) | PCM - Powertrain Control Module | | X | X | X | |
| AII | TRANSIT | 2.3L (DIESEL) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| AII | TRANSIT | 2.3L (DIESEL) | CSM - Security module | | X | X | X | |
| AII | TRANSIT | 2.3L (DIESEL) | FFH - Fuel Fired Coolant Heating Module | | X | X | X | |
| AII | TRANSIT | 2.3L (DIESEL) | PAM - Parking Aid Module | | X | X | X | |
| AII | TRANSIT | 2.3L (DIESEL) | RASM - Rear Air Suspension Module | | X | X | X | |
| AII | TRANSIT | 2.3L (DIESEL) | RCM - Restraint Control Module | | X | X | X | |
| AII | TRANSIT | 2.3L (DIESEL) | PATS - Passive Anti-Theft System | | X | | | 1.Key Programming. |
| AII | TRANSIT | 2.4L (DIESEL/TDCI) | PCM - Powertrain Control Module | | X | X | X | |
| AII | TRANSIT | 2.4L (DIESEL/TDCI) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| AII | TRANSIT | 2.4L (DIESEL/TDCI) | CSM - Security module | | X | X | X | |
| AII | TRANSIT | 2.4L (DIESEL/TDCI) | FFH - Fuel Fired Coolant Heating Module | | X | X | X | |
| AII | TRANSIT | 2.4L (DIESEL/TDCI) | PAM - Parking Aid Module | | X | X | X | |
| AII | TRANSIT | 2.4L (DIESEL/TDCI) | RASM - Rear Air Suspension Module | | X | X | X | |
| AII | TRANSIT | 2.4L (DIESEL/TDCI) | RCM - Restraint Control Module | | X | X | X | |
| AII | TRANSIT | 2.4L (DIESEL/TDCI) | PATS - Passive Anti-Theft System | | X | | | 1.Key Programming. |
| AII | WINDSTAR | 3.0L (V6 SFI) | PCM - Powertrain Control Module | | X | X | X | |
| AII | WINDSTAR | 3.0L (V6 SFI) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| AII | WINDSTAR | 3.0L (V6 SFI) | RCM - Restraint Control Module | | X | X | X | |
| AII | TRANSIT CONNECT | 1.8L (ZETEC/DURATORQ/TDCI) | PCM - Powertrain Control Module | | X | X | X | |
| AII | TRANSIT CONNECT | 1.8L (ZETEC/DURATORQ/TDCI) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| AII | TRANSIT CONNECT | 1.8L (ZETEC/DURATORQ/TDCI) | CSM - Security module | | X | X | X | |
| AII | TRANSIT CONNECT | 1.8L (ZETEC/DURATORQ/TDCI) | FFH - Fuel Fired Coolant Heating Module | | X | X | X | |
| AII | TRANSIT CONNECT | 1.8L (ZETEC/DURATORQ/TDCI) | PAM - Parking Aid Module | | X | X | X | |
| AII | TRANSIT CONNECT | 1.8L (ZETEC/DURATORQ/TDCI) | RASM - Rear Air Suspension Module | | X | X | X | |
| AII | TRANSIT CONNECT | 1.8L (ZETEC/DURATORQ/TDCI) | RCM - Restraint Control Module | | X | X | X | |
| AII | TRANSIT CONNECT | 1.8L (ZETEC/DURATORQ/TDCI) | PATS - Passive Anti-Theft System | | X | | | |

| | | | | | | | | |
|-----|----------------|------------------------------|---|--|---|---|---|--|
| AII | CROWN-VICTORIA | 4.6L(2V) | PCM - Powertrain Control Module | | X | X | | |
| AII | CROWN-VICTORIA | 4.6L(2V) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | | |
| AII | CROWN-VICTORIA | 4.6L(2V) | RCM - Restraint Control Module | | X | X | | |
| AII | EXCURSION | 5.4L(2V) | PCM - Powertrain Control Module | | X | X | | |
| AII | EXCURSION | 5.4L(2V) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | | |
| AII | EXCURSION | 5.4L(2V) | GEM - Generic electric module(CTM) | | X | X | | |
| AII | EXCURSION | 6.8L(2V) | PCM - Powertrain Control Module | | X | X | | |
| AII | EXCURSION | 6.8L(2V) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | | |
| AII | EXCURSION | 6.8L(2V) | GEM - Generic electric module(CTM) | | X | X | | |
| AII | EXCURSION | 6.0L(Direct-Injection-Turbo) | PCM - Powertrain Control Module | | X | X | | |
| AII | EXCURSION | 6.0L(Direct-Injection-Turbo) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | | |
| AII | EXCURSION | 6.0L(Direct-Injection-Turbo) | TCM - Transmission Control Module | | X | X | | |
| AII | EXCURSION | 6.0L(Direct-Injection-Turbo) | GEM - Generic electric module(CTM) | | X | X | | |
| AII | EXPEDITION | 4.6L(2V) | PCM - Powertrain Control Module | | X | X | | |
| AII | EXPEDITION | 4.6L(2V) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | | |
| AII | EXPEDITION | 4.6L(2V) | RCM - Restraint Control Module | | X | X | | |
| AII | EXPEDITION | 5.4L(2V) | PCM - Powertrain Control Module | | X | X | | |
| AII | EXPEDITION | 5.4L(2V) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | | |
| AII | EXPEDITION | 5.4L(2V) | RCM - Restraint Control Module | | X | X | | |
| AII | EXPLORER | 4.0L (SOHC SFI) | PCM - Powertrain Control Module | | X | X | X | |
| AII | EXPLORER | 4.0L (SOHC SFI) | 4X4M - 4X4 Control Module | | X | X | X | |
| AII | EXPLORER | 4.0L (SOHC SFI) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| AII | EXPLORER | 4.0L (SOHC SFI) | RCM - Restraint Control Module | | X | X | X | |
| AII | EXPLORER | 4.6L | PCM - Powertrain Control Module | | X | X | X | |
| AII | EXPLORER | 4.6L | 4X4M - 4X4 Control Module | | X | X | X | |
| AII | EXPLORER | 4.6L | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| AII | EXPLORER | 4.6L | RCM - Restraint Control Module | | X | X | X | |
| AII | EXPLORER | 4.0L(V6-SOHC) | PCM - Powertrain Control Module | | X | X | | |
| AII | EXPLORER | 4.0L(V6-SOHC) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | | |
| AII | EXPLORER | 4.0L(V6-SOHC) | RCM - Restraint Control Module | | X | X | | |
| AII | EXPLORER | 4.0L(V6-SOHC) | ICM - Instrument Cluster | | X | X | | |
| AII | EXPLORER | 4.6L(2V) | PCM - Powertrain Control Module | | X | X | | |
| AII | EXPLORER | 4.6L(2V) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | | |
| AII | EXPLORER | 4.6L(2V) | RCM - Restraint Control Module | | X | X | | |
| AII | EXPLORER | 4.6L(2V) | ICM - Instrument Cluster | | X | X | | |
| AII | FIESTA | 1.25L(16V/DOHC) | PCM - Powertrain Control Module | | X | X | X | |
| AII | FIESTA | 1.25L(16V/DOHC) | RCM - Restraint Control Module | | X | X | X | |
| AII | FIESTA | 1.25L(16V/DOHC) | GEM - Generic electric module(CTM) | | X | X | X | |
| AII | FIESTA | 1.25L(16V/DOHC) | ICM - Instrument Cluster | | X | X | X | |
| AII | FIESTA | 1.3L (DOHC/SOHC) | PCM - Powertrain Control Module | | X | X | X | |
| AII | FIESTA | 1.3L (DOHC/SOHC) | RCM - Restraint Control Module | | X | X | X | |

| | | | | | | | | |
|-----|--------|------------------------------------|---|--|---|---|---|--|
| AII | FIESTA | 1.3L (DOHC/SOHC) | GEM - Generic electric module(CTM) | | X | X | X | |
| AII | FIESTA | 1.3L (DOHC/SOHC) | ICM - Instrument Cluster | | X | X | X | |
| AII | FIESTA | 1.4L (16V/16V DOHC/T-DIESEL) | PCM - Powertrain Control Module | | X | X | X | |
| AII | FIESTA | 1.4L (16V/16V DOHC/T-DIESEL) | RCM - Restraint Control Module | | X | X | X | |
| AII | FIESTA | 1.4L (16V/16V DOHC/T-DIESEL) | GEM - Generic electric module(CTM) | | X | X | X | |
| AII | FIESTA | 1.4L (16V/16V DOHC/T-DIESEL) | ICM - Instrument Cluster | | X | X | X | |
| AII | FIESTA | 1.5L (DOHC) | PCM - Powertrain Control Module | | X | X | X | |
| AII | FIESTA | 1.5L (DOHC) | RCM - Restraint Control Module | | X | X | X | |
| AII | FIESTA | 1.5L (DOHC) | GEM - Generic electric module(CTM) | | X | X | X | |
| AII | FIESTA | 1.5L (DOHC) | ICM - Instrument Cluster | | X | X | X | |
| AII | FIESTA | 1.6L (SFI) | PCM - Powertrain Control Module | | X | X | X | |
| AII | FIESTA | 1.6L (SFI) | RCM - Restraint Control Module | | X | X | X | |
| AII | FIESTA | 1.6L (SFI) | GEM - Generic electric module(CTM) | | X | X | X | |
| AII | FIESTA | 1.6L (SFI) | ICM - Instrument Cluster | | X | X | X | |
| AII | FOCUS | 1.4L (ZETEC-SE/SIGMA) | PCM - Powertrain Control Module | | X | X | X | |
| AII | FOCUS | 1.4L (ZETEC-SE/SIGMA) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| AII | FOCUS | 1.4L (ZETEC-SE/SIGMA) | ICM - Instrument Cluster | | X | X | X | |
| AII | FOCUS | 1.4L (ZETEC-SE/SIGMA) | RCM - Restraint Control Module | | X | X | X | |
| AII | FOCUS | 1.4L (ZETEC-SE/SIGMA) | PATS - Passive Anti-Theft System | | X | X | X | |
| AII | FOCUS | 1.6L (ALT FUEL/ZETEC/DURATEC/TDCI) | PCM - Powertrain Control Module | | X | X | X | |
| AII | FOCUS | 1.6L (ALT FUEL/ZETEC/DURATEC/TDCI) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| AII | FOCUS | 1.6L (ALT FUEL/ZETEC/DURATEC/TDCI) | ICM - Instrument Cluster | | X | X | X | |
| AII | FOCUS | 1.6L (ALT FUEL/ZETEC/DURATEC/TDCI) | RCM - Restraint Control Module | | X | X | X | |
| AII | FOCUS | 1.6L (ALT FUEL/ZETEC/DURATEC/TDCI) | PATS - Passive Anti-Theft System | | X | X | X | |
| AII | FOCUS | 1.8L (LPG/ZETEC/TDDI/TDCI/LYNX) | PCM - Powertrain Control Module | | X | X | X | |
| AII | FOCUS | 1.8L (LPG/ZETEC/TDDI/TDCI/LYNX) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| AII | FOCUS | 1.8L (LPG/ZETEC/TDDI/TDCI/LYNX) | ICM - Instrument Cluster | | X | X | X | |
| AII | FOCUS | 1.8L (LPG/ZETEC/TDDI/TDCI/LYNX) | RCM - Restraint Control Module | | X | X | X | |
| AII | FOCUS | 1.8L (LPG/ZETEC/TDDI/TDCI/LYNX) | PATS - Passive Anti-Theft System | | X | X | X | |
| AII | FOCUS | 2.0L (ZETEC/DURATEC/TDCI) | PCM - Powertrain Control Module | | X | X | X | |
| AII | FOCUS | 2.0L (ZETEC/DURATEC/TDCI) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| AII | FOCUS | 2.0L (ZETEC/DURATEC/TDCI) | ICM - Instrument Cluster | | X | X | X | |
| AII | FOCUS | 2.0L (ZETEC/DURATEC/TDCI) | RCM - Restraint Control Module | | X | X | X | |
| AII | FOCUS | 2.0L (ZETEC/DURATEC/TDCI) | PATS - Passive Anti-Theft System | | X | X | X | |
| AII | FOCUS | 2.3L (DURATEC-HE/I4) | PCM - Powertrain Control Module | | X | X | X | |
| AII | FOCUS | 2.3L (DURATEC-HE/I4) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| AII | FOCUS | 2.3L (DURATEC-HE/I4) | ICM - Instrument Cluster | | X | X | X | |
| AII | FOCUS | 2.3L (DURATEC-HE/I4) | RCM - Restraint Control Module | | X | X | X | |
| AII | FOCUS | 2.3L (DURATEC-HE/I4) | PATS - Passive Anti-Theft System | | X | X | X | |

| | | | | | | | | |
|-----|-------------|------------------------------------|---|--|---|---|---|--|
| AII | FOCUS | 2.5L (TURBO) | PCM - Powertrain Control Module | | X | X | X | |
| AII | FOCUS | 2.5L (TURBO) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| AII | FOCUS | 2.5L (TURBO) | ICM - Instrument Cluster | | X | X | X | |
| AII | FOCUS | 2.5L (TURBO) | RCM - Restraint Control Module | | X | X | X | |
| AII | FOCUS | 2.5L (TURBO) | PATS - Passive Anti-Theft System | | X | X | X | |
| AII | FOCUS RS | 1.4L (ZTTEC-SE/SIGMA) | PCM - Powertrain Control Module | | X | X | X | |
| AII | FOCUS RS | 1.4L (ZTTEC-SE/SIGMA) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| AII | FOCUS RS | 1.4L (ZTTEC-SE/SIGMA) | ICM - Instrument Cluster | | X | X | X | |
| AII | FOCUS RS | 1.4L (ZTTEC-SE/SIGMA) | RCM - Restraint Control Module | | X | X | X | |
| AII | FOCUS RS | 1.6L (ALT FUEL/ZETEC/DURATEC/TDCI) | PCM - Powertrain Control Module | | X | X | X | |
| AII | FOCUS RS | 1.6L (ALT FUEL/ZETEC/DURATEC/TDCI) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| AII | FOCUS RS | 1.6L (ALT FUEL/ZETEC/DURATEC/TDCI) | ICM - Instrument Cluster | | X | X | X | |
| AII | FOCUS RS | 1.6L (ALT FUEL/ZETEC/DURATEC/TDCI) | RCM - Restraint Control Module | | X | X | X | |
| AII | FOCUS RS | 1.8L (LPG/ZETEC/TDDI/TDCI/LYNX) | PCM - Powertrain Control Module | | X | X | X | |
| AII | FOCUS RS | 1.8L (LPG/ZETEC/TDDI/TDCI/LYNX) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| AII | FOCUS RS | 1.8L (LPG/ZETEC/TDDI/TDCI/LYNX) | ICM - Instrument Cluster | | X | X | X | |
| AII | FOCUS RS | 1.8L (LPG/ZETEC/TDDI/TDCI/LYNX) | RCM - Restraint Control Module | | X | X | X | |
| AII | FOCUS RS | 2.0L (ZETEC/DURATEC/TDCI) | PCM - Powertrain Control Module | | X | X | X | |
| AII | FOCUS RS | 2.0L (ZETEC/DURATEC/TDCI) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| AII | FOCUS RS | 2.0L (ZETEC/DURATEC/TDCI) | ICM - Instrument Cluster | | X | X | X | |
| AII | FOCUS RS | 2.0L (ZETEC/DURATEC/TDCI) | RCM - Restraint Control Module | | X | X | X | |
| AII | FOCUS RS | 2.5L (TURBO) | PCM - Powertrain Control Module | | X | X | X | |
| AII | FOCUS RS | 2.5L (TURBO) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| AII | FOCUS RS | 2.5L (TURBO) | ICM - Instrument Cluster | | X | X | X | |
| AII | FOCUS RS | 2.5L (TURBO) | RCM - Restraint Control Module | | X | X | X | |
| AII | FOCUS C-MAX | 1.4L (ZTTEC-SE/SIGMA) | PCM - Powertrain Control Module | | X | X | X | |
| AII | FOCUS C-MAX | 1.4L (ZTTEC-SE/SIGMA) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| AII | FOCUS C-MAX | 1.4L (ZTTEC-SE/SIGMA) | ICM - Instrument Cluster | | X | X | X | |
| AII | FOCUS C-MAX | 1.6L (ALT FUEL/ZETEC/DURATEC/TDCI) | PCM - Powertrain Control Module | | X | X | X | |
| AII | FOCUS C-MAX | 1.6L (ALT FUEL/ZETEC/DURATEC/TDCI) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| AII | FOCUS C-MAX | 1.6L (ALT FUEL/ZETEC/DURATEC/TDCI) | ICM - Instrument Cluster | | X | X | X | |
| AII | FOCUS C-MAX | 1.8L (LPG/ZETEC/TDDI/TDCI/LYNX) | PCM - Powertrain Control Module | | X | X | X | |

| | | | | | | | | |
|-----|-------------|---------------------------------|---|--|---|---|---|--|
| AII | FOCUS C-MAX | 1.8L (LPG/ZETEC/TDDI/TDCI/LYNX) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| AII | FOCUS C-MAX | 1.8L (LPG/ZETEC/TDDI/TDCI/LYNX) | ICM - Instrument Cluster | | X | X | X | |
| AII | FOCUS C-MAX | 2.0L (ZETEC/DURATEC/TDCI) | PCM - Powertrain Control Module | | X | X | X | |
| AII | FOCUS C-MAX | 2.0L (ZETEC/DURATEC/TDCI) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| AII | FOCUS C-MAX | 2.0L (ZETEC/DURATEC/TDCI) | ICM - Instrument Cluster | | X | X | X | |
| AII | FOCUS C-MAX | 2.5L (TURBO) | PCM - Powertrain Control Module | | X | X | X | |
| AII | FOCUS C-MAX | 2.5L (TURBO) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| AII | FOCUS C-MAX | 2.5L (TURBO) | ICM - Instrument Cluster | | X | X | X | |
| AII | FUSION | 1.25L(16V/DOHC) | PCM - Powertrain Control Module | | X | X | X | |
| AII | FUSION | 1.25L(16V/DOHC) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| AII | FUSION | 1.25L(16V/DOHC) | ICM - Instrument Cluster | | X | X | X | |
| AII | FUSION | 1.25L(16V/DOHC) | RCM - Restraint Control Module | | X | X | X | |
| AII | FUSION | 1.3L (DOHC/SOHC) | PCM - Powertrain Control Module | | X | X | X | |
| AII | FUSION | 1.3L (DOHC/SOHC) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| AII | FUSION | 1.3L (DOHC/SOHC) | ICM - Instrument Cluster | | X | X | X | |
| AII | FUSION | 1.3L (DOHC/SOHC) | RCM - Restraint Control Module | | X | X | X | |
| AII | FUSION | 1.4L (16V/16V DOHC/T-DIESEL) | PCM - Powertrain Control Module | | X | X | X | |
| AII | FUSION | 1.4L (16V/16V DOHC/T-DIESEL) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| AII | FUSION | 1.4L (16V/16V DOHC/T-DIESEL) | ICM - Instrument Cluster | | X | X | X | |
| AII | FUSION | 1.4L (16V/16V DOHC/T-DIESEL) | RCM - Restraint Control Module | | X | X | X | |
| AII | FUSION | 1.5L (DOHC) | PCM - Powertrain Control Module | | X | X | X | |
| AII | FUSION | 1.5L (DOHC) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| AII | FUSION | 1.5L (DOHC) | ICM - Instrument Cluster | | X | X | X | |
| AII | FUSION | 1.5L (DOHC) | RCM - Restraint Control Module | | X | X | X | |
| AII | FUSION | 1.6L (SFI) | PCM - Powertrain Control Module | | X | X | X | |
| AII | FUSION | 1.6L (SFI) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| AII | FUSION | 1.6L (SFI) | ICM - Instrument Cluster | | X | X | X | |
| AII | FUSION | 1.6L (SFI) | RCM - Restraint Control Module | | X | X | X | |
| AII | GALAXY | 1.9L (T-DIESEL) | PCM - Powertrain Control Module | | X | | | |
| AII | GALAXY | 1.9L (T-DIESEL) | TCM - Transmission Control Module | | X | | | |
| AII | GALAXY | 1.9L (T-DIESEL) | ABS - Anti-Lock Brake / Traction Control Module | | X | | | |
| AII | GALAXY | 1.9L (T-DIESEL) | RCM - Restraint Control Module | | X | | | |
| AII | GALAXY | 1.9L (T-DIESEL) | ICM - Instrument Cluster | | X | | | |
| AII | GALAXY | 1.9L (T-DIESEL) | NAV - Navigation System | | X | | | |
| AII | GALAXY | 2.0L (DOHC) | PCM - Powertrain Control Module | | X | | | |
| AII | GALAXY | 2.0L (DOHC) | TCM - Transmission Control Module | | X | | | |

| | | | | | | | |
|-----|----------|------------------|---|---|---|--|--|
| AII | GALAXY | 2.0L (DOHC) | ABS - Anti-Lock Brake / Traction Control Module | X | | | |
| AII | GALAXY | 2.0L (DOHC) | RCM - Restraint Control Module | X | | | |
| AII | GALAXY | 2.0L (DOHC) | ICM - Instrument Cluster | X | | | |
| AII | GALAXY | 2.0L (DOHC) | NAV - Navigation System | X | | | |
| AII | GALAXY | 2.8L (CD-24V-V6) | PCM - Powertrain Control Module | X | | | |
| AII | GALAXY | 2.8L (CD-24V-V6) | TCM - Transmission Control Module | X | | | |
| AII | GALAXY | 2.8L (CD-24V-V6) | ABS - Anti-Lock Brake / Traction Control Module | X | | | |
| AII | GALAXY | 2.8L (CD-24V-V6) | RCM - Restraint Control Module | X | | | |
| AII | GALAXY | 2.8L (CD-24V-V6) | ICM - Instrument Cluster | X | | | |
| AII | GALAXY | 2.8L (CD-24V-V6) | NAV - Navigation System | X | | | |
| AII | KA | 1.0L | PCM - Powertrain Control Module | X | X | | |
| AII | KA | 1.0L | ABS - Anti-Lock Brake / Traction Control Module | X | X | | |
| AII | KA | 1.0L | ECS - Electronic Crash Sensor(or IABM) | X | X | | |
| AII | KA | 1.0L | ICM - Instrument Cluster | X | X | | |
| AII | KA | 1.0L | EPS - Electronic Controlled Power Steering | X | X | | |
| AII | KA | 1.0L | GEM - Generic electric module(CTM) | X | X | | |
| AII | KA | 1.0L | PATS - Passive Anti-Theft System | X | X | | |
| AII | KA | 1.3L | PCM - Powertrain Control Module | X | X | | |
| AII | KA | 1.3L | ABS - Anti-Lock Brake / Traction Control Module | X | X | | |
| AII | KA | 1.3L | ECS - Electronic Crash Sensor(or IABM) | X | X | | |
| AII | KA | 1.3L | ICM - Instrument Cluster | X | X | | |
| AII | KA | 1.3L | EPS - Electronic Controlled Power Steering | X | X | | |
| AII | KA | 1.3L | GEM - Generic electric module(CTM) | X | X | | |
| AII | KA | 1.3L | PATS - Passive Anti-Theft System | X | X | | |
| AII | KA | 1.6L | PCM - Powertrain Control Module | X | X | | |
| AII | KA | 1.6L | ABS - Anti-Lock Brake / Traction Control Module | X | X | | |
| AII | KA | 1.6L | ECS - Electronic Crash Sensor(or IABM) | X | X | | |
| AII | KA | 1.6L | ICM - Instrument Cluster | X | X | | |
| AII | KA | 1.6L | EPS - Electronic Controlled Power Steering | X | X | | |
| AII | KA | 1.6L | GEM - Generic electric module(CTM) | X | X | | |
| AII | KA | 1.6L | PATS - Passive Anti-Theft System | X | X | | |
| AII | KA | 1.7L | PCM - Powertrain Control Module | X | X | | |
| AII | KA | 1.7L | ABS - Anti-Lock Brake / Traction Control Module | X | X | | |
| AII | KA | 1.7L | ECS - Electronic Crash Sensor(or IABM) | X | X | | |
| AII | KA | 1.7L | ICM - Instrument Cluster | X | X | | |
| AII | KA | 1.7L | EPS - Electronic Controlled Power Steering | X | X | | |
| AII | KA | 1.7L | GEM - Generic electric module(CTM) | X | X | | |
| AII | KA | 1.7L | PATS - Passive Anti-Theft System | X | X | | |
| AII | MAVERICK | 2.0L | PCM - Powertrain Control Module | X | X | | |
| AII | MAVERICK | 2.0L | ABS - Anti-Lock Brake / Traction Control Module | X | X | | |
| AII | MAVERICK | 2.0L | RCM - Restraint Control Module | X | X | | |
| AII | MAVERICK | 2.0L | ICM - Instrument Cluster | X | X | | |
| AII | MAVERICK | 2.0L | GEM - Generic electric module(CTM) | X | X | | |
| AII | MAVERICK | 2.0L | PAM - Parking Aid Module | X | X | | |
| AII | MAVERICK | 2.0L | 4X4M - 4X4 Control Module | X | X | | |

| | | | | | | | | |
|-----|------------------------|------|---|--|---|---|--|--|
| All | MAVERICK | 2.3L | PCM - Powertrain Control Module | | X | X | | |
| All | MAVERICK | 2.3L | ABS - Anti-Lock Brake / Traction Control Module | | X | X | | |
| All | MAVERICK | 2.3L | RCM - Restraint Control Module | | X | X | | |
| All | MAVERICK | 2.3L | ICM - Instrument Cluster | | X | X | | |
| All | MAVERICK | 2.3L | GEM - Generic electric module(CTM) | | X | X | | |
| All | MAVERICK | 2.3L | PAM - Parking Aid Module | | X | X | | |
| All | MAVERICK | 2.3L | 4X4M - 4X4 Control Module | | X | X | | |
| All | MAVERICK | 3.0L | PCM - Powertrain Control Module | | X | X | | |
| All | MAVERICK | 3.0L | ABS - Anti-Lock Brake / Traction Control Module | | X | X | | |
| All | MAVERICK | 3.0L | RCM - Restraint Control Module | | X | X | | |
| All | MAVERICK | 3.0L | ICM - Instrument Cluster | | X | X | | |
| All | MAVERICK | 3.0L | GEM - Generic electric module(CTM) | | X | X | | |
| All | MAVERICK | 3.0L | PAM - Parking Aid Module | | X | X | | |
| All | MAVERICK | 3.0L | 4X4M - 4X4 Control Module | | X | X | | |
| All | F-SERIES SUPER DUTY | 5.4L | PCM - Powertrain Control Module | | X | | | |
| All | F-SERIES SUPER DUTY | 5.4L | ABS - Anti-Lock Brake / Traction Control Module | | X | X | | |
| All | F-SERIES SUPER DUTY | 5.4L | RCM - Restraint Control Module | | X | X | | |
| All | F-SERIES SUPER DUTY | 5.4L | TCM - Transmission Control Module | | X | X | | |
| All | F-SERIES SUPER DUTY | 5.4L | ICM - Instrument Cluster | | X | X | | |
| All | F-SERIES SUPER DUTY | 5.4L | GEM - Generic electric module(CTM) | | X | X | | |
| All | F-SERIES SUPER DUTY | 5.4L | PATS - Passive Anti-Theft System | | X | X | | |
| All | F-SERIES SUPER DUTY | 6.0L | PCM - Powertrain Control Module | | X | | | |
| All | F-SERIES SUPER DUTY | 6.0L | ABS - Anti-Lock Brake / Traction Control Module | | X | X | | |
| All | F-SERIES SUPER DUTY | 6.0L | RCM - Restraint Control Module | | X | X | | |
| All | F-SERIES SUPER DUTY | 6.0L | TCM - Transmission Control Module | | X | X | | |
| All | F-SERIES SUPER DUTY | 6.0L | ICM - Instrument Cluster | | X | X | | |
| All | F-SERIES SUPER DUTY | 6.0L | GEM - Generic electric module(CTM) | | X | X | | |
| All | F-SERIES SUPER DUTY | 6.0L | PATS - Passive Anti-Theft System | | X | X | | |
| All | F-SERIES SUPER DUTY | 6.8L | PCM - Powertrain Control Module | | X | | | |

| | | | | | | | | |
|-----|------------------------|------------------------------|---|--|---|---|---|---|
| AII | F-SERIES SUPER DUTY | 6.8L | ABS - Anti-Lock Brake / Traction Control Module | | X | X | | |
| AII | F-SERIES SUPER DUTY | 6.8L | RCM - Restraint Control Module | | X | X | | |
| AII | F-SERIES SUPER DUTY | 6.8L | TCM - Transmission Control Module | | X | X | | |
| AII | F-SERIES SUPER DUTY | 6.8L | ICM - Instrument Cluster | | X | X | | |
| AII | F-SERIES SUPER DUTY | 6.8L | GEM - Generic electric module(CTM) | | X | X | | |
| AII | F-SERIES SUPER DUTY | 6.8L | PATS - Passive Anti-Theft System | | X | X | | |
| AII | F-SERIES SUPER DUTY | 7.3L | PCM - Powertrain Control Module | | X | | | |
| AII | F-SERIES SUPER DUTY | 7.3L | ABS - Anti-Lock Brake / Traction Control Module | | X | X | | |
| AII | F-SERIES SUPER DUTY | 7.3L | RCM - Restraint Control Module | | X | X | | |
| AII | F-SERIES SUPER DUTY | 7.3L | TCM - Transmission Control Module | | X | X | | |
| AII | F-SERIES SUPER DUTY | 7.3L | ICM - Instrument Cluster | | X | X | | |
| AII | F-SERIES SUPER DUTY | 7.3L | GEM - Generic electric module(CTM) | | X | X | | |
| AII | F-SERIES SUPER DUTY | 7.3L | PATS - Passive Anti-Theft System | | X | X | | |
| AII | STREETKA | 1.0L (SHOV/OHV) | PCM - Powertrain Control Module | | X | X | X | |
| AII | STREETKA | 1.0L (SHOV/OHV) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| AII | STREETKA | 1.0L (SHOV/OHV) | ICM - Instrument Cluster | | X | X | X | |
| AII | STREETKA | 1.0L (SHOV/OHV) | RCM - Restraint Control Module | | X | X | X | |
| AII | STREETKA | 1.3L (SHOC/OHV) | PCM - Powertrain Control Module | | X | X | X | |
| AII | STREETKA | 1.3L (SHOC/OHV) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| AII | STREETKA | 1.3L (SHOC/OHV) | ICM - Instrument Cluster | | X | X | X | |
| AII | STREETKA | 1.3L (SHOC/OHV) | RCM - Restraint Control Module | | X | X | X | |
| AII | STREETKA | 1.6L (SHOC/DHOC) | PCM - Powertrain Control Module | | X | X | X | |
| AII | STREETKA | 1.6L (SHOC/DHOC) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| AII | STREETKA | 1.6L (SHOC/DHOC) | ICM - Instrument Cluster | | X | X | X | |
| AII | STREETKA | 1.6L (SHOC/DHOC) | RCM - Restraint Control Module | | X | X | X | |
| AII | STREETKA | 1.7L (DHOC) | PCM - Powertrain Control Module | | X | X | X | |
| AII | STREETKA | 1.7L (DHOC) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| AII | STREETKA | 1.7L (DHOC) | ICM - Instrument Cluster | | X | X | X | |
| AII | STREETKA | 1.7L (DHOC) | RCM - Restraint Control Module | | X | X | X | |
| AII | MONDEO | 1.8L (DURATEC-SC/DURATEC-HE) | PCM - Powertrain Control Module | | X | X | X | 1.Fuel Injector Coding. 2.Key Programming. |

| | | | | | | | | |
|-----|--------|------------------------------------|---|--|---|---|---|---|
| AII | MONDEO | 1.8L (DURATEC-SC/DURATEC-HE) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| AII | MONDEO | 1.8L (DURATEC-SC/DURATEC-HE) | RCM - Restraint Control Module | | X | X | X | |
| AII | MONDEO | 1.8L (DURATEC-SC/DURATEC-HE) | GEM - Generic electric module(CTM) | | X | X | X | |
| AII | MONDEO | 1.8L (DURATEC-SC/DURATEC-HE) | HEC - Hybrid Electronic Cluster | | X | X | X | |
| AII | MONDEO | 1.8L (DURATEC-SC/DURATEC-HE) | ICM - Instrument Cluster | | X | X | X | |
| AII | MONDEO | 1.8L (DURATEC-SC/DURATEC-HE) | ACM - Audio Control Module | | X | X | X | |
| AII | MONDEO | 1.8L (DURATEC-SC/DURATEC-HE) | EATC - Electronic Automatic Temperature Control | | X | X | X | |
| AII | MONDEO | 1.8L (DURATEC-SC/DURATEC-HE) | PATS - Passive Anti-Theft System | | X | | | 1.Key Programming. |
| AII | MONDEO | 2.0L (DURATORQ TDDI/DURATORQ TDCI) | PCM - Powertrain Control Module | | X | X | X | |
| AII | MONDEO | 2.0L (DURATORQ TDDI/DURATORQ TDCI) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| AII | MONDEO | 2.0L (DURATORQ TDDI/DURATORQ TDCI) | RCM - Restraint Control Module | | X | X | X | |
| AII | MONDEO | 2.0L (DURATORQ TDDI/DURATORQ TDCI) | GEM - Generic electric module(CTM) | | X | X | X | |
| AII | MONDEO | 2.0L (DURATORQ TDDI/DURATORQ TDCI) | HEC - Hybrid Electronic Cluster | | X | X | X | |
| AII | MONDEO | 2.0L (DURATORQ TDDI/DURATORQ TDCI) | ICM - Instrument Cluster | | X | X | X | |
| AII | MONDEO | 2.0L (DURATORQ TDDI/DURATORQ TDCI) | ACM - Audio Control Module | | X | X | X | |
| AII | MONDEO | 2.0L (DURATORQ TDDI/DURATORQ TDCI) | EATC - Electronic Automatic Temperature Control | | X | X | X | |
| AII | MONDEO | 2.0L (DURATORQ TDDI/DURATORQ TDCI) | PATS - Passive Anti-Theft System | | X | | | 1.Key Programming. |
| AII | MONDEO | 2.2L (DURATORQ TDCI) | PCM - Powertrain Control Module | | X | X | X | 1.Fuel Injector Coding. 2.Key Programming. |
| AII | MONDEO | 2.2L (DURATORQ TDCI) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| AII | MONDEO | 2.2L (DURATORQ TDCI) | RCM - Restraint Control Module | | X | X | X | |
| AII | MONDEO | 2.2L (DURATORQ TDCI) | GEM - Generic electric module(CTM) | | X | X | X | |
| AII | MONDEO | 2.2L (DURATORQ TDCI) | HEC - Hybrid Electronic Cluster | | X | X | X | |
| AII | MONDEO | 2.2L (DURATORQ TDCI) | ICM - Instrument Cluster | | X | X | X | |
| AII | MONDEO | 2.2L (DURATORQ TDCI) | ACM - Audio Control Module | | X | X | X | |
| AII | MONDEO | 2.2L (DURATORQ TDCI) | EATC - Electronic Automatic Temperature Control | | X | X | X | |
| AII | MONDEO | 2.2L (DURATORQ TDCI) | PATS - Passive Anti-Theft System | | X | | | 1.Key Programming. |
| AII | MONDEO | 2.5L (DURATEC/DURATEC-VE) | PCM - Powertrain Control Module | | X | X | X | |
| AII | MONDEO | 2.5L (DURATEC/DURATEC-VE) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| AII | MONDEO | 2.5L (DURATEC/DURATEC-VE) | RCM - Restraint Control Module | | X | X | X | |
| AII | MONDEO | 2.5L (DURATEC/DURATEC-VE) | GEM - Generic electric module(CTM) | | X | X | X | |
| AII | MONDEO | 2.5L (DURATEC/DURATEC-VE) | HEC - Hybrid Electronic Cluster | | X | X | X | |
| AII | MONDEO | 2.5L (DURATEC/DURATEC-VE) | ICM - Instrument Cluster | | X | X | X | |
| AII | MONDEO | 2.5L (DURATEC/DURATEC-VE) | ACM - Audio Control Module | | X | X | X | |
| AII | MONDEO | 2.5L (DURATEC/DURATEC-VE) | EATC - Electronic Automatic Temperature Control | | X | X | X | |

| | | | | | | | | |
|-----|--------------------|-----------------------------|---|--|---|---|---|--------------------|
| All | MONDEO | 2.5L (DURATEC/DURATEC-VE) | PATS - Passive Anti-Theft System | | X | | | 1.Key Programming. |
| All | MONDEO | 3.0L (DURATEC/DURATEC-ST) | PCM - Powertrain Control Module | | X | X | X | |
| All | MONDEO | 3.0L (DURATEC/DURATEC-ST) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| All | MONDEO | 3.0L (DURATEC/DURATEC-ST) | RCM - Restraint Control Module | | X | X | X | |
| All | MONDEO | 3.0L (DURATEC/DURATEC-ST) | GEM - Generic electric module(CTM) | | X | X | X | |
| All | MONDEO | 3.0L (DURATEC/DURATEC-ST) | HEC - Hybrid Electronic Cluster | | X | X | X | |
| All | MONDEO | 3.0L (DURATEC/DURATEC-ST) | ICM - Instrument Cluster | | X | X | X | |
| All | MONDEO | 3.0L (DURATEC/DURATEC-ST) | ACM - Audio Control Module | | X | X | X | |
| All | MONDEO | 3.0L (DURATEC/DURATEC-ST) | EATC - Electronic Automatic Temperature Control | | X | X | X | |
| All | MONDEO | 3.0L (DURATEC/DURATEC-ST) | PATS - Passive Anti-Theft System | | X | | | 1.Key Programming. |
| All | RANGER | 2.5L (DIESEL/T-DIESEL) | PCM - Powertrain Control Module | | X | X | X | |
| All | RANGER | 2.5L (DIESEL/T-DIESEL) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| All | RANGER | 2.5L (DIESEL/T-DIESEL) | RCM - Restraint Control Module | | X | X | X | |
| All | TRANSIT | 2.0L (DIESEL/ALT FUEL/TDCI) | PCM - Powertrain Control Module | | X | X | X | |
| All | TRANSIT | 2.0L (DIESEL/ALT FUEL/TDCI) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| All | TRANSIT | 2.0L (DIESEL/ALT FUEL/TDCI) | CSM - Security module | | X | X | X | |
| All | TRANSIT | 2.0L (DIESEL/ALT FUEL/TDCI) | FFH - Fuel Fired Coolant Heating Module | | X | X | X | |
| All | TRANSIT | 2.0L (DIESEL/ALT FUEL/TDCI) | PAM - Parking Aid Module | | X | X | X | |
| All | TRANSIT | 2.0L (DIESEL/ALT FUEL/TDCI) | RASM - Rear Air Suspension Module | | X | X | X | |
| All | TRANSIT | 2.0L (DIESEL/ALT FUEL/TDCI) | RCM - Restraint Control Module | | X | X | X | |
| All | TRANSIT | 2.0L (DIESEL/ALT FUEL/TDCI) | PATS - Passive Anti-Theft System | | X | | | 1.Key Programming. |
| All | TRANSIT | 2.3L (DIESEL) | PCM - Powertrain Control Module | | X | X | X | |
| All | TRANSIT | 2.3L (DIESEL) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| All | TRANSIT | 2.3L (DIESEL) | CSM - Security module | | X | X | X | |
| All | TRANSIT | 2.3L (DIESEL) | FFH - Fuel Fired Coolant Heating Module | | X | X | X | |
| All | TRANSIT | 2.3L (DIESEL) | PAM - Parking Aid Module | | X | X | X | |
| All | TRANSIT | 2.3L (DIESEL) | RASM - Rear Air Suspension Module | | X | X | X | |
| All | TRANSIT | 2.3L (DIESEL) | RCM - Restraint Control Module | | X | X | X | |
| All | TRANSIT | 2.3L (DIESEL) | PATS - Passive Anti-Theft System | | X | | | 1.Key Programming. |
| All | TRANSIT | 2.4L (DIESEL/TDCI) | PCM - Powertrain Control Module | | X | X | X | |
| All | TRANSIT | 2.4L (DIESEL/TDCI) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| All | TRANSIT | 2.4L (DIESEL/TDCI) | CSM - Security module | | X | X | X | |
| All | TRANSIT | 2.4L (DIESEL/TDCI) | FFH - Fuel Fired Coolant Heating Module | | X | X | X | |
| All | TRANSIT | 2.4L (DIESEL/TDCI) | PAM - Parking Aid Module | | X | X | X | |
| All | TRANSIT | 2.4L (DIESEL/TDCI) | RASM - Rear Air Suspension Module | | X | X | X | |
| All | TRANSIT | 2.4L (DIESEL/TDCI) | RCM - Restraint Control Module | | X | X | X | |
| All | TRANSIT | 2.4L (DIESEL/TDCI) | PATS - Passive Anti-Theft System | | X | | | 1.Key Programming. |
| All | TRANSIT CONNECT | 1.8L (ZETEC/DURATORQ/TDCI) | PCM - Powertrain Control Module | | X | X | X | |
| All | TRANSIT CONNECT | 1.8L (ZETEC/DURATORQ/TDCI) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| All | TRANSIT CONNECT | 1.8L (ZETEC/DURATORQ/TDCI) | CSM - Security module | | X | X | X | |

| | | | | | | | | |
|-----|--------------------|------------------------------|---|--|---|---|---|--------------------|
| All | TRANSIT CONNECT | 1.8L (ZETEC/DURATORQ/TDCI) | FFH - Fuel Fired Coolant Heating Module | | X | X | X | |
| All | TRANSIT CONNECT | 1.8L (ZETEC/DURATORQ/TDCI) | PAM - Parking Aid Module | | X | X | X | |
| All | TRANSIT CONNECT | 1.8L (ZETEC/DURATORQ/TDCI) | RASM - Rear Air Suspension Module | | X | X | X | |
| All | TRANSIT CONNECT | 1.8L (ZETEC/DURATORQ/TDCI) | RCM - Restraint Control Module | | X | X | X | |
| All | TRANSIT CONNECT | 1.8L (ZETEC/DURATORQ/TDCI) | PATS - Passive Anti-Theft System | | X | | | 1.Key Programming. |
| All | WINDSTAR | 3.0L (V6 SFI) | PCM - Powertrain Control Module | | X | X | X | |
| All | WINDSTAR | 3.0L (V6 SFI) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| All | WINDSTAR | 3.0L (V6 SFI) | RCM - Restraint Control Module | | X | X | X | |
| All | WINDSTAR | 2.0(DURATEC-HE/I4) | RCM - Restraint Control Module | | X | X | | |
| All | WINDSTAR | 2.3(DURATEC-HE/I4) | RCM - Restraint Control Module | | X | X | | |
| All | EXCURSION | 5.4L(2V) | PCM - Powertrain Control Module | | X | X | | |
| All | EXCURSION | 5.4L(2V) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | | |
| All | EXCURSION | 5.4L(2V) | RCM - Restraint Control Module | | X | X | | |
| All | EXCURSION | 5.4L(2V) | GEM - Generic electric module(CTM) | | X | X | | |
| All | EXCURSION | 6.8L(2V) | PCM - Powertrain Control Module | | X | X | | |
| All | EXCURSION | 6.8L(2V) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | | |
| All | EXCURSION | 6.8L(2V) | RCM - Restraint Control Module | | X | X | | |
| All | EXCURSION | 6.8L(2V) | GEM - Generic electric module(CTM) | | X | X | | |
| All | EXCURSION | 6.0L(Direct-Injection-Turbo) | PCM - Powertrain Control Module | | X | X | | |
| All | EXCURSION | 6.0L(Direct-Injection-Turbo) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | | |
| All | EXCURSION | 6.0L(Direct-Injection-Turbo) | RCM - Restraint Control Module | | X | X | | |
| All | EXCURSION | 6.0L(Direct-Injection-Turbo) | TCM - Transmission Control Module | | X | X | | |
| All | EXCURSION | 6.0L(Direct-Injection-Turbo) | GEM - Generic electric module(CTM) | | X | X | | |
| All | FORD-GT | 5.4L(4V) | PCM - Powertrain Control Module | | X | X | | |
| All | FORD-GT | 5.4L(4V) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | | |
| All | FORD-GT | 5.4L(4V) | RCM - Restraint Control Module | | X | X | | |
| All | FORD-GT | 5.4L(4V) | ICM - Instrument Cluster | | X | X | | |
| All | FORD-GT | 5.4L(4V) | GEM - Generic electric module(CTM) | | X | X | | |
| All | FORD-GT | 5.4L(4V) | PATS - Passive Anti-Theft System | | X | X | | |
| All | EXPEDITION | 5.4L(3V) | PCM - Powertrain Control Module | | X | X | | |
| All | EXPEDITION | 5.4L(3V) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | | |
| All | EXPEDITION | 5.4L(3V) | RCM - Restraint Control Module | | X | X | | |
| All | EXPEDITION | 5.4L(3V) | ICM - Instrument Cluster | | X | X | | |
| All | CROWN- VICTORIA | 4.6L(2V) | PCM - Powertrain Control Module | | X | X | | |
| All | CROWN- VICTORIA | 4.6L(2V) | RCM - Restraint Control Module | | X | X | | |
| All | EXPLORER | 4.0L (SOHC SFI) | PCM - Powertrain Control Module | | X | X | X | |
| All | EXPLORER | 4.0L (SOHC SFI) | 4X4M - 4X4 Control Module | | X | X | X | |

| | | | | | | | | |
|-----|----------|------------------------------|---|--|---|---|---|--|
| AII | EXPLORER | 4.0L (SOHC SFI) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| AII | EXPLORER | 4.0L (SOHC SFI) | RCM - Restraint Control Module | | X | X | X | |
| AII | EXPLORER | 4.0L(2V) | PCM - Powertrain Control Module | | X | X | | |
| AII | EXPLORER | 4.0L(2V) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | | |
| AII | EXPLORER | 4.0L(2V) | RCM - Restraint Control Module | | X | X | | |
| AII | EXPLORER | 4.0L(2V) | ICM - Instrument Cluster | | X | X | | |
| AII | EXPLORER | 4.0L(2V) | GEM - Generic electric module(CTM) | | X | X | | |
| AII | EXPLORER | 4.6L(3V) | PCM - Powertrain Control Module | | X | X | | |
| AII | EXPLORER | 4.6L(3V) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | | |
| AII | EXPLORER | 4.6L(3V) | RCM - Restraint Control Module | | X | X | | |
| AII | EXPLORER | 4.6L(3V) | TCM - Transmission Control Module | | X | X | | |
| AII | EXPLORER | 4.6L(3V) | ICM - Instrument Cluster | | X | X | | |
| AII | EXPLORER | 4.6L(3V) | GEM - Generic electric module(CTM) | | X | X | | |
| AII | FIESTA | 1.25L(16V/DOHC) | PCM - Powertrain Control Module | | X | X | X | |
| AII | FIESTA | 1.25L(16V/DOHC) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| AII | FIESTA | 1.25L(16V/DOHC) | RCM - Restraint Control Module | | X | X | X | |
| AII | FIESTA | 1.25L(16V/DOHC) | ICM - Instrument Cluster | | X | X | X | |
| AII | FIESTA | 1.3L (DOHC/SOHC) | PCM - Powertrain Control Module | | X | X | X | |
| AII | FIESTA | 1.3L (DOHC/SOHC) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| AII | FIESTA | 1.3L (DOHC/SOHC) | RCM - Restraint Control Module | | X | X | X | |
| AII | FIESTA | 1.3L (DOHC/SOHC) | ICM - Instrument Cluster | | X | X | X | |
| AII | FIESTA | 1.4L (16V/16V DOHC/T-DIESEL) | PCM - Powertrain Control Module | | X | X | X | |
| AII | FIESTA | 1.4L (16V/16V DOHC/T-DIESEL) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| AII | FIESTA | 1.4L (16V/16V DOHC/T-DIESEL) | RCM - Restraint Control Module | | X | X | X | |
| AII | FIESTA | 1.4L (16V/16V DOHC/T-DIESEL) | ICM - Instrument Cluster | | X | X | X | |
| AII | FIESTA | 1.5L (DOHC) | PCM - Powertrain Control Module | | X | X | X | |
| AII | FIESTA | 1.5L (DOHC) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| AII | FIESTA | 1.5L (DOHC) | RCM - Restraint Control Module | | X | X | X | |
| AII | FIESTA | 1.5L (DOHC) | ICM - Instrument Cluster | | X | X | X | |
| AII | FIESTA | 1.6L (SFI) | PCM - Powertrain Control Module | | X | X | X | |
| AII | FIESTA | 1.6L (SFI) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| AII | FIESTA | 1.6L (SFI) | RCM - Restraint Control Module | | X | X | X | |
| AII | FIESTA | 1.6L (SFI) | ICM - Instrument Cluster | | X | X | X | |
| AII | FIESTA | 1.3L(BZ) | PCM - Powertrain Control Module | | X | X | | |
| AII | FIESTA | 1.3L(BZ) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | | |
| AII | FIESTA | 1.3L(BZ) | RCM - Restraint Control Module | | X | X | | |
| AII | FIESTA | 1.3L(BZ) | ICM - Instrument Cluster | | X | X | | |
| AII | FIESTA | 1.3L(BZ) | GEM - Generic electric module(CTM) | | X | X | | |
| AII | FIESTA | 1.6L(BZ) | PCM - Powertrain Control Module | | X | X | | |
| AII | FIESTA | 1.6L(BZ) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | | |
| AII | FIESTA | 1.6L(BZ) | RCM - Restraint Control Module | | X | X | | |
| AII | FIESTA | 1.6L(BZ) | ICM - Instrument Cluster | | X | X | | |
| AII | FIESTA | 1.6L(BZ) | GEM - Generic electric module(CTM) | | X | X | | |
| AII | FIESTA | 1.3L(DURATEC-8V) | PCM - Powertrain Control Module | | X | X | | |
| AII | FIESTA | 1.3L(DURATEC-8V) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | | |

| | | | | | | | | |
|-----|--------|--|---|--|---|---|--|--|
| All | FIESTA | 1.3L(DURATEC-8V) | RCM - Restraint Control Module | | X | X | | |
| All | FIESTA | 1.3L(DURATEC-8V) | ICM - Instrument Cluster | | X | X | | |
| All | FIESTA | 1.3L(DURATEC-8V) | GEM - Generic electric module(CTM) | | X | X | | |
| All | FIESTA | 1.25L(DURATEC-16V) | PCM - Powertrain Control Module | | X | X | | |
| All | FIESTA | 1.25L(DURATEC-16V) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | | |
| All | FIESTA | 1.25L(DURATEC-16V) | RCM - Restraint Control Module | | X | X | | |
| All | FIESTA | 1.25L(DURATEC-16V) | ICM - Instrument Cluster | | X | X | | |
| All | FIESTA | 1.25L(DURATEC-16V) | GEM - Generic electric module(CTM) | | X | X | | |
| All | FIESTA | 1.4L(DURATEC-16V) | PCM - Powertrain Control Module | | X | X | | |
| All | FIESTA | 1.4L(DURATEC-16V) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | | |
| All | FIESTA | 1.4L(DURATEC-16V) | RCM - Restraint Control Module | | X | X | | |
| All | FIESTA | 1.4L(DURATEC-16V) | TCM - Transmission Control Module | | X | X | | |
| All | FIESTA | 1.4L(DURATEC-16V) | ICM - Instrument Cluster | | X | X | | |
| All | FIESTA | 1.4L(DURATEC-16V) | GEM - Generic electric module(CTM) | | X | X | | |
| All | FIESTA | 1.6L(DURATEC-16V) | PCM - Powertrain Control Module | | X | X | | |
| All | FIESTA | 1.6L(DURATEC-16V) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | | |
| All | FIESTA | 1.6L(DURATEC-16V) | RCM - Restraint Control Module | | X | X | | |
| All | FIESTA | 1.6L(DURATEC-16V) | TCM - Transmission Control Module | | X | X | | |
| All | FIESTA | 1.6L(DURATEC-16V) | ICM - Instrument Cluster | | X | X | | |
| All | FIESTA | 1.6L(DURATEC-16V) | GEM - Generic electric module(CTM) | | X | X | | |
| All | FIESTA | 1.6L(TDCi/Duratorq-Turbo-Diesel-Common-Rail-Injection) | PCM - Powertrain Control Module | | X | X | | |
| All | FIESTA | 1.6L(TDCi/Duratorq-Turbo-Diesel-Common-Rail-Injection) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | | |
| All | FIESTA | 1.6L(TDCi/Duratorq-Turbo-Diesel-Common-Rail-Injection) | RCM - Restraint Control Module | | X | X | | |
| All | FIESTA | 1.6L(TDCi/Duratorq-Turbo-Diesel-Common-Rail-Injection) | ICM - Instrument Cluster | | X | X | | |
| All | FIESTA | 1.6L(TDCi/Duratorq-Turbo-Diesel-Common-Rail-Injection) | GEM - Generic electric module(CTM) | | X | X | | |
| All | FIESTA | 1.6L(TDCi/Duratorq-Turbo-Diesel-Common-Rail-Injection) | EPS - Electronic Controlled Power Steering | | X | X | | |
| All | FIESTA | 1.4L(TDCi/Duratorq-Turbo-Diesel-Common-Rail-Injection) | PCM - Powertrain Control Module | | X | X | | |
| All | FIESTA | 1.4L(TDCi/Duratorq-Turbo-Diesel-Common-Rail-Injection) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | | |
| All | FIESTA | 1.4L(TDCi/Duratorq-Turbo-Diesel-Common-Rail-Injection) | RCM - Restraint Control Module | | X | X | | |
| All | FIESTA | 1.4L(TDCi/Duratorq-Turbo-Diesel-Common-Rail-Injection) | TCM - Transmission Control Module | | X | X | | |
| All | FIESTA | 1.4L(TDCi/Duratorq-Turbo-Diesel-Common-Rail-Injection) | ICM - Instrument Cluster | | X | X | | |
| All | FIESTA | 1.4L(TDCi/Duratorq-Turbo-Diesel-Common-Rail-Injection) | GEM - Generic electric module(CTM) | | X | X | | |

| | | | | | | | | |
|-----|-------|------------------------------------|---|--|---|---|---|--|
| AII | FOCUS | 1.4L (ZETEC-SE/SIGMA) | PCM - Powertrain Control Module | | X | X | X | |
| AII | FOCUS | 1.4L (ZETEC-SE/SIGMA) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| AII | FOCUS | 1.4L (ZETEC-SE/SIGMA) | RCM - Restraint Control Module | | X | X | X | |
| AII | FOCUS | 1.4L (ZETEC-SE/SIGMA) | ICM - Instrument Cluster | | X | X | X | |
| AII | FOCUS | 1.4L (ZETEC-SE/SIGMA) | TCM - Transmission Control Module | | X | X | X | |
| AII | FOCUS | 1.4L (ZETEC-SE/SIGMA) | EPS - Electronic Controlled Power Steering | | X | X | X | |
| AII | FOCUS | 1.4L (ZETEC-SE/SIGMA) | PATS - Passive Anti-Theft System | | X | X | X | |
| AII | FOCUS | 1.4L (ZETEC-SE/SIGMA) | EATC - Electronic Automatic Temperature Control | | X | X | X | |
| AII | FOCUS | 1.6L (ALT FUEL/ZETEC/DURATEC/TDCI) | PCM - Powertrain Control Module | | X | X | X | |
| AII | FOCUS | 1.6L (ALT FUEL/ZETEC/DURATEC/TDCI) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| AII | FOCUS | 1.6L (ALT FUEL/ZETEC/DURATEC/TDCI) | RCM - Restraint Control Module | | X | X | X | |
| AII | FOCUS | 1.6L (ALT FUEL/ZETEC/DURATEC/TDCI) | ICM - Instrument Cluster | | X | X | X | |
| AII | FOCUS | 1.6L (ALT FUEL/ZETEC/DURATEC/TDCI) | TCM - Transmission Control Module | | X | X | X | |
| AII | FOCUS | 1.6L (ALT FUEL/ZETEC/DURATEC/TDCI) | EPS - Electronic Controlled Power Steering | | X | X | X | |
| AII | FOCUS | 1.6L (ALT FUEL/ZETEC/DURATEC/TDCI) | PATS - Passive Anti-Theft System | | X | X | X | |
| AII | FOCUS | 1.6L (ALT FUEL/ZETEC/DURATEC/TDCI) | EATC - Electronic Automatic Temperature Control | | X | X | X | |
| AII | FOCUS | 1.8L (LPG/ZETEC/TDDI/TDCI/LYNX) | PCM - Powertrain Control Module | | X | X | X | |
| AII | FOCUS | 1.8L (LPG/ZETEC/TDDI/TDCI/LYNX) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| AII | FOCUS | 1.8L (LPG/ZETEC/TDDI/TDCI/LYNX) | RCM - Restraint Control Module | | X | X | X | |
| AII | FOCUS | 1.8L (LPG/ZETEC/TDDI/TDCI/LYNX) | ICM - Instrument Cluster | | X | X | X | |
| AII | FOCUS | 1.8L (LPG/ZETEC/TDDI/TDCI/LYNX) | TCM - Transmission Control Module | | X | X | X | |
| AII | FOCUS | 1.8L (LPG/ZETEC/TDDI/TDCI/LYNX) | EATC - Electronic Automatic Temperature Control | | X | X | X | |
| AII | FOCUS | 1.8L (LPG/ZETEC/TDDI/TDCI/LYNX) | EPS - Electronic Controlled Power Steering | | X | X | X | |
| AII | FOCUS | 1.8L (LPG/ZETEC/TDDI/TDCI/LYNX) | PATS - Passive Anti-Theft System | | X | X | X | |
| AII | FOCUS | 2.0L (ZETEC/DURATEC/TDCI) | PCM - Powertrain Control Module | | X | X | X | |
| AII | FOCUS | 2.0L (ZETEC/DURATEC/TDCI) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| AII | FOCUS | 2.0L (ZETEC/DURATEC/TDCI) | RCM - Restraint Control Module | | X | X | X | |
| AII | FOCUS | 2.0L (ZETEC/DURATEC/TDCI) | ICM - Instrument Cluster | | X | X | X | |
| AII | FOCUS | 2.0L (ZETEC/DURATEC/TDCI) | TCM - Transmission Control Module | | X | X | X | |
| AII | FOCUS | 2.0L (ZETEC/DURATEC/TDCI) | EATC - Electronic Automatic Temperature Control | | X | X | X | |
| AII | FOCUS | 2.0L (ZETEC/DURATEC/TDCI) | EPS - Electronic Controlled Power Steering | | X | X | X | |
| AII | FOCUS | 2.0L (ZETEC/DURATEC/TDCI) | PATS - Passive Anti-Theft System | | X | X | X | |
| AII | FOCUS | 2.3L (DURATEC-HE/I4) | PCM - Powertrain Control Module | | X | X | X | |
| AII | FOCUS | 2.3L (DURATEC-HE/I4) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| AII | FOCUS | 2.3L (DURATEC-HE/I4) | RCM - Restraint Control Module | | X | X | X | |
| AII | FOCUS | 2.3L (DURATEC-HE/I4) | ICM - Instrument Cluster | | X | X | X | |

| | | | | | | | | |
|-----|-------------|------------------------------------|---|--|---|---|---|--|
| AII | FOCUS | 2.3L (DURATEC-HE/I4) | TCM - Transmission Control Module | | X | X | X | |
| AII | FOCUS | 2.3L (DURATEC-HE/I4) | EATC - Electronic Automatic Temperature Control | | X | X | X | |
| AII | FOCUS | 2.3L (DURATEC-HE/I4) | EPS - Electronic Controlled Power Steering | | X | X | X | |
| AII | FOCUS | 2.3L (DURATEC-HE/I4) | PATS - Passive Anti-Theft System | | X | X | X | |
| AII | FOCUS | 2.5L (TURBO) | PCM - Powertrain Control Module | | X | X | X | |
| AII | FOCUS | 2.5L (TURBO) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| AII | FOCUS | 2.5L (TURBO) | RCM - Restraint Control Module | | X | X | X | |
| AII | FOCUS | 2.5L (TURBO) | ICM - Instrument Cluster | | X | X | X | |
| AII | FOCUS | 2.5L (TURBO) | TCM - Transmission Control Module | | X | X | X | |
| AII | FOCUS | 2.5L (TURBO) | EATC - Electronic Automatic Temperature Control | | X | X | X | |
| AII | FOCUS | 2.5L (TURBO) | EPS - Electronic Controlled Power Steering | | X | X | X | |
| AII | FOCUS | 2.5L (TURBO) | PATS - Passive Anti-Theft System | | X | X | X | |
| AII | FOCUS RS | 1.4L (ZTTEC-SE/SIGMA) | PCM - Powertrain Control Module | | X | X | X | |
| AII | FOCUS RS | 1.4L (ZTTEC-SE/SIGMA) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| AII | FOCUS RS | 1.4L (ZTTEC-SE/SIGMA) | RCM - Restraint Control Module | | X | X | X | |
| AII | FOCUS RS | 1.4L (ZTTEC-SE/SIGMA) | ICM - Instrument Cluster | | X | X | X | |
| AII | FOCUS RS | 1.6L (ALT FUEL/ZETEC/DURATEC/TDCI) | PCM - Powertrain Control Module | | X | X | X | |
| AII | FOCUS RS | 1.6L (ALT FUEL/ZETEC/DURATEC/TDCI) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| AII | FOCUS RS | 1.6L (ALT FUEL/ZETEC/DURATEC/TDCI) | RCM - Restraint Control Module | | X | X | X | |
| AII | FOCUS RS | 1.6L (ALT FUEL/ZETEC/DURATEC/TDCI) | ICM - Instrument Cluster | | X | X | X | |
| AII | FOCUS RS | 1.8L (LPG/ZETEC/TDDI/TDCI/LYNX) | PCM - Powertrain Control Module | | X | X | X | |
| AII | FOCUS RS | 1.8L (LPG/ZETEC/TDDI/TDCI/LYNX) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| AII | FOCUS RS | 1.8L (LPG/ZETEC/TDDI/TDCI/LYNX) | RCM - Restraint Control Module | | X | X | X | |
| AII | FOCUS RS | 1.8L (LPG/ZETEC/TDDI/TDCI/LYNX) | ICM - Instrument Cluster | | X | X | X | |
| AII | FOCUS RS | 2.0L (ZETEC/DURATEC/TDCI) | PCM - Powertrain Control Module | | X | X | X | |
| AII | FOCUS RS | 2.0L (ZETEC/DURATEC/TDCI) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| AII | FOCUS RS | 2.0L (ZETEC/DURATEC/TDCI) | RCM - Restraint Control Module | | X | X | X | |
| AII | FOCUS RS | 2.0L (ZETEC/DURATEC/TDCI) | ICM - Instrument Cluster | | X | X | X | |
| AII | FOCUS RS | 2.5L (TURBO) | PCM - Powertrain Control Module | | X | X | X | |
| AII | FOCUS RS | 2.5L (TURBO) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| AII | FOCUS RS | 2.5L (TURBO) | RCM - Restraint Control Module | | X | X | X | |
| AII | FOCUS RS | 2.5L (TURBO) | ICM - Instrument Cluster | | X | X | X | |
| AII | FOCUS C-MAX | 1.4L (ZTTEC-SE/SIGMA) | PCM - Powertrain Control Module | | X | X | X | |
| AII | FOCUS C-MAX | 1.4L (ZTTEC-SE/SIGMA) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| AII | FOCUS C-MAX | 1.4L (ZTTEC-SE/SIGMA) | RCM - Restraint Control Module | | X | X | X | |
| AII | FOCUS C-MAX | 1.4L (ZTTEC-SE/SIGMA) | ICM - Instrument Cluster | | X | X | X | |

| | | | | | | | | |
|-----|-------------|------------------------------------|---|--|---|---|---|--|
| AII | FOCUS C-MAX | 1.6L (ALT FUEL/ZETEC/DURATEC/TDCI) | PCM - Powertrain Control Module | | X | X | X | |
| AII | FOCUS C-MAX | 1.6L (ALT FUEL/ZETEC/DURATEC/TDCI) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| AII | FOCUS C-MAX | 1.6L (ALT FUEL/ZETEC/DURATEC/TDCI) | RCM - Restraint Control Module | | X | X | X | |
| AII | FOCUS C-MAX | 1.6L (ALT FUEL/ZETEC/DURATEC/TDCI) | ICM - Instrument Cluster | | X | X | X | |
| AII | FOCUS C-MAX | 1.8L (LPG/ZETEC/TDDI/TDCI/LYNX) | PCM - Powertrain Control Module | | X | X | X | |
| AII | FOCUS C-MAX | 1.8L (LPG/ZETEC/TDDI/TDCI/LYNX) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| AII | FOCUS C-MAX | 1.8L (LPG/ZETEC/TDDI/TDCI/LYNX) | RCM - Restraint Control Module | | X | X | X | |
| AII | FOCUS C-MAX | 1.8L (LPG/ZETEC/TDDI/TDCI/LYNX) | ICM - Instrument Cluster | | X | X | X | |
| AII | FOCUS C-MAX | 2.0L (ZETEC/DURATEC/TDCI) | PCM - Powertrain Control Module | | X | X | X | |
| AII | FOCUS C-MAX | 2.0L (ZETEC/DURATEC/TDCI) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| AII | FOCUS C-MAX | 2.0L (ZETEC/DURATEC/TDCI) | RCM - Restraint Control Module | | X | X | X | |
| AII | FOCUS C-MAX | 2.0L (ZETEC/DURATEC/TDCI) | ICM - Instrument Cluster | | X | X | X | |
| AII | FOCUS C-MAX | 2.5L (TURBO) | PCM - Powertrain Control Module | | X | X | X | |
| AII | FOCUS C-MAX | 2.5L (TURBO) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| AII | FOCUS C-MAX | 2.5L (TURBO) | RCM - Restraint Control Module | | X | X | X | |
| AII | FOCUS C-MAX | 2.5L (TURBO) | ICM - Instrument Cluster | | X | X | X | |
| AII | FUSION | 1.25L(16V/DOHC) | PCM - Powertrain Control Module | | X | X | X | |
| AII | FUSION | 1.25L(16V/DOHC) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| AII | FUSION | 1.25L(16V/DOHC) | RCM - Restraint Control Module | | X | X | X | |
| AII | FUSION | 1.25L(16V/DOHC) | ICM - Instrument Cluster | | X | X | X | |
| AII | FUSION | 1.3L (DOHC/SOHC) | PCM - Powertrain Control Module | | X | X | X | |
| AII | FUSION | 1.3L (DOHC/SOHC) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| AII | FUSION | 1.3L (DOHC/SOHC) | RCM - Restraint Control Module | | X | X | X | |
| AII | FUSION | 1.3L (DOHC/SOHC) | ICM - Instrument Cluster | | X | X | X | |
| AII | FUSION | 1.4L (16V/16V DOHC/T-DIESEL) | PCM - Powertrain Control Module | | X | X | X | |
| AII | FUSION | 1.4L (16V/16V DOHC/T-DIESEL) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| AII | FUSION | 1.4L (16V/16V DOHC/T-DIESEL) | RCM - Restraint Control Module | | X | X | X | |
| AII | FUSION | 1.4L (16V/16V DOHC/T-DIESEL) | ICM - Instrument Cluster | | X | X | X | |

| | | | | | | | | |
|-----|--------|--|---|--|---|---|---|--|
| All | FUSION | 1.5L (DOHC) | PCM - Powertrain Control Module | | X | X | X | |
| All | FUSION | 1.5L (DOHC) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| All | FUSION | 1.5L (DOHC) | RCM - Restraint Control Module | | X | X | X | |
| All | FUSION | 1.5L (DOHC) | ICM - Instrument Cluster | | X | X | X | |
| All | FUSION | 1.6L (SFI) | PCM - Powertrain Control Module | | X | X | X | |
| All | FUSION | 1.6L (SFI) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| All | FUSION | 1.6L (SFI) | RCM - Restraint Control Module | | X | X | X | |
| All | FUSION | 1.6L (SFI) | ICM - Instrument Cluster | | X | X | X | |
| All | FUSION | 1.4L(DURATEC-16V) | PCM - Powertrain Control Module | | X | X | | |
| All | FUSION | 1.4L(DURATEC-16V) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | | |
| All | FUSION | 1.4L(DURATEC-16V) | RCM - Restraint Control Module | | X | X | | |
| All | FUSION | 1.4L(DURATEC-16V) | ICM - Instrument Cluster | | X | X | | |
| All | FUSION | 1.4L(DURATEC-16V) | GEM - Generic electric module(CTM) | | X | X | | |
| All | FUSION | 1.6L(DURATEC-16V) | PCM - Powertrain Control Module | | X | X | | |
| All | FUSION | 1.6L(DURATEC-16V) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | | |
| All | FUSION | 1.6L(DURATEC-16V) | RCM - Restraint Control Module | | X | X | | |
| All | FUSION | 1.6L(DURATEC-16V) | ICM - Instrument Cluster | | X | X | | |
| All | FUSION | 1.6L(DURATEC-16V) | GEM - Generic electric module(CTM) | | X | X | | |
| All | FUSION | 1.6L(DURATEC-16V) | PCM - Powertrain Control Module | | X | X | | |
| All | FUSION | 1.6L(DURATEC-16V) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | | |
| All | FUSION | 1.6L(DURATEC-16V) | RCM - Restraint Control Module | | X | X | | |
| All | FUSION | 1.6L(DURATEC-16V) | ICM - Instrument Cluster | | X | X | | |
| All | FUSION | 1.6L(DURATEC-16V) | GEM - Generic electric module(CTM) | | X | X | | |
| All | FUSION | 1.6L(TDCi/Duratorq-Turbo-Diesel-Common-Rail-Injection) | PCM - Powertrain Control Module | | X | X | | |
| All | FUSION | 1.6L(TDCi/Duratorq-Turbo-Diesel-Common-Rail-Injection) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | | |
| All | FUSION | 1.6L(TDCi/Duratorq-Turbo-Diesel-Common-Rail-Injection) | RCM - Restraint Control Module | | X | X | | |
| All | FUSION | 1.6L(TDCi/Duratorq-Turbo-Diesel-Common-Rail-Injection) | ICM - Instrument Cluster | | X | X | | |
| All | FUSION | 1.6L(TDCi/Duratorq-Turbo-Diesel-Common-Rail-Injection) | GEM - Generic electric module(CTM) | | X | X | | |
| All | FUSION | 1.6L(TDCi/Duratorq-Turbo-Diesel-Common-Rail-Injection) | EPS - Electronic Controlled Power Steering | | X | X | | |
| All | FUSION | 1.4L(TDCi/Duratorq-Turbo-Diesel-Common-Rail-Injection) | PCM - Powertrain Control Module | | X | X | | |
| All | FUSION | 1.4L(TDCi/Duratorq-Turbo-Diesel-Common-Rail-Injection) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | | |
| All | FUSION | 1.4L(TDCi/Duratorq-Turbo-Diesel-Common-Rail-Injection) | RCM - Restraint Control Module | | X | X | | |
| All | FUSION | 1.4L(TDCi/Duratorq-Turbo-Diesel-Common-Rail-Injection) | ICM - Instrument Cluster | | X | X | | |

| | | | | | | | |
|-----|----------|--|---|--|---|---|------------------------------------|
| All | | | | | | | |
| | FUSION | 1.4L(TDCi/Duratorq-Turbo-Diesel-Common-Rail-Injection) | GEM - Generic electric module(CTM) | | X | X | |
| All | FUSION | 1.25L(DURATEC-16V) | PCM - Powertrain Control Module | | X | X | |
| All | FUSION | 1.25L(DURATEC-16V) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | |
| All | FUSION | 1.25L(DURATEC-16V) | RCM - Restraint Control Module | | X | X | |
| All | FUSION | 1.25L(DURATEC-16V) | ICM - Instrument Cluster | | X | X | |
| All | FUSION | 1.25L(DURATEC-16V) | GEM - Generic electric module(CTM) | | X | X | |
| All | GALAXY | 1.9L (T-DIESEL) | PCM - Powertrain Control Module | | X | | |
| All | GALAXY | 1.9L (T-DIESEL) | TCM - Transmission Control Module | | X | | |
| All | GALAXY | 1.9L (T-DIESEL) | ABS - Anti-Lock Brake / Traction Control Module | | X | | |
| All | GALAXY | 1.9L (T-DIESEL) | RCM - Restraint Control Module | | X | | |
| All | GALAXY | 1.9L (T-DIESEL) | ICM - Instrument Cluster | | X | | |
| All | GALAXY | 1.9L (T-DIESEL) | NAV - Navigation System | | X | | |
| All | GALAXY | 2.0L (DOHC) | PCM - Powertrain Control Module | | X | | |
| All | GALAXY | 2.0L (DOHC) | TCM - Transmission Control Module | | X | | |
| All | GALAXY | 2.0L (DOHC) | ABS - Anti-Lock Brake / Traction Control Module | | X | | |
| All | GALAXY | 2.0L (DOHC) | RCM - Restraint Control Module | | X | | |
| All | GALAXY | 2.0L (DOHC) | ICM - Instrument Cluster | | X | | |
| All | GALAXY | 2.0L (DOHC) | NAV - Navigation System | | X | | |
| All | GALAXY | 2.8L (CD-24V-V6) | PCM - Powertrain Control Module | | X | | |
| All | GALAXY | 2.8L (CD-24V-V6) | TCM - Transmission Control Module | | X | | |
| All | GALAXY | 2.8L (CD-24V-V6) | ABS - Anti-Lock Brake / Traction Control Module | | X | | |
| All | GALAXY | 2.8L (CD-24V-V6) | RCM - Restraint Control Module | | X | | |
| All | GALAXY | 2.8L (CD-24V-V6) | ICM - Instrument Cluster | | X | | |
| All | GALAXY | 2.8L (CD-24V-V6) | NAV - Navigation System | | X | | |
| All | GALAXY | 1.8L(TDCi/Duratorq-Turbo-Diesel-Common-Rail-Injection) | PCM - Powertrain Control Module | | X | X | * Fuel Injector Correction Factors |
| All | GALAXY | 2.0L(DURATEC-HE/I4) | PCM - Powertrain Control Module | | X | X | |
| All | GALAXY | 2.0L(TDCi/Duratorq-Turbo-Diesel-Common-Rail-Injection) | PCM - Powertrain Control Module | | X | X | * Fuel Injector Correction Factors |
| All | GALAXY | 2.2L(TDCi/Duratorq-Turbo-Diesel-Common-Rail-Injection) | PCM - Powertrain Control Module | | X | X | * Fuel Injector Correction Factors |
| All | GALAXY | 2.0L(DURATEC-HE/I4) | PCM - Powertrain Control Module | | X | X | |
| All | GALAXY | 2.0L(DURATEC-HE/I4) | PCM - Powertrain Control Module | | X | X | |
| All | GALAXY | 2.0L(DURATEC-HE/I4) | PCM - Powertrain Control Module | | X | X | |
| All | GALAXY | 2.3L(DURATEC-HE/I4) | PCM - Powertrain Control Module | | X | X | |
| All | GALAXY | 2.3L(DURATEC-HE/I4) | TCM - Transmission Control Module | | X | X | |
| All | GALAXY | 2.5L(I5) | PCM - Powertrain Control Module | | X | X | |
| All | GALAXY | 5.4L(4V) | PCM - Powertrain Control Module | | X | X | |
| All | GALAXY | 5.4L(4V) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | |
| All | GALAXY | 5.4L(4V) | RCM - Restraint Control Module | | X | X | |
| All | GALAXY | 5.4L(4V) | TCM - Transmission Control Module | | X | X | |
| All | WINDSTAR | 2.0L(DURATEC-HE/I4) | RCM - Restraint Control Module | | X | X | |
| All | WINDSTAR | 2.3L(DURATEC-HE/I4) | RCM - Restraint Control Module | | X | X | |

| | | | | | | | | |
|-----|----------|-----------------------|---|--|---|---|--|--|
| AII | RANGER | 2.5L(DIESEL/T-DIESEL) | PCM - Powertrain Control Module | | X | X | | |
| AII | RANGER | 2.5L(DIESEL/T-DIESEL) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | | |
| AII | RANGER | 2.5L(DIESEL/T-DIESEL) | RCM - Restraint Control Module | | X | X | | |
| AII | RANGER | 2.5L(DIESEL/T-DIESEL) | ICM - Instrument Cluster | | X | X | | |
| AII | KA | 1.0L | PCM - Powertrain Control Module | | X | X | | |
| AII | KA | 1.0L | ABS - Anti-Lock Brake / Traction Control Module | | X | X | | |
| AII | KA | 1.0L | ECS - Electronic Crash Sensor(or IABM) | | X | X | | |
| AII | KA | 1.0L | ICM - Instrument Cluster | | X | X | | |
| AII | KA | 1.0L | EPS - Electronic Controlled Power Steering | | X | X | | |
| AII | KA | 1.0L | GEM - Generic electric module(CTM) | | X | X | | |
| AII | KA | 1.0L | PATS - Passive Anti-Theft System | | X | X | | |
| AII | KA | 1.3L | PCM - Powertrain Control Module | | X | X | | |
| AII | KA | 1.3L | ABS - Anti-Lock Brake / Traction Control Module | | X | X | | |
| AII | KA | 1.3L | ECS - Electronic Crash Sensor(or IABM) | | X | X | | |
| AII | KA | 1.3L | ICM - Instrument Cluster | | X | X | | |
| AII | KA | 1.3L | EPS - Electronic Controlled Power Steering | | X | X | | |
| AII | KA | 1.3L | GEM - Generic electric module(CTM) | | X | X | | |
| AII | KA | 1.3L | PATS - Passive Anti-Theft System | | X | X | | |
| AII | KA | 1.6L | PCM - Powertrain Control Module | | X | X | | |
| AII | KA | 1.6L | ABS - Anti-Lock Brake / Traction Control Module | | X | X | | |
| AII | KA | 1.6L | ECS - Electronic Crash Sensor(or IABM) | | X | X | | |
| AII | KA | 1.6L | ICM - Instrument Cluster | | X | X | | |
| AII | KA | 1.6L | EPS - Electronic Controlled Power Steering | | X | X | | |
| AII | KA | 1.6L | GEM - Generic electric module(CTM) | | X | X | | |
| AII | KA | 1.6L | PATS - Passive Anti-Theft System | | X | X | | |
| AII | KA | 1.7L | PCM - Powertrain Control Module | | X | X | | |
| AII | KA | 1.7L | ABS - Anti-Lock Brake / Traction Control Module | | X | X | | |
| AII | KA | 1.7L | ECS - Electronic Crash Sensor(or IABM) | | X | X | | |
| AII | KA | 1.7L | ICM - Instrument Cluster | | X | X | | |
| AII | KA | 1.7L | EPS - Electronic Controlled Power Steering | | X | X | | |
| AII | KA | 1.7L | GEM - Generic electric module(CTM) | | X | X | | |
| AII | KA | 1.7L | PATS - Passive Anti-Theft System | | X | X | | |
| AII | MAVERICK | 2.0L | PCM - Powertrain Control Module | | X | X | | |
| AII | MAVERICK | 2.0L | ABS - Anti-Lock Brake / Traction Control Module | | X | X | | |
| AII | MAVERICK | 2.0L | RCM - Restraint Control Module | | X | X | | |
| AII | MAVERICK | 2.0L | GEM - Generic electric module(CTM) | | X | X | | |
| AII | MAVERICK | 2.0L | PAM - Parking Aid Module | | X | X | | |
| AII | MAVERICK | 2.0L | 4X4M - 4X4 Control Module | | X | X | | |
| AII | MAVERICK | 2.3L | PCM - Powertrain Control Module | | X | X | | |
| AII | MAVERICK | 2.3L | ABS - Anti-Lock Brake / Traction Control Module | | X | X | | |
| AII | MAVERICK | 2.3L | RCM - Restraint Control Module | | X | X | | |
| AII | MAVERICK | 2.3L | GEM - Generic electric module(CTM) | | X | X | | |
| AII | MAVERICK | 2.3L | PAM - Parking Aid Module | | X | X | | |
| AII | MAVERICK | 2.3L | 4X4M - 4X4 Control Module | | X | X | | |
| AII | MAVERICK | 3.0L | PCM - Powertrain Control Module | | X | X | | |

| | | | | | | | | |
|-----|------------------------|------|---|--|---|---|--|--|
| All | MAVERICK | 3.0L | ABS - Anti-Lock Brake / Traction Control Module | | X | X | | |
| All | MAVERICK | 3.0L | RCM - Restraint Control Module | | X | X | | |
| All | MAVERICK | 3.0L | GEM - Generic electric module(CTM) | | X | X | | |
| All | MAVERICK | 3.0L | PAM - Parking Aid Module | | X | X | | |
| All | MAVERICK | 3.0L | 4X4M - 4X4 Control Module | | X | X | | |
| All | F-SERIES SUPER DUTY | 5.4L | PCM - Powertrain Control Module | | X | | | |
| All | F-SERIES SUPER DUTY | 5.4L | ABS - Anti-Lock Brake / Traction Control Module | | X | X | | |
| All | F-SERIES SUPER DUTY | 5.4L | RCM - Restraint Control Module | | X | X | | |
| All | F-SERIES SUPER DUTY | 5.4L | TCM - Transmission Control Module | | X | X | | |
| All | F-SERIES SUPER DUTY | 5.4L | ICM - Instrument Cluster | | X | X | | |
| All | F-SERIES SUPER DUTY | 5.4L | GEM - Generic electric module(CTM) | | X | X | | |
| All | F-SERIES SUPER DUTY | 5.4L | PATS - Passive Anti-Theft System | | X | X | | |
| All | F-SERIES SUPER DUTY | 6.0L | PCM - Powertrain Control Module | | X | | | |
| All | F-SERIES SUPER DUTY | 6.0L | ABS - Anti-Lock Brake / Traction Control Module | | X | X | | |
| All | F-SERIES SUPER DUTY | 6.0L | RCM - Restraint Control Module | | X | X | | |
| All | F-SERIES SUPER DUTY | 6.0L | TCM - Transmission Control Module | | X | X | | |
| All | F-SERIES SUPER DUTY | 6.0L | ICM - Instrument Cluster | | X | X | | |
| All | F-SERIES SUPER DUTY | 6.0L | GEM - Generic electric module(CTM) | | X | X | | |
| All | F-SERIES SUPER DUTY | 6.0L | PATS - Passive Anti-Theft System | | X | X | | |
| All | F-SERIES SUPER DUTY | 6.8L | PCM - Powertrain Control Module | | X | | | |
| All | F-SERIES SUPER DUTY | 6.8L | ABS - Anti-Lock Brake / Traction Control Module | | X | X | | |
| All | F-SERIES SUPER DUTY | 6.8L | RCM - Restraint Control Module | | X | X | | |
| All | F-SERIES SUPER DUTY | 6.8L | TCM - Transmission Control Module | | X | X | | |
| All | F-SERIES SUPER DUTY | 6.8L | ICM - Instrument Cluster | | X | X | | |

| | | | | | | | | |
|-----|------------------------|------------------------------------|---|--|---|---|---|---|
| All | F-SERIES SUPER DUTY | 6.8L | GEM - Generic electric module(CTM) | | X | X | | |
| All | F-SERIES SUPER DUTY | 6.8L | PATS - Passive Anti-Theft System | | X | X | | |
| All | F-SERIES SUPER DUTY | 7.3L | PCM - Powertrain Control Module | | X | | | |
| All | F-SERIES SUPER DUTY | 7.3L | ABS - Anti-Lock Brake / Traction Control Module | | X | X | | |
| All | F-SERIES SUPER DUTY | 7.3L | RCM - Restraint Control Module | | X | X | | |
| All | F-SERIES SUPER DUTY | 7.3L | TCM - Transmission Control Module | | X | X | | |
| All | F-SERIES SUPER DUTY | 7.3L | ICM - Instrument Cluster | | X | X | | |
| All | F-SERIES SUPER DUTY | 7.3L | GEM - Generic electric module(CTM) | | X | X | | |
| All | F-SERIES SUPER DUTY | 7.3L | PATS - Passive Anti-Theft System | | X | X | | |
| All | MONDEO | 1.8L (DURATEC-SC/DURATEC-HE) | PCM - Powertrain Control Module | | X | X | X | 1.Fuel Injector Coding. 2.Key Programming. |
| All | MONDEO | 1.8L (DURATEC-SC/DURATEC-HE) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| All | MONDEO | 1.8L (DURATEC-SC/DURATEC-HE) | RCM - Restraint Control Module | | X | X | X | |
| All | MONDEO | 1.8L (DURATEC-SC/DURATEC-HE) | GEM - Generic electric module(CTM) | | X | X | X | |
| All | MONDEO | 1.8L (DURATEC-SC/DURATEC-HE) | HEC - Hybrid Electronic Cluster | | X | X | X | |
| All | MONDEO | 1.8L (DURATEC-SC/DURATEC-HE) | ICM - Instrument Cluster | | X | X | X | |
| All | MONDEO | 1.8L (DURATEC-SC/DURATEC-HE) | ACM - Audio Control Module | | X | X | X | |
| All | MONDEO | 1.8L (DURATEC-SC/DURATEC-HE) | EATC - Electronic Automatic Temperature Control | | X | X | X | |
| All | MONDEO | 1.8L (DURATEC-SC/DURATEC-HE) | PATS - Passive Anti-Theft System | | X | | | 1.Key Programming. |
| All | MONDEO | 2.0L (DURATORQ TDDI/DURATORQ TDCI) | PCM - Powertrain Control Module | | X | X | X | |
| All | MONDEO | 2.0L (DURATORQ TDDI/DURATORQ TDCI) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| All | MONDEO | 2.0L (DURATORQ TDDI/DURATORQ TDCI) | RCM - Restraint Control Module | | X | X | X | |
| All | MONDEO | 2.0L (DURATORQ TDDI/DURATORQ TDCI) | GEM - Generic electric module(CTM) | | X | X | X | |
| All | MONDEO | 2.0L (DURATORQ TDDI/DURATORQ TDCI) | HEC - Hybrid Electronic Cluster | | X | X | X | |
| All | MONDEO | 2.0L (DURATORQ TDDI/DURATORQ TDCI) | ICM - Instrument Cluster | | X | X | X | |
| All | MONDEO | 2.0L (DURATORQ TDDI/DURATORQ TDCI) | ACM - Audio Control Module | | X | X | X | |
| All | MONDEO | 2.0L (DURATORQ TDDI/DURATORQ TDCI) | EATC - Electronic Automatic Temperature Control | | X | X | X | |

| | | | | | | | | |
|-----|---------|------------------------------------|---|--|---|---|---|---|
| All | MONDEO | 2.0L (DURATORQ TDDI/DURATORQ TDCI) | PATS - Passive Anti-Theft System | | X | | | 1.Key Programming. |
| All | MONDEO | 2.2L (DURATORQ TDCI) | PCM - Powertrain Control Module | | X | X | X | 1.Fuel Injector Coding. 2.Key Programming. |
| All | MONDEO | 2.2L (DURATORQ TDCI) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| All | MONDEO | 2.2L (DURATORQ TDCI) | RCM - Restraint Control Module | | X | X | X | |
| All | MONDEO | 2.2L (DURATORQ TDCI) | GEM - Generic electric module(CTM) | | X | X | X | |
| All | MONDEO | 2.2L (DURATORQ TDCI) | HEC - Hybrid Electronic Cluster | | X | X | X | |
| All | MONDEO | 2.2L (DURATORQ TDCI) | ICM - Instrument Cluster | | X | X | X | |
| All | MONDEO | 2.2L (DURATORQ TDCI) | ACM - Audio Control Module | | X | X | X | |
| All | MONDEO | 2.2L (DURATORQ TDCI) | EATC - Electronic Automatic Temperature Control | | X | X | X | |
| All | MONDEO | 2.2L (DURATORQ TDCI) | PATS - Passive Anti-Theft System | | X | | | 1.Key Programming. |
| All | MONDEO | 2.5L (DURATEC/DURATEC-VE) | PCM - Powertrain Control Module | | X | X | X | |
| All | MONDEO | 2.5L (DURATEC/DURATEC-VE) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| All | MONDEO | 2.5L (DURATEC/DURATEC-VE) | RCM - Restraint Control Module | | X | X | X | |
| All | MONDEO | 2.5L (DURATEC/DURATEC-VE) | GEM - Generic electric module(CTM) | | X | X | X | |
| All | MONDEO | 2.5L (DURATEC/DURATEC-VE) | HEC - Hybrid Electronic Cluster | | X | X | X | |
| All | MONDEO | 2.5L (DURATEC/DURATEC-VE) | ICM - Instrument Cluster | | X | X | X | |
| All | MONDEO | 2.5L (DURATEC/DURATEC-VE) | ACM - Audio Control Module | | X | X | X | |
| All | MONDEO | 2.5L (DURATEC/DURATEC-VE) | EATC - Electronic Automatic Temperature Control | | X | X | X | |
| All | MONDEO | 2.5L (DURATEC/DURATEC-VE) | PATS - Passive Anti-Theft System | | X | | | 1.Key Programming. |
| All | MONDEO | 3.0L (DURATEC/DURATEC-ST) | PCM - Powertrain Control Module | | X | X | X | |
| All | MONDEO | 3.0L (DURATEC/DURATEC-ST) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| All | MONDEO | 3.0L (DURATEC/DURATEC-ST) | RCM - Restraint Control Module | | X | X | X | |
| All | MONDEO | 3.0L (DURATEC/DURATEC-ST) | GEM - Generic electric module(CTM) | | X | X | X | |
| All | MONDEO | 3.0L (DURATEC/DURATEC-ST) | HEC - Hybrid Electronic Cluster | | X | X | X | |
| All | MONDEO | 3.0L (DURATEC/DURATEC-ST) | ICM - Instrument Cluster | | X | X | X | |
| All | MONDEO | 3.0L (DURATEC/DURATEC-ST) | ACM - Audio Control Module | | X | X | X | |
| All | MONDEO | 3.0L (DURATEC/DURATEC-ST) | EATC - Electronic Automatic Temperature Control | | X | X | X | |
| All | MONDEO | 3.0L (DURATEC/DURATEC-ST) | PATS - Passive Anti-Theft System | | X | | | 1.Key Programming. |
| All | TRANSIT | 2.0L (DIESEL/ALT FUEL/TDCI) | PCM - Powertrain Control Module | | X | X | X | |
| All | TRANSIT | 2.0L (DIESEL/ALT FUEL/TDCI) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| All | TRANSIT | 2.0L (DIESEL/ALT FUEL/TDCI) | RCM - Restraint Control Module | | X | X | X | |
| All | TRANSIT | 2.0L (DIESEL/ALT FUEL/TDCI) | BEM - Body electronic module | | X | X | X | |
| All | TRANSIT | 2.0L (DIESEL/ALT FUEL/TDCI) | ICM - Instrument Cluster | | X | X | X | |
| All | TRANSIT | 2.0L (DIESEL/ALT FUEL/TDCI) | ACM - Audio Control Module | | X | X | X | |
| All | TRANSIT | 2.3L (DIESEL) | PCM - Powertrain Control Module | | X | X | X | |
| All | TRANSIT | 2.3L (DIESEL) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| All | TRANSIT | 2.3L (DIESEL) | RCM - Restraint Control Module | | X | X | X | |
| All | TRANSIT | 2.3L (DIESEL) | BEM - Body electronic module | | X | X | X | |
| All | TRANSIT | 2.3L (DIESEL) | ICM - Instrument Cluster | | X | X | X | |
| All | TRANSIT | 2.3L (DIESEL) | ACM - Audio Control Module | | X | X | X | |
| All | TRANSIT | 2.4L (DIESEL/TDCI) | PCM - Powertrain Control Module | | X | X | X | |
| All | TRANSIT | 2.4L (DIESEL/TDCI) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |

| | | | | | | | | |
|-----|-----------------|--|---|--|---|---|---|--|
| All | TRANSIT | 2.4L (DIESEL/TDCI) | RCM - Restraint Control Module | | X | X | X | |
| All | TRANSIT | 2.4L (DIESEL/TDCI) | BEM - Body electronic module | | X | X | X | |
| All | TRANSIT | 2.4L (DIESEL/TDCI) | ICM - Instrument Cluster | | X | X | X | |
| All | TRANSIT | 2.4L (DIESEL/TDCI) | ACM - Audio Control Module | | X | X | X | |
| All | TRANSIT | 2.3L(DURATEC-HE/I4) | PCM - Powertrain Control Module | | X | X | | |
| All | TRANSIT | 2.3L(DURATEC-HE/I4) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | | |
| All | TRANSIT | 2.2L(TDCi/Duratorq-Turbo-Diesel-Common-Rail-Injection) | PCM - Powertrain Control Module | | X | X | | |
| All | TRANSIT | 2.2L(TDCi/Duratorq-Turbo-Diesel-Common-Rail-Injection) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | | |
| All | TRANSIT | 2.4L(TDCi/Duratorq-Turbo-Diesel-Common-Rail-Injection) | PCM - Powertrain Control Module | | X | X | | |
| All | TRANSIT | 2.4L(TDCi/Duratorq-Turbo-Diesel-Common-Rail-Injection) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | | |
| All | TRANSIT | 3.2L(TDCi/Duratorq-Turbo-Diesel-Common-Rail-Injection) | PCM - Powertrain Control Module | | X | X | | |
| All | TRANSIT | 3.2L(TDCi/Duratorq-Turbo-Diesel-Common-Rail-Injection) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | | |
| All | TRANSIT CONNECT | 1.8L (ZETEC/DURATORQ/TDCI) | PCM - Powertrain Control Module | | X | X | X | |
| All | TRANSIT CONNECT | 1.8L (ZETEC/DURATORQ/TDCI) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| All | TRANSIT CONNECT | 1.8L (ZETEC/DURATORQ/TDCI) | RCM - Restraint Control Module | | X | X | X | |
| All | TRANSIT CONNECT | 1.8L (ZETEC/DURATORQ/TDCI) | BEM - Body electronic module | | X | X | X | |
| All | TRANSIT CONNECT | 1.8L (ZETEC/DURATORQ/TDCI) | ICM - Instrument Cluster | | X | X | X | |
| All | TRANSIT CONNECT | 1.8L (ZETEC/DURATORQ/TDCI) | ACM - Audio Control Module | | X | X | X | |
| All | CROWN-VICTORIA | 4.6L(2V) | PCM - Powertrain Control Module | | X | X | | |
| All | CROWN-VICTORIA | 4.6L(2V) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | | |
| All | CROWN-VICTORIA | 4.6L(2V) | RCM - Restraint Control Module | | X | X | | |
| All | CROWN-VICTORIA | 4.6L(2V) | ICM - Instrument Cluster | | X | X | | |
| All | FORD-GT | 5.4L(4V) | PCM - Powertrain Control Module | | X | X | | |
| All | FORD-GT | 5.4L(4V) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | | |
| All | FORD-GT | 5.4L(4V) | RCM - Restraint Control Module | | X | X | | |
| All | FORD-GT | 5.4L(4V) | ICM - Instrument Cluster | | X | X | | |
| All | FORD-GT | 5.4L(4V) | GEM - Generic electric module(CTM) | | X | X | | |
| All | FORD-GT | 5.4L(4V) | PATS - Passive Anti-Theft System | | X | X | | |

| | | | | | | | | |
|-----|------------|------------------------------|---|--|---|---|---|--|
| AII | EXPEDITION | 5.4L(3V) | PCM - Powertrain Control Module | | X | X | | |
| AII | EXPEDITION | 5.4L(3V) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | | |
| AII | EXPEDITION | 5.4L(3V) | RCM - Restraint Control Module | | X | X | | |
| AII | EXPEDITION | 5.4L(3V) | ICM - Instrument Cluster | | X | X | | |
| AII | EXPLORER | 4.0L (SOHC SFI) | PCM - Powertrain Control Module | | X | X | X | |
| AII | EXPLORER | 4.0L (SOHC SFI) | 4X4M - 4X4 Control Module | | X | X | X | |
| AII | EXPLORER | 4.0L (SOHC SFI) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| AII | EXPLORER | 4.0L (SOHC SFI) | RCM - Restraint Control Module | | X | X | X | |
| AII | EXPLORER | 4.0L(V6-SOHC) | PCM - Powertrain Control Module | | X | X | | |
| AII | EXPLORER | 4.0L(V6-SOHC) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | | |
| AII | EXPLORER | 4.0L(V6-SOHC) | RCM - Restraint Control Module | | X | X | | |
| AII | EXPLORER | 4.0L(V6-SOHC) | ICM - Instrument Cluster | | X | X | | |
| AII | EXPLORER | 4.0L(V6-SOHC) | GEM - Generic electric module(CTM) | | X | X | | |
| AII | EXPLORER | 4.0L(2V) | PCM - Powertrain Control Module | | X | X | | |
| AII | EXPLORER | 4.0L(2V) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | | |
| AII | EXPLORER | 4.0L(2V) | RCM - Restraint Control Module | | X | X | | |
| AII | EXPLORER | 4.0L(2V) | ICM - Instrument Cluster | | X | X | | |
| AII | EXPLORER | 4.0L(2V) | GEM - Generic electric module(CTM) | | X | X | | |
| AII | EXPLORER | 4.6L(3V) | PCM - Powertrain Control Module | | X | X | | |
| AII | EXPLORER | 4.6L(3V) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | | |
| AII | EXPLORER | 4.6L(3V) | RCM - Restraint Control Module | | X | X | | |
| AII | EXPLORER | 4.6L(3V) | TCM - Transmission Control Module | | X | X | | |
| AII | EXPLORER | 4.6L(3V) | ICM - Instrument Cluster | | X | X | | |
| AII | EXPLORER | 4.6L(3V) | GEM - Generic electric module(CTM) | | X | X | | |
| AII | FIESTA | 1.25L(16V/DOHC) | PCM - Powertrain Control Module | | X | X | X | |
| AII | FIESTA | 1.25L(16V/DOHC) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| AII | FIESTA | 1.25L(16V/DOHC) | RCM - Restraint Control Module | | X | X | X | |
| AII | FIESTA | 1.25L(16V/DOHC) | ICM - Instrument Cluster | | X | X | X | |
| AII | FIESTA | 1.3L (DOHC/SOHC) | PCM - Powertrain Control Module | | X | X | X | |
| AII | FIESTA | 1.3L (DOHC/SOHC) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| AII | FIESTA | 1.3L (DOHC/SOHC) | RCM - Restraint Control Module | | X | X | X | |
| AII | FIESTA | 1.3L (DOHC/SOHC) | ICM - Instrument Cluster | | X | X | X | |
| AII | FIESTA | 1.4L (16V/16V DOHC/T-DIESEL) | PCM - Powertrain Control Module | | X | X | X | |
| AII | FIESTA | 1.4L (16V/16V DOHC/T-DIESEL) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| AII | FIESTA | 1.4L (16V/16V DOHC/T-DIESEL) | RCM - Restraint Control Module | | X | X | X | |
| AII | FIESTA | 1.4L (16V/16V DOHC/T-DIESEL) | ICM - Instrument Cluster | | X | X | X | |
| AII | FIESTA | 1.5L (DOHC) | PCM - Powertrain Control Module | | X | X | X | |
| AII | FIESTA | 1.5L (DOHC) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| AII | FIESTA | 1.5L (DOHC) | RCM - Restraint Control Module | | X | X | X | |
| AII | FIESTA | 1.5L (DOHC) | ICM - Instrument Cluster | | X | X | X | |
| AII | FIESTA | 1.6L (SFI) | PCM - Powertrain Control Module | | X | X | X | |
| AII | FIESTA | 1.6L (SFI) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| AII | FIESTA | 1.6L (SFI) | RCM - Restraint Control Module | | X | X | X | |
| AII | FIESTA | 1.6L (SFI) | ICM - Instrument Cluster | | X | X | X | |
| AII | FOCUS | 1.4L (ZETEC-SE/SIGMA) | PCM - Powertrain Control Module | | X | X | X | |

| | | | | | | | | |
|-----|-------|------------------------------------|---|--|---|---|---|--|
| AII | FOCUS | 1.4L (ZETEC-SE/SIGMA) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| AII | FOCUS | 1.4L (ZETEC-SE/SIGMA) | RCM - Restraint Control Module | | X | X | X | |
| AII | FOCUS | 1.4L (ZETEC-SE/SIGMA) | ICM - Instrument Cluster | | X | X | X | |
| AII | FOCUS | 1.4L (ZETEC-SE/SIGMA) | TCM - Transmission Control Module | | X | X | X | |
| AII | FOCUS | 1.4L (ZETEC-SE/SIGMA) | EPS - Electronic Controlled Power Steering | | X | X | X | |
| AII | FOCUS | 1.4L (ZETEC-SE/SIGMA) | PATS - Passive Anti-Theft System | | X | X | X | |
| AII | FOCUS | 1.4L (ZETEC-SE/SIGMA) | EATC - Electronic Automatic Temperature Control | | X | X | X | |
| AII | FOCUS | 1.6L (ALT FUEL/ZETEC/DURATEC/TDCI) | PCM - Powertrain Control Module | | X | X | X | |
| AII | FOCUS | 1.6L (ALT FUEL/ZETEC/DURATEC/TDCI) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| AII | FOCUS | 1.6L (ALT FUEL/ZETEC/DURATEC/TDCI) | RCM - Restraint Control Module | | X | X | X | |
| AII | FOCUS | 1.6L (ALT FUEL/ZETEC/DURATEC/TDCI) | ICM - Instrument Cluster | | X | X | X | |
| AII | FOCUS | 1.6L (ALT FUEL/ZETEC/DURATEC/TDCI) | TCM - Transmission Control Module | | X | X | X | |
| AII | FOCUS | 1.6L (ALT FUEL/ZETEC/DURATEC/TDCI) | EPS - Electronic Controlled Power Steering | | X | X | X | |
| AII | FOCUS | 1.6L (ALT FUEL/ZETEC/DURATEC/TDCI) | PATS - Passive Anti-Theft System | | X | X | X | |
| AII | FOCUS | 1.6L (ALT FUEL/ZETEC/DURATEC/TDCI) | EATC - Electronic Automatic Temperature Control | | X | X | X | |
| AII | FOCUS | 1.8L (LPG/ZETEC/TDDI/TDCI/LYNX) | PCM - Powertrain Control Module | | X | X | X | |
| AII | FOCUS | 1.8L (LPG/ZETEC/TDDI/TDCI/LYNX) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| AII | FOCUS | 1.8L (LPG/ZETEC/TDDI/TDCI/LYNX) | RCM - Restraint Control Module | | X | X | X | |
| AII | FOCUS | 1.8L (LPG/ZETEC/TDDI/TDCI/LYNX) | ICM - Instrument Cluster | | X | X | X | |
| AII | FOCUS | 1.8L (LPG/ZETEC/TDDI/TDCI/LYNX) | TCM - Transmission Control Module | | X | X | X | |
| AII | FOCUS | 1.8L (LPG/ZETEC/TDDI/TDCI/LYNX) | EPS - Electronic Controlled Power Steering | | X | X | X | |
| AII | FOCUS | 1.8L (LPG/ZETEC/TDDI/TDCI/LYNX) | PATS - Passive Anti-Theft System | | X | X | X | |
| AII | FOCUS | 1.8L (LPG/ZETEC/TDDI/TDCI/LYNX) | EATC - Electronic Automatic Temperature Control | | X | X | X | |
| AII | FOCUS | 2.0L (ZETEC/DURATEC/TDCI) | PCM - Powertrain Control Module | | X | X | X | |
| AII | FOCUS | 2.0L (ZETEC/DURATEC/TDCI) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| AII | FOCUS | 2.0L (ZETEC/DURATEC/TDCI) | RCM - Restraint Control Module | | X | X | X | |
| AII | FOCUS | 2.0L (ZETEC/DURATEC/TDCI) | ICM - Instrument Cluster | | X | X | X | |
| AII | FOCUS | 2.0L (ZETEC/DURATEC/TDCI) | TCM - Transmission Control Module | | X | X | X | |
| AII | FOCUS | 2.0L (ZETEC/DURATEC/TDCI) | EPS - Electronic Controlled Power Steering | | X | X | X | |
| AII | FOCUS | 2.0L (ZETEC/DURATEC/TDCI) | PATS - Passive Anti-Theft System | | X | X | X | |
| AII | FOCUS | 2.0L (ZETEC/DURATEC/TDCI) | EATC - Electronic Automatic Temperature Control | | X | X | X | |
| AII | FOCUS | 2.3L (DURATEC-HE/I4) | PCM - Powertrain Control Module | | X | X | X | |
| AII | FOCUS | 2.3L (DURATEC-HE/I4) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| AII | FOCUS | 2.3L (DURATEC-HE/I4) | RCM - Restraint Control Module | | X | X | X | |
| AII | FOCUS | 2.3L (DURATEC-HE/I4) | ICM - Instrument Cluster | | X | X | X | |
| AII | FOCUS | 2.3L (DURATEC-HE/I4) | TCM - Transmission Control Module | | X | X | X | |

| | | | | | | | | |
|-----|-------------|------------------------------------|---|--|---|---|---|--|
| AII | FOCUS | 2.3L (DURATEC-HE/I4) | EPS - Electronic Controlled Power Steering | | X | X | X | |
| AII | FOCUS | 2.3L (DURATEC-HE/I4) | PATS - Passive Anti-Theft System | | X | X | X | |
| AII | FOCUS | 2.3L (DURATEC-HE/I4) | EATC - Electronic Automatic Temperature Control | | X | X | X | |
| AII | FOCUS | 2.5L (TURBO) | PCM - Powertrain Control Module | | X | X | X | |
| AII | FOCUS | 2.5L (TURBO) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| AII | FOCUS | 2.5L (TURBO) | RCM - Restraint Control Module | | X | X | X | |
| AII | FOCUS | 2.5L (TURBO) | ICM - Instrument Cluster | | X | X | X | |
| AII | FOCUS | 2.5L (TURBO) | TCM - Transmission Control Module | | X | X | X | |
| AII | FOCUS | 2.5L (TURBO) | EPS - Electronic Controlled Power Steering | | X | X | X | |
| AII | FOCUS | 2.5L (TURBO) | PATS - Passive Anti-Theft System | | X | X | X | |
| AII | FOCUS | 2.5L (TURBO) | EATC - Electronic Automatic Temperature Control | | X | X | X | |
| AII | FOCUS RS | 1.4L (ZTTEC-SE/SIGMA) | PCM - Powertrain Control Module | | X | X | X | |
| AII | FOCUS RS | 1.4L (ZTTEC-SE/SIGMA) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| AII | FOCUS RS | 1.4L (ZTTEC-SE/SIGMA) | RCM - Restraint Control Module | | X | X | X | |
| AII | FOCUS RS | 1.4L (ZTTEC-SE/SIGMA) | ICM - Instrument Cluster | | X | X | X | |
| AII | FOCUS RS | 1.6L (ALT FUEL/ZETEC/DURATEC/TDCI) | PCM - Powertrain Control Module | | X | X | X | |
| AII | FOCUS RS | 1.6L (ALT FUEL/ZETEC/DURATEC/TDCI) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| AII | FOCUS RS | 1.6L (ALT FUEL/ZETEC/DURATEC/TDCI) | RCM - Restraint Control Module | | X | X | X | |
| AII | FOCUS RS | 1.6L (ALT FUEL/ZETEC/DURATEC/TDCI) | ICM - Instrument Cluster | | X | X | X | |
| AII | FOCUS RS | 1.8L (LPG/ZETEC/TDDI/TDCI/LYNX) | PCM - Powertrain Control Module | | X | X | X | |
| AII | FOCUS RS | 1.8L (LPG/ZETEC/TDDI/TDCI/LYNX) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| AII | FOCUS RS | 1.8L (LPG/ZETEC/TDDI/TDCI/LYNX) | RCM - Restraint Control Module | | X | X | X | |
| AII | FOCUS RS | 1.8L (LPG/ZETEC/TDDI/TDCI/LYNX) | ICM - Instrument Cluster | | X | X | X | |
| AII | FOCUS RS | 2.0L (ZETEC/DURATEC/TDCI) | PCM - Powertrain Control Module | | X | X | X | |
| AII | FOCUS RS | 2.0L (ZETEC/DURATEC/TDCI) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| AII | FOCUS RS | 2.0L (ZETEC/DURATEC/TDCI) | RCM - Restraint Control Module | | X | X | X | |
| AII | FOCUS RS | 2.0L (ZETEC/DURATEC/TDCI) | ICM - Instrument Cluster | | X | X | X | |
| AII | FOCUS RS | 2.5L (TURBO) | PCM - Powertrain Control Module | | X | X | X | |
| AII | FOCUS RS | 2.5L (TURBO) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| AII | FOCUS RS | 2.5L (TURBO) | RCM - Restraint Control Module | | X | X | X | |
| AII | FOCUS RS | 2.5L (TURBO) | ICM - Instrument Cluster | | X | X | X | |
| AII | FOCUS C-MAX | 1.4L (ZTTEC-SE/SIGMA) | PCM - Powertrain Control Module | | X | X | X | |
| AII | FOCUS C-MAX | 1.4L (ZTTEC-SE/SIGMA) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| AII | FOCUS C-MAX | 1.4L (ZTTEC-SE/SIGMA) | RCM - Restraint Control Module | | X | X | X | |
| AII | FOCUS C-MAX | 1.4L (ZTTEC-SE/SIGMA) | ICM - Instrument Cluster | | X | X | X | |

| | | | | | | | | |
|-----|-------------|------------------------------------|---|--|---|---|---|--|
| All | FOCUS C-MAX | 1.6L (ALT FUEL/ZETEC/DURATEC/TDCI) | PCM - Powertrain Control Module | | X | X | X | |
| All | FOCUS C-MAX | 1.6L (ALT FUEL/ZETEC/DURATEC/TDCI) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| All | FOCUS C-MAX | 1.6L (ALT FUEL/ZETEC/DURATEC/TDCI) | RCM - Restraint Control Module | | X | X | X | |
| All | FOCUS C-MAX | 1.6L (ALT FUEL/ZETEC/DURATEC/TDCI) | ICM - Instrument Cluster | | X | X | X | |
| All | FOCUS C-MAX | 1.8L (LPG/ZETEC/TDDI/TDCI/LYNX) | PCM - Powertrain Control Module | | X | X | X | |
| All | FOCUS C-MAX | 1.8L (LPG/ZETEC/TDDI/TDCI/LYNX) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| All | FOCUS C-MAX | 1.8L (LPG/ZETEC/TDDI/TDCI/LYNX) | RCM - Restraint Control Module | | X | X | X | |
| All | FOCUS C-MAX | 1.8L (LPG/ZETEC/TDDI/TDCI/LYNX) | ICM - Instrument Cluster | | X | X | X | |
| All | FOCUS C-MAX | 2.0L (ZETEC/DURATEC/TDCI) | PCM - Powertrain Control Module | | X | X | X | |
| All | FOCUS C-MAX | 2.0L (ZETEC/DURATEC/TDCI) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| All | FOCUS C-MAX | 2.0L (ZETEC/DURATEC/TDCI) | RCM - Restraint Control Module | | X | X | X | |
| All | FOCUS C-MAX | 2.0L (ZETEC/DURATEC/TDCI) | ICM - Instrument Cluster | | X | X | X | |
| All | FOCUS C-MAX | 2.5L (TURBO) | PCM - Powertrain Control Module | | X | X | X | |
| All | FOCUS C-MAX | 2.5L (TURBO) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| All | FOCUS C-MAX | 2.5L (TURBO) | RCM - Restraint Control Module | | X | X | X | |
| All | FOCUS C-MAX | 2.5L (TURBO) | ICM - Instrument Cluster | | X | X | X | |
| All | FOCUS-C-MAX | 1.4L(DURATEC-16V) | PCM - Powertrain Control Module | | X | X | | |
| All | FOCUS-C-MAX | 1.6L(DURATEC-16V) | PCM - Powertrain Control Module | | X | X | | |
| All | FOCUS-C-MAX | 1.6L(DURATEC-16V) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | | |
| All | FOCUS-C-MAX | 1.6L(DURATEC-16V) | RCM - Restraint Control Module | | X | X | | |
| All | FOCUS-C-MAX | 1.6L(DURATEC-16V) | TCM - Transmission Control Module | | X | X | | |
| All | FOCUS-C-MAX | 1.6L(DURATEC-16V) | ICM - Instrument Cluster | | X | X | | |

| | | | | | | | | |
|-----|-------------|--|---|--|---|---|--|--|
| All | FOCUS-C-MAX | 1.6L(DURATEC-16V) | GEM - Generic electric module(CTM) | | X | X | | |
| All | FOCUS-C-MAX | 1.6L(DURATEC-16V) | EPS - Electronic Controlled Power Steering | | X | X | | |
| All | FOCUS-C-MAX | 1.6L(DURATEC-VCT) | PCM - Powertrain Control Module | | X | X | | |
| All | FOCUS-C-MAX | 1.6L(DURATEC-VCT) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | | |
| All | FOCUS-C-MAX | 1.6L(DURATEC-VCT) | RCM - Restraint Control Module | | X | X | | |
| All | FOCUS-C-MAX | 1.6L(DURATEC-VCT) | TCM - Transmission Control Module | | X | X | | |
| All | FOCUS-C-MAX | 1.6L(DURATEC-VCT) | ICM - Instrument Cluster | | X | X | | |
| All | FOCUS-C-MAX | 1.6L(DURATEC-VCT) | GEM - Generic electric module(CTM) | | X | X | | |
| All | FOCUS-C-MAX | 1.6L(DURATEC-VCT) | EPS - Electronic Controlled Power Steering | | X | X | | |
| All | FOCUS-C-MAX | 1.6L(TDCi/Duratorq-Turbo-Diesel-Common-Rail-Injection) | PCM - Powertrain Control Module | | X | X | | |
| All | FOCUS-C-MAX | 1.6L(TDCi/Duratorq-Turbo-Diesel-Common-Rail-Injection) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | | |
| All | FOCUS-C-MAX | 1.6L(TDCi/Duratorq-Turbo-Diesel-Common-Rail-Injection) | RCM - Restraint Control Module | | X | X | | |
| All | FOCUS-C-MAX | 1.6L(TDCi/Duratorq-Turbo-Diesel-Common-Rail-Injection) | TCM - Transmission Control Module | | X | X | | |
| All | FOCUS-C-MAX | 1.6L(TDCi/Duratorq-Turbo-Diesel-Common-Rail-Injection) | ICM - Instrument Cluster | | X | X | | |
| All | FOCUS-C-MAX | 1.6L(TDCi/Duratorq-Turbo-Diesel-Common-Rail-Injection) | GEM - Generic electric module(CTM) | | X | X | | |
| All | FOCUS-C-MAX | 1.6L(TDCi/Duratorq-Turbo-Diesel-Common-Rail-Injection) | EPS - Electronic Controlled Power Steering | | X | X | | |
| All | FOCUS-C-MAX | 1.6L(DURATEC-HE/I4) | PCM - Powertrain Control Module | | X | X | | |
| All | FOCUS-C-MAX | 1.6L(DURATEC-HE/I4) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | | |
| All | FOCUS-C-MAX | 1.6L(DURATEC-HE/I4) | RCM - Restraint Control Module | | X | X | | |
| All | FOCUS-C-MAX | 1.6L(DURATEC-HE/I4) | TCM - Transmission Control Module | | X | X | | |
| All | FOCUS-C-MAX | 1.6L(DURATEC-HE/I4) | ICM - Instrument Cluster | | X | X | | |
| All | FOCUS-C-MAX | 1.6L(DURATEC-HE/I4) | GEM - Generic electric module(CTM) | | X | X | | |

| | | | | | | | | |
|-----|-------------|--|---|--|---|---|---|--|
| All | FOCUS-C-MAX | 1.6L(DURATEC-HE/I4) | EPS - Electronic Controlled Power Steering | | X | X | | |
| All | FOCUS-C-MAX | 1.8L(DURATEC-HE/I4) | PCM - Powertrain Control Module | | X | X | | |
| All | FOCUS-C-MAX | 1.8L(TDCi/Duratorq-Turbo-Diesel-Common-Rail-Injection) | PCM - Powertrain Control Module | | X | X | | |
| All | FOCUS-C-MAX | 1.8L(TDCi/Duratorq-Turbo-Diesel-Common-Rail-Injection) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | | |
| All | FOCUS-C-MAX | 1.8L(TDCi/Duratorq-Turbo-Diesel-Common-Rail-Injection) | RCM - Restraint Control Module | | X | X | | |
| All | FOCUS-C-MAX | 1.8L(TDCi/Duratorq-Turbo-Diesel-Common-Rail-Injection) | TCM - Transmission Control Module | | X | X | | |
| All | FOCUS-C-MAX | 1.8L(TDCi/Duratorq-Turbo-Diesel-Common-Rail-Injection) | ICM - Instrument Cluster | | X | X | | |
| All | FOCUS-C-MAX | 1.8L(TDCi/Duratorq-Turbo-Diesel-Common-Rail-Injection) | GEM - Generic electric module(CTM) | | X | X | | |
| All | FOCUS-C-MAX | 1.8L(TDCi/Duratorq-Turbo-Diesel-Common-Rail-Injection) | EPS - Electronic Controlled Power Steering | | X | X | | |
| All | FOCUS-C-MAX | 2.0L(DURATEC-HE/I4) | PCM - Powertrain Control Module | | X | X | | |
| All | FOCUS-C-MAX | 2.0L(TDCi/Duratorq-Turbo-Diesel-Common-Rail-Injection) | PCM - Powertrain Control Module | | X | X | | |
| All | FOCUS-C-MAX | 2.0L(TDCi/Duratorq-Turbo-Diesel-Common-Rail-Injection) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | | |
| All | FOCUS-C-MAX | 2.0L(TDCi/Duratorq-Turbo-Diesel-Common-Rail-Injection) | RCM - Restraint Control Module | | X | X | | |
| All | FOCUS-C-MAX | 2.0L(TDCi/Duratorq-Turbo-Diesel-Common-Rail-Injection) | TCM - Transmission Control Module | | X | X | | |
| All | FOCUS-C-MAX | 2.0L(TDCi/Duratorq-Turbo-Diesel-Common-Rail-Injection) | ICM - Instrument Cluster | | X | X | | |
| All | FOCUS-C-MAX | 2.0L(TDCi/Duratorq-Turbo-Diesel-Common-Rail-Injection) | GEM - Generic electric module(CTM) | | X | X | | |
| All | FOCUS-C-MAX | 2.0L(TDCi/Duratorq-Turbo-Diesel-Common-Rail-Injection) | EPS - Electronic Controlled Power Steering | | X | X | | |
| All | FUSION | 1.25L(16V/DOHC) | PCM - Powertrain Control Module | | X | X | X | |
| All | FUSION | 1.25L(16V/DOHC) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| All | FUSION | 1.25L(16V/DOHC) | RCM - Restraint Control Module | | X | X | X | |
| All | FUSION | 1.25L(16V/DOHC) | ICM - Instrument Cluster | | X | X | X | |
| All | FUSION | 1.3L (DOHC/SOHC) | PCM - Powertrain Control Module | | X | X | X | |
| All | FUSION | 1.3L (DOHC/SOHC) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| All | FUSION | 1.3L (DOHC/SOHC) | RCM - Restraint Control Module | | X | X | X | |
| All | FUSION | 1.3L (DOHC/SOHC) | ICM - Instrument Cluster | | X | X | X | |
| All | FUSION | 1.4L (16V/16V DOHC/T-DIESEL) | PCM - Powertrain Control Module | | X | X | X | |
| All | FUSION | 1.4L (16V/16V DOHC/T-DIESEL) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |

| | | | | | | | | |
|-----|--------|------------------------------|---|--|---|---|---|--|
| AII | FUSION | 1.4L (16V/16V DOHC/T-DIESEL) | RCM - Restraint Control Module | | X | X | X | |
| AII | FUSION | 1.4L (16V/16V DOHC/T-DIESEL) | ICM - Instrument Cluster | | X | X | X | |
| AII | FUSION | 1.5L (DOHC) | PCM - Powertrain Control Module | | X | X | X | |
| AII | FUSION | 1.5L (DOHC) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| AII | FUSION | 1.5L (DOHC) | RCM - Restraint Control Module | | X | X | X | |
| AII | FUSION | 1.5L (DOHC) | ICM - Instrument Cluster | | X | X | X | |
| AII | FUSION | 1.6L (SFI) | PCM - Powertrain Control Module | | X | X | X | |
| AII | FUSION | 1.6L (SFI) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| AII | FUSION | 1.6L (SFI) | RCM - Restraint Control Module | | X | X | X | |
| AII | FUSION | 1.6L (SFI) | ICM - Instrument Cluster | | X | X | X | |
| AII | GALAXY | 1.9L (T-DIESEL) | PCM - Powertrain Control Module | | X | | | |
| AII | GALAXY | 1.9L (T-DIESEL) | TCM - Transmission Control Module | | X | | | |
| AII | GALAXY | 1.9L (T-DIESEL) | ABS - Anti-Lock Brake / Traction Control Module | | X | | | |
| AII | GALAXY | 1.9L (T-DIESEL) | RCM - Restraint Control Module | | X | | | |
| AII | GALAXY | 1.9L (T-DIESEL) | ICM - Instrument Cluster | | X | | | |
| AII | GALAXY | 1.9L (T-DIESEL) | NAV - Navigation System | | X | | | |
| AII | GALAXY | 2.0L (DOHC) | PCM - Powertrain Control Module | | X | | | |
| AII | GALAXY | 2.0L (DOHC) | TCM - Transmission Control Module | | X | | | |
| AII | GALAXY | 2.0L (DOHC) | ABS - Anti-Lock Brake / Traction Control Module | | X | | | |
| AII | GALAXY | 2.0L (DOHC) | RCM - Restraint Control Module | | X | | | |
| AII | GALAXY | 2.0L (DOHC) | ICM - Instrument Cluster | | X | | | |
| AII | GALAXY | 2.0L (DOHC) | NAV - Navigation System | | X | | | |
| AII | GALAXY | 2.8L (CD-24V-V6) | PCM - Powertrain Control Module | | X | | | |
| AII | GALAXY | 2.8L (CD-24V-V6) | TCM - Transmission Control Module | | X | | | |
| AII | GALAXY | 2.8L (CD-24V-V6) | ABS - Anti-Lock Brake / Traction Control Module | | X | | | |
| AII | GALAXY | 2.8L (CD-24V-V6) | RCM - Restraint Control Module | | X | | | |
| AII | GALAXY | 2.8L (CD-24V-V6) | ICM - Instrument Cluster | | X | | | |
| AII | GALAXY | 2.8L (CD-24V-V6) | NAV - Navigation System | | X | | | |
| AII | KA | 1.0L | PCM - Powertrain Control Module | | X | X | | |
| AII | KA | 1.0L | ABS - Anti-Lock Brake / Traction Control Module | | X | X | | |
| AII | KA | 1.0L | ECS - Electronic Crash Sensor(or IABM) | | X | X | | |
| AII | KA | 1.0L | ICM - Instrument Cluster | | X | X | | |
| AII | KA | 1.0L | EPS - Electronic Controlled Power Steering | | X | X | | |
| AII | KA | 1.0L | GEM - Generic electric module(CTM) | | X | X | | |
| AII | KA | 1.0L | PATS - Passive Anti-Theft System | | X | X | | |
| AII | KA | 1.3L | PCM - Powertrain Control Module | | X | X | | |
| AII | KA | 1.3L | ABS - Anti-Lock Brake / Traction Control Module | | X | X | | |
| AII | KA | 1.3L | ECS - Electronic Crash Sensor(or IABM) | | X | X | | |
| AII | KA | 1.3L | ICM - Instrument Cluster | | X | X | | |
| AII | KA | 1.3L | EPS - Electronic Controlled Power Steering | | X | X | | |
| AII | KA | 1.3L | GEM - Generic electric module(CTM) | | X | X | | |
| AII | KA | 1.3L | PATS - Passive Anti-Theft System | | X | X | | |
| AII | KA | 1.6L | PCM - Powertrain Control Module | | X | X | | |
| AII | KA | 1.6L | ABS - Anti-Lock Brake / Traction Control Module | | X | X | | |
| AII | KA | 1.6L | ECS - Electronic Crash Sensor(or IABM) | | X | X | | |

| | | | | | | | | |
|-----|------------------------|------|---|--|---|---|--|--|
| AII | KA | 1.6L | ICM - Instrument Cluster | | X | X | | |
| AII | KA | 1.6L | EPS - Electronic Controlled Power Steering | | X | X | | |
| AII | KA | 1.6L | GEM - Generic electric module(CTM) | | X | X | | |
| AII | KA | 1.6L | PATS - Passive Anti-Theft System | | X | X | | |
| AII | KA | 1.7L | PCM - Powertrain Control Module | | X | X | | |
| AII | KA | 1.7L | ABS - Anti-Lock Brake / Traction Control Module | | X | X | | |
| AII | KA | 1.7L | ECS - Electronic Crash Sensor(or IABM) | | X | X | | |
| AII | KA | 1.7L | ICM - Instrument Cluster | | X | X | | |
| AII | KA | 1.7L | EPS - Electronic Controlled Power Steering | | X | X | | |
| AII | KA | 1.7L | GEM - Generic electric module(CTM) | | X | X | | |
| AII | KA | 1.7L | PATS - Passive Anti-Theft System | | X | X | | |
| AII | MAVERICK | 2.0L | PCM - Powertrain Control Module | | X | X | | |
| AII | MAVERICK | 2.0L | ABS - Anti-Lock Brake / Traction Control Module | | X | X | | |
| AII | MAVERICK | 2.0L | RCM - Restraint Control Module | | X | X | | |
| AII | MAVERICK | 2.0L | GEM - Generic electric module(CTM) | | X | X | | |
| AII | MAVERICK | 2.0L | PAM - Parking Aid Module | | X | X | | |
| AII | MAVERICK | 2.0L | 4X4M - 4X4 Control Module | | X | X | | |
| AII | MAVERICK | 2.3L | PCM - Powertrain Control Module | | X | X | | |
| AII | MAVERICK | 2.3L | ABS - Anti-Lock Brake / Traction Control Module | | X | X | | |
| AII | MAVERICK | 2.3L | RCM - Restraint Control Module | | X | X | | |
| AII | MAVERICK | 2.3L | GEM - Generic electric module(CTM) | | X | X | | |
| AII | MAVERICK | 2.3L | PAM - Parking Aid Module | | X | X | | |
| AII | MAVERICK | 2.3L | 4X4M - 4X4 Control Module | | X | X | | |
| AII | MAVERICK | 3.0L | PCM - Powertrain Control Module | | X | X | | |
| AII | MAVERICK | 3.0L | ABS - Anti-Lock Brake / Traction Control Module | | X | X | | |
| AII | MAVERICK | 3.0L | RCM - Restraint Control Module | | X | X | | |
| AII | MAVERICK | 3.0L | GEM - Generic electric module(CTM) | | X | X | | |
| AII | MAVERICK | 3.0L | PAM - Parking Aid Module | | X | X | | |
| AII | MAVERICK | 3.0L | 4X4M - 4X4 Control Module | | X | X | | |
| AII | F-SERIES SUPER DUTY | 5.4L | PCM - Powertrain Control Module | | X | | | |
| AII | F-SERIES SUPER DUTY | 5.4L | ABS - Anti-Lock Brake / Traction Control Module | | X | X | | |
| AII | F-SERIES SUPER DUTY | 5.4L | RCM - Restraint Control Module | | X | X | | |
| AII | F-SERIES SUPER DUTY | 5.4L | TCM - Transmission Control Module | | X | X | | |
| AII | F-SERIES SUPER DUTY | 5.4L | ICM - Instrument Cluster | | X | X | | |
| AII | F-SERIES SUPER DUTY | 5.4L | GEM - Generic electric module(CTM) | | X | X | | |
| AII | F-SERIES SUPER DUTY | 5.4L | PATS - Passive Anti-Theft System | | X | X | | |

| | | | | | | | | |
|-----|------------------------|--------------------|---|--|---|---|---|---|
| All | F-SERIES SUPER DUTY | 6.0L | PCM - Powertrain Control Module | | X | | | |
| All | F-SERIES SUPER DUTY | 6.0L | ABS - Anti-Lock Brake / Traction Control Module | | X | X | | |
| All | F-SERIES SUPER DUTY | 6.0L | RCM - Restraint Control Module | | X | X | | |
| All | F-SERIES SUPER DUTY | 6.0L | TCM - Transmission Control Module | | X | X | | |
| All | F-SERIES SUPER DUTY | 6.0L | ICM - Instrument Cluster | | X | X | | |
| All | F-SERIES SUPER DUTY | 6.0L | GEM - Generic electric module(CTM) | | X | X | | |
| All | F-SERIES SUPER DUTY | 6.0L | PATS - Passive Anti-Theft System | | X | X | | |
| All | F-SERIES SUPER DUTY | 6.8L | PCM - Powertrain Control Module | | X | | | |
| All | F-SERIES SUPER DUTY | 6.8L | ABS - Anti-Lock Brake / Traction Control Module | | X | X | | |
| All | F-SERIES SUPER DUTY | 6.8L | RCM - Restraint Control Module | | X | X | | |
| All | F-SERIES SUPER DUTY | 6.8L | TCM - Transmission Control Module | | X | X | | |
| All | F-SERIES SUPER DUTY | 6.8L | ICM - Instrument Cluster | | X | X | | |
| All | F-SERIES SUPER DUTY | 6.8L | GEM - Generic electric module(CTM) | | X | X | | |
| All | F-SERIES SUPER DUTY | 6.8L | PATS - Passive Anti-Theft System | | X | X | | |
| All | F-SERIES SUPER DUTY | 7.3L | PCM - Powertrain Control Module | | X | | | |
| All | F-SERIES SUPER DUTY | 7.3L | ABS - Anti-Lock Brake / Traction Control Module | | X | X | | |
| All | F-SERIES SUPER DUTY | 7.3L | RCM - Restraint Control Module | | X | X | | |
| All | F-SERIES SUPER DUTY | 7.3L | TCM - Transmission Control Module | | X | X | | |
| All | F-SERIES SUPER DUTY | 7.3L | ICM - Instrument Cluster | | X | X | | |
| All | F-SERIES SUPER DUTY | 7.3L | GEM - Generic electric module(CTM) | | X | X | | |
| All | F-SERIES SUPER DUTY | 7.3L | PATS - Passive Anti-Theft System | | X | X | | |
| All | MONDEO | 1.6L (DURATEC VCT) | PCM - Powertrain Control Module | | X | X | X | 1.Fuel Injector Coding. 2.Key Programming. |

| | | | | | | | | |
|-----|--------|------------------------------------|---|--|---|---|---|---|
| AII | MONDEO | 1.6L (DURATEC VCT) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| AII | MONDEO | 1.6L (DURATEC VCT) | RCM - Restraint Control Module | | X | X | X | |
| AII | MONDEO | 1.6L (DURATEC VCT) | GEM - Generic electric module(CTM) | | X | X | X | |
| AII | MONDEO | 1.6L (DURATEC VCT) | PATS - Passive Anti-Theft System | | X | X | X | |
| AII | MONDEO | 1.6L (DURATEC VCT) | ICM - Instrument Cluster | | X | X | X | |
| AII | MONDEO | 1.6L (DURATEC VCT) | ACM - Audio Control Module | | X | X | X | |
| AII | MONDEO | 1.6L (DURATEC VCT) | EATC - Electronic Automatic Temperature Control | | X | X | X | |
| AII | MONDEO | 1.6L (DURATEC VCT) | PATS - Passive Anti-Theft System | | X | | | 1.Key Programming. |
| AII | MONDEO | 1.8L (DURATEC-SC/DURATEC-HE) | PCM - Powertrain Control Module | | X | X | X | 1.Fuel Injector Coding. 2.Key Programming. |
| AII | MONDEO | 1.8L (DURATEC-SC/DURATEC-HE) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| AII | MONDEO | 1.8L (DURATEC-SC/DURATEC-HE) | RCM - Restraint Control Module | | X | X | X | |
| AII | MONDEO | 1.8L (DURATEC-SC/DURATEC-HE) | GEM - Generic electric module(CTM) | | X | X | X | |
| AII | MONDEO | 1.8L (DURATEC-SC/DURATEC-HE) | HEC - Hybrid Electronic Cluster | | X | X | X | |
| AII | MONDEO | 1.8L (DURATEC-SC/DURATEC-HE) | ICM - Instrument Cluster | | X | X | X | |
| AII | MONDEO | 1.8L (DURATEC-SC/DURATEC-HE) | ACM - Audio Control Module | | X | X | X | |
| AII | MONDEO | 1.8L (DURATEC-SC/DURATEC-HE) | EATC - Electronic Automatic Temperature Control | | X | X | X | |
| AII | MONDEO | 1.8L (DURATEC-SC/DURATEC-HE) | PATS - Passive Anti-Theft System | | X | | | 1.Key Programming. |
| AII | MONDEO | 2.0L (DURATORQ TDDI/DURATORQ TDCI) | PCM - Powertrain Control Module | | X | X | X | |
| AII | MONDEO | 2.0L (DURATORQ TDDI/DURATORQ TDCI) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| AII | MONDEO | 2.0L (DURATORQ TDDI/DURATORQ TDCI) | RCM - Restraint Control Module | | X | X | X | |
| AII | MONDEO | 2.0L (DURATORQ TDDI/DURATORQ TDCI) | GEM - Generic electric module(CTM) | | X | X | X | |
| AII | MONDEO | 2.0L (DURATORQ TDDI/DURATORQ TDCI) | HEC - Hybrid Electronic Cluster | | X | X | X | |
| AII | MONDEO | 2.0L (DURATORQ TDDI/DURATORQ TDCI) | ICM - Instrument Cluster | | X | X | X | |
| AII | MONDEO | 2.0L (DURATORQ TDDI/DURATORQ TDCI) | ACM - Audio Control Module | | X | X | X | |
| AII | MONDEO | 2.0L (DURATORQ TDDI/DURATORQ TDCI) | EATC - Electronic Automatic Temperature Control | | X | X | X | |
| AII | MONDEO | 2.0L (DURATORQ TDDI/DURATORQ TDCI) | PATS - Passive Anti-Theft System | | X | | | 1.Key Programming. |
| AII | MONDEO | 2.2L (DURATORQ TDCI) | PCM - Powertrain Control Module | | X | X | X | 1.Fuel Injector Coding. 2.Key Programming. |
| AII | MONDEO | 2.2L (DURATORQ TDCI) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| AII | MONDEO | 2.2L (DURATORQ TDCI) | RCM - Restraint Control Module | | X | X | X | |
| AII | MONDEO | 2.2L (DURATORQ TDCI) | GEM - Generic electric module(CTM) | | X | X | X | |
| AII | MONDEO | 2.2L (DURATORQ TDCI) | HEC - Hybrid Electronic Cluster | | X | X | X | |
| AII | MONDEO | 2.2L (DURATORQ TDCI) | ICM - Instrument Cluster | | X | X | X | |
| AII | MONDEO | 2.2L (DURATORQ TDCI) | ACM - Audio Control Module | | X | X | X | |

| | | | | | | | | |
|-----|---------|-----------------------------|---|--|---|---|---|---|
| AII | MONDEO | 2.2L (DURATORQ TDCI) | EATC - Electronic Automatic Temperature Control | | X | X | X | |
| AII | MONDEO | 2.2L (DURATORQ TDCI) | PATS - Passive Anti-Theft System | | X | | | 1.Key Programming. |
| AII | MONDEO | 2.3L (DURATEC-HE/I4) | PCM - Powertrain Control Module | | X | X | X | 1.Fuel Injector Coding. 2.Key Programming. |
| AII | MONDEO | 2.3L (DURATEC-HE/I4) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| AII | MONDEO | 2.3L (DURATEC-HE/I4) | RCM - Restraint Control Module | | X | X | X | |
| AII | MONDEO | 2.3L (DURATEC-HE/I4) | GEM - Generic electric module(CTM) | | X | X | X | |
| AII | MONDEO | 2.3L (DURATEC-HE/I4) | HEC - Hybrid Electronic Cluster | | X | X | X | |
| AII | MONDEO | 2.3L (DURATEC-HE/I4) | ICM - Instrument Cluster | | X | X | X | |
| AII | MONDEO | 2.3L (DURATEC-HE/I4) | ACM - Audio Control Module | | X | X | X | |
| AII | MONDEO | 2.3L (DURATEC-HE/I4) | EATC - Electronic Automatic Temperature Control | | X | X | X | |
| AII | MONDEO | 2.3L (DURATEC-HE/I4) | PATS - Passive Anti-Theft System | | X | | | 1.Key Programming. |
| AII | MONDEO | 2.5L (DURATEC/DURATEC-VE) | PCM - Powertrain Control Module | | X | X | X | |
| AII | MONDEO | 2.5L (DURATEC/DURATEC-VE) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| AII | MONDEO | 2.5L (DURATEC/DURATEC-VE) | RCM - Restraint Control Module | | X | X | X | |
| AII | MONDEO | 2.5L (DURATEC/DURATEC-VE) | GEM - Generic electric module(CTM) | | X | X | X | |
| AII | MONDEO | 2.5L (DURATEC/DURATEC-VE) | HEC - Hybrid Electronic Cluster | | X | X | X | |
| AII | MONDEO | 2.5L (DURATEC/DURATEC-VE) | ICM - Instrument Cluster | | X | X | X | |
| AII | MONDEO | 2.5L (DURATEC/DURATEC-VE) | ACM - Audio Control Module | | X | X | X | |
| AII | MONDEO | 2.5L (DURATEC/DURATEC-VE) | EATC - Electronic Automatic Temperature Control | | X | X | X | |
| AII | MONDEO | 2.5L (DURATEC/DURATEC-VE) | PATS - Passive Anti-Theft System | | X | | | 1.Key Programming. |
| AII | MONDEO | 3.0L (DURATEC/DURATEC-ST) | PCM - Powertrain Control Module | | X | X | X | |
| AII | MONDEO | 3.0L (DURATEC/DURATEC-ST) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| AII | MONDEO | 3.0L (DURATEC/DURATEC-ST) | RCM - Restraint Control Module | | X | X | X | |
| AII | MONDEO | 3.0L (DURATEC/DURATEC-ST) | GEM - Generic electric module(CTM) | | X | X | X | |
| AII | MONDEO | 3.0L (DURATEC/DURATEC-ST) | HEC - Hybrid Electronic Cluster | | X | X | X | |
| AII | MONDEO | 3.0L (DURATEC/DURATEC-ST) | ICM - Instrument Cluster | | X | X | X | |
| AII | MONDEO | 3.0L (DURATEC/DURATEC-ST) | ACM - Audio Control Module | | X | X | X | |
| AII | MONDEO | 3.0L (DURATEC/DURATEC-ST) | EATC - Electronic Automatic Temperature Control | | X | X | X | |
| AII | MONDEO | 3.0L (DURATEC/DURATEC-ST) | PATS - Passive Anti-Theft System | | X | | X | |
| AII | RANGER | 2.5L (DIESEL/T-DIESEL) | PCM - Powertrain Control Module | | X | X | X | |
| AII | RANGER | 2.5L (DIESEL/T-DIESEL) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| AII | RANGER | 2.5L (DIESEL/T-DIESEL) | RCM - Restraint Control Module | | X | X | X | |
| AII | RANGER | 2.5L (DIESEL/T-DIESEL) | GEM - Generic electric module(CTM) | | X | X | X | |
| AII | RANGER | 2.5L (DIESEL/T-DIESEL) | HEC - Hybrid Electronic Cluster | | X | X | X | |
| AII | RANGER | 2.5L (DIESEL/T-DIESEL) | PATS - Passive Anti-Theft System | | X | X | X | |
| AII | TRANSIT | 2.0L (DIESEL/ALT FUEL/TDCI) | PCM - Powertrain Control Module | | X | X | X | |
| AII | TRANSIT | 2.0L (DIESEL/ALT FUEL/TDCI) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| AII | TRANSIT | 2.0L (DIESEL/ALT FUEL/TDCI) | RCM - Restraint Control Module | | X | X | X | |
| AII | TRANSIT | 2.0L (DIESEL/ALT FUEL/TDCI) | BEM - Body electronic module | | X | X | X | |
| AII | TRANSIT | 2.0L (DIESEL/ALT FUEL/TDCI) | ICM - Instrument Cluster | | X | X | X | |
| AII | TRANSIT | 2.0L (DIESEL/ALT FUEL/TDCI) | ACM - Audio Control Module | | X | X | X | |
| AII | TRANSIT | 2.3L (DIESEL) | PCM - Powertrain Control Module | | X | X | X | |
| AII | TRANSIT | 2.3L (DIESEL) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |

| | | | | | | | | |
|-----|----------------------------------|--------------------|---|--|---|---|---|--|
| All | TRANSIT | 2.3L (DIESEL) | RCM - Restraint Control Module | | X | X | X | |
| All | TRANSIT | 2.3L (DIESEL) | BEM - Body electronic module | | X | X | X | |
| All | TRANSIT | 2.3L (DIESEL) | ICM - Instrument Cluster | | X | X | X | |
| All | TRANSIT | 2.3L (DIESEL) | ACM - Audio Control Module | | X | X | X | |
| All | TRANSIT | 2.4L (DIESEL/TDCI) | PCM - Powertrain Control Module | | X | X | X | |
| All | TRANSIT | 2.4L (DIESEL/TDCI) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| All | TRANSIT | 2.4L (DIESEL/TDCI) | RCM - Restraint Control Module | | X | X | X | |
| All | TRANSIT | 2.4L (DIESEL/TDCI) | BEM - Body electronic module | | X | X | X | |
| All | TRANSIT | 2.4L (DIESEL/TDCI) | ICM - Instrument Cluster | | X | X | X | |
| All | TRANSIT | 2.4L (DIESEL/TDCI) | ACM - Audio Control Module | | X | X | X | |
| All | TRANSIT | 2.4L (DIESEL/TDCI) | PCM - Powertrain Control Module | | X | X | X | |
| All | TRANSIT | 2.4L (DIESEL/TDCI) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| All | TRANSIT | 2.4L (DIESEL/TDCI) | RCM - Restraint Control Module | | X | X | X | |
| All | TRANSIT | 2.4L (DIESEL/TDCI) | BEM - Body electronic module | | X | X | X | |
| All | TRANSIT | 2.4L (DIESEL/TDCI) | ICM - Instrument Cluster | | X | X | X | |
| All | TRANSIT | 2.4L (DIESEL/TDCI) | ACM - Audio Control Module | | X | X | X | |
| All | TRANSIT-CONNECT/TO URNEO-CONNECT | 1.8L(TDCI) | PCM - Powertrain Control Module | | X | X | | |
| All | TRANSIT-CONNECT/TO URNEO-CONNECT | 1.8L(TDCI) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | | |
| All | TRANSIT-CONNECT/TO URNEO-CONNECT | 1.8L(TDCI) | RCM - Restraint Control Module | | X | X | | |
| All | TRANSIT-CONNECT/TO URNEO-CONNECT | 1.8L(TDCI) | ICM - Instrument Cluster | | X | X | | |
| All | EXPEDITION | 5.4L(3V) | PCM - Powertrain Control Module | | X | X | | |
| All | EXPEDITION | 5.4L(3V) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | | |
| All | EXPEDITION | 5.4L(3V) | RCM - Restraint Control Module | | X | X | | |
| All | EXPEDITION | 5.4L(3V) | TCM - Transmission Control Module | | X | X | | |
| All | EXPEDITION | 5.4L(3V) | ICM - Instrument Cluster | | X | X | | |
| All | EXPEDITION | 5.4L(3V) | GEM - Generic electric module(CTM) | | X | X | | |
| All | CROWN-VICTORIA | 4.6L(2V) | PCM - Powertrain Control Module | | X | X | | |
| All | CROWN-VICTORIA | 4.6L(2V) | RCM - Restraint Control Module | | X | X | | |
| All | KA | 1.2L | PCM - Powertrain Control Module | | X | | | |
| All | KA | 1.2L | ABS - Anti-Lock Brake / Traction Control Module | | X | X | | |

| | | | | | | | | |
|-----|------------------------|------|---|--|---|---|--|--|
| All | KA | 1.2L | EPS - Electronic Power Steering | | X | X | | |
| All | KA | 1.2L | ECS - Electronic Crash Sensor(or IABM) | | X | X | | |
| All | KA | 1.2L | GEM – Generic Electronic Module(or CTM) | | X | X | | |
| All | KA | 1.2L | PATS – Passive Anti-Theft System | | X | X | | |
| All | KA | 1.3L | PCM - Powertrain Control Module | | X | | | |
| All | KA | 1.3L | ABS - Anti-Lock Brake / Traction Control Module | | X | X | | |
| All | KA | 1.3L | EPS - Electronic Power Steering | | X | X | | |
| All | KA | 1.3L | ECS - Electronic Crash Sensor(or IABM) | | X | X | | |
| All | KA | 1.3L | GEM – Generic Electronic Module(or CTM) | | X | X | | |
| All | KA | 1.3L | PATS – Passive Anti-Theft System | | X | X | | |
| All | F-SERIES SUPER DUTY | 5.4L | PCM - Powertrain Control Module | | X | | | |
| All | F-SERIES SUPER DUTY | 5.4L | ABS - Anti-Lock Brake / Traction Control Module | | X | X | | |
| All | F-SERIES SUPER DUTY | 5.4L | RCM - Restraint Control Module | | X | X | | |
| All | F-SERIES SUPER DUTY | 5.4L | GEM - Generic Electronic Module | | X | X | | |
| All | F-SERIES SUPER DUTY | 5.4L | ICM - Instrument Cluster Module | | X | X | | |
| All | F-SERIES SUPER DUTY | 5.4L | TCM - Transmission Control Module | | X | X | | |
| All | F-SERIES SUPER DUTY | 5.4L | PATS–Passive Anti-Theft System | | X | X | | |
| All | F-SERIES SUPER DUTY | 6.0L | PCM - Powertrain Control Module | | X | | | |
| All | F-SERIES SUPER DUTY | 6.0L | ABS - Anti-Lock Brake / Traction Control Module | | X | X | | |
| All | F-SERIES SUPER DUTY | 6.0L | RCM - Restraint Control Module | | X | X | | |
| All | F-SERIES SUPER DUTY | 6.0L | GEM - Generic Electronic Module | | X | X | | |
| All | F-SERIES SUPER DUTY | 6.0L | ICM - Instrument Cluster Module | | X | X | | |
| All | F-SERIES SUPER DUTY | 6.0L | TCM - Transmission Control Module | | X | X | | |
| All | F-SERIES SUPER DUTY | 6.0L | PATS–Passive Anti-Theft System | | X | X | | |
| All | F-SERIES SUPER DUTY | 6.8L | PCM - Powertrain Control Module | | X | | | |
| All | F-SERIES SUPER DUTY | 6.8L | ABS - Anti-Lock Brake / Traction Control Module | | X | X | | |
| All | F-SERIES SUPER DUTY | 6.8L | RCM - Restraint Control Module | | X | X | | |

| | | | | | | | | |
|-----|------------------------|--------------------|---|--|---|---|---|--|
| All | F-SERIES SUPER DUTY | 6.8L | GEM - Generic Electronic Module | | X | X | | |
| All | F-SERIES SUPER DUTY | 6.8L | ICM - Instrument Cluster Module | | X | X | | |
| All | F-SERIES SUPER DUTY | 6.8L | TCM - Transmission Control Module | | X | X | | |
| All | F-SERIES SUPER DUTY | 6.8L | PATS—Passive Anti-Theft System | | X | X | | |
| All | F-SERIES SUPER DUTY | 7.3L | PCM - Powertrain Control Module | | X | | | |
| All | F-SERIES SUPER DUTY | 7.3L | ABS - Anti-Lock Brake / Traction Control Module | | X | X | | |
| All | F-SERIES SUPER DUTY | 7.3L | RCM - Restraint Control Module | | X | X | | |
| All | F-SERIES SUPER DUTY | 7.3L | GEM - Generic Electronic Module | | X | X | | |
| All | F-SERIES SUPER DUTY | 7.3L | ICM - Instrument Cluster Module | | X | X | | |
| All | F-SERIES SUPER DUTY | 7.3L | TCM - Transmission Control Module | | X | X | | |
| All | F-SERIES SUPER DUTY | 7.3L | PATS—Passive Anti-Theft System | | X | X | | |
| All | MAVERICK | 2.0L | PCM - Powertrain Control Module | | X | X | | |
| All | MAVERICK | 2.0L | ABS - Anti-Lock Brake / Traction Control Module | | X | X | | |
| All | MAVERICK | 2.0L | RCM - Restraint Control Module | | X | X | | |
| All | MAVERICK | 2.0L | GEM - Generic Electronic Module | | X | X | | |
| All | MAVERICK | 2.0L | PAM - Parking Aid Module | | X | X | | |
| All | MAVERICK | 2.0L | 4X4M - 4X4 Control Module | | X | X | | |
| All | MAVERICK | 2.3L | PCM - Powertrain Control Module | | X | X | | |
| All | MAVERICK | 2.3L | ABS - Anti-Lock Brake / Traction Control Module | | X | X | | |
| All | MAVERICK | 2.3L | RCM - Restraint Control Module | | X | X | | |
| All | MAVERICK | 2.3L | GEM - Generic Electronic Module | | X | X | | |
| All | MAVERICK | 2.3L | PAM - Parking Aid Module | | X | X | | |
| All | MAVERICK | 2.3L | 4X4M - 4X4 Control Module | | X | X | | |
| All | MAVERICK | 3.0L | PCM - Powertrain Control Module | | X | X | | |
| All | MAVERICK | 3.0L | ABS - Anti-Lock Brake / Traction Control Module | | X | X | | |
| All | MAVERICK | 3.0L | RCM - Restraint Control Module | | X | X | | |
| All | MAVERICK | 3.0L | GEM - Generic Electronic Module | | X | X | | |
| All | MAVERICK | 3.0L | PAM - Parking Aid Module | | X | X | | |
| All | MAVERICK | 3.0L | 4X4M - 4X4 Control Module | | X | X | | |
| All | FOCUS | 1.4L (DURATEC 16V) | PCM - Powertrain Control Module | | X | X | X | |
| All | FOCUS | 1.4L (DURATEC 16V) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| All | FOCUS | 1.4L (DURATEC 16V) | RCM - Restraint Control Module | | X | X | X | |
| All | FOCUS | 1.4L (DURATEC 16V) | ICM - Instrument Cluster | | X | X | X | |

| | | | | | | | | |
|-----|-------|-------------------------------------|---|--|---|---|---|--|
| AII | FOCUS | 1.4L (DURATEC 16V) | TCM - Transmission Control Module | | X | X | X | |
| AII | FOCUS | 1.4L (DURATEC 16V) | EPS - Electronic Controlled Power Steering | | X | X | X | |
| AII | FOCUS | 1.4L (DURATEC 16V) | PATS - Passive Anti-Theft System | | X | X | X | |
| AII | FOCUS | 1.4L (DURATEC 16V) | EATC - Electronic Automatic Temperature Control | | X | X | X | |
| AII | FOCUS | 1.6L (DURATEC 16V/DURATEC VCT/TDCI) | PCM - Powertrain Control Module | | X | X | X | |
| AII | FOCUS | 1.6L (DURATEC 16V/DURATEC VCT/TDCI) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| AII | FOCUS | 1.6L (DURATEC 16V/DURATEC VCT/TDCI) | RCM - Restraint Control Module | | X | X | X | |
| AII | FOCUS | 1.6L (DURATEC 16V/DURATEC VCT/TDCI) | ICM - Instrument Cluster | | X | X | X | |
| AII | FOCUS | 1.6L (DURATEC 16V/DURATEC VCT/TDCI) | TCM - Transmission Control Module | | X | X | X | |
| AII | FOCUS | 1.6L (DURATEC 16V/DURATEC VCT/TDCI) | EPS - Electronic Controlled Power Steering | | X | X | X | |
| AII | FOCUS | 1.6L (DURATEC 16V/DURATEC VCT/TDCI) | PATS - Passive Anti-Theft System | | X | X | X | |
| AII | FOCUS | 1.6L (DURATEC 16V/DURATEC VCT/TDCI) | EATC - Electronic Automatic Temperature Control | | X | X | X | |
| AII | FOCUS | 1.8L (DURATEC-HE/I4/TDCI) | PCM - Powertrain Control Module | | X | X | X | |
| AII | FOCUS | 1.8L (DURATEC-HE/I4/TDCI) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| AII | FOCUS | 1.8L (DURATEC-HE/I4/TDCI) | RCM - Restraint Control Module | | X | X | X | |
| AII | FOCUS | 1.8L (DURATEC-HE/I4/TDCI) | ICM - Instrument Cluster | | X | X | X | |
| AII | FOCUS | 1.8L (DURATEC-HE/I4/TDCI) | TCM - Transmission Control Module | | X | X | X | |
| AII | FOCUS | 1.8L (DURATEC-HE/I4/TDCI) | EPS - Electronic Controlled Power Steering | | X | X | X | |
| AII | FOCUS | 1.8L (DURATEC-HE/I4/TDCI) | PATS - Passive Anti-Theft System | | X | X | X | |
| AII | FOCUS | 1.8L (DURATEC-HE/I4/TDCI) | EATC - Electronic Automatic Temperature Control | | X | X | X | |
| AII | FOCUS | 2.0L (DURATEC-HE/I4/TDCI) | PCM - Powertrain Control Module | | X | X | X | |
| AII | FOCUS | 2.0L (DURATEC-HE/I4/TDCI) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| AII | FOCUS | 2.0L (DURATEC-HE/I4/TDCI) | RCM - Restraint Control Module | | X | X | X | |
| AII | FOCUS | 2.0L (DURATEC-HE/I4/TDCI) | ICM - Instrument Cluster | | X | X | X | |
| AII | FOCUS | 2.0L (DURATEC-HE/I4/TDCI) | TCM - Transmission Control Module | | X | X | X | |
| AII | FOCUS | 2.0L (DURATEC-HE/I4/TDCI) | EPS - Electronic Controlled Power Steering | | X | X | X | |
| AII | FOCUS | 2.0L (DURATEC-HE/I4/TDCI) | PATS - Passive Anti-Theft System | | X | X | X | |
| AII | FOCUS | 2.0L (DURATEC-HE/I4/TDCI) | EATC - Electronic Automatic Temperature Control | | X | X | X | |
| AII | FOCUS | 2.0L (I5) | PCM - Powertrain Control Module | | X | X | X | |
| AII | FOCUS | 2.0L (I5) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| AII | FOCUS | 2.0L (I5) | RCM - Restraint Control Module | | X | X | X | |
| AII | FOCUS | 2.0L (I5) | ICM - Instrument Cluster | | X | X | X | |
| AII | FOCUS | 2.0L (I5) | TCM - Transmission Control Module | | X | X | X | |
| AII | FOCUS | 2.0L (I5) | EPS - Electronic Controlled Power Steering | | X | X | X | |
| AII | FOCUS | 2.0L (I5) | PATS - Passive Anti-Theft System | | X | X | X | |
| AII | FOCUS | 2.0L (I5) | EATC - Electronic Automatic Temperature Control | | X | X | X | |

| | | | | | | | | |
|-----|-------------|---------------------|---|--|---|---|---|--|
| All | FOCUS | 2.5L (Duratec RS) | PCM - Powertrain Control Module | | X | X | X | |
| All | FOCUS | 2.5L (Duratec RS) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| All | FOCUS | 2.5L (Duratec RS) | RCM - Restraint Control Module | | X | X | X | |
| All | FOCUS | 2.5L (Duratec RS) | ICM - Instrument Cluster | | X | X | X | |
| All | FOCUS | 2.5L (Duratec RS) | TCM - Transmission Control Module | | X | X | X | |
| All | FOCUS | 2.5L (Duratec RS) | EPS - Electronic Controlled Power Steering | | X | X | X | |
| All | FOCUS | 2.5L (Duratec RS) | PATS - Passive Anti-Theft System | | X | X | X | |
| All | FOCUS | 2.5L (Duratec RS) | EATC - Electronic Automatic Temperature Control | | X | X | X | |
| All | FOCUS-C-MAX | 1.6L(DURATEC-16V) | PCM - Powertrain Control Module | | X | X | | |
| All | FOCUS-C-MAX | 1.6L(DURATEC-16V) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | | |
| All | FOCUS-C-MAX | 1.6L(DURATEC-16V) | RCM - Restraint Control Module | | X | X | | |
| All | FOCUS-C-MAX | 1.6L(DURATEC-16V) | TCM - Transmission Control Module | | X | X | | |
| All | FOCUS-C-MAX | 1.6L(DURATEC-16V) | ICM - Instrument Cluster | | X | X | | |
| All | FOCUS-C-MAX | 1.6L(DURATEC-16V) | GEM - Generic Electronic Module | | X | X | | |
| All | FOCUS-C-MAX | 1.6L(DURATEC-16V) | EPS - Electronic Power Steering | | X | X | | |
| All | FOCUS-C-MAX | 1.6L(DURATEC-VCT) | PCM - Powertrain Control Module | | X | X | | |
| All | FOCUS-C-MAX | 1.6L(DURATEC-VCT) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | | |
| All | FOCUS-C-MAX | 1.6L(DURATEC-VCT) | RCM - Restraint Control Module | | X | X | | |
| All | FOCUS-C-MAX | 1.6L(DURATEC-VCT) | TCM - Transmission Control Module | | X | X | | |
| All | FOCUS-C-MAX | 1.6L(DURATEC-VCT) | ICM - Instrument Cluster | | X | X | | |
| All | FOCUS-C-MAX | 1.6L(DURATEC-VCT) | GEM - Generic Electronic Module | | X | X | | |
| All | FOCUS-C-MAX | 1.6L(DURATEC-VCT) | EPS - Electronic Power Steering | | X | X | | |
| All | FOCUS-C-MAX | 1.6L(DURATEC-HE/I4) | PCM - Powertrain Control Module | | X | X | | |
| All | FOCUS-C-MAX | 1.6L(DURATEC-HE/I4) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | | |
| All | FOCUS-C-MAX | 1.6L(DURATEC-HE/I4) | RCM - Restraint Control Module | | X | X | | |
| All | FOCUS-C-MAX | 1.6L(DURATEC-HE/I4) | TCM - Transmission Control Module | | X | X | | |

| | | | | | | | | |
|-----|-------------|--|---|--|---|---|--|--|
| All | FOCUS-C-MAX | 1.6L(DURATEC-HE/I4) | ICM - Instrument Cluster | | X | X | | |
| All | FOCUS-C-MAX | 1.6L(DURATEC-HE/I4) | GEM - Generic Electronic Module | | X | X | | |
| All | FOCUS-C-MAX | 1.6L(DURATEC-HE/I4) | EPS - Electronic Power Steering | | X | X | | |
| All | FOCUS-C-MAX | 1.6L(TDCi/Duratorq-Turbo-Diesel-Common-Rail-Injection) | PCM - Powertrain Control Module | | X | X | | |
| All | FOCUS-C-MAX | 1.6L(TDCi/Duratorq-Turbo-Diesel-Common-Rail-Injection) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | | |
| All | FOCUS-C-MAX | 1.6L(TDCi/Duratorq-Turbo-Diesel-Common-Rail-Injection) | RCM - Restraint Control Module | | X | X | | |
| All | FOCUS-C-MAX | 1.6L(TDCi/Duratorq-Turbo-Diesel-Common-Rail-Injection) | TCM - Transmission Control Module | | X | X | | |
| All | FOCUS-C-MAX | 1.6L(TDCi/Duratorq-Turbo-Diesel-Common-Rail-Injection) | ICM - Instrument Cluster | | X | X | | |
| All | FOCUS-C-MAX | 1.6L(TDCi/Duratorq-Turbo-Diesel-Common-Rail-Injection) | GEM - Generic Electronic Module | | X | X | | |
| All | FOCUS-C-MAX | 1.6L(TDCi/Duratorq-Turbo-Diesel-Common-Rail-Injection) | EPS - Electronic Power Steering | | X | X | | |
| All | FOCUS-C-MAX | 1.8L(DURATEC-HE/I4) | PCM - Powertrain Control Module | | X | X | | |
| All | FOCUS-C-MAX | 1.8L(TDCi/Duratorq-Turbo-Diesel-Common-Rail-Injection) | PCM - Powertrain Control Module | | X | X | | |
| All | FOCUS-C-MAX | 1.8L(TDCi/Duratorq-Turbo-Diesel-Common-Rail-Injection) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | | |
| All | FOCUS-C-MAX | 1.8L(TDCi/Duratorq-Turbo-Diesel-Common-Rail-Injection) | RCM - Restraint Control Module | | X | X | | |
| All | FOCUS-C-MAX | 1.8L(TDCi/Duratorq-Turbo-Diesel-Common-Rail-Injection) | TCM - Transmission Control Module | | X | X | | |
| All | FOCUS-C-MAX | 1.8L(TDCi/Duratorq-Turbo-Diesel-Common-Rail-Injection) | ICM - Instrument Cluster | | X | X | | |
| All | FOCUS-C-MAX | 1.8L(TDCi/Duratorq-Turbo-Diesel-Common-Rail-Injection) | GEM - Generic Electronic Module | | X | X | | |
| All | FOCUS-C-MAX | 1.8L(TDCi/Duratorq-Turbo-Diesel-Common-Rail-Injection) | EPS - Electronic Power Steering | | X | X | | |
| All | FOCUS-C-MAX | 2.0L(DURATEC-HE/I4) | PCM - Powertrain Control Module | | X | X | | |
| All | FOCUS-C-MAX | 2.0L(TDCi/Duratorq-Turbo-Diesel-Common-Rail-Injection) | PCM - Powertrain Control Module | | X | X | | |
| All | FOCUS-C-MAX | 2.0L(TDCi/Duratorq-Turbo-Diesel-Common-Rail-Injection) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | | |
| All | FOCUS-C-MAX | 2.0L(TDCi/Duratorq-Turbo-Diesel-Common-Rail-Injection) | RCM - Restraint Control Module | | X | X | | |

| | | | | | | | | |
|-----|----------------|--|---|--|---|---|--|--|
| All | FOCUS-C-MAX | 2.0L(TDCi/Duratorq-Turbo-Diesel-Common Rail-Injection) | TCM - Transmission Control Module | | X | X | | |
| All | FOCUS-C-MAX | 2.0L(TDCi/Duratorq-Turbo-Diesel-Common Rail-Injection) | ICM - Instrument Cluster | | X | X | | |
| All | FOCUS-C-MAX | 2.0L(TDCi/Duratorq-Turbo-Diesel-Common Rail-Injection) | GEM - Generic Electronic Module | | X | X | | |
| All | FOCUS-C-MAX | 2.0L(TDCi/Duratorq-Turbo-Diesel-Common Rail-Injection) | EPS - Electronic Power Steering | | X | X | | |
| All | FIESTA | 1.25L(DURATEC 16V) | PCM - Powertrain Control Module | | X | X | | |
| All | FIESTA | 1.25L(DURATEC 16V) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | | |
| All | FIESTA | 1.25L(DURATEC 16V) | RCM - Restraint Control Module | | X | X | | |
| All | FIESTA | 1.4L(DURATEC 16V) | PCM - Powertrain Control Module | | X | X | | |
| All | FIESTA | 1.4L(DURATEC 16V) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | | |
| All | FIESTA | 1.4L(DURATEC 16V) | RCM - Restraint Control Module | | X | X | | |
| All | FIESTA | 1.4L(DURATEC 16V) | TCM - Transmission Control Module | | X | X | | |
| All | FIESTA | 1.4L(TDCi/Duratorq-Turbo Diesel Common Rail Injection) | PCM - Powertrain Control Module | | X | X | | |
| All | FIESTA | 1.4L(TDCi/Duratorq-Turbo Diesel Common Rail Injection) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | | |
| All | FIESTA | 1.4L(TDCi/Duratorq-Turbo Diesel Common Rail Injection) | RCM - Restraint Control Module | | X | X | | |
| All | FIESTA | 1.6L(DURATEC VCT) | PCM - Powertrain Control Module | | X | X | | |
| All | FIESTA | 1.6L(DURATEC VCT) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | | |
| All | FIESTA | 1.6L(DURATEC VCT) | RCM - Restraint Control Module | | X | X | | |
| All | FIESTA | 1.6L(TDCi/Duratorq-Turbo Diesel Common Rail Injection) | PCM - Powertrain Control Module | | X | X | | |
| All | FIESTA | 1.6L(TDCi/Duratorq-Turbo Diesel Common Rail Injection) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | | |
| All | FIESTA | 1.6L(TDCi/Duratorq-Turbo Diesel Common Rail Injection) | RCM - Restraint Control Module | | X | X | | |
| All | FIESTA | 1.3L (BZ) | PCM - Powertrain Control Module | | X | X | | |
| All | FIESTA | 1.5L (BZ) | PCM - Powertrain Control Module | | X | X | | |
| All | CROWN-VICTORIA | 4.6L(2V) | PCM - Powertrain Control Module | | X | X | | |
| All | CROWN-VICTORIA | 4.6L(2V) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | | |
| All | CROWN-VICTORIA | 4.6L(2V) | RCM - Restraint Control Module | | X | X | | |
| All | CROWN-VICTORIA | 4.6L(2V) | ICM - Instrument Cluster | | X | X | | |
| All | EXPEDITION | 5.4L(3V) | PCM - Powertrain Control Module | | X | X | | |
| All | EXPEDITION | 5.4L(3V) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | | |
| All | EXPEDITION | 5.4L(3V) | RCM - Restraint Control Module | | X | X | | |
| All | EXPEDITION | 5.4L(3V) | TCM - Transmission Control Module | | X | X | | |

| | | | | | | | | |
|-----|------------|--|---|--|---|---|--|--|
| All | EXPEDITION | 5.4L(3V) | ICM - Instrument Cluster | | X | X | | |
| All | FUSION | 1.25L(DURATEC-16V) | PCM - Powertrain Control Module | | X | X | | |
| All | FUSION | 1.25L(DURATEC-16V) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | | |
| All | FUSION | 1.25L(DURATEC-16V) | RCM - Restraint Control Module | | X | X | | |
| All | FUSION | 1.4L(DURATEC-16V) | PCM - Powertrain Control Module | | X | X | | |
| All | FUSION | 1.4L(DURATEC-16V) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | | |
| All | FUSION | 1.4L(DURATEC-16V) | RCM - Restraint Control Module | | X | X | | |
| All | FUSION | 1.4L(TDCi/Duratorq-Turbo-Diesel-Common Rail-Injection) | PCM - Powertrain Control Module | | X | X | | |
| All | FUSION | 1.4L(TDCi/Duratorq-Turbo-Diesel-Common Rail-Injection) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | | |
| All | FUSION | 1.4L(TDCi/Duratorq-Turbo-Diesel-Common Rail-Injection) | RCM - Restraint Control Module | | X | X | | |
| All | FUSION | 1.6L(TDCi/Duratorq-Turbo-Diesel-Common Rail-Injection) | PCM - Powertrain Control Module | | X | X | | |
| All | FUSION | 1.6L(TDCi/Duratorq-Turbo-Diesel-Common Rail-Injection) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | | |
| All | FUSION | 1.6L(TDCi/Duratorq-Turbo-Diesel-Common Rail-Injection) | RCM - Restraint Control Module | | X | X | | |
| All | FUSION | 1.6L(DURATEC-VCT) | PCM - Powertrain Control Module | | X | X | | |
| All | FUSION | 1.6L(DURATEC-VCT) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | | |
| All | FUSION | 1.6L(DURATEC-VCT) | RCM - Restraint Control Module | | X | X | | |
| All | EXPLORER | 4.0L(2V) | PCM - Powertrain Control Module | | X | X | | |
| All | EXPLORER | 4.0L(2V) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | | |
| All | EXPLORER | 4.0L(2V) | RCM - Restraint Control Module | | X | X | | |
| All | EXPLORER | 4.0L(2V) | ICM - Instrument Cluster | | X | X | | |
| All | EXPLORER | 4.0L(V6-SOHC) | PCM - Powertrain Control Module | | X | X | | |
| All | EXPLORER | 4.0L(V6-SOHC) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | | |
| All | EXPLORER | 4.0L(V6-SOHC) | RCM - Restraint Control Module | | X | X | | |
| All | EXPLORER | 4.0L(V6-SOHC) | ICM - Instrument Cluster | | X | X | | |
| All | EXPLORER | 4.6L(3V) | PCM - Powertrain Control Module | | X | X | | |
| All | EXPLORER | 4.6L(3V) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | | |
| All | EXPLORER | 4.6L(3V) | RCM - Restraint Control Module | | X | X | | |
| All | EXPLORER | 4.6L(3V) | TCM - Transmission Control Module | | X | X | | |
| All | EXPLORER | 4.6L(3V) | ICM - Instrument Cluster | | X | X | | |
| All | KUGA | 2.0L(TDCi/Duratorq-Turbo-Diesel-Common Rail-Injection) | PCM - Powertrain Control Module | | X | X | | |
| All | KUGA | 2.0L(TDCi/Duratorq-Turbo-Diesel-Common Rail-Injection) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | | |
| All | KUGA | 2.0L(TDCi/Duratorq-Turbo-Diesel-Common Rail-Injection) | RCM - Restraint Control Module | | X | X | | |
| All | KUGA | 2.0L(TDCi/Duratorq-Turbo-Diesel-Common Rail-Injection) | ICM - Instrument Cluster | | X | X | | |

| | | | | | | | | |
|-----|------------------------|--|---|--|---|---|--|-----------------------------------|
| All | KUGA | 2.0L(TDCi/Duratorq-Turbo-Diesel-Common Rail-Injection) | GEM - Generic Electronic Module | | X | X | | |
| All | KUGA | 2.0L(TDCi/Duratorq-Turbo-Diesel-Common Rail-Injection) | EPS - Electronic Power Steering | | X | X | | |
| All | KUGA | 2.5L(I5) | PCM - Powertrain Control Module | | X | X | | |
| All | KUGA | 2.5L(I5) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | | |
| All | KUGA | 2.5L(I5) | RCM - Restraint Control Module | | X | X | | |
| All | KUGA | 2.5L(I5) | ICM - Instrument Cluster | | X | X | | |
| All | KUGA | 2.5L(I5) | GEM - Generic Electronic Module | | X | X | | |
| All | KUGA | 2.5L(I5) | EPS - Electronic Power Steering | | X | X | | |
| All | MONDEO | 1.8L(TDCi/Duratorq-Turbo Diesel Common Rail Injection) | PCM - Powertrain Control Module | | X | * | | XFuel Injector Correction Factors |
| All | KA | 1.2L | PCM - Powertrain Control Module | | X | | | |
| All | KA | 1.2L | ABS - Anti-Lock Brake / Traction Control Module | | X | X | | |
| All | KA | 1.2L | EPS - Electronic Power Steering | | X | X | | |
| All | KA | 1.2L | ECS - Electronic Crash Sensor(or IABM) | | X | X | | |
| All | KA | 1.2L | GEM - Generic Electronic Module(or CTM) | | X | X | | |
| All | KA | 1.2L | PATS - Passive Anti-Theft System | | X | X | | |
| All | KA | 1.3L | PCM - Powertrain Control Module | | X | | | |
| All | KA | 1.3L | ABS - Anti-Lock Brake / Traction Control Module | | X | X | | |
| All | KA | 1.3L | EPS - Electronic Power Steering | | X | X | | |
| All | KA | 1.3L | ECS - Electronic Crash Sensor(or IABM) | | X | X | | |
| All | KA | 1.3L | GEM - Generic Electronic Module(or CTM) | | X | X | | |
| All | KA | 1.3L | PATS - Passive Anti-Theft System | | X | X | | |
| All | F-SERIES SUPER DUTY | 5.4L | PCM - Powertrain Control Module | | X | | | |
| All | F-SERIES SUPER DUTY | 5.4L | ABS - Anti-Lock Brake / Traction Control Module | | X | X | | |
| All | F-SERIES SUPER DUTY | 5.4L | RCM - Restraint Control Module | | X | X | | |
| All | F-SERIES SUPER DUTY | 5.4L | GEM - Generic Electronic Module | | X | X | | |
| All | F-SERIES SUPER DUTY | 5.4L | ICM - Instrument Cluster Module | | X | X | | |
| All | F-SERIES SUPER DUTY | 5.4L | TCM - Transmission Control Module | | X | X | | |
| All | F-SERIES SUPER DUTY | 5.4L | PATS-Passive Anti-Theft System | | X | X | | |
| All | F-SERIES SUPER DUTY | 6.0L | PCM - Powertrain Control Module | | X | | | |
| All | F-SERIES SUPER DUTY | 6.0L | ABS - Anti-Lock Brake / Traction Control Module | | X | X | | |
| All | F-SERIES SUPER DUTY | 6.0L | RCM - Restraint Control Module | | X | X | | |

| | | | | | | | | |
|-----|------------------------|------|---|--|---|---|--|--|
| All | F-SERIES SUPER DUTY | 6.0L | GEM - Generic Electronic Module | | X | X | | |
| All | F-SERIES SUPER DUTY | 6.0L | ICM - Instrument Cluster Module | | X | X | | |
| All | F-SERIES SUPER DUTY | 6.0L | TCM - Transmission Control Module | | X | X | | |
| All | F-SERIES SUPER DUTY | 6.0L | PATS—Passive Anti-Theft System | | X | X | | |
| All | F-SERIES SUPER DUTY | 6.8L | PCM - Powertrain Control Module | | X | X | | |
| All | F-SERIES SUPER DUTY | 6.8L | ABS - Anti-Lock Brake / Traction Control Module | | X | | | |
| All | F-SERIES SUPER DUTY | 6.8L | RCM - Restraint Control Module | | X | X | | |
| All | F-SERIES SUPER DUTY | 6.8L | GEM - Generic Electronic Module | | X | X | | |
| All | F-SERIES SUPER DUTY | 6.8L | ICM - Instrument Cluster Module | | X | X | | |
| All | F-SERIES SUPER DUTY | 6.8L | TCM - Transmission Control Module | | X | X | | |
| All | F-SERIES SUPER DUTY | 6.8L | PATS—Passive Anti-Theft System | | X | X | | |
| All | F-SERIES SUPER DUTY | 7.3L | PCM - Powertrain Control Module | | X | | | |
| All | F-SERIES SUPER DUTY | 7.3L | ABS - Anti-Lock Brake / Traction Control Module | | X | X | | |
| All | F-SERIES SUPER DUTY | 7.3L | RCM - Restraint Control Module | | X | X | | |
| All | F-SERIES SUPER DUTY | 7.3L | GEM - Generic Electronic Module | | X | X | | |
| All | F-SERIES SUPER DUTY | 7.3L | ICM - Instrument Cluster Module | | X | X | | |
| All | F-SERIES SUPER DUTY | 7.3L | TCM - Transmission Control Module | | X | X | | |
| All | F-SERIES SUPER DUTY | 7.3L | PATS—Passive Anti-Theft System | | X | X | | |
| All | MAVERICK | 2.0L | PCM - Powertrain Control Module | | X | X | | |
| All | MAVERICK | 2.0L | ABS - Anti-Lock Brake / Traction Control Module | | X | X | | |
| All | MAVERICK | 2.0L | RCM - Restraint Control Module | | X | X | | |
| All | MAVERICK | 2.0L | GEM - Generic Electronic Module | | X | X | | |
| All | MAVERICK | 2.0L | PAM - Parking Aid Module | | X | X | | |
| All | MAVERICK | 2.0L | 4X4M - 4X4 Control Module | | X | X | | |
| All | MAVERICK | 2.3L | PCM - Powertrain Control Module | | X | X | | |
| All | MAVERICK | 2.3L | ABS - Anti-Lock Brake / Traction Control Module | | X | X | | |

| | | | | | | | | |
|-----|----------------|----------------------|---|--|---|---|---|--|
| AII | MAVERICK | 2.3L | RCM - Restraint Control Module | | X | X | | |
| AII | MAVERICK | 2.3L | GEM - Generic Electronic Module | | X | X | | |
| AII | MAVERICK | 2.3L | PAM - Parking Aid Module | | X | X | | |
| AII | MAVERICK | 2.3L | 4X4M - 4X4 Control Module | | X | X | | |
| AII | MAVERICK | 3.0L | PCM - Powertrain Control Module | | X | X | | |
| AII | MAVERICK | 3.0L | ABS - Anti-Lock Brake / Traction Control Module | | X | X | | |
| AII | MAVERICK | 3.0L | RCM - Restraint Control Module | | X | X | | |
| AII | MAVERICK | 3.0L | GEM - Generic Electronic Module | | X | X | | |
| AII | MAVERICK | 3.0L | PAM - Parking Aid Module | | X | X | | |
| AII | MAVERICK | 3.0L | 4X4M - 4X4 Control Module | | X | X | | |
| AII | FOCUS | 2.0L (DURATEC-HE/I4) | PCM - Powertrain Control Module | | X | X | X | |
| AII | FOCUS | 2.0L (DURATEC-HE/I4) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | X | |
| AII | FOCUS | 2.0L (DURATEC-HE/I4) | RCM - Restraint Control Module | | X | X | X | |
| AII | FOCUS | 2.0L (DURATEC-HE/I4) | ICM - Instrument Cluster | | X | X | X | |
| AII | FOCUS | 2.0L (DURATEC-HE/I4) | TCM - Transmission Control Module | | X | X | X | |
| AII | FOCUS | 2.0L (DURATEC-HE/I4) | EPS - Electronic Controlled Power Steering | | X | X | X | |
| AII | FOCUS | 2.0L (DURATEC-HE/I4) | PATS - Passive Anti-Theft System | | X | X | X | |
| AII | FOCUS | 2.0L (DURATEC-HE/I4) | EATC - Electronic Automatic Temperature Control | | X | X | X | |
| AII | CROWN-VICTORIA | 4.6L(2V) | PCM - Powertrain Control Module | | X | X | | |
| AII | CROWN-VICTORIA | 4.6L(2V) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | | |
| AII | CROWN-VICTORIA | 4.6L(2V) | RCM - Restraint Control Module | | X | X | | |
| AII | CROWN-VICTORIA | 4.6L(2V) | ICM - Instrument Cluster | | X | X | | |
| AII | EXPEDITION | 5.4L(3V) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | | |
| AII | EXPEDITION | 5.4L(3V) | RCM - Restraint Control Module | | X | X | | |
| AII | EXPEDITION | 5.4L(3V) | TCM - Transmission Control Module | | X | X | | |
| AII | EXPEDITION | 5.4L(3V) | ICM - Instrument Cluster | | X | X | | |
| AII | EXPLORER | 4.0L(V6-SOHC) | PCM - Powertrain Control Module | | X | X | | |
| AII | EXPLORER | 4.0L(V6-SOHC) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | | |
| AII | EXPLORER | 4.0L(V6-SOHC) | RCM - Restraint Control Module | | X | X | | |
| AII | EXPLORER | 4.0L(V6-SOHC) | ICM - Instrument Cluster | | X | X | | |
| AII | EXPLORER | 4.0L(2V) | PCM - Powertrain Control Module | | X | X | | |
| AII | EXPLORER | 4.0L(2V) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | | |
| AII | EXPLORER | 4.0L(2V) | RCM - Restraint Control Module | | X | X | | |
| AII | EXPLORER | 4.0L(2V) | ICM - Instrument Cluster | | X | X | | |
| AII | EXPLORER | 4.6L(3V) | PCM - Powertrain Control Module | | X | X | | |
| AII | EXPLORER | 4.6L(3V) | ABS - Anti-Lock Brake / Traction Control Module | | X | X | | |
| AII | EXPLORER | 4.6L(3V) | RCM - Restraint Control Module | | X | X | | |
| AII | EXPLORER | 4.6L(3V) | TCM - Transmission Control Module | | X | X | | |
| AII | EXPLORER | 4.6L(3V) | ICM - Instrument Cluster | | X | X | | |

| | | | | | | | | |
|-----|--------|--|---|--|---|---|--|------------------------------------|
| All | GALAXY | 2.0L(TDCi/Duratorq-Turbo Diesel Common Rail Injection) | PCM - Powertrain Control Module | | X | | | X Fuel Injector Correction Factors |
| All | MONDEO | 2.0L(TDCi/Duratorq-Turbo Diesel Common Rail Injection) | HCM - Headlamp Control Module | | X | * | | |
| All | MONDEO | 2.0L(TDCi/Duratorq-Turbo Diesel Common Rail Injection) | BCMii - Body Control Module | | * | * | | |
| All | MONDEO | 2.0L(TDCi/Duratorq-Turbo Diesel Common Rail Injection) | SASM - Steering Angle Sensor Module | | * | * | | |
| All | MONDEO | 2.0L(TDCi/Duratorq-Turbo Diesel Common Rail Injection) | DDM - Driver's Door Module | | * | * | | |
| All | MONDEO | 2.0L(TDCi/Duratorq-Turbo Diesel Common Rail Injection) | PDM - Passenger's Door Module | | * | * | | |
| All | MONDEO | 2.0L(TDCi/Duratorq-Turbo Diesel Common Rail Injection) | RFA - Remote Function Actuator | | * | * | | |
| All | MONDEO | 2.0L(TDCi/Duratorq-Turbo Diesel Common Rail Injection) | HVAC - Heating ventilation Air Conditioning | | * | * | | |
| All | MONDEO | 2.0L(TDCi/Duratorq-Turbo Diesel Common Rail Injection) | IPC - Instrument Panel Control Module | | * | * | | |
| All | MONDEO | 2.0L(TDCi/Duratorq-Turbo Diesel Common Rail Injection) | SRM - Speech Recognition Module | | * | * | | |
| All | MONDEO | 2.0L(TDCi/Duratorq-Turbo Diesel Common Rail Injection) | RCM - Restraint Control Module | | * | * | | |
| All | MONDEO | 2.0L(TDCi/Duratorq-Turbo Diesel Common Rail Injection) | ABS - Anti-Lock Brake Module | | * | * | | |
| All | MONDEO | 2.0L(TDCi/Duratorq-Turbo Diesel Common Rail Injection) | ACM - Audio Control Module | | * | * | | |
| All | MONDEO | 2.0L(TDCi/Duratorq-Turbo Diesel Common Rail Injection) | PCM - Powertrain Control Module | | * | * | | XFuel Injector Correction Factors |
| All | MONDEO | 2.0L(TDCi/Duratorq-Turbo Diesel Common Rail Injection) | HCM - Headlamp Control Module | | * | * | | |
| All | MONDEO | 2.0L(TDCi/Duratorq-Turbo Diesel Common Rail Injection) | BCMii - Body Control Module | | * | * | | |
| All | MONDEO | 2.0L(TDCi/Duratorq-Turbo Diesel Common Rail Injection) | SASM - Steering Angle Sensor Module | | * | * | | |
| All | MONDEO | 2.0L(TDCi/Duratorq-Turbo Diesel Common Rail Injection) | DDM - Driver's Door Module | | * | * | | |
| All | MONDEO | 2.0L(TDCi/Duratorq-Turbo Diesel Common Rail Injection) | PDM - Passenger's Door Module | | * | * | | |
| All | MONDEO | 2.0L(TDCi/Duratorq-Turbo Diesel Common Rail Injection) | RFA - Remote Function Actuator | | * | * | | |
| All | MONDEO | 2.0L(TDCi/Duratorq-Turbo Diesel Common Rail Injection) | HVAC - Heating ventilation Air Conditioning | | * | * | | |
| All | MONDEO | 2.0L(TDCi/Duratorq-Turbo Diesel Common Rail Injection) | IPC - Instrument Panel Control Module | | * | * | | |

| | | | | | | | | |
|-----|--------|--|---------------------------------|--|---|---|--|--|
| All | MONDEO | 2.0L(TDCi/Duratorq-Turbo Diesel Common Rail Injection) | SRM - Speech Recognition Module | | * | * | | |
| All | MONDEO | 2.0L(TDCi/Duratorq-Turbo Diesel Common Rail Injection) | RCM - Restraint Control Module | | * | * | | |
| All | MONDEO | 2.0L(TDCi/Duratorq-Turbo Diesel Common Rail Injection) | ABS - Anti-Lock Brake Module | | * | * | | |
| All | MONDEO | 2.0L(TDCi/Duratorq-Turbo Diesel Common Rail Injection) | ACM - Audio Control Module | | * | * | | |